




Quick Installation Guide

300Mbps SD-LAN Wireless Router




WK-R300


www.wireless-tek.com

1.Packing Content


- WK-R300




Wireless Router x 1



Power Adapter x 1



Ethernet Cable x 1




Quick Installation Guide x 1

2.Hardware Overview

WK-R300

- Back panel



DC 5V Input Port
 1*10/100Mbps RJ45 WAN Port
 4*10/100Mbps RJ45 LAN Ports
 Reset Button

• Port and Indicator


Item	Description
LAN	10/100Mbps Ethernet RJ45 Port, which can be used to connect to the wired clients such as PC, Laptop
WAN	10/100Mbps Ethernet RJ45 Port
Reset Button	Press for more than 8 seconds to restore the Router to factory.

• LED Indicator

Item	Status	Description
PWR	On	The device is powered on
	Off	The device is powered off
WAN	On	The WAN port is connected
	Off	The WAN port is disconnected
Wi-Fi	On	The Wireless function is enabled
	Off	The Wireless function is disabled







3.Web Management

1. Connect the power adapter to the router
2. Connect the router's WAN port to the Internet via Ethernet cable, and then connect the LAN port to a PC




3. Open a browser such as Chrome or Firefox and launch the login page with default IP **192.168.10.1**, then type the password **admin** to enter the Management UI. Please follow the steps as followings to finish the quick wizard.

Note: The default SSID is WIKING_XXXX, and the default password is 88888888.



4.Cloud Management

Make sure your device has access to the Internet. Enter <https://cloud2.wireless-tek.com> in the browser and log in to the cloud, add a network, or select the existing network. Go to "Device > SOHO Router", click < ADD DEVICE >, enter the device's SN and last six hexes of the device MAC address, and click < ADD >. Wait a moment, you can find it in the device list and view it in "Topology".



Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within the warranty period, we will provide professional maintenance service.
- Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
- Any other defects that are not caused by workmanship or product quality, such as natural disasters, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card loss will disqualify the product from limited warranty.



Wireless-Tek Technology Limited
 Address: Building 3, Units 1801-1807, 1812,
 Huaqiang Era Plaza, Tangwei Community,
 Fuhai Street, Bao'an District, Shenzhen City,
 Guangdong Province, China.
 Website: www.wireless-tek.com
 Tel: 86-0755-32811290
 Email: sales@wireless-tek.com
 Technical Support: tech@wireless-tek.com

