



Superic Industrial Switch CLI User Manual

www.wireless-tek.com

Contents

| | |
|---|----|
| 1. System Management | 14 |
| 1.1. Command Line Interface Mode | 14 |
| 1.2. Management IP Address | 14 |
| 1.2.1. Configuring | 14 |
| 1.2.2. Examples | 15 |
| 1.3. Backup/Restore Configuration | 15 |
| 1.4. System Warm Restart | 15 |
| 1.5. User Login Management | 16 |
| 1.6. System Hostname Configuration | 17 |
| 1.7. Firmware Upgrade | 17 |
| 1.8. System Data And Time Configuration | 18 |
| 2. Configuring Ethernet Interface | 20 |
| 2.1. Overview of Interface Types | 20 |
| 2.2. Configuring | 20 |
| 2.3. Examples | 22 |
| 2.4. Display Information | 22 |
| 3. Configuring Storm Control | 25 |
| 3.1. Overview of Storm Control | 25 |
| 3.2. Configuring | 25 |
| 3.3. Examples | 25 |
| 3.4. Display information | 25 |

| | |
|---|----|
| 4. Configuring SPAN | 27 |
| 4.1. Overview of SPAN | 27 |
| 4.2. Configuring | 27 |
| 4.3. Examples | 28 |
| 4.4. Display information | 28 |
| 5. Configuring Port Aggregation | 29 |
| 5.1. Overview of Port Aggregation | 29 |
| 5.2. Overview of LACP | 29 |
| 5.3. Configuring | 30 |
| 5.4. Examples | 31 |
| 5.5. Display information | 31 |
| 6. Configuring PoE | 35 |
| 6.1. Overview of PoE | 35 |
| 6.2. Configuring | 35 |
| 6.3. Examples | 36 |
| 6.4. Display Information | 36 |
| 7. Configuring VLAN | 37 |
| 7.1. Overview of VLAN | 37 |
| 7.2. Configuring | 37 |
| 7.3. Display Information | 39 |
| 8. Configuring QINQ | 41 |
| 8.1. Overview of QINQ | 41 |

| | |
|--|----|
| 8.1.1. VLAN Stacking | 41 |
| 8.1.2. VLAN Mapping | 41 |
| 8.2. Configuring | 42 |
| 8.3. Examples | 44 |
| 8.4. Display Information | 47 |
| 8.5. Configuring ERPS | 48 |
| 8.6. Overview of ERPS | 48 |
| 8.7. Introduction to ERPS Rationale | 48 |
| 8.8. Configuring | 50 |
| 8.9. Examples | 52 |
| 8.10. Display Information | 57 |
| 9. Configuring IGMP Snooping | 59 |
| 9.1. Overview of IGMP Snooping | 59 |
| 9.2. Configuring | 59 |
| 9.3. Examples | 60 |
| 9.4. Display Information | 61 |
| 10. Configuring Spanning Tree Protocol | 63 |
| 10.1. Overview of Spanning Tree Protocol | 63 |
| 10.2. Configuring | 63 |
| 10.3. Examples | 68 |
| 10.4. Display Information | 71 |
| 11. Configuring MAC Address | 72 |

| | |
|---|----|
| 11.1. Overview of MAC Address | 72 |
| 11.2. Configuring | 72 |
| 11.3. Examples | 73 |
| 11.4. Display Information | 73 |
| 12. Configuring LLDP | 75 |
| 1.1. Overview of LLDP | 75 |
| 1.2. Configuring | 78 |
| 1.2.1. Configuring Switch and Operating Mode | 78 |
| 1.2.2. Configuring Optional Basic Parameter | 79 |
| 1.2.3. Configuring Optional State Machine Parameter | 80 |
| 1.2.4. Configuring Send Tlv List | 81 |
| 1.3. Examples | 82 |
| 1.3.1. LLDP Basic Function Configuration Example | 82 |
| 1.4. Display Information | 82 |
| 13. Configuring L3 | 84 |
| 13.1. Overview of L3 | 84 |
| 13.2. Configuring | 86 |
| 13.3. Examples | 89 |
| 13.4. Display Information | 90 |
| 14. Configuring OSPFv2 | 93 |
| 14.1. Overview of OSPFv2 | 93 |
| 14.2. Configuring | 94 |

| | |
|---|-----|
| 14.2.1. Creating an OSPF Process | 94 |
| 14.2.2. Configuring Interface Network Type | 94 |
| 14.2.3. Configuring Specify Neighbor | 95 |
| 14.2.4. Configuring Protocol Control | 95 |
| 14.2.5. Configuring Passive interface | 97 |
| 14.2.6. Configuring Default Route Advertisement | 97 |
| 14.2.7. Configuring Route Redistribution | 97 |
| 14.2.8. Configuring Route Aggregation | 97 |
| 14.2.9. Configuring Shortest Path | 98 |
| 14.2.10. Configuring Protocol Authentication | 99 |
| 14.2.11. Configuring Virtual-link | 100 |
| 14.2.12. Configuring Stub Domain | 100 |
| 14.2.13. Configuring NSSA Domain | 101 |
| 14.3. Examples | 101 |
| 14.3.1. OSPF Basic Configuration | 101 |
| 14.3.2. OSPF route redistribution configuration | 106 |
| 14.3.3. OSPF Stub Area Configuration | 109 |
| 14.3.4. OSPF NSSA area configuration | 110 |
| 14.3.5. OSPF route aggregation | 115 |
| 14.3.6. OSPF virtual link | 116 |
| 14.3.7. OSPF Authentication | 120 |
| 14.4. Display Information | 121 |

| | |
|--|-----|
| 15. Configuring BGP | 123 |
| 15.1. Overview of BGP | 123 |
| 15.2. Configuring | 123 |
| 15.2.1. Creating a BGP Process | 123 |
| 15.2.2. Configuring BGP Address Family | 123 |
| 15.2.3. Configuring BGP neighbor | 123 |
| 15.2.4. Configuring Reflector | 124 |
| 15.2.5. Configuring AS confederation | 124 |
| 15.2.6. Configuring Route Aggregation | 125 |
| 15.2.7. Configuring Route Attenuation | 125 |
| 15.2.8. Configuring Administrative Distance | 126 |
| 15.2.9. Configuring Multipath Load Balancing | 126 |
| 15.2.10. Configuring Next-hop Update Rigger | 127 |
| 15.2.11. Configuring Route Redistribution | 127 |
| 15.2.12. Configuring Protocol Parameter | 127 |
| 15.3. Examples | 129 |
| 15.3.1. BGP Basic Configuration | 129 |
| 15.3.1.1. Create peer | 129 |
| 15.3.1.2. Create peer group | 134 |
| 15.3.2. Route Reflector Configuration | 143 |
| 15.3.3. AS confederation configuration | 151 |
| 15.3.4. Multipath Load Balancing Configuration | 161 |

| | |
|--|-----|
| 15.4. Display Information | 164 |
| 16. Configuring IS-IS | 166 |
| 16.1. Overview of IS-IS | 166 |
| 16.2. Configuring | 166 |
| 16.2.1. Creating IS-IS Process | 166 |
| 16.2.2. Enabling IS-IS | 166 |
| 16.2.3. Configuring Protocol Packet Parameter | 166 |
| 16.2.4. Configuring IS-IS Hierarchical | 168 |
| 16.2.5. Configuring IS-IS Authentication | 168 |
| 16.3. Examples | 168 |
| 16.3.1. Configuring IS-IS Basic | 168 |
| 16.3.2. Configuring IS-IS Route Redistribution | 172 |
| 16.3.3. Configuring IS-IS Hierarchical | 174 |
| 16.4. Display Information | 178 |
| 17. Configuring RIP | 180 |
| 17.1. Overview of RIP | 180 |
| 17.2. Configuring | 180 |
| 17.2.1. Creating RIP Process | 180 |
| 17.2.2. Configuring RIP Packet Update Unicast Announcement | 180 |
| 17.2.3. Configuring RIP Version | 180 |
| 17.2.4. Configuring Route Redistribution | 181 |
| 17.2.5. Configuring Route Aggregation | 181 |

| | |
|---|-----|
| 17.2.6. Configuring Split Horizon | 181 |
| 17.2.7. Configuring RIP Authentication | 182 |
| 17.2.8. Configuring RIP Timer | 182 |
| 17.2.9. Configuring RIP Source Address Verification | 183 |
| 17.2.10. Configuring the Interface | 183 |
| 17.2.11. Configuring Supernet Routing | 183 |
| 17.2.12. Configuring Default Route Advertisement | 184 |
| 17.3. Examples | 184 |
| 17.3.1. Configuring RIP Routing | 184 |
| 17.3.2. Configuring RIP Unicast Advertisement | 187 |
| 17.3.3. Configuring RIP Default Route | 191 |
| 17.3.4. Configuring RIP Authentication | 194 |
| 17.4. Display Information | 196 |
| 18. Configuring VRRP | 198 |
| 18.1 Overview of VRRP | 198 |
| 18.2 Configuring | 199 |
| 18.3 Examples | 201 |
| 18.3.1 Load Balance Scenario | 201 |
| 18.3.2 MSTP+VRP+OSPFScenario | 203 |
| 18.4 Display Information | 203 |
| 19. Configuring ACL | 205 |
| 19.1. Overview of ACL | 205 |

| | |
|---|-----|
| 18.2. Configuring | 205 |
| 18.3. Examples | 207 |
| 18.4. Display Information | 207 |
| 19. Configuring QoS | 209 |
| 19.1. Overview of QoS | 209 |
| 19.2. Configuring | 210 |
| 19.3. Examples | 215 |
| 19.4. Display Information | 216 |
| 20. Configuring DHCP Snooping | 219 |
| 20.1. Overview of DHCP Snooping | 219 |
| 20.2. Configuring | 219 |
| 20.3. Examples | 221 |
| 20.4. Display Information | 221 |
| 21. Configuring 802.1X Authentication | 223 |
| 21.1. Overview of 802.1X Authentication | 223 |
| 21.1.1. 802.1X Architecture | 223 |
| 21.1.2. 802.1X Authentication Method | 223 |
| 21.1.3. 802.1X Basic Concepts | 224 |
| 21.1.4. Authentication process for 802.1X | 225 |
| 21.2. Configuring | 227 |
| 21.3. Examples | 230 |
| 21.3.1. 802.1X Port Authentication Scenario | 230 |

| | |
|---|-----|
| 21.3.2. MAC Authentication Scenario | 231 |
| 21.4. Display Information | 232 |
| 22. Configuring Port Security | 233 |
| 22.1. Overview of Port Security | 233 |
| 22.2. Configuring | 233 |
| 22.3. Examples | 234 |
| 22.4. Display Information | 235 |
| 23. Configuring Ip Source Guard | 237 |
| 23.1. Overview of Ip Source Guard | 237 |
| 23.2. Configuring | 237 |
| 23.3. Examples | 237 |
| 23.4. Display Information | 238 |
| 24. Configuring Arp-check | 239 |
| 24.1. Overview of Arp-check | 239 |
| 24.2. Configuring | 239 |
| 24.3. Examples | 239 |
| 25. Configuring SNMP Network Management | 240 |
| 25.1. Overview of SNMP Network Management | 240 |
| 25.2. Configuring | 240 |
| 25.3. Examples | 241 |
| 26. Configuring RMON | 242 |
| 26.1. Overview of RMON | 242 |

| | |
|--|-----|
| 26.2. Rationale | 243 |
| 26.3. Configuring | 245 |
| 26.4. Examples | 246 |
| 26.5. Display Information | 246 |
| 27. Configuring IO | 248 |
| 27.1. Overview of IO | 248 |
| 27.2. Configuring | 248 |
| 27.3. Examples | 248 |
| 27.4. Display Information | 248 |
| 28. Configuring AAA | 249 |
| 28.1. Overview of AAA | 249 |
| 28.2. Configuring | 249 |
| 28.3. Examples | 251 |
| 28.3.1. SSH Login Authentication Using Tacacs+ Method | 251 |
| 28.3.2. Use the None Method to Perform Serial Port Login | 252 |
| 28.4. Display Information | 253 |
| 29. Configuring Serial Device Server | 254 |
| 29.1. Overview of Serial Device Server | 254 |
| 29.2. Configuring | 254 |
| 29.3. Examples | 256 |
| 29.3.1. Example for Tcp-client | 256 |
| 29.3.2. Example for Tcp-server | 257 |

| | |
|---|-----|
| 29.4. Display Information | 257 |
| 30. Configuring USB | 259 |
| 30.1. Overview of USB | 259 |
| 30.2. Configuring | 259 |
| 30.3. Examples | 260 |
| 30.3.1. Example of Import Configuration | 260 |
| 30.3.2. Example of Export Configuration | 260 |
| 30.3.3. Example of Firmware Upgrade | 261 |
| 30.3.4. Example of Export Syslog | 261 |
| 30.4. Display Information | 262 |
| 31. Fault Diagnosis | 263 |
| 31.1. Ping/tracerout | 263 |
| 31.2. Display Port Optical Module DDM Information | 263 |
| 31.3. Dying Gasp | 268 |

1. System Management

1.1. Command Line Interface Mode

The command line interface is divided into many different modes, The commands available to you depend on which mode you are currently in. Enter a question mark (?) at the system prompt to obtain a list of commands available for each command mode. Table following describes the main command modes, how to access each one, the prompt you see in that mode, and how to exit the mode. The examples in the table use the hostname SWITCH.

Table Command Mode Summary

| Mode | Prompt | Enter Or Exit | About This Mode |
|-------------------------|--------------------|--|---|
| User Exec | SWITCH> | Enter exit to quit | Use this mode to: Perform basic tests. Display system information. |
| Privileged Mode | SWITCH# | While in user EXEC mode, enter the enable command. Enter disable to exit. | Use this mode to: Exec network utilities. Display module information. System management operation. |
| Global Configuration | SWITCH(config)# | While in Privileged mode, enter the configuration terminal command. Enter exit or end to return. | Use this mode to: configure parameters that apply to the entire switch. |
| Interface Configuration | SWITCH(config-if)# | While in global configuration mode, e interface command (with a specific interface). Enter exit or end to return. | Use this mode to: configure parameters for the Ethernet ports. |

1.2. Management IP Address

1.2.1. Configuring

- Manually Assigning IPv4 Information

| | |
|-------------|---|
| Command | SWITCH(config)#management vlan VLANID ip address IPADDR/MASKLEN gateway IPADDR SWITCH(config)#no management vlan |
| Description | Manually assigning switch management IPv4 information. |

- Configuring DHCP-Based IPv4 Information Autoconfiguration

| | |
|-------------|--|
| Command | SWITCH(config)#management vlan VLANID ip address dhcp SWITCH(config)#no management vlan |
| Description | Configuring DHCP-Based IPv4 information autoconfiguration. |

- Manually Assigning IPv6 Information

| | |
|-------------|---|
| Command | SWITCH(config)#management vlan VLANID ipv6 address IPV6ADDR/MASKLEN gateway IPV6ADDR SWITCH(config)#no management vlan |
| Description | Manually assigning switch management IPv6 information. |

- Configuring DHCP-Based IPv6 Information Autoconfiguration

| | |
|-------------|--|
| Command | SWITCH(config)#management vlan VLANID ipv6 address dhcp SWITCH(config)#no management vlan |
| Description | Configuring DHCP-Based IPv6 information autoconfiguration. |

- Display IP Information

| | |
|-------------|--------------------------------|
| Command | SWITCH#show management summary |
| Description | Display IP information. |

1.2.2. Examples

Example 1: Manually assigning IPv4 information.

The following examples shows how to configure management IPv4 address, The management VLAN is 1, the management IP is 192.168.64.200/24, and the gateway address is 192.168.64.1.

Manually assigning IPv4 information:

```
SWITCH#configure terminal
SWITCH(config)#management vlan 1 ip address 192.168.64.200/24 gateway 192.168.64.1
```

Display IP information:

```
SWITCH#show management summary

Management interface with Ipv4:

Type:      Static
Vlan:      1
Ip address: 192.168.64.200/24
Gateway:    192.168.64.1
```

1.3. Backup/Restore Configuration

- Backup Configuration

| | |
|-------------|--|
| Command | SWITCH#write |
| Description | Save your entries in the configuration file. |

- Restore Configuration

| | |
|-------------|---|
| Command | SWITCH#copy default-config startup-config SWITCH#reload |
| Description | Restore the system default configuration, which will take effect after the device restarts. |

1.4. System Warm Restart

- System Warm Restart

| | |
|-------------|----------------------|
| Command | SWITCH#reload |
| Description | System warm restart. |

1.5. User Login Management

- Configuring Username and Password

| | |
|-------------|---|
| Command | SWITCH(config)# username NAME password LINE SWITCH(config)# no username NAME |
| Description | <p>If the user name does not exist, add a new user, if it exists, modify the user's password.</p> <p>By default, the device has its own user "admin" and password "admin", which supports password modification and deletion operations.</p> <p>The device supports up to 8 users, and the length of the user and password is 0-32 bytes.</p> <p>Password display is encrypted.</p> <p>Password characters are case sensitive.</p> <p>The delete operation does not support deleting the user itself; to delete an online user, the user must be kicked off the line first.</p> |

- Kick Online Users

| | |
|-------------|--|
| Command | SWITCH# clear line {vty console} LINE |
| Description | <p>Vty means remote login user.</p> <p>Console indicates the serial port login user.</p> <p>LINE information can be viewed in the show users command information.</p> <p>Does not support kicking the user itself.</p> |

- Enable WEB Server

| | |
|-------------|--|
| Command | SWITCH(config)# web-server enable {all http https} SWITCH(config)# no web-server enable |
| Description | <p>Enable WEB server.</p> <p>Disabled by default.</p> <p>Support IPv6.</p> |

- Enable Telnet Server

| | |
|-------------|---|
| Command | SWITCH(config)# telnet-server enable SWITCH(config)# no telnet-server enable |
| Description | <p>Enable Telnet Server.</p> <p>Disabled by default.</p> <p>Support IPv6.</p> |

- Enable SSH Server

| | |
|-------------|--|
| Command | SWITCH(config)# ssh-server enable SWITCH(config)# no ssh-server enable |
| Description | <p>Enable SSH Server.</p> <p>Disabled by default.</p> <p>Support IPv6.</p> |

1.6. System Hostname Configuration

- Configuring Hostname

| | |
|-------------|--|
| Command | SWITCH(config)# hostname WORD |
| Description | The name must consist of printable characters and the length cannot exceed 63 bytes. This configuration takes effect immediately. |


1.7. Firmware Upgrade

- Firmware Upgrade

| | |
|-------------|---|
| Command | SWITCH# upgrade tftp tftp://SERVER/FILENAME |
| Description | You need to build a TFTP server on the terminal, and ensure the two-way interconnection between the terminal and the device network. SERVER: TFTP server IP and the relative address of the server window and the firmware upgrade file. FILENAME: Firmware upgrade file. The firmware upgrade process will take 5-6 minutes, reboot the device to complete the firmware upgrade. Do not power off the device during the upgrade process. |


Example 1: The following examples shows firmware upgrade via tftp.

Step 1: As shown in the figure below, SWITCH-A is the device to be upgraded, and the telnet function is enabled; USER-A is the host on the same network segment in the LAN, and USER-B is the management device in the LAN, both of which can log in to SWITCH-A by telnet.



Firmware upgrade connection diagram

Step 2: Select USER-B to perform the version upgrade operation. Open the TFTP server on USER-B and place the upgrade file xcat-release-3.2.0.bin in the Y:/workspace directory.TFTP server as shown in the figure below.



TFTP Server

Step 3: USER-B telnet logs in to SWITCH-A and executes the upgrade command in privileged mode. Upgrade information as shown in the figure below.

```
SWITCH#upgrade tftp tftp://192.168.1.10/xcat-release-3.2.0.bin
% Total    % Received % Xferd  Average Speed   Time    Time     Time  Current
           %             %         Dload  Upload   Total   Spent    Left   Speed
100 55.5M    0 55.5M    0    0  1016k      0  --:--:--  0:00:55 --:--:-- 1033k
100 55.5M    0 55.5M    0    0  1016k      0  --:--:--  0:00:55 --:--:-- 1016k
Un-packet install file, this will last about 60 seconds.
Check upgrade file success.
Start erase and write bin to flash, this will last about 120 seconds.
Erasing 128 Kibyte @ 680000 -- 2 % complete flash_erase: Skipping bad block at 006a0000
Erasing 128 Kibyte @ 12a0000 -- 7 % complete flash_erase: Skipping bad block at 012c0000
Erasing 128 Kibyte @ 3580000 -- 21 % complete flash_erase: Skipping bad block at 035a0000
Erasing 128 Kibyte @ f5e0000 -- 100 % complete
Bad block at 6a0000, 1 block(s) from 6a0000 will be skipped
Bad block at 12c0000, 1 block(s) from 12c0000 will be skipped
Bad block at 35a0000, 1 block(s) from 35a0000 will be skipped
Reboot system to finish upgrade? (y/n):
```

Upgrade Information

Step 4: After the upgrade is over, select "y" to restart the device to complete the upgrade, select "n" to continue running the device, and the upgrade operation will be completed after restart.

1.8. System Data And Time Configuration

- Setting the Systm Clock

| | |
|-------------|--|
| Command | SWITCH# clock set HH:MM:SS DAY MON YEAR |
| Description | Setting the system clock. For example: Clock set 15:30:00 1 october 2017. |

- Setting Ntp Server

| | |
|-------------|--|
| Command | SWITCH(config)# ntp server A.B.C.D |
| Description | Configure the IP address of the NTP server (domain name configuration is not supported). After the configuration is complete, if the device and the server are connected to the network, the device will automatically synchronize the time information from the server. It takes about 4-8 minutes to complete the time synchronization for the first time. |

- Setting Timezone

| | |
|---------|-------------------------------------|
| Command | SWITCH(config)# clock timezone ZONE |
|---------|-------------------------------------|

| | |
|--------------------|---|
| Description | <p>Configure the system time zone.</p> <p>The default timezone is UTC.</p> <p>Supports standard time zone configuration, such as Shanghai time zone keyword "Shanghai", Hong Kong time zone keyword "Hong_Kong", etc.</p> |
|--------------------|---|

- **Display System Clock**

| | |
|--------------------|-----------------------|
| Command | SWITCH# show clock |
| Description | Display system clock. |

- **Display Ntp Status**

| | |
|--------------------|-------------------------|
| Command | SWITCH# show ntp status |
| Description | Display ntp status. |

2. Configuring Ethernet Interface

2.1. Overview of Interface Types

The interfaces of switch can be divided into the following two categories: Layer 2 interfaces and Layer 3 interfaces.

L2 interface, Including common physical ports (Switch Port) and aggregate ports (Port Channel).

Switch Port consists of a single physical port on the device and only support Layer 2 switching. The port can be an Access Port, Hybrid Port or a Trunk Port.

Port Channel is formed by the aggregation of multiple physical member ports. We can bundle multiple physical links together to form a simple logical link, which we call an aggregate port. For Layer 2 switching, the aggregation port can superimpose the bandwidth of multiple ports to expand the link bandwidth.

L3 interface, Here mainly refers to the SVI port.

SVI is a switching virtual interface, a logical interface used to implement Layer 3 switching. SVI can be used as the local management interface, through which the administrator can manage the device. You can create an SVI with the interface vlan interface configuration command, and then assign an IP address to the SVI to establish routing between VLANs.

2.2. Configuring

- Interface Range Mode

| | |
|-------------|--|
| Command | SWITCH(config)# interface IFNAME_RANGE |
| Description | <p>Specify the range of interfaces to be configured, and enter interface-range configuration mode.</p> <p>When there are multiple range combinations, separate them with ',' without spaces.</p> <p>For example, the command interface range gigabitEthernet 0/1-4, gigabitEthernet 0/9-12 is a valid range.</p> <p>You can use the interface range command to configure up to five port ranges;</p> <p>Each interface-range must consist of the same port type.</p> |

- Adding a Description for an Interface

| | |
|-------------|---|
| Command | SWITCH(config-if)# description DESC |
| Description | Add a description (up to 80 characters) for an interface. |

- Shutdown the Interface

| | |
|-------------|---|
| Command | SWITCH(config-if)# shutdown SWITCH(config-if)# no shutdown |
| Description | Shut down an interface. |

- Configuring Interface Speed

| | |
|-------------|--|
| Command | SWITCH(config-if)# speed {10 100 1000 auto} SWITCH(config-if)# no speed |
| Description | <p>Enter auto to enable the interface to autonegotiate speed with the connected device.</p> <p>If you use the 10, 100, or the 1000 keywords with the auto keyword, the port autonegotiates only at the specified speeds;</p> |

- Configuring Interface Duplex Mode

| | |
|-------------|--|
| Command | SWITCH(config-if)# duplex {auto full half} SWITCH(config-if)# no duplex |
| Description | Enable half-duplex mode (for interfaces operating only at 10 or 100 Mbps). You cannot configure half-duplex mode for interfaces operating at 1000 Mbps |

Attention:

- ◆ When both speed and duplex exit auto mode, port auto-negotiation is disabled.

- **Configuring Interface Flowcontrol**

Flow control enables connected Ethernet ports to control traffic rates during congestion by allowing congested nodes to pause link operation at the other end. If one port experiences congestion and cannot receive any more traffic, it notifies the other port by sending a pause frame to stop sending until the condition clears. Upon receipt of a pause frame, the sending device stops sending any data packets, which prevents any loss of data packets during the congestion period.

| | |
|-------------|--|
| Command | SWITCH(config-if)# flowcontrol {on off } |
| Description | Configure the flow control mode for the port. on: The port cannot send pause frames but can operate with an attached device that is required to or can send pause frames; the port can receive pause frames. off: Flow control does not operate in either direction. In case of congestion, no indication is given to the link partner, and no pause frames are sent or received by either device. |

- **Configuring Interface MTU**

When a port performs high-throughput data exchange, it may encounter a frame larger than the Ethernet standard frame length, which is called a jumbo frame.

The user can control the maximum frame length that the port is allowed to send and receive by setting the MTU of the port.

Frames received or forwarded by the port, if the length exceeds the set MTU, will be discarded.

Due to chip limitations, the MTU value only supports even numbers. If the user configures an odd number, the device will auto-align to even. For example, if the MTU is configured as 127, it actually works as 128.

| | |
|-------------|---|
| Command | SWITCH(config-if)# mtu LENGTH SWITCH(config-if)# no mtu |
| Description | Change the MTU size for the interface on the switch. The range is 64 to 10240 bytes; the default is 1526 bytes. |

- **Configuring SFP Interface Mode**

| | |
|-------------|--|
| Command | SWITCH(config-if)# port mode {sgmii 2500BASE-X 1000BASE-X 10G} SWITCH(config-if)# no port mode |
| Description | 1000BASE-X: The port operate at 1000Mbps, full-duplex only. Sgmii: Enables connection to external copper transceivers. 2500BASE-X: The port operate at 2.5G, full-duplex only. 10G: The port operate at 2.5G, full-duplex only. |

- **Configuring Interface Isolate**

In some situations, you need to prevent Layer 2 (L2) connectivity between end devices on a switch, you can use the isolate

function.

When some ports are set as isolated ports, the isolated ports cannot communicate with each other, the isolated port and the non-isolated port can communicate normally, and the non-isolated port and the non-isolated port can communicate normally.

| | |
|-------------|--|
| Command | SWITCH(config-if)#switchport isolate SWITCH(config-if)# no switchport isolate |
| Description | Setting the port as an isolated port. |

2.3. Examples

- Enter gigabitEthernet0/1 Interface Configuration Mode:

```
SWITCH#  
SWITCH#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
SWITCH(config)#interface gigabitEthernet0/1  
SWITCH(config-if)#
```

- Configure the Port Description Information as "TEST_A"

```
SWITCH(config-if)#description TEST_A
```

- No Shutdown Port

```
SWITCH(config-if)#no shutdown
```

- Setting the Port Speed 100M, Duplex Full, and Flowcontrol On

```
SWITCH(config-if)#speed 100  
SWITCH(config-if)#duplex full  
SWITCH(config-if)#flowcontrol on
```

- Setting the Port MTU value 1024

```
SWITCH(config-if)#mtu 1024
```

2.4. Display Information

- Display Brief Information of All Ports

```
SWITCH#show interface brief
```

```
-----  
Ethernet  Type  Status  Reason  Speed  Duplex  Flowcontrol  Autoneg  Port  
Interface                                     Ch #  
-----  
GiE0/1    ETH  down    none    --     --     --           --       --  
GiE0/2    ETH  up      none    1000M  FULL    OFF          ON       --  
GiE0/3    ETH  down    none    --     --     --           --       --  
GiE0/4    ETH  down    none    --     --     --           --       --  
GiE0/5    ETH  down    none    --     --     --           --       --  
GiE0/6    ETH  down    none    --     --     --           --       --  
GiE0/7    ETH  down    none    --     --     --           --       --  
GiE0/8    ETH  up      none    100M   FULL    OFF          ON       --
```

| | | | | | | | | |
|---------|-----|------|------|----|----|----|----|----|
| GiE0/9 | ETH | down | none | -- | -- | -- | -- | -- |
| GiE0/10 | ETH | down | none | -- | -- | -- | -- | -- |
| GiE0/11 | ETH | down | none | -- | -- | -- | -- | -- |
| GiE0/12 | ETH | down | none | -- | -- | -- | -- | -- |

- Display Single Port Configuration and Status

```
SWITCH#show interface gigabitethernet0/1
```

```
Interface gigabitethernet0/1
```

```
Hardware is eth    current hw addr: 0050.4c82.89a0
```

```
Physical:0050.4c82.89a0
```

```
Description: test_a
```

```
Index 1 metric 0 mtu 1024 speed-unknown duplex-unknown flowcontrol-unknown
```

```
Port mode is invalid
```

```
<up>
```

```
vrf binding: not bound
```

```
Bandwidth -8
```

```
Input packets 0677, bytes 072690,
```

```
Multicast packets 0327 broadcast packets 0350 fcs error 00 undersizeerrors 00 oversizeerrors 00
```

```
Output packets 00, bytes 00,
```

```
Multicast packets 00 broadcast packets 00
```

- Display Port Packet Statistics

```
SWITCH#show interface gigabitEthernet0/1 counters
```

```
Interface gigabitEthernet16/1
```

```
Good Octets Tx      : 1914949
```

```
Good Octets Rx      : 0
```

```
Bad Octets Rx       : 0
```

```
Mac Tx Err Pkts     : 0
```

```
Good Packets Tx     : 1913
```

```
Good Packets Rx     : 0
```

```
Bad Packets Rx      : 0
```

```
Broadcast Packet Tx : 24
```

```
Broadcast Packets Rx : 0
```

```
Multicast Packet Tx : 55
```

```
Multicast Packets Rx : 0
```

```
pkts_64_octets      : 285
```

```
pkts_65_127_octets  : 263
```

```
pkts_128_255_octets : 42
```

```
pkts_256_511_octets : 36
```

```
pkts_512_1023_octets : 91
```

```
pkts_1024_max_octets : 1196
```

```
Excessive Collisions : 0
```

UnRecg MAC Cntl Pkts Rx : 0

Flow Ctrl Pkts Sent : 0

Flow Ctrl Pkts Recvd : 0

Drop Events : 0

Undersized Pkts Recvd : 0

Fragments Recvd : 0

Oversized Pkts Recvd : 0

Jabber Pkts Recvd : 0

mac_rcv_error : 0

Bad CRC : 0

Collisions : 0

Late Collisions : 0

Bad Flow Ctrl Recv : 0

- Display Port Isolation Configuration

SWITCH#show switchport isolate

| interface | config |
|-----------|--------|
|-----------|--------|

| | |
|--------|----------|
| GiE0/1 | isolated |
|--------|----------|

| | |
|--------|--------|
| GiE0/2 | normal |
|--------|--------|

| | |
|--------|--------|
| GiE0/3 | normal |
|--------|--------|

| | |
|--------|--------|
| GiE0/4 | normal |
|--------|--------|

| | |
|--------|--------|
| GiE0/5 | normal |
|--------|--------|

| | |
|--------|--------|
| GiE0/6 | normal |
|--------|--------|

| | |
|--------|--------|
| GiE0/7 | normal |
|--------|--------|

| | |
|--------|--------|
| GiE0/8 | normal |
|--------|--------|

| | |
|--------|--------|
| GiE0/9 | normal |
|--------|--------|

| | |
|---------|--------|
| GiE0/10 | normal |
|---------|--------|

3. Configuring Storm Control

3.1. Overview of Storm Control

Storm control prevents traffic on a LAN from being disrupted by a broadcast, multicast, or unicast storm on one of the physical interfaces. A LAN storm occurs when packets flood the LAN, creating excessive traffic and degrading network performance. Errors in the protocol-stack implementation, mistakes in network configurations, or users issuing a denial-of-service attack can cause a storm.,.

Storm control uses bandwidth as a percentage of the total available bandwidth of the port that can be used by the broadcast, multicast, or unicast traffic, to measure traffic activity.

because of hardware limitations and the way in which packets of different sizes are counted, threshold percentages are approximations.

3.2. Configuring

- Configuring Storm Control

| | |
|----|---|
| 命令 | SWITCH(config-if)#storm-control {broadcast multicast unicast all unicast-broadcast multicast-broadcast} level LINE SWITCH(config-if)#no storm-control |
| 描述 | Configure broadcast, multicast, or unicast storm control. By default, storm control is disabled. If you set the threshold to the maximum value (100 percent), no limit is placed on the traffic. If you set the threshold to 0.0, traffic on that port is blocked. The range is 0.00 to 100.00. Support adaptive port rate change. Unicast only containing unknown unicast packets. |

3.3. Examples

3.4. Display information

- Display All Port Storm Control Configurations

| | | | |
|---------------------------|------------|------------|--------------|
| SWITCH#show storm-control | | | |
| Port | BcastLevel | McastLevel | Unicastlevel |
| GiE0/1 | 100.00% | 10.00% | 100.00% |
| GiE0/2 | 100.00% | 100.00% | 100.00% |
| GiE0/3 | 100.00% | 100.00% | 100.00% |
| GiE0/4 | 100.00% | 100.00% | 100.00% |
| GiE0/5 | 100.00% | 100.00% | 100.00% |
| GiE0/6 | 100.00% | 100.00% | 100.00% |
| GiE0/7 | 100.00% | 100.00% | 100.00% |
| GiE0/8 | 100.00% | 100.00% | 100.00% |
| GiE0/9 | 100.00% | 100.00% | 100.00% |
| GiE0/10 | 100.00% | 100.00% | 100.00% |
| GiE0/11 | 100.00% | 100.00% | 100.00% |


| | | | |
|---------|---------|---------|---------|
| GiE0/12 | 100.00% | 100.00% | 100.00% |
|---------|---------|---------|---------|

4. Configuring SPAN

4.1. Overview of SPAN

You can analyze network traffic passing through ports by using SPAN (Local Switched Port Analyzer) to send a copy of the traffic to another port on the switch that has been connected to a network analyzer or other monitoring or security device. SPAN copies traffic received or sent (or both) on source ports to a destination port for analysis.

SPAN does not affect the switching of network traffic on the source ports. You must dedicate the destination port for SPAN use. Except for traffic that is required for the SPAN session, destination ports do not receive or forward traffic.



Example of SPAN configuration

SPAN supports a session entirely within one switch. all source ports and destination ports are in the same switch. SPAN sessions allow you to monitor traffic on one or more ports, and send the monitored traffic to only one destination port. A SPAN session is an association of a destination port with source ports, all on a single network device.

4.2. Configuring

- Creating a Session

| | |
|-------------|---|
| Command | SWITCH(config)#monitor session SESSION-ID SWITCH(config)#no monitor session SESSION-ID |
| Description | Create a SPAN session. For session_number, the range is 1 to 7 |

- Configuring Session Description

| | |
|-------------|--|
| Command | SWITCH(config-monitor)#description DESC |
| Description | Add a description (up to 64 characters) for an interface |

- Configuring Source interface

| | |
|---------|---|
| Command | SWITCH(config-monitor)#source interface IFNAME {both rx tx} SWITCH(config-monitor)#no source interface IFNAME {both rx tx} |
|---------|---|

| | |
|-------------|---|
| Description | Specify the SPAN session and the source port. |
|-------------|---|

- Configuring Destination Interface

| | |
|-------------|---|
| Command | SWITCH(config-monitor)#destination interface IFNAME SWITCH(config-monitor)#no destination interface IFNAME |
| Description | Specify the SPAN session and the destination port. |

4.3. Examples

Example 1: This example shows how to create SPAN session, and configure session source interfaces and destination interface.

Step 1: Create session.

```
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH(config)#monitor session 1
SWITCH(config-monitor)#
```

Step 2: Configuring session description.

```
SWITCH(config-monitor)#description TRAFFIC_MONITOR
```

Step 3: Configuring session source interfaces.

```
SWITCH(config-monitor)#source interface gigabitEthernet0/1 rx
SWITCH(config-monitor)#source interface gigabitEthernet0/2 both
```

Step 4: Configuring session destination interface.

```
SWITCH(config-monitor)#destination interface gigabitEthernet0/8
```

4.4. Display information

- Display Single Session


```
SWITCH#show monitor session 1
session 1
-----
description      : TRAFFIC_MONITOR
type             : local
source intf      :
    tx           : gigabitEthernet0/2
    rx           : gigabitEthernet0/1 gigabitEthernet0/2
    both         : gigabitEthernet0/2
source VLANs     :
    rx           :
destination ports : gigabitEthernet0/8
Legend: f = forwarding enabled, l = learning enabled
```

5. Configuring Port Aggregation

5.1. Overview of Port Aggregation

Port aggregation provides fault-tolerant high-speed links between switches, routers, and servers. You can use it to increase the bandwidth between the wiring closets and the data center, and you can deploy it anywhere in the network where bottlenecks are likely to occur. Port aggregation provides automatic recovery for the loss of a link by redistributing the load across the remaining links. If a link fails, port aggregation redirects traffic from the failed link to the remaining links in the channel without intervention.

Port aggregation consists of individual Fast Ethernet or Gigabit Ethernet links bundled into a single logical link called channel, as shown in Figure below.



Each Channel can consist of up to eight compatibly configured Ethernet ports. All ports in each Channel must be configured as Layer 2 ports. The number of Channels is limited to 12.

You can configure an Channel in one of these modes: Manual(Static), Active(LACP), or Passive(LACP).

5.2. Overview of LACP

LACP (Link Aggregation Control Protocol) based on the IEEE802.3ad standard is a dynamic link aggregation protocol. If a port enables the LACP, the port will send LACPDU message to announce its system priority, system MAC, port priority, port number and operation key, etc. After the connected device receives the LACP message from the peer end, it compares the system priorities of the two ends according to the system ID in the message. On the side with the higher system ID priority, the ports in the aggregation group are set to be in the aggregation state according to the order of port ID priority from high to low, and the updated LACP message is sent out. It will also set the corresponding port to the aggregation state, so that the two sides can reach the same agreement when the port exits or joins the aggregation group.

After the LACP member interface link is bound, periodic LACP packet exchange will be carried out. When no LACP packet is received for a period of time, it is considered that the packet reception timed out, the member interface link is unbound, and the port is in a state of non-forwarding again. There are two modes of timeout here: long timeout mode and short timeout mode. In the long timeout mode, the port sends a packet every 30 seconds. If it does not receive a packet from the peer for 90 seconds, it will be in a packet receiving timeout.; In the short timeout mode, the port sends a packet every 1 second. If it does not receive a packet from the peer for 3 seconds, it is in the packet receiving timeout.




Figure Typical LACP application

As shown Figure, switch A and switch B are connected together through 3 ports. We set the system priority of switch A to 61440, and set the system priority of switch B to 4096. Enable LACP link aggregation on the three directly connected ports of switches A and B.

After receiving the LACP message from the peer, switch B finds that its system ID has a higher priority (switch B has a higher system priority than switch A), so it follows the order of port ID priority (in the case of the same port priority) , in the order of port numbers from small to large) set ports 4, 5, and 6 to be in the aggregation state.

After switch A receives the updated LACP packet from switch B, it finds that the system ID of the peer end has a higher priority, and set the ports 1, 2, and 3 to the aggregation state.

5.3. Configuring

- Configuring Layer 2 Channels

| | |
|-------------|--|
| Command | SWITCH(config-if)#channel-group ID mode manual SWITCH(config-if)#channel-group ID mode {active passive} SWITCH(config-if)#no channel-group |
| Description | Assign the port to a channel group, and specify the mode. For ID, the range is 1 to 12. |

Note

◆ When the first port is added to the aggregation port, a PO port is actively created, and the default attribute of the PO port is the first port attribute.

◆ For Layer 2 Channels:

Ports with different native VLANs cannot form an EtherChannel.

- Configuring LACP System Priority

| | |
|-------------|--|
| Command | SWITCH(config)#lacp system-priority SYSTEM-PRIORITY SWITCH(config)#no lacp system-priority |
| Description | The system priority range is 1 to 65535, the default value is 32768. All dynamic link groups of a device can only have one LACP system priority. Modifying this value will affect all aggregation groups on the switch. |

- Configuring LACP Interface Priority

| | |
|---------|---|
| Command | SWITCH(config-if)#lacp port-priority PORT-PRIORITY SWITCH(config-if)#no lacp port-priority |
|---------|---|

| | |
|-------------|---|
| Description | The interface priority range is 1 to 65535, the default value is 32768. |
|-------------|---|

- Configuring LACP Timeout Mode

| | |
|-------------|---|
| Command | SWITCH(config-if)#lacp timeout {long short} SWITCH(config-if)#no lacp timeout |
| Description | In long mode, the interval for sending LACP protocol packets is 30S, and the timeout is 90S. In short mode, the interval for sending LACP protocol packets is 1S, and the timeout is 3S. Default is in long mode. |

- Configuring Load-balance Method

| | |
|-------------|---|
| Command | SWITCH(config)#port-channel load-balance {dst-ip dst-mac dst-port src-dst-ip src-dst-mac src-dst-port src-ip src-mac src-port} SWITCH(config)#no port-channel load-balance |
| Description | Configure an Channel load-balancing method. The default is src-mac. Select one of these load-distribution methods: • dst-ip: Load distribution is based on the destination IP address. dst-mac: Load distribution is based on the destination MAC address of the incoming packet. Dist-port: Load distribution is based on the destination L4-port of the incoming packet src-dst-ip: Load distribution is based on the source-and-destination IP address. src-dst-mac: Load distribution is based on the source-and-destination MAC address. src-dst-port: Load distribution is based on the source-and-destination L4-port of the incoming packet. src-ip: Load distribution is based on the source IP address. src-mac: Load distribution is based on the source-MAC address of the incoming packet. |

5.4. Examples

Example 1: This example shows how to assign the ports to a channel, and set load-balance method.

- Assign the gigabitEthernet0/5, gigabitEthernet0/6 to PO 1, set load-balance to src-ip:

```
SWITCH(config)#interface gigabitEthernet0/5
SWITCH(config-if)#channel-group 1 mode manual
SWITCH(config-if)#exit
SWITCH(config)#interface gigabitEthernet0/6
SWITCH(config-if)#channel-group 1 mode manual
SWITCH(config-if)#exit
SWITCH(config)#port-channel load-balance src-ip
```

5.5. Display information

- Display Channels Configuration and Status

```
SWITCH#show port-channel
Load balance: Source and Destination Mac address
```

```
Interface po3
Type: static
Member:
  gigabitEthernet0/18    link down    Disable
```

```
Interface po8
Type: LACP
Member:
  gigabitEthernet0/19    link up      Enable
  gigabitEthernet0/17    link up      Enable
```

```
SWITCH#show port-channel 8
Interface po8
Type: LACP
Member:
  gigabitEthernet0/19    link up      Enable
  gigabitEthernet0/17    link up      Enable
```

```
SWITCH#show port-channel load-balance
Source and Destination Mac address
```

- Display LACP Summary

```
SWITCH#show lacp summary
% Aggregator po8 1008
% Aggregator Type: Layer2
% Admin Key: 0008 - Oper Key 0008
%   Link: gigabitEthernet0/17 (17) sync: 1 status: Bundled
%   Link: gigabitEthernet0/19 (19) sync: 1 status: Bundled
```

```
SWITCH#show lacp detail
% Aggregator po8 1008
% Aggregator Type: Layer2
%   Mac address: 74:b9:eb:ee:25:46
%   Admin Key: 0008 - Oper Key 0008
%   Actor LAG ID- 0x8000,74-b9-eb-ee-25-46,0x0008
%   Receive link count: 2 - Transmit link count: 2
%   Individual: 0 - Ready: 1
%   Partner LAG ID- 0x8000,00-01-a0-00-10-10,0x0032
%   Link: gigabitEthernet0/17 (17) sync: 1 status: Bundled
%   Link: gigabitEthernet0/19 (19) sync: 1 status: Bundled
```

```
SWITCH#show lacp 8
% Aggregator po8 1008 Admin Key: 0008 - Oper Key 0008
% Partner LAG ID: 0x8000,00-01-a0-00-10-10,0x0032
% Partner Oper Key 0050
```



```
SWITCH#show lacp sys-id
```

```
% System 8000,74-b9-eb-ee-25-46
```

```
SWITCH#show lacp port gigabitEthernet0/19
```

```
% LACP link info: gigabitEthernet0/19 - 19
```

```
% LAG ID: 0x8000,74-b9-eb-ee-25-46,0x0008
```

```
% Partner oper LAG ID: 0x8000,00-01-a0-00-10-10,0x0032
```

```
% Actor Port priority: 0x8000 (32768)
```

```
% Admin key: 0x0008 (8) Oper key: 0x0008 (8)
```

```
% Physical admin key:(1)
```

```
% Receive machine state : Current
```

```
% Periodic Transmission machine state : Slow periodic
```

```
% Mux machine state : Collecting/Distributing
```

```
% Oper state: ACT:1 TIM:0 AGG:1 SYN:1 COL:1 DIS:1 DEF:0 EXP:0
```

```
% Partner oper state: ACT:1 TIM:0 AGG:1 SYN:1 COL:1 DIS:1 DEF:0 EXP:0
```

```
% Partner link info: admin port 0
```

```
% Partner oper port: 20
```

```
% Partner admin LAG ID: 0x0000-00:00:00:00:0000
```

```
% Admin state: ACT:1 TIM:0 AGG:1 SYN:0 COL:0 DIS:0 DEF:1 EXP:0
```

```
% Partner admin state: ACT:0 TIM:0 AGG:1 SYN:0 COL:0 DIS:0 DEF:1 EXP:0
```

```
% Partner system priority - admin:0x0000 - oper:0x8000
```

```
% Partner port priority - admin:0x0000 - oper:0x8000
```

```
% Aggregator ID: 1008
```

- Display Only One Channel Information

```
SWITCH#show int po8
```

```
Interface po8
```

```
Hardware is AGG Current HW addr: 74b9.ebee.2546
```

```
Logical:(not set)
```

```
Port Mode is access
```

```
interface configure:
```

```
medium-fiber mtu 1526 speed-auto duplex-auto flowcontrol-off autonego-off
```

```
interface status:
```

```
link-up bandwidth-2g
```

```
Aggregate Members:(LACP)
```

| | | |
|---------------------|---------|--------|
| gigabitEthernet0/19 | link up | Enable |
|---------------------|---------|--------|

| | | |
|---------------------|---------|--------|
| gigabitEthernet0/17 | link up | Enable |
|---------------------|---------|--------|

```
input packets:
```

| | |
|----------------|---------|
| Good Octets Rx | : 18986 |
|----------------|---------|

| | |
|-----------------|-------|
| Good Packets Rx | : 104 |
|-----------------|-------|

| | |
|----------------------|-----|
| Broadcast Packets Rx | : 0 |
|----------------------|-----|

| | |
|----------------------|-------|
| Multicast Packets Rx | : 104 |
|----------------------|-------|

```
ouput packets:
```

| | |
|----------------|---------|
| Good Octets Tx | : 38529 |
|----------------|---------|

| | |
|-----------------|-------|
| Good Packets Tx | : 359 |
|-----------------|-------|

| | |
|---------------------|-----|
| Broadcast Packet Tx | : 4 |
|---------------------|-----|

| | |
|---------------------|-------|
| Multicast Packet Tx | : 355 |
|---------------------|-------|

| | |
|--------------------|--|
| un-normal packets: | |
|--------------------|--|

| | |
|-------------|-----|
| Drop Events | : 0 |
|-------------|-----|

| | |
|-----------------------|-----|
| Undersized Pkts Recvd | : 0 |
|-----------------------|-----|


| | |
|----------------------|-----|
| Oversized Pkts Recvd | : 0 |
|----------------------|-----|

| | |
|---------|-----|
| Bad CRC | : 0 |
|---------|-----|

6. Configuring PoE

6.1. Overview of PoE

Power over Ethernet (PoE) is a technology that transmits both electrical power and network data over an ethernet cable. With PoE, each Ethernet interface of LAN switches can supply power to devices like VoIP phones, IP cameras or security cameras, and wireless access points (AP), As shown in the figure below.



PoE powersupply diagram

The PoE device like LAN switches that are supplying power is called Power Sourcing Equipment (PSE). The power that is supplying is in Direct Current (DC) form.

PoE (Power over Ethernet) Standards:

PoE : IEEE 802.3af standard that supplies up to 15 watts of DC power from PSE and 12.95 watts from PD due to losses on an ethernet cable. It uses two pairs of wires like CAT3 or CAT5 cables as a medium.

PoE+: IEEE 802.3at standard that supplies power up to 30 watts of DC power from PSE and 25.5 watts from PD due to losses on an ethernet cable. It is also using two pairs of wires like CAT5 or higher as a medium.

UPoE(Universal PoE): IEEE 802.3bt standard that supplies power up to 60 watts of DC power from PSE and 51 watts from PD due to losses on an ethernet cable. It uses four pairs of wire as a medium.

UPoE+(Universal PoE +): IEEE 802.3bt standard that supplies power up to 100 watts of DC power from PSE and 71.3 watts from PD due to losses on an ethernet cable. It is also using four pairs of ethernet cabling as a medium.

6.2. Configuring

- Configurint the External Powersupply

| | |
|-------------|--|
| Command | SWITCH(config)#poe powersupply POWER SWITCH(config)#no poe powersupply |
| Description | The default power calculation method: the product of the number of PoE power supply ports and the single port 15.4W. If the configured power is less than the current device power consumption, power off the PD device on the port with the lower priority, and the port priority is a higher priority with a smaller port ID. |

- Enabling Port Powersupply

| | |
|---------|-------------------------------|
| Command | SWITCH (config-if)#poe enable |
|---------|-------------------------------|

| | |
|-------------|------------------------------------|
| | SWITCH (config-if)#no poe enable |
| Description | Default port power supply enabled. |

- Enabling Powersupply Legacy Mode

| | |
|-------------|--|
| Command | SWITCH (config)#poe legacy SWITCH (config)#no poe legacy |
| Description | Using this command on a port that is not connected to a PD device may cause the peer device to be burned by wrong power-on. Please make sure that the port uses this command when connecting to a PD device. |

6.3. Examples

Example 1: Enable interface gigabitEthernet0/1 powersupply.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#poe enable
```

6.4. Display Information

- Display System Powersupply Information

```
SWITCH#show poe powersupply
Power supply          : 123.2W
Power consume         : 44.1W
Power management     : energy-saving
Disconnect mode       : DC
Powered ports        : 2
```

- Display Interfaces Powersupply Information

```
SWITCH#show poe interfaces
Interface  enable  status  reason  class  icut(mA) power(W)
-----
GiE0/1    YES    OFF    short   4      --      --
GiE0/2    YES    OFF    --      -      --      --
GiE0/3    YES    OFF    --      -      --      --
GiE0/4    YES    OFF    --      -      --      --
GiE0/5    YES    OFF    --      -      --      --
GiE0/6    YES    ON     --      4      270.2   14.0
GiE0/7    YES    OFF    --      -      --      --
GiE0/8    YES    OFF    --      -      --      --
```

7. Configuring VLAN

7.1. Overview of VLAN

A VLAN is a switched network that is logically segmented by function, project team, or application, without regard to the physical locations of the users. VLANs have the same attributes as physical LANs, but you can group end stations even if they are not physically located on the same LAN segment. Any switch port can belong to a VLAN, and unicast, broadcast, and multicast packets are forwarded and flooded only to end stations in the VLAN. Each VLAN is considered a logical network, and packets destined for stations that do not belong to the VLAN must be forwarded through a router or a switch supporting fallback bridging.

The port link types of Ethernet switches can be divided into three types: Access, Trunk, and Hybrid. These three ports will be processed differently when they join VLAN and forward packets.

Access: An access port can belong to one VLAN and is manually assigned to that VLAN.

Trunk: A trunk port is a member of all VLANs by default, but membership can be limited by configuring the allowed-VLAN list. A trunk port has a native VLAN, the switch forwards untagged traffic in the native VLAN configured for the port. The native VLAN is VLAN 1 by default.

Hybrid: A hybrid port is a member of all VLANs by default, but membership can be limited by configuring the allowed-VLAN list. A hybrid port allows users to configure traffic of a VLAN forwards tagged or untagged. A trunk port has a hybrid VLAN, The hybrid VLAN is VLAN 1 by default.

7.2. Configuring

- Creating VLAN

| | |
|-------------|---|
| Command | SWITCH(config)#vlan (<vlan-id> <vlan-range>) SWITCH(config)#no vlan (<vlan-id> <vlan-range>) |
| Description | Create a VLAN, vlan-id 1-4094, vlan-range example: 2-10. |

- Configuring the Interface as a Access Port

| | |
|-------------|---|
| Command | SWITCH(config)#interface IFNAME SWITCH(config-if)#switchport mode access |
| Description | Configure the interface port mode access. |

| | |
|-------------|---|
| Command | SWITCH(config-if)#switchport access vlan VLANID SWITCH(config-if)#no switchport access vlan |
| Description | Specify the default VLAN of the interface, which is used if the interface is access mode. Default vlan is 1. |

- Configuring the Interface as a Trunk Port

| | |
|---------|--|
| Command | SWITCH(config)#interface IFNAME SWITCH(config-if)#switchport mode trunk |
|---------|--|

| | |
|-------------|--|
| Description | Configure the interface port mode trunk. |
|-------------|--|

| | |
|-------------|---|
| Command | SWITCH(config-if)#switchport trunk allowed vlan { all VLAN_LIST none} SWITCH(config-if)#no switchport trunk allowed vlan VLAN_LIST |
| Description | <p>Configure the list of VLANs allowed on the trunk, which is used if the interface is trunk mode.</p> <p>All: Adds all VLANs in available in the VLAN table, New VLANs added to the VLAN table are added automatically.</p> <p>None: Removes all VLANs.</p> <p>VLAN_LIST: It will manually set the Allowed VLAN list, If it belongs to ALL , the Allowed VLAN list will be cleared first, and then the new VLAN list will be added; vlan-list parameter is either a single VLAN number from 1 to 4094 or a range of VLANs described by two VLAN numbers, the lower one first, separated by a hyphen. Do not enter any spaces between comma-separated VLAN parameters or in hyphen-specified ranges.</p> <p>Only created VLANs can be added to the Allowed VLAN list; when a VLAN is deleted, the corresponding VLAN in the Allowed VLAN list will be automatically deleted.</p> <p>All VLANs are allowed by default.</p> |

| | |
|-------------|---|
| Command | SWITCH(config-if)#switchport trunk native vlan VLANID SWITCH(config-if)#no switchport trunk native vlan |
| Description | <p>Configure the VLAN that is sending and receiving untagged traffic on the trunk port. For VLANID, the range is 1 to 4094.</p> <p>Native VLAN has nothing to do with whether the Allowed VLAN contains this VLAN, or even whether the VLAN is created.</p> <p>Default vlan is 1.</p> |

Note:

- ◆ The default VLAN ID of the trunk port of the local device must be the same as the default VLAN ID of the trunk port of the connected device, otherwise the packets of the default VLAN will not be transmitted correctly.
-

● **Configure the Interface as a Hybrid Port**

| | |
|-------------|---|
| Command | SWITCH(config)#interface IFNAME SWITCH(config-if)#switchport mode hybrid |
| Description | Configure the interface port mode hybrid. |

| | |
|-------------|--|
| Command | SWITCH(config-if)#switchport hybrid allowed vlan { all VLAN_LIST none} SWITCH(config-if)#no switchport hybrid allowed vlan VLAN_LIST |
| Description | <p>Configure the list of VLANs allowed on the trunk, which is used if the interface is hybrid mode.</p> <p>All: Adds all VLANs in available in the VLAN table, New VLANs added to the VLAN table are added</p> |

| | |
|--|---|
| | <p>automatically.</p> <p>None: Removes all VLANs.</p> <p>VLAN_LIST: It will manually set the Allowed VLAN list, If it belongs to ALL , the Allowed VLAN list will be cleared first, and then the new VLAN list will be added;vlan-list parameter is either a single VLAN number from 1 to 4094 or a range of VLANs described by two VLAN numbers, the lower one first, separated by a hyphen. Do not enter any spaces between comma-separated VLAN parameters or in hyphen-specified ranges.</p> <p>Only created VLANs can be added to the Allowed VLAN list; when a VLAN is deleted, the corresponding VLAN in the Allowed VLAN list will be automatically deleted.</p> <p>All VLANs are allowed by default.</p> |
|--|---|

| | |
|--------------------|--|
| Command | <p>SWITCH(config-if)#switchport hybrid vlan VLANID</p> <p>SWITCH(config-if)#no switchport hybrid vlan</p> |
| Description | <p>Configure the default VLAN that is sending and receiving untagged traffic on the hybrid port. For VLANID, the range is 1 to 4094.</p> <p>Native VLAN has nothing to do with whether the Allowed VLAN contains this VLAN, or even whether the VLAN is created.</p> <p>Default vlan is 1.</p> |

| | |
|--------------------|--|
| Command | <p>SWITCH(config-if)#switchport hybrid untagged vlan VLAN_LIST</p> <p>SWITCH(config-if)#no switchport hybrid untagged vlan VLAN_LIST</p> |
| Description | <p>Configure the list of untagged VLANs, which is used if the interface is hybrid mode.</p> <p>The default VLAN must be untagged output, therefore, it is not maintained by the untagged VLAN list.</p> <p>By default the untagged VLAN list is empty.</p> <p>The Untagged VLAN list must be in the Allowed VLAN list of the Hybrid port, Therefore, when a VLAN is deleted from the Allowed VLAN, it will also be deleted from the Untagged VLAN list.</p> <p>Since the untagged VLAN list does not maintain the default VLAN, if a VLAN in the previous list is set as the default VLAN, it will be deleted from the untagged VLAN list.</p> |

| | |
|--|--|
| Note | |
| <p>◆ The default VLAN ID of the hybrid port of the local device must be the same as the default VLAN ID of the hybrid port of the connected device, otherwise the packets of the default VLAN will not be transmitted correctly.</p> | |

7.3. Display Information

Displays the VLAN table, includes VLAN VID, VLAN status, VLAN member ports, and VLAN configuration information.

- Display VLAN Information

| VLAN ID | Name | State | H/W Status | Member ports |
|--------------------------|------|-------|------------|--------------|
| (u)-Untagged, (t)-Tagged | | | | |
| ===== | | | | |

| | | | | |
|---|---------|--------|----|-----------------------|
| 1 | default | ACTIVE | Up | gigabitEthernet0/2(u) |
| | | | | gigabitEthernet0/3(u) |

8. Configuring QINQ

8.1. Overview of QINQ

QINQ technology also known as Stacked VLAN. The standard is derived from IEEE 802.1ad, which means that the public network VLAN Tag of a service provider network is encapsulated before the user packet enters the service provider network, and the private network user VLAN Tag in the user packet is regarded as data, so that the packet carries Two-layer VLAN tag traversal of service provider network.

In the metropolitan area network, a large number of VLANs are required to isolate users. The 4094 VLANs supported by the IEEE 802.1Q protocol are far from meeting the requirements. Through the double-layer Tag encapsulation of QINQ technology, in the service provider network, the packets are only transmitted according to the unique outer VLAN Tag allocated on the public network, so that the VLANs of different private network users can be reused, and the number of VLAN tags available to users is expanded. At the same time, it provides a simple Layer 2 VPN function, so QINQ technology is actually a VLAN VPN technology. In addition to QINQ, common VLAN VPN technologies also include VLAN Mapping. The only difference between the two is that QINQ is for stacking VLANs, and VLAN Mapping is for VLAN mapping.

8.1.1. VLAN Stacking

VLAN Stacking: From the user network to the provider network, a single-layer tag becomes a double-layer tag, and the C-Tag remains in the packet as an inner-layer tag; reverse, from a double-layer tag to a single-layer tag.

VLAN Stacking QINQ is divided into three categories:

- **Type A:** Basic QINQ, which is enabled and disabled based on the interface. When an interface with basic QINQ enabled receives a packet, it is treated as an un-tagged packet. On the basis of the original packet, a VLAN tag of the default VLAN of the port is added.
- **Type B:** Flexible QINQ based on C-tag, according to the C-VLAN Tag on the user side, according to the configured mapping policy, an S-VLAN tag is added to the original packet. There are two optional configuration methods for this type of QINQ, and only one of them can be selected. One way is to configure the mapping relationship between C-VLAN and S-VLAN directly on the interface; the other way is to configure VLAN VPN globally (which includes the mapping relationship between C-VLAN and S-VLAN), and then associate the VPN on the interface. When using the same mapping policy for multiple interfaces, generally choose the latter configuration method. For this type of QINQ, if the packets received by the interface are un-tagged, the C-tag is the default VLAN Tag of the interface.
- **Class C:** ACL-based flexible QINQ, adding outer tags according to the configured traffic policy. The configuration of this type of QINQ is placed in the "QOS" module. For details, please refer to the "Configuring QOS" chapter. The policy pair between Policy-map and Class-map: "nest vlan <1-4094>" is used to configure ACL-based Flexible QINQ.

The above three types of QINQ can be enabled at the same time on the same port, and their priority relationship is: Type C > Type B > Type A.

8.1.2. VLAN Mapping

VLAN Mapping: From the user network to the provider network, it is still a single-layer Tag, but the C-Tag becomes S-Tag; in reverse, from S-Tag to C-Tag.

VLAN Mapping is divided into 1:1 VLAN Mapping and 1:N VLAN Mapping (the reverse is N:1). Currently, only 1:1 VLAN Mapping is supported. VLAN Mapping is configured by configuring VLAN VPN globally, and then associating VPN on interface.

VLAN Mapping only takes effect on tag packets, which is very different from the QINQ function.

The following points should be noted when configuring QINQ and VLAN Mapping.

VLAN Mapping takes effect only for tagged packets. Upstream, original packets must carry tags to implement CVLAN-to-SVLAN mapping; for downstream, the VLAN output rule on downlink interfaces must be tag output to implement SVLAN-to-SVLAN mapping. Mapping of CVLANs.

Note

Only physical interfaces support the configuration of QINQ and VLAN Mapping, but aggregated interfaces do not. When using the QINQ function or the VLAN Mapping function, it needs to be used in conjunction with the VLAN configuration. In the input and output directions, the filtering function of the VLAN, and the rules for whether the VLAN carries tags are all subject to the VLAN configuration. Specific requirements are as follows:

- Both CVLAN and SVLAN need to be added to the allow list of the downlink interface (connected to the Customer network), otherwise the flow will be filtered.
- The SVLAN needs to be added to the allow list of the uplink interface (connected to the provider network), otherwise the flow will be filtered.
- For QINQ, on the downlink interface, SVLAN should be configured with untag output, so as to strip the outer tag of QINQ downstream.
- For VLAN-Map, since it only takes effect for untag packets, for downlink interfaces, SVLAN should be configured with tag output, otherwise the downstream flow cannot complete the mapping from SVLAN to CVLAN.

The globally configured VLAN VPN is either used for VLAN Stacking (QINQ) or VLAN Mapping, but not both.

VLAN Mapping only supports 1:1 mapping. Therefore, if there are VLAN VPNs with N:1 mapping, they cannot be associated with the interface as the VPN of VLAN mapping. Similarly, if the VPN has been associated with the interface as the VLAN mapping, the mapping relationship Cannot change to N:1

The mapping relationship of VLAN Mapping must be consistent globally. Therefore, different interfaces can only be associated with the same VLAN VPN.

On the same interface, if you need to apply VLAN Mapping and QINQ at the same time, it should be noted that the two functions need to control different CVLANs and SVLANs. The specific constraints are as follows.

- If VLAN Mapping is used together with basic QINQ, the basic QINQ will take effect and VLAN Mapping will be invalid.
- If VLAN Mapping and flexible QINQ are used together, if a flow passes through the SVLAN mapped by VLAN Mapping and can be used as CVLAN to match the mapping policy of flexible QINQ, the final packet will take effect with flexible QINQ, adding SVLAN as external Layer TAG, the inner layer TAG remains unchanged (not the VLAN mapped by VLAN Mapping).
- Due to the above constraints, when two applications are enabled on the same interface, it is necessary to pay attention that the VLANs controlled by the two do not overlap. Invalid.

For Type B QINQs, you can either choose to configure the mapping policy directly under the interface, or choose to associate with VPN, but cannot be configured at the same time.

8.2. Configuring

- Creating VLAN VPN

| | |
|-------------|--|
| Command | SWITCH(config)#vlan-vpn VPN-NAME SWITCH(config)#no vlan-vpn VPN-NAME |
| Description | There can be multiple VPNs in the system, and each VPN maintains the mapping relationship between independent CVLANs and SVLANs. A VPN will only actually take effect when applied to an interface. A VPN can be applied to VLAN Stacking (QINQ) or VLAN Mapping, but only one of the two can be selected. |

- Adding VPN Mapping Relations

| | |
|-------------|--|
| Command | SWITCH(config-vlan-vpn)#cvlan VLAN_LIST svlan VLANID SWITCH(config-vlan-vpn)#no cvlan VLAN_LIST SWITCH(config-vlan-vpn)#no cvlan |
| Description | The valid range of VLAN_LIST and VLANID is <1,4094>, VLAN_LIST supports standard multi-vlan representation method ("-" and "," and combination of both). no cvlan without any parameters, clear all the mapping relationships in the VPN. |

- Configuring Port-based QINQ

| | |
|-------------|---|
| Command | SWITCH(config-if)#switchport vlan-stacking basic SWITCH(config-if)#no switchport vlan-stacking basic |
| Description | After basic QINQ is enabled, all incoming packets from this interface match the QINQ rules, and the mapped SVLAN is the default VLAN ID of the interface. |

- Configuring Mapping Relationship of QINQ on the interface

| | |
|-------------|---|
| Command | SWITCH(config-if)#switchport vlan-stacking cvlan VLAN_LIST svlan VLANID SWITCH(config-if)#no switchport vlan-stacking cvlan VLAN_LIST SWITCH(config-if)#no switchport vlan-stacking cvlan |
| Description | Similar to the mapping relationship configuration under VPN. Only when the interface is not associated with a VPN, can the mapping relationship be configured directly. |

- Attaching QINQ VPN on the Interface

| | |
|-------------|---|
| Command | SWITCH(config-if)#switchport vlan-stacking vpn VPN-NAME SWITCH(config-if)#no switchport vlan-stacking vpn |
| Description | An interface can only be associated with one VPN. The VPN association configuration can be performed only when the interface is not configured with a mapping relationship. |

- Clearing QINQ Configuration on the Interface

| | |
|-------------|--|
| Command | SWITCH(config-if)#no switchport vlan-stacking |
| Description | Equivalent to three commands: no switchport vlan-stacking basic no switchport vlan-stacking cvlan no switchport vlan-stacking vpn |

- Attaching VLAN Mapping VPN on the Interface

| | |
|-------------|--|
| Command | SWITCH(config-if)#switchport vlan-mapping vpn VPN-NAME SWITCH(config-if)#no switchport vlan-mapping |
| Description | VLAN mapping configured on different interfaces must be associated with the same VPN. And the mapping relationship in the corresponding VPN must be 1:1. |

8.3. Examples

Example 1: This example shows how to configure L2 VPN service.

Service Provider provides VPN for Enterprise A and Enterprise B:

- Enterprise A and enterprise B belong to different VLANs on the public network, and communicate through their own public network VLANs.
- The VLANs in enterprise A and enterprise B are transparent to the public network, and the user VLANs in enterprise A and enterprise B can be reused without conflict.
- Tunnel encapsulates a layer of VLAN Tag of Native VLAN to user data packets. In the public network, user data packets are transmitted in the native VLAN, which does not affect the use of VLANs in different enterprise user networks, and implements a simple Layer 2 VPN.




Illustration:

- Customer A1, Customer A2, Customer B1 and Customer B2 are the edge devices of the network where enterprise user A and enterprise user B are located, respectively. Provider A and Provider B are edge devices of the service provider network, and enterprise A and enterprise B access the public network through the edge devices of the provider.
- The VLAN range of the office network used by enterprise A is VLAN 1-100.
- The VLAN range of the office network used by enterprise B is VLAN 1-200.

ProviderA and ProviderB are completely symmetrical and have exactly the same configuration:

- Configuring VLAN

```
SWITCH(config)#vlan 2-200
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 1-100
SWITCH(config-if)#switchport trunk native vlan 10
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#switchport mode trunk
```

```
SWITCH(config-if)#switchport trunk native vlan 10
SWITCH(config-if)#interface gigabitEthernet0/5
SWITCH(config-if)#switchport mode trunk
```

- Configuring Base QinQ

```
SWITCH(config)#interface gigabitEthernet0/1-2
SWITCH(config-if)#switchport vlan-stacking basic
SWITCH(config-if)#exit
```

Example 2: This example shows how to Implement Layer 2 VPN and service flow management based on Flexible QinQ.

Basic QinQ can only encapsulate user data packets in the outer tag of a native VLAN, that is, the encapsulation of the outer tag depends on the native VLAN of the tunnel port. Flexible QinQ provides flexible encapsulation of external tags (S-Tags) of service providers (ISPs) according to the tags of user packets (ie C-Tags), so as to flexibly implement VPN transparent transmission and service flow QoS policies.

- Broadband Internet access and IPTV services are an important part of the services carried by the MAN. The MAN service provider network divides VLANs for different service flows to differentiate management, and provides QoS policy settings for these VLANs. You can use QinQ based on C-Tag on the edge device of the service provider to encapsulate the relevant VLAN of the user's business flow, and use the QoS policy of the service provider network for guaranteed transmission while transparent transmission.
- Unified VLAN planning is implemented between enterprise branches, and important services and general services are in different VLAN ranges. The enterprise network can use the flexible QinQ based on C-Tag to transparently transmit the internal services of the company, and can also use the service provider network. The QoS strategy of the company gives priority to ensuring the data transmission of important services.

As shown in the figure below, the client devices in the metropolitan area network are aggregated through the corridor switches in the community, and broadband Internet access and IPTV services are differentiated by assigning different VLANs to enjoy different QoS service policies.

- In the public network, different service flows of broadband Internet access and IPTV are transmitted in different VLANs to realize transparent transmission of user services.
- The ISP network sets the QoS policy for VLAN, and the corresponding VLAN can be encapsulated for the user service on the edge device of the service provider, so that the IPTV service is transmitted preferentially in the ISP network.




Illustration:

- CE1 and CE2 are edge devices that connect to the user's network, and PE1 and PE2 are edge devices that the provider serves on the network.

- VLAN 1-100 and VLAN 101-200 on CE1 and CE2 devices are the broadband Internet service flow for users, and the IPTV service flow for users.
- PE1 and PE2 devices package different s-tags for vlans of different businesses to distinguish different business data. VLAN 1-100 package VLAN100, vlan101-200 package VLAN200.

PE1 and PE2 are configured exactly the same:

- **Configuring VLAN**

```
SWITCH(config)#vlan 2-200
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#switchport mode hybrid
SWITCH(config-if)#switchport hybrid untagged vlan 100,200
SWITCH(config-if)#switchport hybrid vlan 100
SWITCH(config-if)#interface gigabitEthernet0/2
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#exit
```

- **Configuring Flexible QINQ**

```
SWITCH(config)#vlan-vpn isp
SWITCH(config-vlan-vpn)# cvlan 1-100 svlan 100
SWITCH(config-vlan-vpn)# cvlan101-200 svlan 200
SWITCH(config-vlan-vpn)# interface gigabitEthernet0/1
SWITCH(config-if)#switchport vlan-stacking vpn isp
SWITCH(config-if)#exit
```

Example 3: This example shows how to Implement Layer 2 VPN and service flow management based on VLAN Mapping.

Similar to Case 2, the broadband Internet access service and the IPTV service of the user are distinguished. For example, the broadband Internet access service is VLAN2, and the IPTV service is VLAN3. In the ISP network, VLAN200 and VLAN300 are respectively used to represent broadband Internet access services and IPTV services. All ports 1-10 of the PE device are connected to the CE device, and the uplink interface is gigabitEthernet0/11.

PE1 and PE2 are configured exactly the same:

- **Configuring VLAN**

```
SWITCH(config)#vlan2-3,200,300
SWITCH(config)#interface gigabitEthernet0/1-10
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#interface gigabitEthernet0/11
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#exit
```

- **Configuring VLAN Mapping**

```
SWITCH(config)#vlan-vpn isp-map
SWITCH(config-vlan-vpn)#cvlan 2 svlan 200
SWITCH(config-vlan-vpn)#cvlan 3 svlan 300
SWITCH(config-vlan-vpn)#interface gigabitEthernet0/1-10
SWITCH(config-if)#switchport vlan-mapping vpn isp-map
SWITCH(config-if)#exit
```

8.4. Display Information

- Display a VPN Information

```
SWITCH#show vlan-vpn test
```

```
-----  
VLAN VPN: test
```

```
Class: vlan-stacking
```

```
Mapping attributes:
```

```
cvlan 1-25,73,75-80 svlan 3
```

```
cvlan 200 svlan 4
```

```
Applied interfaces:
```

```
gigabitEthernet0/17
```

```
gigabitEthernet0/18
```

- 2) Display all VPN Information

```
SWITCH#show vlan-vpn
```

```
-----  
VLAN VPN: test
```

```
Class: vlan-stacking
```

```
Mapping attributes:
```

```
cvlan 1-25,73,75-80 svlan 3
```

```
cvlan 200 svlan 4
```

```
Applied interfaces:
```

```
gigabitEthernet0/17
```

```
gigabitEthernet0/18
```

```
-----  
VLAN VPN: test-map1
```

```
Class: vlan-mapping
```

```
Mapping attributes:
```

```
cvlan 100 svlan 1
```

```
cvlan 200 svlan 2
```

```
cvlan 800 svlan 8
```

```
cvlan 900 svlan 9
```

```
Applied interfaces:
```

```
gigabitEthernet0/18
```

```
gigabitEthernet0/19
```

```
-----  
VLAN VPN: test1
```

```
Class: unkown
```

```
Mapping attributes:
```

```
cvlan 800 svlan 8
```

```
cvlan 900 svlan 9
```

```
Applied interfaces:
```

```
empty!
```


8.5. Configuring ERPS

8.6. Overview of ERPS

ERPS (Ethernet Ring Protection Switching) was developed by ITU, also known as G.8032. It is a link layer protocol specifically applied to Ethernet. It can prevent the broadcast storm caused by the data loop when the Ethernet ring network is complete, and can quickly restore the communication between each node on the ring network when a link on the Ethernet ring is disconnected.

At present, the technology to solve the Layer 2 network loop problem is STP. STP is more mature to use, but its convergence time is longer (seconds). ERPS is a link layer protocol that is specially applied to Ethernet and has a faster rate than STP for convergence, up to 50ms.

ERPS typical scenario:



8.7. Introduction to ERPS Rationale


ERPS is a standard ring network protocol dedicated to the Ethernet link layer, with the ERPS ring as the basic unit. Only two ports on each layer 2 switch can be added to the same ERPS ring. In the ERPS, in order to prevent network loop, a break-down mechanism can be launched, blocking the RPL owner port and eliminating the ring route. When the ring connection fails, the equipment running the ERPS protocol can quickly forward the blocked port, make the link protection replacement, and restore

link communication between various nodes on the ring network. This section mainly presents the rationale for the implementation of ERPS under the basic network based on the normal -> link failure -> link recovery process (including protection switch operations).

Link OK


As shown in the diagram below, the equipment on the ring consisting of SwitchA~SwitchE is in good condition.

To prevent loops, ERPS first blocks the RPL owner port. If the RPL neighbor port is configured, the port will also be blocked, and other ports can forward traffic normally.



Link Failure

As shown in the diagram, when the link between SwitchD and SwitchE fails, the ERPS protocol starts the protection switching mechanism, blocks the ports on both ends of the faulty link, and then forward the RPL owner port, and the two ports resume user traffic. receiving and sending, thus ensuring uninterrupted traffic.



Link Restore

After the link returns to normal, if the ERPS ring is configured in revert mode, the device where the RPL owner port resides will block the traffic on the RPL link again, and the faulty link will be used again to transmit user traffic.

8.8. Configuring

• Creating Ring

| | |
|-------------|---|
| Command | <pre>SWITCH(config)#erps ring <1-255> east-interface IFNAME west-interface IFNAME SWITCH(config)#no erps ring <1-255></pre> |
| Description | <p>Create/delete ERPS ring.</p> <p>The ERPS ring is made up of the same set of VLAN and interconnected layer 2 switch, which is the basic unit of the ERPS protocol and needs to be configured on each device in the ring.</p> <p>The ring number is the unique identifier for the ERPS ring.</p> |

• Creating ERPS Instance

| | |
|-------------|---|
| Command | <pre>SWITCH(config)#erps instance NAME SWITCH(config)#no erps instance NAME</pre> |
| Description | <p>Create/remove ERPS instances; Create an instance to go into instance configuration mode.</p> <p>For the layer 2 switch operating an ERPS protocol, VLAN transmitting ERPS and data articles must be mapped into a protective instance so that ERPS protocol can be forwarded or blocked in accordance with their</p> |

| | |
|--|--|
| | blocking principles. Otherwise, user traffic could cause broadcast storms in a ring network that could make the network unavailable. |
|--|--|

- Associating ERPS Instances and Rings

| | |
|-------------|---|
| Command | SWITCH(config-erps-inst)#ring <1-255> |
| Description | Configure the corresponding relationships between ERPS instances and rings. |

- Configuring ERPS Instance Level

| | |
|-------------|--------------------------------------|
| Command | SWITCH(config-erps-inst)#level <0-7> |
| Description | Configure ERPS instance level. |

- Configuring the Configuration Profile Used by ERPS Instances

| | |
|-------------|--|
| Command | SWITCH(config-erps-inst)#profile NAME |
| Description | Configure the ERPS configuration profile name. |

- Configuring RPL Roles in ERPS Instance

| | |
|-------------|---|
| Command | SWITCH(config-erps-inst)#rpl-role NAME |
| Description | Configure the ERPS instance RPL role; An ERPS ring has only one RPL owner port, which is determined by user configuration. The RPL owner port is blocked from forwarding user traffic to prevent loops in the ERPS ring. |

- Configuring Raps VLAN for Instance

| | |
|-------------|--|
| Command | SWITCH(config-erps-inst)#vlan <2-4094> raps-channel SWITCH(config-erps-inst)#no raps-channel |
| Description | Configuration/delete raps VLAN for ERPS instances; Each ERPS ring must be configured with a raps VLAN. Different ERPS rings cannot use the same raps VLAN ID. |

- Configuring VLAN Instance

| | |
|-------------|--|
| Command | SWITCH(config-erps-inst)#id <0-255> |
| Description | Configure VLAN Instance; The relationship between VLAN and Instance can be configured in MST mode; by default, all VLANs belong to Instance 0; the default id is 0. Note: Multi-instance is currently not supported in intersecting rings! |

- Configuring Intersecting Sub-ring Block Port

| | |
|-------------|---|
| Command | SWITCH(config-erps-inst)#sub-ring block (east-interface west-interface) |
| Description | Configure the ERPS instance as a sub-ring instance and specify a sub-ring block port. |

- Configuring Sub-ring Virtual Channels and Non-virtual Channels

| | |
|-------------|--|
| Command | SWITCH(config-erps-inst)#virtual-channel attached-to-instance NAME SWITCH(config-erps-inst)# non-virtual-channel |
| Description | Configure the type of ERPS intersecting sub-ring: virtual channel and associated main ring; or non-virtual channel type. Note: The position displayed by this command in show running-config must be after the displayed position of the associated instance. Normally only need to ensure that the sub-ring ID and instance name are larger than the main ring ID and instance name. |

- Creating ERPS Configuration Profile

| | |
|-------------|--|
| Command | SWITCH(config)#erps profile NAME SWITCH(config)#no erps profile NAME |
| Description | Create/Remove ERPS configuration profile; Enter ERPS profile configuration mode after creating it. |

- Configuring ERPS Revert Mode


| | |
|-------------|--|
| Command | SWITCH(config-erps-prof)#revertive non-revertive |
| Description | Configure ERPS revertive/non-revertive. |

- Configuring ERPS Timer Parameters

| | |
|-------------|--|
| Command | SWITCH(config-erps-prof)#timer (wait-to-restore (<1-12> default) hold-off (<0-100> default) guard-timer (<1-200> default)) |
| Description | Configure ERPS timer parameters. <1-12>: in minutes; revert time after recovery, default is 5 minutes. <0-100>: in 100 milliseconds; hold time before port forwarding, the default is 0, direct forwarding without delay. <1-200>: in 10 milliseconds; protection window when state changes, avoid receiving messages from previous state leading to protocol errors, default is 50: 500 ms. guard-timer parameters limit network size. It is conservatively recommended that when there are more than 300 nodes in the ring network, directly configure this parameter to the maximum value to avoid the failure of old packets to be discarded due to the large network size; no special configuration is required for nodes within 300 nodes. |

8.9. Examples

1. Single-ring case requirements: As shown in the figure, the configuration blocks the direct links of S1 and S2 by default, and restores the link in time to ensure the availability of the network in case of failure. Where the data VLANs are 1, 2 and 3.



S1/S2:

- Enter global configuration mode, create ERPS and set related parameters, command reference list below:

Create vlan 2,3;vlan 1 default exists

```
SWITCH(config)#vlan 2,3
```

Change the interface mode to trunk. By default, trunk mode will add all data vlans and management vlans to the interface for forwarding.

```
SWITCH(config)#interface gigabitEthernet0/9-10
```

```
SWITCH(config-if)#switchport mode trunk
```

Create ERPS ring 1

```
SWITCH(config)#erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
```

Create ERPS instance 1, associated with ring 1, and associated details configuration

```
SWITCH(config)#erps instance 1
```

```
SWITCH(config-erps-inst)#ring 1
```

```
SWITCH(config-erps-inst)#rpl-role non-owner
```

```
SWITCH(config-erps-inst)#vlan 1000 raps-channel
```

S3:

- Enter global configuration mode, create ERPS and set related parameters, command reference list below:

```
SWITCH(config)#Vlan 2,3
```

```
SWITCH(config)#interface gigabitEthernet0/9,gigabitEthernet0/10
```

```
SWITCH(config-if)#switchport mode trunk
```

```
SWITCH(config)#Erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
```

```
SWITCH(config)#Erps instance 1
```


```
SWITCH(config-erps-inst)#ring 1
```

```
SWITCH(config-erps-inst)#rpl-role owner east
```

```
SWITCH(config-erps-inst)#vlan 1000 raps-channel
```

2. Intersection ring case requirements

As shown in the following topology, S1, S2, S3, and S4 form intersecting rings, and the data vlans are 1, 2, 3, and 4. It is required to achieve fast convergence when a single point of failure occurs in each ring; a maximum of two faults can occur in the network Points (different rings), without user disconnection, to achieve optimal reliability.



Typical configuration examples:

S1:

```

Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 1
  ring 1
  vlan 1000 raps-channel

Erps ring 2 east gigabitEthernet0/9 west gigabitEthernet0/11
Erps instance 2
  ring 2
  sub-ring block east-interface
  vlan 1100 raps-channel
  virtual-channel attached-to-instance 1
  
```

S2:

```

Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 1
  ring 1
  vlan 1000 raps-channel

Erps ring 2 east gigabitEthernet0/12 west gigabitEthernet0/10
Erps instance 2
  ring 2
  
```

```

sub-ring block east-interface
vlan 1100 raps-channel
virtual-channel attached-to-instance 1

```

S3:

```

Vlan 2,3,4
interface gigabitEthernet0/5-6
switchport mode trunk
Erps ring 1 east gigabitEthernet0/5 west gigabitEthernet0/6
Erps instance 1
ring 1
rpl-role owner east
vlan 1000 raps-channel

```

S4:

```


Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 2 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 2
ring 2
rpl-role owner east
vlan 1100 raps-channel

```

3. Tangent ring case requirements

The topology diagram is shown below. S1 is located in the central computer room, which can be supervised and maintained by the administrator in real time, and has high reliability; S2-S5 are distributed in various deployment points, in order to improve the reliability of the network and avoid the occurrence of single-link external connection. The single-point failure risk is avoided, and the single-machine failure risk that may occur in a dual-link external connection is avoided, and the dual-link external connection is used to form a ring network.

It is required that each ring network can converge quickly when a single point of failure occurs to avoid user network interruption.



Typical configuration examples:

S1:

```
Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 1
  ring 1
  vlan 1000 raps-channel

Erps ring 2 east gigabitEthernet0/11 west gigabitEthernet0/12
Erps instance 2
  ring 2
  vlan 1100 raps-channel
```

S2:

```
Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 1
  ring 1
  rpl-role owner east
  vlan 1000 raps-channel
```

S3:

```
Vlan 2,3,4
interface gigabitEthernet0/5-6
switchport mode trunk
Erps ring 1 east gigabitEthernet0/5 west gigabitEthernet0/6
Erps instance 1
  ring 1
  vlan 1000 raps-channel
```

S4:

```
Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 2 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 2
  ring 2
  rpl-role owner east
  rpl-role owner east
```

S5:

```
Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
```



```
Erps ring 2 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 2
ring 2
vlan 1100 raps-channel
```

8.10. Display Information

- Show ERPS Ring Information

```
SWITCH#show erps ring 1
Ring      : 1
=====
Bridge    : 1
East      : gigabitEthernet0/9
West      : gigabitEthernet0/10
ERP Inst :1,
```

- Show ERPS Instances

```
SWITCH#
SWITCH#show erps instance 1
Inst Name      : 1
Inst Id        : 0
State          : ERPS_ST_IDLE
Last Priority   : RAPS-NR-RB
Phy Ring       : 1
Role           : NON-OWNER
East Link      : Link_Unblocked(up)(00-D0-FA-0A-10-06, 1)
East Link      : Link_Unblocked(up)(00-D0-FA-0A-10-06, 1)
TCN Propagation : Disabled
Attached       : -
Attached To    : -
Virtual ID     : -:-
-----
      Channel      |      Interface      |      Profile
(LEVL, VID, RID)  | (east,ver) , (west,ver) |
=====
(0, 1000, 1)      | (gigabitEthernet0/9, V=1), (gigabitEthernet0/10, V=1) | Default
```

- Show ERPS Profile

```
SWITCH#show erps profile 1
Profile : 1
=====
Wait-To-Restore : 5 mins
Hold Off Timer  : 0 secs
Guard Timer     : 500 ms
Wait-To-Block   : 5500 ms
Protection Type : Revertive
```



9. Configuring IGMP Snooping

9.1. Overview of IGMP Snooping

IGMP Snooping is a short term for Internet Group Management Protocol Snooping, a mechanism running on a layer 2 device for managing and controlling multicast groups.

A Layer 2 device running IGMP Snooping analyzes the received IGMP packets, establishes a mapping relationship between ports and MAC multicast addresses, and forwards multicast data according to the mapping relationship. When the Layer 2 device does not run IGMP Snooping, the multicast data is broadcast at Layer 2; when the Layer 2 device runs IGMP Snooping, the multicast data of the known multicast group will not be broadcast at Layer 2, but at Layer 2.

As shown in the figure below, when the Layer 2 multicast device does not run IGMP Snooping, the IP multicast packets are broadcast in the VLAN; when the Layer 2 multicast device runs IGMP Snooping, the IP multicast packets are only sent to the group members recipient.



9.2. Configuring

- Enabling IGMP Snooping

| | |
|-------------|---|
| Command | SWITCH(config)# igmp snooping SWITCH(config)# no igmp snooping |
| Description | Enable/disable IGMP Snooping function; disabled by default. Global configuration mode. |

- Configuring IGMP Snooping Upstream Ports

| | |
|-------------|---|
| Command | SWITCH(config-if)# igmp snooping mrouter interface IFNAME SWITCH(config-if)# no igmp snooping mrouter interface IFNAME |
| Description | Configure/delete IGMP Snooping upstream port; optional configuration. SVI interface mode. |

- Configuring IGMP Snooping Static Groups


| | |
|-------------|---|
| Command | SWITCH(config-if)# igmp snooping static-group IPADDR source IPADDR interface IFNAME SWITCH(config-if)# no igmp snooping static-group IPADDR source IPADDR interface IFNAME |
| Description | Configure/delete IGMP Snooping static group; optional configuration. SVI interface mode. |

- Configuring IGMP Snooping Fast Leave

| | |
|-------------|--|
| Command | SWITCH(config-if)# igmp snooping fast-leave SWITCH(config-if)# no igmp snooping fast-leave |
| Description | Configure/delete IGMP Snooping fast leave function; optional configuration. SVI interface mode. |

9.3. Examples

Simplified topology:



Basic configuration /roles: (top down)

server:

During the test, VLC is used as the multicast server to provide the multicast service: udp://225.0.0.1:1234, the server IP is 3.3.3.10

router:

Run the multicast routing protocol and enable IGMP, and use Ruijie S57 Layer 3 switch to simulate the test. The main configurations are as follows:

Enable multicast routing

```
ip multicast-routing
```

Configure the uplink port , connect to the server, here is simply to select the PIM dense mode, the actual network scale is large, and the multicast use is less, it is recommended to use the sparse mode

```
interface GigabitEthernet 0/23
no switchport
no ip proxy- arp
ip pim dense-mode
ip address 3.3.3.3 255.255.255.0
```

Configure the downlink port. The PIM dense mode is simply selected here. The actual network scale is large and the multicast usage is small. It is recommended to use the sparse mode

```
interface VLAN 1
no ip proxy- arp
ip pim dense-mode
ip address 2.2.2.1 255.255.255.0
```

SWITCH:

Multicast can be enabled

```
igmp snooping
```

Client:

Watch server multicast video through udp://225.0.0.1:1234, IP 2.2.2.10

9.4. Display Information

- View IGMP Snooping Multicast Groups

```
SWITCH#show igmp snooping groups
```

- Viewing IGMP Snooping Interface Information

```
SWITCH#show igmp snooping interface {ifname}
Example:
IGMP Snooping information for vlan1
IGMP Snooping enabled
Snooping Querier none
IGMP Snooping other querier timeout is 255 seconds
Group Membership interval is 260 seconds
IGMPv2 fast-leave is disabled
IGMPv1/v2 Report suppression enabled
IGMPv3 Report suppression enabled
Router port detection using IGMP Queries
Number of router-ports: 2
Number of Groups: 2
Number of Joins: 891
Number of Leaves: 4
Active Ports:
gigabitEthernet0/1
gigabitEthernet0/2
```

- Viewing IGMP Snooping Routing Port Information

```
SWITCH#show igmp snooping mrouter vlan1
Example:
```

```
SWITCH#show igmp snooping mrouter vlan1
VLAN Interface IP-address Expires
1 gigabitEthernet0/18(dynamic) 2.2.2.1 00:03:34
gigabitEthernet0/20(static) -- --
```

- Viewing IGMP Snooping Interface Statistics

```
SWITCH#show igmp snooping statistics interface vlan1
IGMP Snooping statistics for vlan1
Group Count : 2
IGMP reports received : 893
IGMP leaves received : 4
IGMPv1 query warnings : 0
IGMPv2 query warnings : 456
IGMPv3 query warnings : 0
```

10. Configuring Spanning Tree Protocol

10.1. Overview of Spanning Tree Protocol

Spanning Tree Protocol is a layer 2 management protocol, which eliminates layer 2 loops by selectively blocking redundant links in the network, and also has the function of link backup.

Like the development process of many protocols, the Spanning Tree Protocol is constantly updated with the development of the network, from the original STP (Spanning Tree Protocol) to RSTP (Rapid Spanning Tree Protocol), and then to the latest MSTP (Multiple Spanning Tree Protocol).

For layer 2 Ethernet, there can only be one active path between two LANs, otherwise a broadcast storm will occur. However, in order to strengthen the reliability of a local area network, it is necessary to establish redundant links, some of which must be in a backup state. If the network fails and another link fails, the redundant link must be upgraded to Active status. Controlling such a process manually is obviously a very hard job, and the STP protocol does this automatically. It enables devices on a local area network to:

Find and start an optimal tree topology for the LAN.

Faults are detected and then recovered, automatically updating the network topology so that the best possible tree structure is selected at any time.

10.2. Configuring

- Configuring STP Mode

| | |
|-------------|---|
| Command | SWITCH(config)# spanning-tree mode { stp rstp mstp } |
| Description | stp: Spanning tree protocol (IEEE 802.1d) rstp: Rapid spanning tree protocol (IEEE 802.1w) mstp: Multiple spanning tree protocol (IEEE 802.1s) The default is rstp mode. After the mode is switched, the spanning tree protocol is disabled by default and needs to be re-enabled. Global configuration mode. |

- Enabling Spanning Tree Protocol

| | |
|-------------|---|
| Command | SWITCH(config)# spanning-tree enable SWITCH(config)# no spanning-tree enable |
| Description | Enables/disables STP function; disabled by default. Global configuration mode. |

- Configuring Device Priority

| | |
|---------|---|
| Command | SWITCH(config)# spanning-tree priority <0-61440> SWITCH(config)# no spanning-tree priority SWITCH(config)# spanning-tree instance <1-63> priority <0-61440> |
|---------|---|

| | |
|-------------|---|
| | SWITCH(config) #no spanning-tree instance <1-63> priority |
| Description | Configure/delete STP system priority; default 32768.Optional. Global configuration mode. |

- Configuring Hello Time

| | |
|-------------|--|
| Command | SWITCH(config)# spanning-tree hello-time <1-10> SWITCH(config)# no spanning-tree hello-time |
| Description | Configure/reset BPDU packet period, in seconds; the default is 2s. Optional. Global configuration mode. |

- Configure Forward-Delay Time

| | |
|-------------|--|
| Commands | SWITCH(config)# spanning-tree forward-time <4-30> SWITCH(config)# no spanning-tree forward-time |
| Description | Configure/reset STP port forwarding state delay time, in seconds. the default is 15s. Optional. Global configuration mode. |

- Configure Max-Age Time

| | |
|-------------|--|
| Command | SWITCH(config)# spanning-tree max-age <6-40> SWITCH(config)# no spanning-tree max-age |
| Description | Configure/reset the lifetime of BPDUs, in seconds; the default is 20s.Optional. Hello Time, Forward-Delay Time, Max-Age Time need to follow the conditions: $2 \times (\text{Hello Time} + 1.0 \text{ seconds}) \leq \text{Max-Age Time} \leq 2 \times (\text{Forward-Delay} - 1.0 \text{ seconds})$, otherwise it may lead to topology unstable. The longest path of the STP/RSTP network is affected by this parameter. The default longest path is 20 devices. When there are more than 20 devices, the configuration needs to be modified (forward-delay 21s, max-age 40s can be configured), and the maximum supported longest path is 40. Global configuration mode. |

- Configure Max-Hops

| | |
|-------------|---|
| Command | SWITCH(config)# spanning-tree max-hops <1-40> SWITCH(config)# no spanning-tree max-hops |
| Description | Configure/reset the maximum number of hops for BPDU packets; the default is 20. Optional. The longest path of the MSTP network is affected by this parameter. When there are more than 20 devices, the configuration needs to be modified, with a maximum of 40. MSTP is compatible with the max-age function, and the max-age parameter needs to be adjusted at the same time. Refer to the corresponding command. Global configuration mode. |

- Configuring Transmit-Holdcount

| | |
|---------|---|
| Command | SWITCH(config)# spanning-tree transmit-holdcount <1-10> |
|---------|---|

| | |
|-------------|---|
| | SWITCH(config)# no spanning-tree transmit-holdcount |
| Description | Configure/reset the maximum number of BPDUs sent per second; default is 6.Optional. Global configuration mode. |

- Entering MST Mode

| | |
|-------------|---|
| Command | SWITCH(config)# spanning-tree mst configuration |
| Description | Enter MST mode. Global configuration mode. |

- Configuring the Mapping Between MST VLAN and Instance

| | |
|-------------|--|
| Command | SWITCH(config-mst)# instance <1-63> vlan VLANID SWITCH(config-mst)# no instance <1-63> vlan VLANID |
| Description | Configure/delete the association between MST instances and VLANs; optional configuration. MST mode. |

- Configuring the MST Area Name

| | |
|-------------|--|
| Command | SWITCH(config-mst)# region NAME SWITCH(config-mst)# no region NAME |
| Description | Configure/delete the MST area name; optional configuration. MST mode. |

- Configuring the MST Version Number

| | |
|-------------|---|
| Command | SWITCH(config-mst)# revision <0-65535> |
| Description | Configure/delete the MST version number, the default is 0; optional configuration. MST mode. |

- Configuring the Association Between Ports and Instances

| | |
|-------------|---|
| Command | SWITCH(config-if)# spanning-tree instance <1-63> SWITCH(config-if)# no spanning-tree instance <1-63> |
| Description | Configure/remove association of ports and instances; optional configuration. By default, when configuring the relationship between an instance and a VLAN, the system automatically generates data about the relationship between the port and the instance based on the VLAN and port relationship, and no manual configuration is required. After the instance is configured, if the relationship between ports and VLANs is manually modified, such as adding/exiting all VLANs of an instance to the ports, you need to manually maintain the relationship between ports and instances through this command. When major configuration changes occur, it is recommended to automatically generate port and instance data by reconfiguring the instance-VLAN relationship or restarting the device. MST mode. |

- Configuring Port Priority

| | |
|-------------|--|
| Command | SWITCH(config-if)# spanning-tree priority <0-240> SWITCH(config-if)# spanning-tree instance <1-63> priority <0-240> |
| Description | Configure the port STP priority; the default is 128.Optional. Interface configuration mode. |

- Configuring Port Path Cost

| | |
|-------------|---|
| Command | SWITCH(config-if)# spanning-tree path-cost <1-200000000> SWITCH(config-if)# no spanning-tree path-cost |
| Description | Path cost to configure/reset port; optional configuration. Interface configuration mode. |

- Configuring Link-Type

| | |
|-------------|--|
| Command | SWITCH(config-if)# spanning-tree link-type { auto point-to-point shared } SWITCH(config-if)# no spanning-tree link-type |
| Description | Configure/reset the link type, the default is auto. Optional. auto: Automatic setting mode based on the duplex capability of link negotiation, full duplex is a point-to-point connection. point-to-point: Enable fast forwarding. shared: Disable fast forwarding. Global configuration mode. |

- Configuring Protocol Migration Processing

| | |
|-------------|---|
| Command | SWITCH(config-if)# clear spanning-tree detected protocols |
| Description | Force version checking on all ports. Privileged mode. |

- Enable Portfast

| | |
|-------------|--|
| Command | SWITCH(config-if)# spanning-tree portfast SWITCH(config-if)# no spanning-tree portfast |
| Description | Configure/delete port portfast; the port will be forwarded directly after portfast is enabled. However, the Port Fast Operational State will be disabled due to the receipt of BPDUs, so that it can normally participate in the STP algorithm and forwarding; it is disabled by default; optional configuration. Interface configuration mode. |

- Configuring Edge Ports

| | |
|-------------|---|
| Command | SWITCH(config-if)# spanning-tree {edgeport autoedge} SWITCH(config-if)# no spanning-tree {edgeport autoedge} |
| Description | Configure/delete a port Edge Port; if configured as edgeport, it means that the device directly connected to |

| | |
|--|---|
| | <p>the port is not a bridge device and can be forwarded quickly; if configured as autoedge, it means that the port automatically identifies whether it is an edge port according to the BPDU; it is disabled by default; optional configuration.</p> <p>Interface configuration mode.</p> |
|--|---|

- Configuring Root Guard

| | |
|-------------|--|
| Command | <p>SWITCH(config-if)# spanning-tree guard root</p> <p>SWITCH(config-if)# no spanning-tree guard root</p> |
| Description | <p>Configure/delete port root guard; when the root guard function is enabled on an interface, its port role on all instances is forced to be the designated port. Once the port receives configuration information with a higher priority, the root guard function will set the interface to the designated port. blocked state; closed by default; optional configuration.</p> <p>Interface configuration mode.</p> |

- Configuring BPDU Guard

| | |
|-------------|---|
| Command | <p>SWITCH(config)# spanning-tree portfast bpdu-guard</p> <p>SWITCH(config)# no spanning-tree portfast bpdu-guard</p> <p>SWITCH(config-if)# spanning-tree portfast</p> <p>SWITCH(config-if)# no spanning-tree portfast</p> <p>or:</p> <p>SWITCH(config-if)# spanning-tree bpdu-guard enable</p> <p>SWITCH(config-if)# spanning-tree bpdu-guard disable</p> |
| Description | <p>Configure/delete BPDU Guard; after the port has BPDU Guard enabled, if a BPDU is received on the port, it will enter the Error-disabled (blocked) state; optional configuration.</p> <p>Interface configuration mode.</p> |

- Configuring BPDU Filter

| | |
|-------------|---|
| Command | <p>SWITCH(config)# spanning-tree portfast bpdu-filter</p> <p>SWITCH(config)# no spanning-tree portfast bpdu-filter</p> <p>SWITCH(config-if)# spanning-tree portfast</p> <p>SWITCH(config-if)# no spanning-tree portfast</p> <p>or:</p> <p>SWITCH(config-if)# spanning-tree bpdu-filter enable</p> <p>SWITCH(config-if)# spanning-tree bpdu-filter disable</p> |
| Description | <p>Configure/delete BPDU Filter; after enabling BPDU Filter, the port neither sends BPDU nor receives BPDU packets; optional configuration.</p> <p>Interface configuration mode.</p> |

- Configuring TC Topology Change Notification

| | |
|---------|--|
| Command | <p>SWITCH(config-if)# spanning-tree restricted-tcn</p> <p>SWITCH(config-if)# no spanning-tree restricted-tcn</p> |
|---------|--|

| | |
|-------------|--|
| | SWITCH(config-if)# spanning-tree instance <1-63> restricted-tcn SWITCH(config-if)# no spanning-tree instance <1-63> restricted-tcn |
| Description | Configure/reset the topology change notification limit. After configuration, the port will not forward TC BPDUs, nor refresh the address table; optional configuration. Interface configuration mode. |


- Configuring the Wrong Port Timeout Function

| | |
|-------------|---|
| Command | SWITCH(config)# spanning-tree errdisable-timeout enable SWITCH(config)# no spanning-tree errdisable-timeout enable SWITCH(config)# spanning-tree errdisable-timeout interval <10-1000000> SWITCH(config)# no spanning-tree errdisable-timeout interval |
| Description | Configure/reset error port timeout feature. By default, the error port timeout function is not enabled, that is, the error port will never timeout and automatically recover, and must be recovered manually. The timeout unit is seconds, the default is 300 seconds; Optional. Global configuration mode. |

10.3. Examples

1. RSTP anti-loop to realize link redundancy scheme.

Simplified topology:



Typical configuration:

S1/S2/S3:

- Enter the global configuration mode, configure the rstp mode, and enable the stp switch:

use rstp mode


```
spanning-tree mode rstp
```

enable stp

```
spanning-tree enable
```

2. MSTP implements domain- and instance-based anti-loop and link redundancy.

Simplified topology:



Configuration plan:

The devices belong to the same domain, the default 'Default' domain is used here, no additional configuration is required.

VLAN 20 is a shared vlan and is directly assigned to CST.

| Example | VLAN |
|---------|------|
| 0 | 20 |
| 1 | 10 |
| 3 | 30 |
| 4 | 40 |

Typical configuration:

Switch A:

Configure VLANs and ports

```
SWITCH(config)#vlan 10,20,30,40
SWITCH(config)#interface gigabitEthernet0/9
SWITCH(config-if)#switchport mode trunk
SWITCH(config)#interface gigabitEthernet0/10
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 10,20
SWITCH(config)#interface gigabitEthernet0/11
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20,30
```

Configure MSTP instance

```
SWITCH(config)#spanning-tree mode mstp
SWITCH(config)#spanning-tree mst configuration
SWITCH(config-mst)#instance 1 vlan 10
SWITCH(config-mst)#instance 3 vlan 30
SWITCH(config-mst)#instance 4 vlan 40
```

enable MSTP

```
SWITCH(config)#spanning-tree enable
```

Switch B:

Configure VLANs and ports

```
SWITCH(config)#vlan 10,20,30,40
SWITCH(config)#interface gigabitEthernet0/9
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20,30
SWITCH(config)#interface gigabitEthernet0/10
SWITCH(config-if)#switchport mode trunk
SWITCH(config)#interface gigabitEthernet0/11
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 10,20
```

#Configure MSTP instance

```
SWITCH(config)#spanning-tree mode mstp
SWITCH(config)#spanning-tree mst configuration
SWITCH(config-mst)#instance 1 vlan 10
SWITCH(config-mst)#instance 3 vlan 30
SWITCH(config-mst)#instance 4 vlan 40
```

enable MSTP

```
SWITCH(config)#spanning-tree enable
```

Switch C:

Configure VLANs and ports

```
SWITCH(config)#vlan 10,20,30,40
SWITCH(config)#interface gigabitEthernet0/9
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20,40
SWITCH(config)#interface gigabitEthernet0/10
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20,30
SWITCH(config)#interface gigabitEthernet0/11
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20,30
```

Configure MSTP instance

```
SWITCH(config)#spanning-tree mode mstp
SWITCH(config)#spanning-tree mst configuration
SWITCH(config-mst)#instance 1 vlan 10
SWITCH(config-mst)#instance 3 vlan 30
SWITCH(config-mst)#instance 4 vlan 40
```

enable MSTP

```
SWITCH(config)#spanning-tree enable
```

Switch D:

Configure VLANs and ports

```
SWITCH(config)#vlan 10,20,30,40
SWITCH(config)#interface gigabitEthernet0/9
SWITCH(config-if)#switchport mode trunk
```

```
SWITCH(config-if)#switchport trunk allowed vlan 10,20
SWITCH(config)#interface gigabitEthernet0/10
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20,40
SWITCH(config)#interface gigabitEthernet0/11
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 10,20
```

Configure MSTP instance

```
SWITCH(config)#spanning-tree mode mstp
SWITCH(config)#spanning-tree mst configuration
SWITCH(config-mst)#instance 1 vlan 10
SWITCH(config-mst)#instance 3 vlan 30
SWITCH(config-mst)#instance 4 vlan 40
```

#enable MSTP

```
SWITCH(config)#spanning-tree enable
```

10.4. Display Information

- View STP Status

```
SWITCH#show spanning-tree
```

- View MSTP Instance Status

```
SWITCH#show spanning-tree mst instance <1-63>
```

11. Configuring MAC Address

11.1. Overview of MAC Address

The MAC address table contains address information that the switch uses to forward traffic between ports. The switch sends packets between any combination of ports, based on the destination address of the received packet. Using the MAC address table, the switch forwards the packet only to the port associated with the destination address. If the destination address is on the port that sent the packet, the packet is filtered and not forwarded.

The MAC address table includes these types of addresses:

Dynamic address: a source MAC address that the switch learns and then ages when it is not in use.

Static address: a manually entered unicast address that does not age and that is not lost when the switch resets.

Filter address: Also a static MAC address, but drop the packet with the specified source or destination unicast filter address.

All addresses are associated with a VLAN. An address can exist in more than one VLAN and have different destinations in each.

Each VLAN maintains its own logical address table. A known address in one VLAN is unknown in another until it is learned or statically associated with a port in the other VLAN.

Dynamic addresses are source MAC addresses that the switch learns and then ages when they are not in use. You can change the aging time setting for all VLANs or for a specified VLAN. Setting too short an aging time can cause addresses to be prematurely removed from the table. Then when the switch receives a packet for an unknown destination, it floods the packet to all ports in the same VLAN as the receiving port. This unnecessary flooding can impact performance. Setting too long an aging time can cause the address table to be filled with unused addresses, which prevents new addresses from being learned.

11.2. Configuring

- Changing MAC Address Aging Time

| | |
|-------------|---|
| Command | SWITCH(config)#mac-address-table aging-time <0-600> SWITCH(config)#no mac-address-table aging-time |
| Description | Set the length of time that a dynamic entry remains in the MAC address table. The range is 1 to 600 seconds. The default is 300 seconds. You can also enter 0, which disables aging. |

- Adding Static MAC Address Entries

| | |
|-------------|--|
| Command | SWITCH(config)#mac-address-table static MAC_ADDR vlan VLANID interface IFNAME SWITCH(config)#no mac-address-table static MAC_ADDR vlan VLANID interface IFNAME |
| Description | Add a static address to the MAC address table. MAC_ADDR: specify the destination MAC unicast address to add to the address table. Packets with this destination address received in the specified VLAN are forwarded to the specified interface. VLANID: specify the VLAN for which the packet with the specified MAC address is received, Valid VLAN IDs are 1 to 4094. IFNAME: specify the interface to which the received packet is forwarded, Valid interfaces include physical ports or port channels. |

- Adding Filter MAC Address Entries

| | |
|-------------|---|
| Command | SWITCH(config)#mac-address-table filter MAC_ADDR vlan VLANID SWITCH(config)#no mac-address-table filter MAC_ADDR vlan VLANID |
| Description | Add a filter address to the MAC address table. VLANID: specify the VLAN for which the packet with the specified MAC address is received, Valid VLAN IDs are 1 to 4094. IFNAME: specify the interface to which the received packet is dropped, Valid interfaces include physical ports or port channels. |

- Clearing Dynamic MAC Address Entries

| | |
|-------------|---|
| Command | SWITCH#clear mac-address-table dynamic SWITCH#clear mac-address-table dynamic vlan VLANID SWITCH#clear mac-address-table dynamic interface IFNAME |
| Description | Clear Dynamic Mac Address Entries. Support all, based on vlan or based on interface options. |

11.3. Examples

Example 1: This example shows how to change MAC Address aging time to 60 seconds.

Step1: Enter configuration mode:

```
SWITCH#configure terminal
```

Enter configuration commands, one per line. End with CNTL/Z.

Step2: Change MAC Address aging time to 60 seconds.

```
SWITCH(config)#mac-address-table aging-time 60
```

Example 2: This example shows how to add a static MAC Address entry.

Step1: Enter configuration mode:

```
SWITCH#configure terminal
```

Enter configuration commands, one per line. End with CNTL/Z.

Step2: Add a static MAC Address entry.

```
SWITCH(config)#mac-address-table static 000E.C6C1.C8AB vlan 1 interface gigabitEthernet0/1
```

Example 3: This example shows how to add a filter MAC Address entry.

Step1: Enter configuration mode:

```
SWITCH#configure terminal
```

Enter configuration commands, one per line. End with CNTL/Z.

Step2: Add a filter MAC Address entry

```
SWITCH(config)#mac-address-table filter 000E.C6C1.C8AB vlan 1
```

Example 4: This example shows how to clear dynamic MAC Address entries.

Step1: Clear MAC Address entries by interface.

```
SWITCH#clear mac-address-table dynamic interface gigabitEthernet0/1
```

11.4. Display Information

- Display MAC Address Table Entries

```
SWITCH#show mac-address-table
```

| VLAN | MAC Address | Type | Ports |
|------|-------------|------|-------|
|------|-------------|------|-------|

| | | | |
|--------------------------|----------------|--------|------|
| -----+-----+-----+-----+ | | | |
| 20 | 0000.0000.0009 | filter | drop |
| 20 | 0000.0000.000a | filter | drop |

- Display MAC Address Table Statistics

```
SWITCH#show mac-address-table count
Static Address Count: 0
Filter Address Count: 2
Dynamic Address Count: 0
```

12. Configuring LLDP


1.1. Overview of LLDP

LLDP (Link Layer Discovery Protocol) provides a standard link layer discovery method, enabling devices of different manufacturers to discover each other in the network and exchange their system and configuration information. LLDP encapsulates the information of the local device (including main capabilities, management address, device identification, interface identification, etc.) in LLDPDU (Link Layer Discovery Protocol Data Unit). It is released to the neighbors directly connected to itself. After receiving the information, the neighbors save it in the form of standard MIB up for the network management system to query and judge the communication status of the link.

LLDPDU

LLDPDU is a data unit encapsulated in the data part of an LLDP message. Before forming an LLDPDU, the device first encapsulates the local information into a TLV format, and then combines several TLVs into one LLDPDU and encapsulates it in the data part of the LLDP packet for transmission.

Figure 1 LLDPDU encapsulation format



As shown in Figure 1, the blue Chassis ID TLV, Port ID TLV, and Time To Live TLV must be carried by each LLDPDU, and the remaining TLVs are optional. Each LLDPDU can carry up to 32 TLVs.

TLV

TLV is the unit that makes up LLDPDU, and each TLV represents a piece of information. The TLVs that LLDP can encapsulate include basic TLVs, 802.1 organization-defined TLVs, 802.3 organization-defined TLVs, and LLDP-MED (Link Layer Discovery Protocol Media Endpoint Discovery, Link Layer Discovery Protocol Media Endpoint Discovery) TLVs.

Basic TLV

Basic TLVs are a set of TLVs that are the basis for network device management. 802.1 organization-defined TLVs, 802.3 organization-defined TLVs, and LLDP-MED TLVs are TLVs defined by standards organizations or other organizations to enhance the management of network devices. Need to choose whether to send in LLDPDU.

Among the basic TLVs, there are several TLVs that are mandatory for implementing the LLDP function, that is, they must be published in the LLDPDU, as shown in Table 1.

Table 1 Basic TLV

| TLV name | instruction | Must be published |
|------------|---|-------------------|
| Chassis ID | Bridge MAC address of the sending device | Yes |
| Port ID | Identifies the port of the sender of the LLDPDU.If LLDP-MED TLV is carried in LLDPDU, its content is the MAC address of the p | Yes |

| TLV name | instruction | Must be published |
|---------------------|--|-------------------|
| | ort; otherwise, its content is the name of the port | |
| Time To Live | The survival time of this device information on the neighbor device | Yes |
| End of LLDPDU | The end identifier of the LLDPDU, which is the last TLV of the LLDPDU | no |
| Port Description | Description of the port | no |
| System Name | the name of the device | no |
| System Description | description of the system | no |
| System Capabilities | The main functions of the system and the function items that have been turned on | no |
| Management Address | Management address, as well as the interface number and OID (Object Identifier) corresponding to the address | no |

802.1 Organization-Defined TLV

The content of TLV defined by IEEE 802.1 organization is shown in Table2.

Currently, H3C devices do not support sending Protocol Identity TLV and VID Usage Digest TLV, but can receive these two types of TLVs.

Layer 3 Ethernet interfaces only support Link Aggregation TLVs.

Table2 IEEE 802.1Organization defined TLV

| TLV name | instruction |
|-----------------------------------|--|
| Port VLAN ID (PVID) | Port VLAN ID |
| Port and protocol VLAN ID (PPVID) | Port Protocol VLAN ID |
| VLAN Name | The name of the VLAN to which the port belongs |
| Protocol Identity | The type of protocol supported by the port |
| DCBX | Data Center Bridging Exchange Protocol |
| EVB module | (Not currently supported) Edge Virtual Bridging module, including EVB TLV and DCBP (S-Channel Discovery and Configuration Protocol, S-Channel Discovery and Configuration Protocol) TLV.For the detailed introduction of these two TLVs, please refer to "EVB Configuration Guide" |
| Link Aggregation | Whether the port supports link aggregation and whether link aggregation is enabled |
| Management VID | management VLAN |

| TLV name | instruction |
|---------------------|---|
| VID Usage Digest | Data containing a summary of VLAN ID usage |
| ETS Configuration | Enhanced Transmission Selection configuration |
| ETS Recommendations | Enhanced transfer selection recommendation |
| PFC | Priority-based Flow Control |
| APP | Application Protocol |
| QCN | (Not currently supported) Quantized Congestion Notification |

802.3 Organization-Defined TLV

The content of TLV defined by Table3.

The Power Stateful Control TLV was defined in the IEEE P802.3at D1.0 version, and later versions no longer support this TLV. The H3C device will only send this type of TLV after receiving the Power Stateful Control TLV.

Table3 IEEE 802.3 Organization defined TLV

| TLV name | instruction |
|------------------------------|--|
| MAC/PHY Configuration/Status | The rate and duplex status supported by the port, whether it supports port rate auto-negotiation, whether the auto-negotiation function is enabled, and the current rate and duplex status |
| Link Aggregation | Whether the port supports link aggregation and whether link aggregation is enabled |
| Power Via MDI | The power supply capability of the port, including the type of PoE (Power over Ethernet) (including PSE (Power Sourcing Equipment) and PD (Powered Device)), the remote power supply mode of the PoE port, Whether PSE power supply is supported, whether PSE power supply is enabled, whether the power supply mode is controllable, power supply type, power source, power priority, PD requested power value, and PSE allocated power value |
| Maximum Frame Size | Maximum frame length supported by the port |
| Power Stateful Control | Power status control of ports, including the type of power used by the PSE/PD, the priority of supplying/receiving power, and the power supplied/received |
| Energy-Efficient Ethernet | Energy Efficient Ethernet |

management address

The management address is an address for the network management system to identify and manage network devices. The management address can clearly identify a device, which facilitates the drawing of network topology and facilitates network management. The management address is encapsulated in the Management Address TLV of the LLDP packet and advertised.

LLDP Mode

Under the specified type of LLDP proxy, LLDP has the following four working modes:

- **TxRx:** Both send and receive LLDP packets.
- **Tx:** Only sends and does not receive LLDP packets.
- **Rx:** only receives and does not send LLDP packets.
- **Disable:** Neither sends nor receives LLDP packets.

When the LLDP working mode of the port changes, the port will initialize the protocol state machine. To prevent the port from continuously performing initialization operations due to frequent changes in the working mode of the port, you can configure the port initialization delay time.

Protocol Specification

The protocol specifications related to LLDP are:

- IEEE 802.1AB-2005: Station and Media Access Control Connectivity Discovery.
- IEEE 802.1AB 2009: Station and Media Access Control Connectivity Discovery.
- ANSI/TIA-1057: Link Layer Discovery Protocol for Media Endpoint Devices.
- IEEE Std 802.1Qaz-2011 : Media Access Control (MAC) Bridges and Virtual Bridged Local Area Networks-Amendment 18: Enhanced Transmission Selection for Bandwidth Sharing Between Traffic Classes.

1.2. Configuring

1.2.1. Configuring Switch and Operating Mode

- **Enabling/disabling the LLDP Function Globally**

| | |
|--------------------|--|
| Command | SWITCH(config)# lldp run SWITCH(config)# no lldp run |
| Description | Global configuration mode. Enable/disable LLDP function. required. |

- **Entering LLDP Interface Proxy Configuration Mode**

| | |
|--------------------|--|
| Command | SWITCH(config-if)# lldp -agent SWITCH(lldp-agent)# exit |
| Description | Interface configuration mode. Enter the LLDP interface proxy configuration mode. Optional. |

- **Configuring the Working Mode of an LLDP Interface**

| | |
|--------------------|--|
| Command | SWITCH(lldp-agent)# lldp enable { rxonly txonly txrx } SWITCH(lldp-agent)# lldp disable |
| Description | LLDP interface proxy configuration mode. Configure the working mode of the LLDP interface. |

| | |
|--|-----------|
| | Optional. |
|--|-----------|

1.2.2. Configuring Optional Basic Parameter

- Configuring System Name

| | |
|-------------|--|
| Command | SWITCH(config)# lldp system-name NAME SWITCH(config)# no lldp system-name |
| Description | Global configuration mode. Configure/reset the system name. Optional. |

- Configuring System Descriptor

| | |
|-------------|--|
| Command | SWITCH(config)# lldp system-description LINE SWITCH(config)# no lldp system-description |
| Description | Global configuration mode. Configure /reset system descriptors. Optional. |

- Configuring the Device Locally-assigned

| | |
|-------------|--|
| Command | SWITCH(config)# lldp chassis locally-assigned NAME SWITCH(config)# no lldp chassis locally-assigned |
| Description | Global configuration mode. Configure/reset the device locally-assigned . Optional. |

- Configuring Interface Locally-assigned

| | |
|-------------|--|
| Command | SWITCH(config-if)# lldp locally-assigned NAME SWITCH(config-if)# no lldp locally-assigned |
| Description | Interface configuration mode. Configure/reset the interface locally-assigned . Optional. |

- Configuring Interface Proxy Cable Identification

| | |
|-------------|--|
| Command | SWITCH(config-if)# lldp agt-circuit-id V A L E SWITCH(config-if)# no lldp agt-circuit-id |
| Description | Interface configuration mode. Configuration/reset interface agt-circuit-id can be used as a value for port-id-tlv. Optional. |

- Configuring Interface Port Descriptor

| | |
|---------|---|
| Command | SWITCH(config-if)# lldp port-description LINE |
|---------|---|

| | |
|-------------|---|
| | SWITCH(config-if)# no lldp port-description |
| Description | Interface configuration mode. Configure/reset interface port descriptors. Optional. |

- Configuring the Device ID Type of LLDP Interface

| | |
|-------------|--|
| Command | SWITCH(lldp-agent)# lldp chassis-id-tlv { if-alias if-name ip-address locally-assigned mac-address } SWITCH(lldp-agent)# no lldp chassis-id-tlv |
| Description | LLDP interface proxy configuration mode. Configure the device identification type of the LLDP interface. Optional. |

- Configuring the Management Address Type of LLDP Interface

| | |
|-------------|--|
| Command | SWITCH(lldp-agent)# lldp management-address-tlv { ip-address mac-address } SWITCH(lldp-agent)# no lldp management-address-tlv |
| Description | LLDP interface proxy configuration mode. Configure the management address type of the LLDP interface. Optional. |

- Configuring the Port ID Type of LLDP Interface

| | |
|-------------|---|
| Command | SWITCH(lldp-agent)# lldp port-id-tlv { agt-circuit-id if-alias if-name ip-address locally-assigned mac-address } SWITCH(lldp-agent)# no lldp port-id-tlv |
| Description | LLDP interface proxy configuration mode. Configure the port ID type of the LLDP interface. Optional. |

1.2.3. Configuring Optional State Machine Parameter

- Configuring the MsgTxHold Parameter of an LLDP Interface

| | |
|-------------|---|
| Command | SWITCH(lldp-agent)# lldp msg-tx-hold <1-100> SWITCH(lldp-agent)# no lldp msg-tx-hold |
| Description | LLDP interface proxy configuration mode. This variable is used as a multiplier for msgTxInterval to determine the value of txTTL carried in LLDP frames transmitted by the LLDP proxy. The default msgTxHold is 4. Administrators can change this value to any value in the range 1 to 100. $TTL = msgTxInterval * msgTxHold + 1$. Optional. |

- Configuring the TxFastInit Parameter of the LLDP Interface

| | |
|---------|---|
| Command | SWITCH(lldp-agent)# lldp tx-fast-init <1-8> SWITCH(lldp-agent)# no lldp tx-fast-init |
|---------|---|

| | |
|-------------|---|
| Description | <p>LLDP interface proxy configuration mode.</p> <p>This variable is used as the initial value of the txFast variable. This value determines the number of LLDPDU's transmitted during the fast transmission period. The default value of txFastInit is 4. Administrators can change this value to any value between 1 and 8.</p> <p>Optional.</p> |
|-------------|---|

- Configuring the TxCredit Parameter of the LLDP Interface

| | |
|-------------|--|
| Command | <p>SWITCH(lldp-agent)# lldp tx-max-credit <1-8></p> <p>SWITCH(lldp-agent)# no lldp tx-max-credit</p> |
| Description | <p>LLDP interface proxy configuration mode.</p> <p>Configure the maximum value of txCredit. The default value is 5. Administrators can change this value to any value in the range 1 to 10.</p> <p>Optional.</p> |

- Configuring the msgFastTx Parameter of the LLDP Interface

| | |
|-------------|--|
| Command | <p>SWITCH(lldp-agent)# lldp timer msg-fast-tx <1-3600></p> <p>SWITCH(lldp-agent)# no lldp timer msg-fast-tx</p> |
| Description | <p>LLDP interface proxy configuration mode.</p> <p>This variable defines the time interval of the timer interval between two transfers in a fast transfer period (i.e. txFast is not zero). The default value for msgFastTx is 1; administrators can change this value to any value between 1 and 3600.</p> <p>Optional.</p> |

- Configuring the MsgTxInterval Parameter of the LLDP Interface

| | |
|-------------|---|
| Command | <p>SWITCH(lldp-agent)# lldp timer msg-tx-interval <5-3600></p> <p>SWITCH(lldp-agent)# no lldp timer msg-tx-interval</p> |
| Description | <p>LLDP interface proxy configuration mode.</p> <p>This variable defines the timer interval between normal transfers (i.e. txFast is zero). The default value for msgTxInterval is 30 s; admin can change this value to any value between 5 and 300.</p> <p>Optional.</p> |

- Configuring the ReinitDelay Parameter of an LLDP Interface

| | |
|-------------|--|
| Command | <p>SWITCH(lldp-agent)# lldp timer reinit-delay <1-10></p> <p>SWITCH(lldp-agent)# no lldp timer reinit-delay</p> |
| Description | <p>LLDP interface proxy configuration mode.</p> <p>This parameter represents the amount of delay between when adminStatus becomes "disabled" and when reinitialization is attempted. The default value of reinitDelay is 2 s.</p> <p>Optional.</p> |

1.2.4. Configuring Send Tlv List

- Configuring Tlv Selection for LLDP Interfaces

| | |
|-------------|---|
| Command | SWITCH(lldp-agent)# [no] lldp tlv-select basic-mgmt { management-address port-description system-capabilities system-description system-name} SWITCH(lldp-agent)# [no] lldp tlv-select ieee-8021-org-specific { link-aggr mgmt-vid port-ptcl-vlanid port-vlanid ptcl-identity vid-digest vlan-name } SWITCH(lldp-agent)# [no] lldp tlv-select ieee-802 3 -org-specific { mac-phy max-mtu-size } |
| Description | LLDP interface proxy configuration mode. tlvs can be selected with multiple commands. Optional. Note: When there are many VLAN configurations on the device, the VLAN-related tlv may cause the packet length to exceed the MTU, resulting in packet sending errors. It is necessary to configure not to send this type of tlv. |

1.3. Examples

1.3.1. LLDP Basic Function Configuration Example


Requirements

NMS (Network Management System, network management system) is connected to Switch A, and Switch A is connected to the Terminal device and Switch B respectively.

By configuring the LLDP function on Switch A and Switch B, the NMS can judge the communication status of the link between Switch A and the terminal device, and between Switch A and Switch B.

Network diagram

Figure2 LLDP basic function configuration network diagram



Typical configuration example

Switch A/B:

```
Lldp run
```

1.4. Display Information

- Display the Status of the LLDP Interface

```
#show lldp interface gigabitEthernet0/2
```

Agent Mode : Nearest bridge

Enable (tx/rx): Y/Y

Message fast transmit time:1

Message transmission interval: 30

Reinitialisation delay: 2

MED Enabled:Y

Device Type: NOT_DEFINED

LLDP Agent traffic statistics:

Total frames transmitted: 4608

Total entries aged: 0

Total frames received: 150

Total frames received in error: 0

Total frames discarded: 0

Total discarded TLVs: 0

Total unrecognised TLVs: 0

- Show LLDP Interface Neighbors

```
#show lldp interface gigabitEthernet0/2 neighbor
```

Nearest bridge Neighbors

Interface Name : gigabitEthernet0/2

System Name :

System Description :

Port Description :

TTL: 3601

System Capabilities : Routing

Mandatory TLVs :

CHASSIS ID TYPE :

Chassis MAC Address: 000e.c6c1.3841

PORT ID TYPE :

Port MAC Address: 000e.c6c1.3841

8021 ORIGIN SPECIFIC TLV

Port Vlan id :0

PP Vlan id :0

Remote Protocols Advertised :

Remote VID Usage Digest : 0

Remote Management Vlan : 0

Link Aggregation Status : Disabled

Link Aggregation Port ID : 0

8023 ORIGIN SPECIFIC TLV

AutoNego Support : Supported Enabled

AutoNego Capability : 1

Operational MAU Type : 0

Max Frame Size : 0

MED Capabilities : Capabilities
MED Capabilities Dev Type : End Point Class-1
MED Application Type : Reserved
MED Vlan id : 0
MED Tag/Untag: Untagged
MED L2 Priority : 0
MED DSCP Val : 0

13. Configuring L3

13.1. Overview of L3

L3 functions include :Layer 3 port management, ARP management and Routing management.

- Layer 3 Port Management:

Layer 3 ports are generally divided into routing ports (physical ports switched to Layer 3 ports) or SVI ports (Switch Virtual Interface, corresponding to a VLAN).

The SVI port is a logical interface, which is constructed on top of all the member ports included in the corresponding VLAN, Unlike the routing port, the packets that are forwarded through the SVI at Layer 3 will first pass through Layer 2 (such as VLAN filtering, address learning, etc.) and then go through three layers, and then go through three layers and then two layers when outputting (such as VLAN output rules).

At the network layer, routing devices use IP addresses to complete packet forwarding. (Protocol specification: RFC 1918: Address Allocation for Private Internets, RFC 1166: Internet Numbers).

Layer 3 port management includes IP address maintenance for Layer 3 ports.

An IP address is composed of 32-bit binary. For the convenience of writing and description, it is generally expressed in dotted decimal. When expressed in dotted decimal, it is divided into four groups, each with 8 digits, ranging from 0 to 255. The groups are separated by ".", for example, "192.168.1.1" is the IP address expressed in decimal.

The IP address, as the name suggests, is naturally the interconnection address of the IP layer protocol. A 32-bit IP address consists of two parts:

- 1) the network address part, which indicates which network it is;
- 2) the host address part, which indicates which host in the network.

The network address part and the host address part of the IP address are divided by the network mask. The network mask is also a 32-bit value, consisting of several bits "1" in the front and several bits "0" in the back. The IP address is related to the network.

The mask and the obtained is the corresponding part of the network address. Likewise, the netmask can also be directly represented by the mask length.

For example, "192.168.1.1 255.255.255.0" and "192.168.1.1/24" represent the same IP address.

The device supports the configuration of the second IP address, that is, a Layer 3 port can be configured with at most one IP address.

When a Layer 3 port is configured with an IP address, a network segment is determined.

Different Layer 3 ports of the same device must belong to different network segments, and IP addresses configured with different Layer 3 ports must belong to different network segments.

The Layer 3 port represented by the SVI, and the corresponding VLAN is used as the unique identifier of the Layer 3 port.

After the different Layer 3 ports of the device are divided into different network segments, the forwarding between these different network segments (such as VLAN1 and VLAN2) is called "Layer 3 forwarding" (across network segments, or across

different VLANs).

- **ARP Management:**

In a local area network, each IP network device has two addresses:

- 1) The local address, since it is included in the frame header of the data link layer, should be more precisely the data link layer address, but in fact the local address is processed by the MAC sublayer in the data link layer, Therefore, it is customarily called a MAC address, and a MAC address represents an IP network device on a local area network.
- 2) The network address represents the IP network device on the Internet, and it also indicates the network to which the device belongs.

To communicate between two IP devices on the LAN, they must know each other's 48-bit MAC address. The process of learning the MAC address from the IP address is called address resolution.

There are two types of address resolution methods:

- 1) Address Resolution Protocol (ARP).
- 2) Proxy Address Resolution Protocol (Proxy ARP).

About ARP and Proxy ARP, they are described in RFC 826 and RFC 1027 documents respectively.

ARP (Address Resolution Protocol) is used to bind a MAC address and an IP address. Taking the IP address as an input, ARP can know its associated MAC address. Once the MAC address is known, the IP address to MAC address correspondence is stored in the device's ARP cache. With the MAC address, the IP device can encapsulate the link layer frame, and then send the data frame to the LAN. The encapsulation of IP and ARP on Ethernet is Ethernet II type.

ARP entries are divided into two categories: dynamic entries generated by the ARP protocol and static entries derived from static configuration. Dynamic ARP entries are formed by triggering the opening of IP packets. The opening process is an ARP request/response process. If the ARP entries formed after opening are unreachable, they will automatically age out. Static ARP entries do not need to be opened and will not age out.

- **Routing Management:**

Routing management is responsible for managing routing tables, integrate routes issued by various routing protocols to select the optimal route.

According to different sources, the routing table is usually divided into the following three categories:

- **Directly connected route:** The route discovered by the link layer protocol is also called the interface route. A direct route is automatically generated when an IP address is configured on a Layer 3 port, and the route prefix is the network directly connected to the Layer 3 port.
- **Static route:** manually configured by the network administrator.
- **Dynamic routes:** routes discovered by dynamic routing protocols (such as RIP, OSPF).

A routing table entry consists of two parts:

- **Prefix:** It is represented by an IP address and network mask (or mask length), which refers to the destination network or host determined by the routing table entry (when the mask length is 32, it means the host).
- **Direct connection or next hop:** Direct connection means that the destination network or host belongs to the directly connected network, and the direct connection route belongs to this situation. When configuring a static route, specifying a Layer 3 port instead of an IP address will also generate such a routing table item; the next hop is represented by an IP host address, indicating that to reach the destination network or host, it needs to be forwarded to the IP network device indicated by the IP address.

When forwarding IP packets according to the routing table entry, if the routing table entry specifies the next hop, when the link layer encapsulates the ARP query, the IP of the next hop is used, that is, the destination MAC address of the link layer

encapsulation is the next hop. The destination MAC address of the hop. If the routing table entry is directly connected, the destination IP address of the packet is directly used for ARP query, that is, the destination MAC address encapsulated at the link layer is the final destination MAC address of the packet. Either way, if the ARP query fails, the route will be opened (a dynamic ARP entry will be generated). If the connection cannot be made, the IP packet cannot be forwarded and will be discarded.

There may be an inclusion relationship between routing table entries (depending on the length of the mask), so the route lookup process satisfies the LPM (Longest Prefix Match). That is, when IP packets are forwarded for route lookup, if multiple routing entries are hit at the same time, the routing entry with the longest prefix mask length is selected.

13.2. Configuring

- Configuring SVI Port IP/IPv6 Address

| | |
|-------------|--|
| Command | <p>Configure SVI Port IP:</p> <pre>SWITCH(config)#int vlan10 SWITCH(config-if)#ip address IPADDR/MASKLEN [secondary] SWITCH(config-if)#ipv6 address IP(X:X::X:X/M)</pre> <p>Or</p> <pre>SWITCH(config-if)#ip address IPADDR MASK [secondary]</pre> <p>Delete SVI Port IP:</p> <pre>SWITCH(config)#int vlan10 SWITCH(config-if)#no ip address IPADDR/MASKLEN [secondary] SWITCH(config-if)#no ipv6 address IP(X:X::X:X/M)</pre> <p>Or</p> <pre>SWITCH(config-if)#no ip address IPADDR MASK [secondary]</pre> <p>Show the IP/IPv6 address of the Layer 3 port:</p> <pre>SWITCH#show ip interface brief SWITCH#show ipv6 interface brief</pre> |
| Description | <p>Configure in the interface mode of the SVI.</p> <p>When a VLAN is created, the SVI is automatically created, and when the VLAN is deleted, the SVI is automatically deleted. int vlanXX is to enter the interface mode of the SVI. Therefore, when the SVI does not exist (the corresponding VLAN does not exist), entering the interface mode of the SVI will fail. At the same time, when the SVI is deleted, the IP address configured on it will be automatically cleared.</p> <p>Layer 3 ports support IP/IPv6 address configuration update, which has the same effect as deleting and reconfiguring. The IP addresses configured on different Layer 3 ports must belong to different network segments.</p> <p>SVI supports the configuration of the second ip. When configuring the second ip, you need to configure the primary ip first. When deleting the primary ip, if the second ip already exists, you need to delete all the second ip before deleting the primary ip, otherwise it cannot be deleted.</p> <p>Note: After this command is configured, the system will clear the management IP configuration (refer to: Configuring Management IP), and use the Layer 3 port IP address as the device management IP instead.</p> |

- Configuring Routing Port IP/IPv6 Address

| | |
|-------------|---|
| Command | <p>Configure Routing Port IP:</p> <pre>SWITCH(config)#interface gigabitEthernet0/1 SWITCH(config-if)#no switchport SWITCH(config-if)#ip address IP(A.B.C.D/M) [secondary] SWITCH(config-if)#ipv6 address IP(X:X::X:X/M)</pre> <p>Or</p> <pre>SWITCH(config-if)#ip address IP(A.B.C.D) MASK(A.B.C.D) [secondary]</pre> <p>Delete Routing Port IP:</p> <pre>SWITCH(config)# interface gigabitEthernet0/1 SWITCH(config-if)#no ip address IP(A.B.C.D/M) SWITCH(config-if)#no ipv6 address IP(X:X::X:X/M)</pre> <p>Or</p> <pre>SWITCH(config-if)#no ip address IP(A.B.C.D) MASK(A.B.C.D) SWITCH(config-if)#switchport</pre> |
| Description | <p>Configure in interface mode.</p> <p>Before configuring the routing port IP, since the default attribute of the interface is the Layer 2 port attribute, you need to use the no switchport command to switch the port from the Layer 2 port attribute to the Layer 3 routing port attribute, and then use the ip address command to configure the routing port attribute. IP configuration, otherwise, switch the routing port to the Layer 2 port attribute, use the switchport command.</p> <p>Layer 3 ports support IP address configuration update, which has the same effect as deleting and reconfiguring. The IP addresses configured on different Layer 3 ports must belong to different network segments.</p> <p>The Layer 3 interface supports the configuration of the second ip. When configuring the second ip, you need to configure the primary ip first.</p> <p>When deleting the primary ip, if the second ip already exists, you need to delete all the second ip before deleting the primary ip, otherwise it cannot be deleted.</p> |

- Configuring Static ARP Entries

| | |
|-------------|---|
| Command | <pre>SWITCH(config)#arp IPADDR MACADD SWITCH(config)#no arp IPADDR</pre> |
| Description | <p>Configure in global configuration mode.</p> <p>The IP address configured with static ARP must belong to the directly connected network segment, otherwise the configuration fails.</p> <p>Static ARP has a higher priority than dynamic ARP. When the two conflict, static ARP takes effect.</p> <p>When the IP address of the Layer 3 port is deleted or the Layer 3 port is deleted, if the IP address of the static ARP belongs to the directly connected network segment of the Layer 3 port, the static ARP will be invalid (you can see that the entry does not exist through show arp, but show run, you can see that the configuration is still there); Similarly, when a Layer 3 port is configured with an IP address, the ARP entry of the directly connected network segment whose IP address belongs to the Layer 3 port will change from an invalid state to a valid state. (You can see the existence of ARP entries through show arp).</p> |

- Clearing ARP Cache

| | |
|-------------|--|
| Command | SWITCH#clear arp-cache |
| Description | Clear the ARP cache in privileged mode. This Command only clears dynamic ARP entries, and static ARP entries will not be cleared. |

- Configuring Static IPv6 Neighbor Entries

| | |
|-------------|--|
| Command | SWITCH(config)# ipv6 neighbor <i>IPv6(X:X::X:X) IFNAME MAC(XXXX.XXXX.XXXX)</i> SWITCH(config)#no ipv6 neighbor <i>IPv6(X:X::X:X) IFNAME</i> |
| Description | Configure in global configuration mode. The IPv6 address configured with the static ipv6 neighbor must belong to the directly connected network segment, otherwise the configuration fails. The static ipv6 neighbor has a higher priority than the dynamic ipv6 neighbor. When the two conflict, the static ipv6 neighbor takes effect. When the IPv6 address of the Layer 3 port is deleted or the Layer 3 port is deleted, if the IPv6 address of the static ipv6 neighbor belongs to the directly connected network segment of the Layer 3 port, the static ipv6 neighbor will be invalid (you can see that the table does not exist through show ipv6 neighbors Item, but show run can see that the configuration is still there); Similarly, when a Layer 3 port is configured with an IPv6 address, the ipv6 neighbor entry whose IPv6 address belongs to the directly connected network segment of the Layer 3 port will change from an invalid state to valid state. (You can see that the neighbors table entry exists by show ipv6 neighbors). |

- Configuring Static Routes

| | |
|-------------|---|
| Command | SWITCH(config)#ip route {IPADDR/MASKLEN} IPADDR MASK {NH_IPADDR IFNAME} SWITCH(config)#no ip route {IPADDR/MASKLEN} IPADDR MASK {NH_IPADDR IFNAME} SWITCH(config)#ipv6 route [<i>IPv6(X:X::X:X/M)</i>] [<i>NH_IPv6(X:X::X:X)</i>] IFNAME] SWITCH(config)#no ip v6 route [<i>IPv6(X:X::X:X/M)</i>] [<i>IPv6(X:X::X:X)</i>] IFNAME] |
| Description | Configure in global configuration mode. Recursive routing is not supported (the configured next-hop IP must belong to the directly connected network segment); The route prefix cannot belong to the directly connected network segment (that is, the directly connected route is automatically generated and cannot be statically configured). When a Layer 3 port is configured with an IP address, if the prefix of a static routing entry belongs to the directly connected network segment of the Layer 3 port, the static route will be automatically deleted and a LOG prompt will be displayed; When the IP address of a Layer 3 port is deleted or the Layer 3 port is deleted, if the next hop IP of a static routing entry belongs to the directly connected network segment of the Layer 3 port, the static route is automatically deleted and a LOG prompt is displayed. |


- Configuring ECMP

If there are redundant links in the network environment, that is, there are multiple next hops for the route to the same destination address. On devices that support ECMP technology, multiple next hops can work at the same time, so that redundant links can be fully utilized, and when a link failure occurs on a redundant link, traffic can be switched to other redundant links. Network reliability and stability.

ECMP (Equal-Cost Multipath Routing), this technology enables the device to use multiple next-hop links of the corresponding route concurrently, and balance the traffic among the multiple next-hop links according to the set balance factor distribution; and supports fast switchover of faulty links.

13.3. Examples

Case 1: Weak Layer 3 Gateway



As a weak Layer 3 gateway, the Switch reduces the ARP burden for the real gateway.

- **Configure PC:**

Configure the IP addresses of PC1, PC2 and PC3 as shown in the figure, and specify the gateway at the same time. For example, the gateway of PC1 and P2 is 192.168.1.1.

- **Configure SWITCH:**


- Configure the Layer 3 port and IP address: (Assume that the interface connecting PC1-PC4 is gigabitEthernet0/1-4, and the uplink interface is gigabitEthernet0/17)

```
SWITCH(config)#vlan 2-3,100
SWITCH(config)#interface gigabitEthernet0/1-2
SWITCH(config-if)#switch access vlan 2
SWITCH(config)#interface gigabitEthernet0/3-4
SWITCH(config-if)#switch access vlan 3
SWITCH(config)#interface gigabitEthernet0/17
SWITCH(config-if)#switch access vlan 100
SWITCH(config)#int vlan2
SWITCH(config-if)#ip address 192.168.1.1/24
SWITCH(config)#int vlan3
SWITCH(config-if)#ip address 192.168.2.1/24
SWITCH(config)#int vlan100
SWITCH(config-if)#ip address 192.168.100.2/24
```

- Configure a static route (default route):

```
SWITCH(config-if)#ip route 0.0.0.0/0 192.168.100.1
```

Case 2: Intranet Layer 3 Interconnection



In the network environment shown above, PC1, PC2 and PC3 are interconnected through S1, S2 and S3 respectively.

- **Configure PC**

Configure the IP addresses of PC1, PC2 and PC3 as shown in the figure, and specify the gateway at the same time. For example, the gateway of PC1 is 192.168.1.1.

- **Configure S1**

- Configure the Layer 3 port and IP address:

```
SWITCH(config)#vlan 2-4
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#switch access vlan 2
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#switch access vlan 3
SWITCH(config)#interface gigabitEthernet0/3
SWITCH(config-if)#switch access vlan 4
SWITCH(config)#int vlan2
SWITCH(config-if)#ip address 192.168.1.1/24
SWITCH(config)#int vlan3
SWITCH(config-if)#ip address 192.168.12.1/24
SWITCH(config)#int vlan4
SWITCH(config-if)#ip address 192.168.13.1/24
```

- Configure a static route:

```
SWITCH(config)#ip route 192.168.2.0/24 192.168.12.2
SWITCH(config)#ip route 192.168.3.0/24 192.168.11.3
```

- S2 and S3 are configured similarly to S1.

13.4. Display Information

- **Show L3 Interface**

```
SWITCH#show ip interface brief
```

| Interface | IP-Address | Admin-Status | Link-Status |
|-----------|----------------|--------------|-------------|
| GiE0/3 | 10.10.20.1 | up | down |
| vlan10 | 192.168.65.166 | up | up |

SWITCH#show ipv6 interface brief

| Interface | IPv6-Address | Admin-Status |
|-----------|--------------------|--------------|
| vlan10 | 2001:db8:0:f104::1 | [up/up] |
| vlan1000 | unassigned | [up/up] |

- Show ARP Entries

SWITCH#show arp

| Address | HWaddress | Interface | Type |
|---------------|-------------------|-----------|---------|
| 192.168.1.238 | 00:00:00:00:04:86 | vlan2 | Static |
| 192.168.2.46 | 00:00:00:00:05:45 | vlan3 | Static |
| 192.168.3.110 | 00:00:00:00:08:59 | vlan4 | Static |
| 192.168.0.12 | 00:00:00:00:00:09 | vlan1 | Static |
| 192.168.0.1 | 00:0e:c6:d8:c7:f7 | vlan1 | Dynamic |
| 10.100.2.2 | 00:01:a0:00:10:11 | GiE0/2 | Dynamic |

- Show Ipv6 Neighbor Entries

SWITCH #show ipv6 neighbors

| IPv6 Address | MAC Address | Interface | Type |
|-------------------|----------------|-----------|---------|
| ff02::16 | 3333.0000.0016 | vlan10 | dynamic |
| ff02::1:ff00:1 | 3333.ff00.0001 | vlan10 | dynamic |
| ff02::1:ff40:251a | 3333.ff40.251a | vlan10 | dynamic |

- Show Routing Table Entries

SWITCH#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

Gateway of last resort is 192.168.1.3 to network 0.0.0.0

```
S*    0.0.0.0/0 [1/0] via 192.168.1.3, vlan2
S     192.168.0.0/16 [1/0] via 192.168.0.10, vlan1
C     192.168.0.0/24 is directly connected, vlan1
C     192.168.1.0/24 is directly connected, vlan2
C     192.168.2.0/24 is directly connected, vlan3
C     192.168.3.0/24 is directly connected, vlan4
C     10.100.2.0/30 is directly connected, gigabitEthernet0/2
```

SWITCH #show ipv6 route

IPv6 Routing Table

Codes: K - kernel route, C - connected, S - static, R - RIP, O - OSPF,

IA - OSPF inter area, E1 - OSPF external type 1,

E2 - OSPF external type 2, N1 - OSPF NSSA external type 1,

N2 - OSPF NSSA external type 2, I - IS-IS, B - BGP

Timers: Uptime

IP Route Table for VRF "default"

C 2001:db8:0:f104::/64 via ::, vlan10, 00:00:56

14. Configuring OSPFv2

14.1. Overview of OSPFv2

OSPF (Open Shortest Path First) is a link-state-based interior gateway routing protocol developed by the IETF OSPF working group.

OSPF is a routing protocol specially developed for IP. It runs directly at the IP layer. The protocol number is 89. It uses multicast to exchange OSPF packets. The multicast addresses are 224.0.0.5 (all OSPF devices) and 224.0.0.6 (specified devices). It is applied inside AS (Autonomous System, autonomous system). A group of devices running the OSPF routing protocol constitute the autonomous domain system of the OSPF routing domain.

An autonomous domain system refers to all the devices controlled and managed by an organization. Only one IGP routing protocol runs in the autonomous domain system. The BGP routing protocol is usually used to exchange routing information between autonomous domain systems. Different autonomous domain systems can choose the same IGP routing protocol. If they want to connect to the Internet, each autonomous domain system needs to apply for the autonomous domain system number from the relevant organization.

When the OSPF routing domain is large, a hierarchical structure is generally adopted, that is, the OSPF routing domain is divided into several areas, and the areas are interconnected through a backbone area, and each non-backbone area needs to be directly connected to the backbone area.

In an OSPF routing domain, there are three device roles depending on where the device is deployed:

- **Device within a zone:** All interface networks of the device belong to a zone.
- **ABR Device:** Area Border Routers. The interface network of the device belongs to at least two areas, one of which must be the backbone area.
- **ASBR Device:** Autonomous System Boundary Routers, is the only way for the OSPF routing domain to exchange routes with external routing domains.

The link state algorithm is a completely different algorithm from the Huffman vector algorithm (distance vector algorithm). The traditional routing protocol using the Huffman vector algorithm is RIP, while the OSPF routing protocol is a typical implementation of the link state algorithm. Compared with the RIP routing protocol, in addition to the algorithm difference, OSPF also introduces new concepts such as routing update authentication, VLSMs (variable-length subnet masks), and route aggregation. The RIP protocol has two fatal weaknesses: slow convergence speed and limited network size (the maximum number of hops does not exceed 16). OSPF overcomes the weaknesses of RIP and can be used in medium-to-large and complex network environments.

The OSPF routing protocol uses the link state algorithm to establish and calculate the shortest path to each target network. The algorithm itself is relatively complex. The following briefly describes the overall process of the link state algorithm:

- In the initialization phase, the device will generate a link status advertisement, which contains all the link status of the device;
- All devices exchange link status information through multicast. When each device receives the link status update message, it will copy a copy to the local database, and then spread it to other devices;
- When each device has a complete link state database, the device applies the Dijkstra algorithm to calculate the shortest path tree for all target networks. The result includes: target network, next hop address, and cost, which is a key part of the IP routing table.

If there is no link cost, network addition or deletion changes, OSPF will be very quiet. If there is any change in the network, OSPF will advertise through the link state, but only the changed link state will be advertised, and the devices involved in the change will re-run the Dijkstra algorithm, to generate a new shortest path tree.

Devices in an OSPF autonomous domain have two special roles:

- DR: Designated router.
- BDR: Backup the designated router.

In an OSPF network, only the DR device advertises the link status of the network, and all other devices maintain the neighbor relationship, but all devices only maintain the adjacency relationship with the DR/BDR, that is, the devices other than the DR/BDR only communicate with the DR /BDR devices exchange link state data packets, and DR summarizes and calculates them and then advertises them to other devices. OSPF protocol uses this mechanism to ensure that the link state data of all devices in the network are consistent.

The DR is elected by comparing the interface priorities. The device with the highest priority is elected as the DR device, and the device whose priority is set to 0 is the device that gives up the election qualification. If OSPF neighbors do not receive DR hello packets within a certain period of time, they will consider that the DR is down and will initiate a new round of DR election. This is the only condition for DR election. The device's dynamic priority modification does not take effect immediately, and only takes effect when a new round of election is triggered.

14.2. Configuring

14.2.1. Creating an OSPF Process

| | |
|-------------|--|
| Command | <code>SWITCH(config)#router ospf <i>process-id</i></code> <code>SWITCH(config-router)#router-id <i>router-id</i></code> <code>SWITCH(config-router)# network <i>IP(A.B.C.D) MASK(A.B.C.D) area area-id</i></code> |
| Description | <p>To run the OSPF routing protocol, you need to create an OSPF routing process and associate the corresponding network with the OSPF routing process.</p> <p><code>router ospf</code>: is to create an OSPF routing process. The <code>process-id</code> is the instance number of the OSPF routing process. If it is not configured, it means process instance 1.</p> <p><code>router-id</code>: is to set the ID of the routing device, expressed in the form of IP address. Each OSPF process uses a different Router ID to distinguish.</p> <p><code>network</code>: indicates the routing information of the associated network advertised by OSPFCommand externally, and also indicates that the protocol advertisement and routing information update are performed only on the interface corresponding to the associated network.</p> <p>IP and MASK together form the address range.</p> <p><code>area-id</code>: is the OSPF area identifier, which is always associated with an IP address range. Usually, for the convenience of management, the subnet mask is used as the OSPF area identifier.</p> |

14.2.2. Configuring Interface Network Type

| | |
|-------------|--|
| Command | <code>SWITCH(config-if)#ip ospf network {broadcast non-broadcast point-to-multipoint [non-broadcast] point-to-point}</code> |
| Description | <p><code>broadcast</code>: indicates the broadcast type. It sends OSPF packets in multicast mode, can automatically discover neighbors, and elect DR (Designated Router) and BDR (Backup Designated Router).</p> <p><code>non-broadcast</code>: means sending OSPF packets in unicast mode. In this type, you need to manually specify the neighbor address and elect the DR and BDR. The devices are fully meshed, and the interconnected devices can communicate directly.</p> <p><code>point-to-multipoint</code>: This type does not require a full mesh connection and can be regarded as multiple P2P links, so multiple host routes will be generated. This type does not perform DR/BDR elections, and metric values can be set for each neighbor.</p> |

| | |
|--|--|
| | <p>without non-broadcast: Send OSPF packets in multicast mode to automatically discover neighbors.</p> <p>with non-broadcast: To send OSPF packets in unicast mode, you need to manually specify neighbors.</p> <p>point-to-point: indicates a point-to-point connection, requiring interfaces to be interconnected in a 1-to-1 mode, sending OSPF packets in multicast mode, and automatically discovering neighbors without DR/BDR election.</p> |
|--|--|

| | |
|-------------|--|
| Command | SWITCH(config-if)#ip ospf priority <i>priority</i> |
| Description | priority: is used to specify the priority of the interface. The larger the value, the higher the priority. The default is 1. |

14.2.3. Configuring Specify Neighbor

| | |
|-------------|--|
| Command | SWITCH(config-router)#neighbor ip-address [cost cost-value] [priority <i>priority-value</i>] [poll-interval <i>seconds</i>] |
| Description | <p>ip-address: indicates the ip address of the neighbor.</p> <p>cost: represents the metric value of the interface to the neighbor. Only valid when the interface type is point-to-multipoint.</p> <p>priority: indicates the priority of the neighbor. The larger the value, the higher the priority. The default is 0. Valid when the interface type is non-broadcast.</p> <p>poll-interval: indicates the interval for sending hello packets to a neighbor in the down state. The default value is 120 seconds. Valid when the interface type is non-broadcast.</p> |

14.2.4. Configuring Protocol Control

- Configuring the Hello Packet Interval

| | |
|-------------|---|
| Command | SWITCH(config-if)#ip ospf hello-interval <i>seconds</i> |
| Description | hello-interval: is used to set the interval for sending hello packets on the interface. The value of the two ends of the neighbor must be the same. |

- Configuring the Dead Judgment Interval

| | |
|-------------|---|
| Command | SWITCH(config-if)#ip ospf dead-interval <i>seconds</i> |
| Description | dead-interval: is used to set the time interval for determining the death of a neighbor on the interface. The values on both ends of the neighbor must be the same. |

- Configuring OSPF Advertise MTU

| | |
|-------------|--|
| Command | SWITCH(config-if)#ip ospf mtu <i>mtu-value</i> |
| Description | mtu: is used to set the mtu value of the interface advertised by OSPF. |

- Configuring Ignore Mtu Verification

| | |
|---------|--------------------------------------|
| Command | SWITCH(config-if)#ip ospf mtu-ignore |
|---------|--------------------------------------|

| | |
|-------------|--|
| Description | mtu-ignore: is used to disable the MTU check. The OSPF protocol will check the MTU of the neighbor interface when receiving the database description packet. If the MTU of the interface indicated in the receiving database description packet is greater than the MTU of the receiving interface, the adjacency relationship cannot be established. In this case, except for modifying the mtu value In addition, you can also use this configuration to turn off mtu verification to solve the problem. |
|-------------|--|

- Configuring Disabling LSA

| | |
|-------------|---|
| Command | SWITCH(config-if)#ip ospf database-filter all out |
| Description | This command is used to prohibit the specified interface from sending LSA, that is, the outbound direction of the specified port will not be propagated by OSPF active routing information, but the inbound direction will not be affected. |

- Configuring the Delay in Sending Lsu Packets

The LSU packet contains the Age field of LSAs (link state description), which is incremented before the LSU packet is sent. When the Age reaches 3600, the Lsu packet will be retransmitted or requested to be retransmitted. If it is not refreshed in time, the expired LSA will be deleted from the link state database. For low-speed lines, due to the large delay in interface transmission and line propagation, the Age field needs to be incremented faster. In this case, the Lsu packet transmission delay needs to be increased, and the Age field should be increased in increments to trigger retransmission.

| | |
|-------------|---|
| Command | SWITCH(config-if)#ip ospf transmit-delay <i>seconds</i> |
| Description | transmit-delay: is used to set the delay of Lsu packets on the interface, in seconds. |

- Configuring the Retransmission Interval of Lsu Packets

After the device sends an Lsu packet, the Lsu packet may not be delivered due to various reasons or may not receive an acknowledgment response from the other party. In this case, the Lsu packet needs to be retransmitted. Set the retransmission interval by configuring the Lsu packet retransmission interval. transmission time.

| | |
|-------------|--|
| Command | SWITCH(config-if)#ip ospf retransmit-interval <i>seconds</i> |
| Description | retransmit-interval: is used to set the retransmission interval of Lsu packets on the interface, in seconds. The time needs to be greater than the round-trip transmission delay of data packets between neighbors. |

- Configuring SPF Refresh Delay

| | |
|-------------|--|
| Command | SWITCH(config-router)#timers spf spf-delay <i>spf-holdtime</i> |
| Description | spf-delay: indicates the delay time from the change of network topology to the start of SPF calculation, which is used to set the sensitivity of SPF calculation to the perception of network topology changes. spf-holdtime: indicates the minimum time interval from the first trigger of SPF calculation to the second trigger of SPF calculation. |

Instruction:

If link flapping occurs only occasionally, setting the spf-delay and spf-holdtime values to a small value can help speed up the OSPF convergence; setting a high value to prevent rapid link flapping and large consumption of CPU resources.

14.2.5. Configuring Passive interface

Passive interface configuration can be used to prevent the routing information of the device from being learned by other devices. It can be set based on the whole machine or the passive interface and address of the specified interface device. Passive interfaces/passive addresses cannot establish neighbors and cannot exchange OSPF packets, but the routing information of passive addresses can be advertised through non-passive addresses and learned by neighbors.

| | |
|-------------|--|
| Command | SWITCH(config-router)#passive-interface default SWITCH(config-router)#passive-interface <i>interface-name</i> SWITCH(config-router)#passive-interface <i>interface-name ip-address</i> SWITCH(config-router)#no passive-interface <i>interface-name</i> |
| Description | default: means that all interfaces are set as passive interfaces. interface-name: indicates that the specified interface is configured as a passive interface. ip-address: means to configure a passive address. no: means to delete the passive interface. |

14.2.6. Configuring Default Route Advertisement

| | |
|-------------|--|
| Command | SWITCH(config-router)#default-information originate [always] [metric <i>metric</i>] [metric-type <i>type</i>] [route-map <i>map-name</i>] |
| Description | always: means that OSPF will unconditionally generate a default route regardless of whether there is a default route locally. metric: indicates the metric value of the default route. metric-type: indicates the type of the default route. There are two types of external routes in OSPF: the external routes of type 1 have different metric values on different routing devices; the external routes of type 2 have the same metric value on all routing devices. map-name: indicates the map associated with route-map. |

Instruction:

After the default-information originate command is configured, the device will automatically become an ASBR.

The ABR in the STUB area will automatically advertise the default route to the STUB area.

The ABR in the NSSA area will automatically advertise the default route to the NSSA area.

14.2.7. Configuring Route Redistribution

| | |
|-------------|---|
| Command | SWITCH(config-router)# redistribute {bgp connected isis [area-tag] ospf process-id rip static} [metric <i>value</i>] [metric-type {1 2}] [route-map <i>map-name</i>] [subnets] [tag <i>value</i>] |
| Description | This command is used to configure the import of external routes (including other OSPF processes/static routes/routes of other routing protocols) to the OSPF process on the ASBR. |

14.2.8. Configuring Route Aggregation

- Configuring Inter-Area Route Aggregation

| | |
|-------------|--|
| Command | SWITCH(config-router)#area area-id range <i>ip-address/mask</i> [advertise not-advertise] |
| Description | area-id: indicates the OSPF area id of route aggregation. ip-address and mask: indicate the network segment IP and mask of the aggregation route. |

| | |
|--|---|
| | advertise and not-advertise: indicate whether the aggregation route needs to be advertised. |
|--|---|

Instruction:

This command is only valid on ABR devices. The function is to merge and aggregate multiple routes in the area into one route and then advertise it to other areas. Since the aggregation occurs only on the ABR device, the routes inside the area see specific routing information, but other devices outside the area can only see the aggregated route. Multiple area aggregation routes can be defined at the same time. Route aggregation can simplify the routing of the entire routing domain.

- **Configuring External Route Aggregation**

| | |
|-------------|---|
| Command | SWITCH(config-router)#summary-address <i>ip-address mask</i> [not-advertise tag <i>tag-value</i>] |
| Description | <p>area-id: indicates the OSPF area id of route aggregation.</p> <p>ip-address and mask: indicate the network segment IP and mask of the aggregation route.</p> <p>not-advertise: means not to advertise the aggregated route, and not using this parameter means to advertise.</p> <p>tag-value: indicates the tag value of the route.</p> |

Instruction:

The routes advertised to the OSPF routing process by other routing processes are advertised to OSPF in the form of external link states. If the injected routes are in a continuous address space, the AS domain convenient device routing device can aggregate multiple routes in the continuous address space. It can be advertised as a route, which can reduce the size of the routing table of the routing device in the domain.

When summary-address is configured on the ABR in the NSSA domain, only redistributed routes and LSA type 7 to type 5 routes are aggregated. When the summary-address is configured on the ASBR, only the redistributed routes are aggregated.

The difference between the summary-address and the area range is that the area range aggregates the routes within the OSPF area, and the summary-address aggregates the routes outside the OSPF area.

14.2.9. Configuring Shortest Path

- **Configuring the Metric For the Outbound Direction of an Interface**

There are three ways to configure the metric value in the outbound direction of an interface:

- One is to configure the reference bandwidth and use the ratio of the automatically calculated reference bandwidth to the interface bandwidth as the metric for the outbound direction of the interface. Assume that the interface bandwidth is 100Mbps, and we configure the reference bandwidth to be 1000Mbps, then the default cost value of the interface is $1000/100=10$.

| | |
|-------------|---|
| Command | SWITCH(config-router)#auto-cost reference-bandwidth <i>ref-bw</i> |
| Description | ref-bw represents the reference bandwidth. |

- The other is to directly configure the metric value on the interface based on elements such as link bandwidth and delay.

| | |
|-------------|--|
| Command | SWITCH(config-if)#ip ospf cost <i>cost-value</i> |
| Description | cost-value represents the metric value. |

- For point-to-multipoint interfaces, you can configure metrics based on neighbors in router mode.

| | |
|-------------|---|
| Command | SWITCH(config-router)#neighbor ip-address [cost <i>cost-value</i>] |
| Description | cost-value represents the metric value. |

- Configuring the Default Route Metric in the STUB/NSSA Area

The default route metric sent by the ABR device to the STUB/NSSA area is 1 by default, and the metric can be specified by configuration.

| | |
|-------------|--|
| Command | SWITCH(config-router)#area <i>area-id</i> default-cost <i>cost-value</i> |
| Description | area-id indicates the OSPF domain id. cost-value represents the metric value. |

- Configuring the Default Metric for Republished Routes

The default metric value of the BGP route republished by the ASBR device is 1, and the default metric value of other republished routes is 20. The metric value can be specified through configuration, but it needs to be used in conjunction with redistributeCommand.

| | |
|-------------|--|
| Command | SWITCH(config-router)#default-metric <i>metric-value</i> |
| Description | cost-value represents the metric value. |

- Configuring the Route Administrative Distance Value

The route administrative distance refers to the reliability of the route source. It is a value between 0 and 255. The larger the data, the lower the reliability. When selecting a route, OSPF will preferentially select a route with a small administrative distance, which means high reliability routing. The default value of the OSPF administrative distance is 110.

| | |
|-------------|--|
| Command | SWITCH(config-router)#distance { <i>distance</i> ospf {intra-area distance inter-area distance external <i>distance</i> }} |
| Description | intra-area indicates intra-area routing. inter-area indicates inter-area routing. external represents an external route. distance represents a measure. |

14.2.10. Configuring Protocol Authentication

- Configuring Interface Authentication

| | |
|-------------|--|
| Command | SWITCH(config-if)# ip ospf authentication [message-digest null] |
| Description | authentication: indicates that authentication is enabled. authentication message-digest: Indicates that the message digest algorithm is used. authentication null: indicates that authentication is not enabled. |

| | |
|-------------|---|
| Command | SWITCH(config-if)# ip ospf authentication-key [0 7] <i>key</i> |
| Description | Set the password for text authentication. 0 represents the plaintext key, and 7 represents the ciphertext key. |

| | |
|-------------|---|
| Command | SWITCH(config-if)# ip ospf message-digest-key <i>keyid</i> md5 [0 7] <i>key</i> |
| Description | Set the password for MD5 authentication. keyid: You can set authentication passwords corresponding to multiple keyids. 0 represents the plaintext key, and 7 represents the ciphertext key. |

- Configuring Area ASauthentication

| | |
|-------------|---|
| Command | SWITCH(config-router)#area <i>area-id</i> authentication [message-digest] |
| Description | area-id indicates the OSPF domain id. router-id: indicates the ID of the routing device, in the form of an IP address. authentication: Indicates the enabled authentication. authentication message-digest: Indicates that the message digest algorithm is used. |

14.2.11. Configuring Virtual-link

OSPF requires that the non-backbone area must be connected with the backbone area to implement OSPF routing update. However, in actual network deployment, due to various reasons, this requirement cannot be met, and the function of virtual connection is used to solve the problem of such scenarios.

| | |
|-------------|--|
| Command | SWITCH(config-router)#area <i>area-id</i> virtual-link <i>router-id</i> [authentication [message-digest null]] [dead-interval { <i>seconds</i> minimal hello-multiplier <i>multiplier</i> }] [hello-interval <i>seconds</i>] [retransmit-interval <i>seconds</i>][transmit-delay <i>seconds</i>] [[authentication-key [0 7] <i>key</i>] [message-digest-key <i>key-id</i> md5 [0 7] <i>key</i>]] |
| Description | area-id: indicates the OSPF domain id. router-id: indicates the ID of the routing device, in the form of an IP address. authentication [message-digest null] : Indicates the set authentication method. authentication-key: indicates the set password for plaintext authentication. dead-interval: Indicates the set neighbor dead time, in seconds. dead-interval minimal hello-multiplier: Indicates that the Fast Hello function is enabled. hello-interval: Indicates the set hello polling interval, in seconds. retransmit-interval: Indicates the set LSA retransmission interval, in seconds. transmit-delay: Indicates the set transmission delay of the LSA, in seconds. message-digest-key md5 [0 7]: indicates the set password for MD5 authentication, 0 indicates plaintext, and 7 indicates ciphertext. |

14.2.12. Configuring Stub Domain

The stub area is a specific area. The ABR in the stub area is not allowed to inject Type5 LSAs. In these areas, the size of the router's routing table and the number of routing information transmitted will be greatly reduced. You can further configure the stub area as a Totally Stub stub area. The ABR in this area will not transmit the inter-area routing information and external routing information to this area, which will further reduce the routing table size and routing information of the routers in the stub area. Quantity passed.

Typically, (Totally) Stub areas are located at the boundaries of autonomous systems.

In order to ensure that routes to other areas of the autonomous system or outside the autonomous system are still reachable, the ABR in this area will generate a default route and advertise it to other non-ABR routers in the area.

Note the following points when configuring (Totally) Stub areas:

- The backbone area cannot be configured as a (Totally) stub area.
- If an area is to be configured as a (Totally) stub area, all routers in the area must be configured with the stub [no-summary] command.
- (Totally) ASBR cannot exist in the stub area, that is, routes outside the AS cannot be propagated in this area.
- Virtual-link cannot pass through (Totally) Stub areas.

| | |
|-------------|--|
| Command | SWITCH(config-router)# area <i>area-id</i> stub [no-summary] |
| Description | area-id: indicates the OSPF domain id. no-summary: Configure this parameter on the ABR role device to configure the area as a full residual area. |

14.2.13. Configuring NSSA Domain

The NSSA (Not-So-Stubby Area) area is a variant of the Stub area and has many similarities with the Stub area. The NSSA area also does not allow Type5 LSA injection, but can allow Type7 LSA injection. Type7 LSAs are generated by ASBRs in the NSSA area and propagated within the NSSA area. When the Type7 LSA reaches the ABR of the NSSA, the ABR converts the Type7 LSA to the Type5 LSA and propagates it to other areas.

| | |
|-------------|--|
| Command | SWITCH(config-router)# area <i>area-id</i> nssa [no-redistribution] [no-summary] [default-information-originate [metric <i>metric</i>] [metric-type [1 2]]] [translator type7 suppress-fa] [translator-role [always candidate never]] |
| Description | area-id: indicates the OSPF domain id. no-redistribution: Indicates that external routes are prohibited from entering the NSSA area. no-summary: Indicates that routes from other areas are prohibited from entering the NSSA area. default-information-originate: If the current device is in the ABR role, this parameter indicates that a default route can be advertised to the NSSA area; if the current device is in the ASBR role (non-ABR), this parameter indicates that when there is a default route in the routing table, Advertise a default route to the NSSA area. The metric parameter is used to select the optimal route. |


14.3. Examples

14.3.1. OSPF Basic Configuration

Need

- 4 devices configure 3 areas in one autonomous domain;
- The device runs the OSPF protocol;
- Each device can learn all routes in the autonomous domain

Networking



Configuration example

- Device S1 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/1
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.1.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/2
S1(config-if)#no switchport
S1(config-if)#ip address 192.168.100.1/24
```

Configure the OSPF process

```
S1(config)#router ospf 1
S1(config-router)#router-id 10.10.1.1
```

Associated Network

```
S1(config-router)#network 10.10.1.0 255.255.255.0 area 1
S1(config-router)#network 192.168.100.0 255.255.255.0 area 1
```

- Device S2 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/1
S2(config-if)#no switchport
S2(config-if)#ip address 10.10.20.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/2
S2(config-if)#no switchport
S2(config-if)#ip address 10.10.10.1/24
```

Configure the OSPF process

```
S2(config)#router ospf 1
S2(config-router)#router-id 10.10.1.2
```

Associated Network

```
S2(config-router)#network 10.10.10.0 255.255.255.0 area 1
S2(config-router)#network 10.10.20.0 255.255.255.0 area 0
```

- Device S3 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/1
S3(config-if)#no switchport
S3(config-if)#ip address 10.10.20.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/2
S3(config-if)#no switchport
S3(config-if)#ip address 10.10.30.1/24
```

Configure the OSPF process

```
S3(config)#router ospf 1
S3(config-router)#router-id 10.10.20.2
```

Associated Network

```
S3(config-router)#network 10.10.20.0 255.255.255.0
S3(config-router)#network 10.10.30.0 255.255.255.0
```

- Device S4 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/1
S4(config-if)#no switchport
S4(config-if)#ip address 10.10.30.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/2
S4(config-if)#no switchport
S4(config-if)#ip address 192.168.111.1/24
```

Configure the OSPF process

```
S4(config)#router ospf 1
S4(config-router)#router-id 10.10.30.2
```

Associated Network

```
S4(config-router)#network 10.10.30.0 255.255.255.0 area 2
S4(config-router)#network 192.168.111.0 255.255.255.0 area 2
```

- Show result

Device S1:

Display routing table on device S1

```
S1#show ip ospf neighbor
```

OSPF process 1:

| Neighbor ID | Pri | State | Dead Time | Address | Interface |
|-------------|-----|---------|-----------|-----------|-----------|
| 10.10.1.2 | 1 | Full/DR | 00:00:31 | 10.10.1.2 | GiE0/1 |

S1#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```

C      10.10.1.0/24 is directly connected, gigabitEthernet0/1
O IA   10.10.20.0/24 [110/2] via 10.10.1.2, gigabitEthernet0/1, 00:37:09
O IA   10.10.30.0/24 [110/3] via 10.10.1.2, gigabitEthernet0/1, 00:36:19
C      192.168.100.0/24 is directly connected, gigabitEthernet0/2
O IA   192.168.111.0/24 [110/4] via 10.10.1.2, gigabitEthernet0/1, 00:36:19

```

Gateway of last resort is not set

S1#

Device S2:

Display routing table on device S2

S2#show ip ospf neighbor

OSPF process 1:

| Neighbor ID | Pri | State | Dead Time | Address | Interface |
|-------------|-----|----------|-----------|------------|-----------|
| 10.10.1.1 | 1 | Full/BDR | 00:00:36 | 10.10.1.1 | GiE0/1 |
| 10.10.20.2 | 1 | Full/DR | 00:00:31 | 10.10.20.2 | GiE0/2 |

S2#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```

C      10.10.1.0/24 is directly connected, gigabitEthernet0/1
C      10.10.20.0/24 is directly connected, gigabitEthernet0/2
O IA   10.10.30.0/24 [110/2] via 10.10.20.2, gigabitEthernet0/2, 00:38:36
O      192.168.100.0/24 [110/2] via 10.10.1.1, gigabitEthernet0/1, 00:45:08
O IA   192.168.111.0/24 [110/3] via 10.10.20.2, gigabitEthernet0/2, 00:38:36

```


Gateway of last resort is not set

S2#

Device S3:

Display routing table on device S3

S3#show ip ospf neighbor

OSPF process 1:

| Neighbor ID | Pri | State | Dead Time | Address | Interface |
|-------------|-----|----------|-----------|------------|-----------|
| 10.10.1.2 | 1 | Full/BDR | 00:00:34 | 10.10.20.1 | GiE0/2 |
| 10.10.30.2 | 1 | Full/DR | 00:00:31 | 10.10.30.2 | GiE0/1 |

S3#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

O IA 10.10.1.0/24 [110/2] via 10.10.20.1, gigabitEthernet0/2, 00:39:20
C 10.10.20.0/24 is directly connected, gigabitEthernet0/2
C 10.10.30.0/24 is directly connected, gigabitEthernet0/1
O IA 192.168.100.0/24 [110/3] via 10.10.20.1, gigabitEthernet0/2, 00:39:20
O 192.168.111.0/24 [110/2] via 10.10.30.2, gigabitEthernet0/1, 00:39:20

Gateway of last resort is not set

S3#

Device S4:

Display routing table on device S4

S4#show ip ospf neighbor

OSPF process 1:

| Neighbor ID | Pri | State | Dead Time | Address | Interface |
|-------------|-----|----------|-----------|------------|-----------|
| 10.10.20.2 | 1 | Full/BDR | 00:00:39 | 10.10.30.1 | GiE0/1 |

S4#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
O IA 10.10.1.0/24 [110/3] via 10.10.30.1, gigabitEthernet0/1, 00:39:51
O IA 10.10.20.0/24 [110/2] via 10.10.30.1, gigabitEthernet0/1, 00:39:51
C 10.10.30.0/24 is directly connected, gigabitEthernet0/1
O IA 192.168.100.0/24 [110/4] via 10.10.30.1, gigabitEthernet0/1, 00:39:51
C 192.168.111.0/24 is directly connected, gigabitEthernet0/2
```

Gateway of last resort is not set


S4#

14.3.2. OSPF route redistribution configuration

Need

- Area0 where S1 and S2 are in the same OSPF autonomous domain
- As an ASBR, S2 exchanges routes with S3 through RIP, and distributes default routes and static routes to the AS domain
- S1, S2, and S3 can learn each other's routes

Networking



Configuration example

- Device S1 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 192.168.100.1/24
```

Configure the OSPF process

```
SWITCH(config)#router ospf 1
```

Associated Network

```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0 area 0
SWITCH(config-router)#network 192.168.100.0 255.255.255.0 area 0
```

- Device S2 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.20.1/24
```

Configure default and static routes

```
SWITCH#configure terminal
SWITCH(config)#ip route 0.0.0.0/0 10.10.20.2
SWITCH(config)#ip route 80.0.0.0/6 10.10.20.2
```

Configure the OSPF process and Associated Network

S2 is the ASBR of OSPF, and needs to import the external routes advertised by RIP into the OSPF domain, that is, redistribute the routes of RIP to OSPF. You also need to configure static route redistribution and default route redistribution.

```
SWITCH(config)#router ospf 1
SWITCH(config-router)#network 10.10.1.0 255.255.255.0 area 0
SWITCH(config-router)#redistribute rip
SWITCH(config-router)#redistribute static
SWITCH(config-router)#default-information originate always
```

Configure the RIP process and Associated Network.

The routes between S2 and S3 are advertised through the RIP protocol. The routes in the OSPF domain need to be imported into the RIP process and then advertised to S3, that is, the OSPF routes are redistributed to RIP.

```
SWITCH(config)#router rip
SWITCH(config-router)#network 10.10.20.0 255.255.255.0
SWITCH(config-router)#redistribute ospf 1
```

- Device S3 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.20.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 192.168.200.1/24
```

Configure the RIP process and Associated Network

```
SWITCH(config)#router rip
SWITCH(config-router)#network 10.10.20.0 255.255.255.0
SWITCH(config-router)#network 192.168.200.0 255.255.255.0
```

- Show result

Device S1

Display the routing table on Device S1, you can see:

- ✧ The route of the 192.168.200.0/24 network segment learned from the external AS, that is, the RIP domain, learned through S2;
- ✧ Static route 80.0.0.0/6 learned through S2
- ✧ Default route 0.0.0.0/0 learned through S2

SWITCH#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

Gateway of last resort is 10.10.1.2 to network 0.0.0.0

```
O*E2    0.0.0.0/0 [110/1] via 10.10.1.2, gigabitEthernet0/1, 4d00h19m
C       10.10.1.0/24 is directly connected, gigabitEthernet0/1
O E2    80.0.0.0/6 [110/20] via 10.10.1.2, gigabitEthernet0/1, 4d00h19m
C       192.168.100.0/24 is directly connected, gigabitEthernet0/2
O E2    192.168.200.0/24 [110/20] via 10.10.1.2, gigabitEthernet0/1, 4d00h19m
```

SWITCH#

Device S2

Display the routing table on Device S2, you can see:

- ✧ The internal AS learned through S1 is the route of the 192.168.100.0/24 network segment learned by the OSPF domain;
- ✧ Self-configured static route 80.0.0.0/6 and default route 0.0.0.0/0
- ✧ Route 192.168.200.0/24 learned through RIP of S3

SWITCH#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

Gateway of last resort is 10.10.20.2 to network 0.0.0.0

```
S*      0.0.0.0/0 [1/0] via 10.10.20.2, gigabitEthernet0/2
```

```

C    10.10.1.0/24 is directly connected, gigabitEthernet0/1
C    10.10.20.0/24 is directly connected, gigabitEthernet0/2
S    80.0.0.0/6 [1/0] via 10.10.20.2, gigabitEthernet0/2
O    192.168.100.0/24 [110/2] via 10.10.1.1, gigabitEthernet0/1, 4d00h25m
R    192.168.200.0/24 [120/1] via 10.10.20.2, gigabitEthernet0/2, 4d00h26m
SWITCH#

```

Device S3

Display the routing table on Device S3, you can see:

✧ The route of network segment 192.168.100.0/24 redistributed from OSPF learned through RIP of S2;

```
SWITCH#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```

C    10.10.20.0/24 is directly connected, gigabitEthernet0/2
R    192.168.100.0/24 [120/1] via 10.10.20.1, gigabitEthernet0/2, 00:00:08
C    192.168.200.0/24 is directly connected, gigabitEthernet0/1

```

Gateway of last resort is not set


SWITCH#

14.3.3. OSPF Stub Area Configuration

Need

- Four devices are configured with three areas in one autonomous area; one of the areas is configured as a stub area to reduce the size of the routing table and reduce routing information transmission.
- The device runs the OSPF protocol;
- Each device can learn all routes in the autonomous domain;

Networking



Configuration example

Interface IP, OSPF basic configuration, see Configuration example in Chapter 20.3.1 OSPF Basic Configuration. Correspondingly add the related configuration of the Stub domain of area1 of S1 and S2.

- Device S1 configuration steps

Configure Area1 as a stub domain.

```
S1(config-router)#area 1 stub
```

- Device S2 configuration steps

Configure Area1 as a stub domain.

Configuring the no-summary parameter can prevent the ABR from sending network summary link advertisements to the stub domain (the configured stub domain is the Totally Stub domain, that is, the all-stub domain). This parameter can only be configured on ABR devices.

```
S1(config-router)#area 1 stub no-summary
```

- Show result

Device S1:

Display the routing table on Device S1, and you can see that only one default route to the external domain is reserved on Device S1.

```
S1#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

Gateway of last resort is 10.10.1.2 to network 0.0.0.0

```
O*IA 0.0.0.0/0 [110/2] via 10.10.1.2, gigabitEthernet0/1, 00:18:33
```

```
C 10.10.1.0/24 is directly connected, gigabitEthernet0/1
```

```
C 192.168.100.0/24 is directly connected, gigabitEthernet0/2
```


```
S1#
```

14.3.4. OSPF NSSA area configuration

Need

- Four devices are configured with three areas in an autonomous domain; one of the domains is configured as an NSSA domain to reduce the size of the routing table and reduce routing information transmission.
- The device runs the OSPF protocol;
- Each device can learn all routes in the autonomous domain;

Networking



Configuration example

Interface IP, OSPF basic configuration, see Configuration example in Chapter 20.3.1 OSPF Basic Configuration. Correspondingly, the static route redistribution of S1, and the NSSA domain related configuration of area2 of S3 and S4 are added.

- Device S1 configuration steps

Configure static routes

```
S1(config)#ip route 112.0.0.0/6 192.168.100.2
```

Configure static route redistribution

```
S1(config-router)#redistribute static
```

- Device S3 configuration steps

Configure Area2 as an NSSA domain

Configuring the no-summary parameter can prevent the ABR from sending summary LSAs to the NSSA domain. This parameter is only configured on the ABR device.

```
S1(config-router)#area 2 nssa no-summary
```

- Device S4 configuration steps

Configure static routes

```
S4(config)#ip route 80.0.0.0/6 192.168.111.2
```

Configure static route redistribution

```
S4(config-router)#redistribute static
```

Configure Area2 as an NSSA domain

```
S1(config-router)#area 2 nssa
```

- Show result

Before S3 and S4 configure area 2 as an NSSA domain:

Device S1:

The routing table displayed on Device S1 is as follows. You can see that there are all routes advertised in the autonomous domain on Device S1, including:

- ✧ The route to the 80.0.0.0/6 network segment, that is, the static route advertised by S4
- ✧ The route to the network segment 192.168.111.0/24, that is, the dynamic route advertised by S4

```
S1#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
C      10.10.1.0/24 is directly connected, gigabitEthernet0/1
O IA   10.10.20.0/24 [110/2] via 10.10.1.2, gigabitEthernet0/1, 00:13:28
O IA   10.10.30.0/24 [110/3] via 10.10.1.2, gigabitEthernet0/1, 00:13:28
O E2   80.0.0.0/6 [110/20] via 10.10.1.2, gigabitEthernet0/1, 00:12:38
S      112.0.0.0/6 [1/0] via 192.168.100.2, gigabitEthernet0/2
C      192.168.100.0/24 is directly connected, gigabitEthernet0/2
```

```
O IA 192.168.111.0/24 [110/4] via 10.10.1.2, gigabitEthernet0/1, 00:13:28
```

Gateway of last resort is not set

S1#

Device S3:

The routing table displayed on Device S3 is as follows. You can see that all routes advertised in the autonomous domain exist on the S3 device.

```
S3#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
O IA 10.10.1.0/24 [110/2] via 10.10.20.1, gigabitEthernet0/2, 01:35:21
```

```
C 10.10.20.0/24 is directly connected, gigabitEthernet0/2
```

```
C 10.10.30.0/24 is directly connected, gigabitEthernet0/1
```

```
O E2 80.0.0.0/6 [110/20] via 10.10.30.2, gigabitEthernet0/1, 00:16:37
```

```
O E2 112.0.0.0/6 [110/20] via 10.10.20.1, gigabitEthernet0/2, 00:16:18
```

```
O IA 192.168.100.0/24 [110/3] via 10.10.20.1, gigabitEthernet0/2, 00:17:27
```

```
C 192.168.101.0/24 is directly connected, vlan100
```

```
O 192.168.111.0/24 [110/2] via 10.10.30.2, gigabitEthernet0/1, 01:51:26
```

Gateway of last resort is not set

S3#

Device S4:

The routing table displayed on Device S4 is as follows. You can see that all routes advertised in the autonomous domain exist on the S4 device.

```
S4#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
O IA 10.10.1.0/24 [110/3] via 10.10.30.1, gigabitEthernet0/1, 01:37:28
```

```
O IA 10.10.20.0/24 [110/2] via 10.10.30.1, gigabitEthernet0/1, 01:38:18
```

```
C 10.10.30.0/24 is directly connected, gigabitEthernet0/1
```

```
S 80.0.0.0/6 [1/0] via 192.168.111.2, gigabitEthernet0/2
```

```
O E2 112.0.0.0/6 [110/20] via 10.10.30.1, gigabitEthernet0/1, 00:18:25
```



```
O IA 192.168.100.0/24 [110/4] via 10.10.30.1, gigabitEthernet0/1, 00:19:33
C    192.168.111.0/24 is directly connected, gigabitEthernet0/2
```

Gateway of last resort is not set

S4#

After configuring area 2 as an NSSA domain on S3 and S4:

Device S1:

The routing table displayed on Device S1 is as follows. You can see that there are all routes advertised in the autonomous domain on Device S1, including:

- ✧ The route to the 80.0.0.0/6 network segment, that is, the static route advertised by S4
- ✧ The route to the network segment 192.168.111.0/24, that is, the dynamic route advertised by S4

S1#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
C    10.10.1.0/24 is directly connected, gigabitEthernet0/1
O IA 10.10.20.0/24 [110/2] via 10.10.1.2, gigabitEthernet0/1, 00:05:28
O IA 10.10.30.0/24 [110/3] via 10.10.1.2, gigabitEthernet0/1, 00:05:28
O E2 80.0.0.0/6 [110/20] via 10.10.1.2, gigabitEthernet0/1, 00:01:18
S    112.0.0.0/6 [1/0] via 192.168.100.2, gigabitEthernet0/2
C    192.168.100.0/24 is directly connected, gigabitEthernet0/2
O IA 192.168.111.0/24 [110/4] via 10.10.1.2, gigabitEthernet0/1, 00:01:19
```

Gateway of last resort is not set

S1#

Device S3:

The routing table displayed on Device S3 is as follows. You can see that there are all routes advertised in the autonomous domain on the S3 device, but the route 80.0.0.0/6 imported from the autonomous domain has changed from E2 type to N2 type and is passed to other domains.

S3#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
O IA 10.10.1.0/24 [110/2] via 10.10.20.1, gigabitEthernet0/2, 00:07:46
```

```

C      10.10.20.0/24 is directly connected, gigabitEthernet0/2
C      10.10.30.0/24 is directly connected, gigabitEthernet0/1
O N2   80.0.0.0/6 [110/20] via 10.10.30.2, gigabitEthernet0/1, 00:03:27
O E2   112.0.0.0/6 [110/20] via 10.10.20.1, gigabitEthernet0/2, 00:04:12
O IA   192.168.100.0/24 [110/3] via 10.10.20.1, gigabitEthernet0/2, 00:04:13
C      192.168.101.0/24 is directly connected, vlan100
O      192.168.111.0/24 [110/2] via 10.10.30.2, gigabitEthernet0/1, 00:03:27

```

Gateway of last resort is not set

S3#

Device S4:

The routing table displayed on Device S4 is as follows. It can be seen that the routes on the S4 device have changed from all routes advertised in the autonomous domain to one less route 112.0.0.0/6 outside the autonomous domain imported by S1.

S4#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```

O IA   10.10.1.0/24 [110/3] via 10.10.30.1, gigabitEthernet0/1, 00:00:11
O IA   10.10.20.0/24 [110/2] via 10.10.30.1, gigabitEthernet0/1, 00:00:11
C      10.10.30.0/24 is directly connected, gigabitEthernet0/1
S      80.0.0.0/6 [1/0] via 192.168.111.2, gigabitEthernet0/2
O IA   192.168.100.0/24 [110/4] via 10.10.30.1, gigabitEthernet0/1, 00:00:11
C      192.168.111.0/24 is directly connected, gigabitEthernet0/2

```

Gateway of last resort is not set

S4#

After S3 and S4 configure area 2 as an NSSA domain and increase the no-summary parameter:

Device S4:

The routing table displayed on Device S4 is as follows. You can see that the routes on the S4 device have changed from all routes advertised in the autonomous domain to a default route.

S4#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

Gateway of last resort is 10.10.30.1 to network 0.0.0.0


```
O*IA    0.0.0.0/0 [110/2] via 10.10.30.1, gigabitEthernet0/1, 00:08:06
C       10.10.30.0/24 is directly connected, gigabitEthernet0/1
S       80.0.0.0/6 [1/0] via 192.168.111.2, gigabitEthernet0/2
C       192.168.111.0/24 is directly connected, gigabitEthernet0/2
S4#
```

14.3.5. OSPF route aggregation

Need

- Four devices are configured with three areas in an autonomous domain; one of the domains is configured as an NSSA domain to reduce the size of the routing table and reduce routing information transmission.
- The device runs the OSPF protocol;
- Each device can learn all routes in the autonomous domain;

Networking



Configuration example

For the interface IP and basic OSPF configuration, see Configuration example in Chapter 20.3.1 Basic OSPF Configuration.

Correspondingly add the route aggregation configuration of area1 of S1.

- Device S1 configuration steps

Configure route aggregation for Area1

Aggregate the four network segments 192.168.1.0/24 – 192.168.4.0/24 into one network segment 192.168.0.0/21.

```
S1(config-router)#area 1 range 192.168.0.0/21
```

- Show result

Before S1 configures the route aggregation Command, the routing table of S2 has routes for the four network segments 192.168.1.0/24 – 192.168.4.0/24, as shown below:

```
S2#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default

IP Route Table for VRF "default"

```
C      10.10.1.0/24 is directly connected, gigabitEthernet0/1
O IA   192.168.1.0/24 [110/3] via 10.10.1.1, gigabitEthernet0/1, 00:00:02
O IA   192.168.2.0/24 [110/3] via 10.10.1.1, gigabitEthernet0/1, 00:00:02
O IA   192.168.3.0/24 [110/2] via 10.10.1.1, gigabitEthernet0/1, 00:00:02
O IA   192.168.4.0/24 [110/2] via 10.10.1.1, gigabitEthernet0/1, 00:00:02
```

Gateway of last resort is not set

S2#

After configuring the route aggregation command in S1, the routing table of S2 is as follows

S2#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
C      10.10.1.0/24 is directly connected, gigabitEthernet0/1
O IA   192.168.0.0/21 [110/3] via 10.10.1.1, gigabitEthernet0/1, 01:29:42
```

Gateway of last resort is not set


S2#

14.3.6. OSPF virtual link

Need

- Four devices are configured in three areas in an autonomous domain; S1 and S2 are in area 0, and S2 and S3 are in area 1. S3 and S4 are in area 2. S4 has no direct physical connection to backbone area area 0;
- The device runs the OSPF protocol;
- Each device can learn all routes in the autonomous domain;

Networking



Configuration example

Since S4 does not have a direct physical connection with the backbone area, if you need to import the routes of area 2 into the autonomous area, you need to create a virtual connection for area 2 to area 0.

- Device S1 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/1
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.10.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/2
S1(config-if)#no switchport
S1(config-if)#ip address 192.168.100.1/24
```

Configure the OSPF process

```
S1(config)#router ospf 1
S1(config-router)#router-id 10.10.10.1
```

Associated Network

```
S1(config-router)#network 10.10.10.0 255.255.255.0 area 0
S1(config-router)#network 192.168.100.0 255.255.255.0 area 0
```

- Device S2 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/1
S2(config-if)#no switchport
S2(config-if)#ip address 10.10.10.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/2
S2(config-if)#no switchport
S2(config-if)#ip address 10.10.20.1/24
```

Configure the OSPF process

```
S2(config)#router ospf 1
S2(config-router)#router-id 10.10.10.2
```

Associated Network

```
S2(config-router)#network 10.10.10.0 255.255.255.0 area 0
S2(config-router)#network 10.10.20.0 255.255.255.0 area 1
```

Configure virtual-link

```
S2(config-router)#area 1 virtual-link 10.10.30.1
```

- Device S3 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/1
S3(config-if)#no switchport
S3(config-if)#ip address 10.10.30.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/2
S3(config-if)#no switchport
S3(config-if)#ip address 10.10.20.2/24
```

Configure the OSPF process

```
S3(config)#router ospf 1
S3(config-router)#router-id 10.10.30.1
```

Associated Network

```
S3(config-router)#network 10.10.20.0 255.255.255.0 area 1
S3(config-router)#network 10.10.30.0 255.255.255.0 area 2
```

Configure virtual-link

```
S3(config-router)#area 1 virtual-link 10.10.10.2
```

- Device S4 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/1
S4(config-if)#no switchport
S4(config-if)#ip address 10.10.30.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/2
S4(config-if)#no switchport
S4(config-if)#ip address 192.168.101.1/24
```

Configure the OSPF process

```
S4(config)#router ospf 1
S4(config-router)#router-id 10.10.30.2
```

Associated Network

```
S4(config-router)#network 10.10.30.0 255.255.255.0 area 2
S4(config-router)#network 192.168.101.0 255.255.255.0 area 2
```

- Show result

Before Configure virtual-link, the routing table of S1 is as follows:

```
S1#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

C 10.10.10.0/24 is directly connected, gigabitEthernet0/1

O IA 10.10.20.0/24 [110/2] via 10.10.10.2, gigabitEthernet0/1, 00:02:11

```
C      192.168.100.0/24 is directly connected, gigabitEthernet0/2
```

Gateway of last resort is not set

```
S1#
```

Before Configure virtual-link, the routing table of S4 is as follows:

```
S4#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
C      10.10.30.0/24 is directly connected, gigabitEthernet0/1
```

```
C      192.168.101.0/24 is directly connected, gigabitEthernet0/2
```

Gateway of last resort is not set

```
S4#
```

After configuring virtual-link, the routing table of S1 is as follows:

```
S1#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
C      10.10.10.0/24 is directly connected, gigabitEthernet0/1
```

```
O IA   10.10.20.0/24 [110/2] via 10.10.10.2, gigabitEthernet0/1, 00:03:19
```

```
O IA   10.10.30.0/24 [110/3] via 10.10.10.2, gigabitEthernet0/1, 00:00:01
```

```
C      192.168.100.0/24 is directly connected, gigabitEthernet0/2
```

```
O IA   192.168.101.0/24 [110/4] via 10.10.10.2, gigabitEthernet0/1, 00:00:01
```

Gateway of last resort is not set

```
S1#
```

After configuring virtual-link, the routing table of S4 is as follows:

```
S4#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default

IP Route Table for VRF "default"

```
O IA    10.10.10.0/24 [110/3] via 10.10.30.1, gigabitEthernet0/1, 00:01:44
O IA    10.10.20.0/24 [110/2] via 10.10.30.1, gigabitEthernet0/1, 00:01:53
C       10.10.30.0/24 is directly connected, gigabitEthernet0/1
O IA    192.168.100.0/24 [110/4] via 10.10.30.1, gigabitEthernet0/1, 00:01:44
C       192.168.101.0/24 is directly connected, gigabitEthernet0/2
```

Gateway of last resort is not set

S4#

14.3.7. OSPF Authentication

Need

- The device runs the OSPF protocol;
- Enable authentication on area 0 and virtual connections

Networking

Networking based on chapter 1.3.6

Configuration example

Added authentication related configuration in addition to the configuration based on section 1.3.6.

- Device S1 configuration steps

Enable MD5 authentication on area 0

```
S1(config)#router ospf 1
S1(config-router)#area 0 authentication message-digest
S1(config-router)#
```

Configuring an Authentication Password on an Interface

```
S1(config)#interface gigabitEthernet0/1
S1(config-if)#ip ospf message-digest-key 1 md5 test-password
S1(config-if)#
```

- Device S2 configuration steps

Enable MD5 authentication on area 0

```
S2(config)#router ospf 1
S2(config-router)#area 0 authentication message-digest
S2(config-router)#
```

Configuring an Authentication Password on an Interface

```
S2(config)#interface gigabitEthernet0/1
S2(config-if)#ip ospf message-digest-key 1 md5 test-password
S2(config-if)#
```

Enable MD5 authentication on the virtual interface and configure the authentication password


```
S2(config-router)#area 1 virtual-link 10.10.30.1 authentication message-digest
S2(config-router)#area 1 virtual-link 10.10.30.1 message-digest-key 1 md5
test-password
```

- Device S3 configuration steps

Enable MD5 authentication on the virtual interface and configure the authentication password

```
S3(config-router)#area 1 virtual-link 10.10.10.2 authentication message-digest
S3(config-router)#area 1 virtual-link 10.10.30.1 message-digest-key 1 md5
test-password
```

- Show result

When S1 enables authentication and configures a password, but S2 does not enable authentication and configure a password, S1 and S2 will notify that the authentication methods do not match:

S1's announcement log:

```
S1(config-router)#
1970 Jan 01 00:16:13 SWITCH OSPF-4: RECV[Hello]: From 10.10.10.2 via
gigabitEthernet0/1:10.10.10.1: Authentication type mismatch
```

S2's announcement log

```
S2(config-router)#
1970 Jan 01 00:20:39 SWITCH OSPF-4: RECV[Hello]: From 10.10.10.1 via
gigabitEthernet0/1:10.10.10.2: Authentication type mismatch
```

After the authentication methods and authentication passwords on both ends are the same, the warning log will not be printed repeatedly.

Route advertisement and learning are normal.

14.4. Display Information

- show routing information

```
S2#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

```
IP Route Table for VRF "default"
```

```
C      10.10.1.0/24 is directly connected, gigabitEthernet0/1
O IA   192.168.0.0/21 [110/3] via 10.10.1.1, gigabitEthernet0/1, 01:30:09
O IA   192.168.1.0/24 [110/3] via 10.10.1.1, gigabitEthernet0/1, 00:00:02
O IA   192.168.2.0/24 [110/3] via 10.10.1.1, gigabitEthernet0/1, 00:00:02
O IA   192.168.3.0/24 [110/2] via 10.10.1.1, gigabitEthernet0/1, 00:00:02
O IA   192.168.4.0/24 [110/2] via 10.10.1.1, gigabitEthernet0/1, 00:00:02
```

Gateway of last resort is not set

S2#

- Show only OSPF routing information

S2#show ip route ospf

IP Route Table for VRF "default"

```
O IA    192.168.0.0/21 [110/3] via 10.10.1.1, gigabitEthernet0/1, 01:49:00
O IA    192.168.1.0/24 [110/3] via 10.10.1.1, gigabitEthernet0/1, 00:18:53
O IA    192.168.2.0/24 [110/3] via 10.10.1.1, gigabitEthernet0/1, 00:18:53
O IA    192.168.3.0/24 [110/2] via 10.10.1.1, gigabitEthernet0/1, 00:18:53
O IA    192.168.4.0/24 [110/2] via 10.10.1.1, gigabitEthernet0/1, 00:18:53
```

Gateway of last resort is not set

S2#

- Additional OSPF Information

| Command | Effect |
|-----------------------------|--|
| show ip ospf process-id | Displays brief information about the process corresponding to OSPF |
| show ip ospf border-routers | Display OSPF border and border router information |
| show ip ospf database | Display OSPF database information |
| show ip ospf interface | Display OSPF interface-related information |
| show ip ospf neighbor | Display OSPF neighbor information |
| show ip ospf virtual-links | Display OSPF virtual-link information |

15. Configuring BGP

15.1. Overview of BGP

BGP (Border Gateway Protocol) is an exterior gateway protocol (Exterior Gateway Protocol, EGP) that communicates between routing devices of different autonomous systems. Its main function is to exchange networks between different AS (Autonomous Systems) reachable information, and eliminate routing loops through the protocol's own mechanism.

BGP uses the TCP protocol as the transmission protocol, and ensures the transmission reliability of BGP through the reliable transmission mechanism of the TCP protocol.

A router running the BGP protocol is called a BGP speaker, and the BGP speakers that establish a BGP session connection are called peers (BGP peers).

There are two modes for establishing peers between BGP speakers: IBGP (Internal BGP) and EBGP (External BGP). IBGP refers to BGP connections established within the same AS, and EBGP refers to BGP connections established between different ASs. In short, the functions of the two are as follows: EBGP is to complete the exchange of routing information between different ASs, and IBGP is to complete the transition of routing information within this AS.

15.2. Configuring

15.2.1. Creating a BGP Process

| | |
|-------------|---|
| Command | SWITCH(config)#router bgp <i>as-number</i> SWITCH(config-router)# bgp router-id <i>router-id</i> |
| Description | Create a process and configure a unique ID. |

15.2.2. Configuring BGP Address Family

| | |
|-------------|---|
| Command | SWITCH(config-router)#address-family ipv4 [unicast multicast] |
| Description | Configure the routing mode of BGP as IPv4 unicast/multicast address family. |

15.2.3. Configuring BGP neighbor

BGP neighbors need to be manually configured, and both ends of the BGP session need to be configured with peers as local neighbors. Therefore, BGP neighbors are also called BGP peers.

- Configuring Peers

| | |
|-------------|---|
| Command | SWITCH(config-router)# [no] neighbor <i>address</i> remote-as <i>as-number</i> |
| Description | address: indicates the address of the BGP peer. as-number: represents the as number in the range 1 – 4294967295. |

- Configuring Peer Group

| | |
|-------------|---|
| Command | SWITCH(config-router)# [no] neighbor <i>group-name</i> peer-group SWITCH(config-router)#[no]neighbor address peer-group <i>group-name</i> SWITCH(config-router)#neighbor <i>group-name</i> remote-as <i>as-number</i> |
| Description | group-name: indicates the BGP peer group name. as-number: indicates the as number in the range 1 - 4294967295. |

- Configuring MD5 Authentication

| | |
|-------------|--|
| Command | SWITCH(config-router)# [no] neighbor <i>address</i> password [0 7] <i>key</i> |
| Description | Set the password for MD5 authentication. address: indicates the address of the BGP peer. 0 represents the plaintext key, and 7 represents the ciphertext key. key is the password string. |

15.2.4. Configuring Reflector

All BGP speakers in an AS need to establish full connections. Therefore, as the number of BGP speakers in the AS increases, the connections that need to be maintained between the speakers also increase accordingly, which will increase the resource consumption of the speakers. In order to reduce this consumption, you can use the BGP route reflector to design the network. In the use of route reflectors, BGP speaker devices can be classified into clients and non-clients according to their types. A group is formed between a route reflector and its client (more than one). The client of the route reflector only establishes a connection with the reflector, no connection is established between the client and the client, and no connection is established between the client and the speaker outside the group. Based on the above principles, the BGP route reflector can reduce AS The number of connections in IBGP peers.

Configuring a router as a reflector is all about specifying which neighbors are clients to it.

The rules of route reflector for route learning are as follows:

- The routes learned by the client will be synchronized to other clients and other non-clients;
- Routes learned by non-clients through IBGP will be synchronized to other clients;
- Routes learned through EBGP Speaker will be synchronized to other clients and other non-clients;

If there are multiple route reflectors in a group, you need to configure a group ID for the group. If there is only one route reflector, this need not be configured. The group is identified by the router-id of the reflector.

- Configuring the Device as a Route Reflector and Specify the Client

| | |
|-------------|--|
| Command | SWITCH(config-router)# [no] neighbor { <i>address</i> <i>group-name</i> } route-reflector-client |
| Description | address: indicates the peer IP address. group-name: indicates the peer group address. |

- Configuring the Route Reflector Group ID

| | |
|-------------|--|
| Command | SWITCH(config-router)#bgp cluster-id <i>cluster-id</i> |
| Description | cluster-id: indicates the cluster ID of the route reflector. |

- Configuring to Cancel Route Reflection Between Clients

| | |
|-------------|--|
| Command | SWITCH(config-router)#no bgp client-to-client reflection |
| Description | Cancel route reflection between clients. |

15.2.5. Configuring AS confederation

AS confederation can be used to reduce the number of connections to peers in homebrew systems (another approach is to configure route reflectors).

By configuring AS confederation, an autonomous system can be divided into multiple subsystems, and the subsystems can be

merged into an confederation by setting the same confederation ID. For external autonomous systems, the confederation is an AS and a unified confederation AS number; for confederations Internally, BGP speakers are still connected according to complete IBGP peers, and BGP speakers between subsystems are still connected according to EBGP.

- **Configuring the AS Confederation Number**

| | |
|-------------|---|
| Command | SWITCH(config-router)#bgp confederation identifier <i>as-number</i> |
| Description | as-number: indicates confederation number |

- **Configuring Other Sub-ASs in the Confederation**

| | |
|-------------|--|
| Command | SWITCH(config-router)#bgp confederation peer <i>as-number1 as-numberN</i> |
| Description | as-number1 as-numberN: indicates the sub-as number that joins the confederation. |

15.2.6. Configuring Route Aggregation

| | |
|-------------|---|
| Command | SWITCH(config-router)#aggregate-address <i>address mask</i> [as-set] [summary-only] |
| Description | <p>address and mask: indicate the configured aggregate address.</p> <p>as-set: indicates that if this parameter is configured, the AS path information of the paths in the aggregated address range will be retained.</p> <p>summary-only: indicates that if this parameter is configured, only the aggregated paths will be advertised. The default is to advertise all path information before and after aggregation.</p> |

15.2.7. Configuring Route Attenuation

Frequent switching between valid and invalid routes will cause route flapping, which may cause a chain reaction and make the entire network unstable. In order to solve this problem, the route attenuation function is introduced.

The principle of the route damping function is that each time a route flap occurs, the corresponding route will increase the penalty value. When the cumulative penalty value exceeds the suppression threshold, the suppression will be triggered. The suppression time starts to count. When the count is equal to the half-life time, the penalty value becomes half of the original value and decreases in turn. When the penalty value is reduced to less than the restart value, the suppression of the route will be lifted and activated again.

| | |
|-------------|--|
| Command | SWITCH(config-router)#bgp dampening [<i>half-life-time reuse-time suppress-time max-suppress-time</i>] |
| Description | <p>half-life-time: indicates the half-life, that is, the time when the penalty value is reduced to half, the unit is minutes, the range is 1-45, and the default value is 15.</p> <p>reuse-time: indicates the restart value, that is, when the penalty value of the route is lower than this value, the route suppression is lifted. The range is 1-20000, the default is 750.</p> <p>suppress-time: indicates the upper limit of suppression, that is, when the penalty value of a route is higher than this value, route suppression takes effect. The range is 1-20000, the default is 2000.</p> <p>max-suppress-time: indicates the maximum time for route suppression, in minutes, ranging from 1 to 255. The default value is 4 times half-life-time.</p> |

| | |
|---------|--|
| Command | SWITCH#show ip bgp dampening {flap-statics dampened-paths} |
|---------|--|

| | |
|-------------|--|
| Description | <p>flap-statics: indicates the statistics of route flapping.</p> <p>dampened-paths: indicates suppressed statistics.</p> |
|-------------|--|

| | |
|-------------|---|
| Command | SWITCH#clear ip bgp dampening {flap-statics [address [mask]] dampened-paths [address [mask]]} |
| Description | <p>flap-statics: used to clear the statistics of all route flapping. If the address and mask parameters are included, it is used to clear the statistics of the specified route.</p> <p>dampened-paths: used to clear the statistics of all suppressed routes. The suppressed routes will also be contacted and suppressed. If the address and mask parameters are included, they are used to clear the statistics of the specified routes.</p> |

15.2.8. Configuring Administrative Distance

The administrative distance is an attribute used to evaluate the reliability of the route source. The smaller the administrative distance, the higher the priority of the route.

| | |
|-------------|---|
| Command | SWITCH(config-router)#distance bgp <i>external-distance internal-distance local-distance</i> |
| Description | <p>external-distance: Indicates the administrative distance of routes learned from EBGp peers.</p> <p>internal-distance: Indicates the administrative distance of routes learned from IBGP peers.</p> <p>local-distance: Indicates the administrative distance learned from the peer, but it is considered that there is a better route that can be learned from the IGP, usually these routes are represented by the network backdoor command.</p> |

If a route is configured as a backdoor route, and both IGP and EBGp learn this route, the IGP route will be used preferentially, but the route learned by IGP will not be advertised.

| | |
|-------------|---|
| Command | SWITCH(config-router)#network <i>address mask</i> backdoor |
| Description | <p>address and mask: Indicates the network segment address.</p> <p>backdoor: Indicates that this route is a backdoor route.</p> |

15.2.9. Configuring Multipath Load Balancing

If there are multiple paths to a unified network segment, data can be forwarded in a balanced manner through these multiple paths, which is called multi-path load balancing. You can enable or disable this function by enabling/disabling the multi-path load balancing configuration. In BGP, EBGp routes can form multi-path load balancing with EBGp routes, but cannot form multi-path load balancing with IBGP routes. Similarly, IBGP cannot form multi-path load balancing with EBGp routes.

- Configuring EBGp Multipath Load Balancing

| | |
|-------------|---|
| Command | SWITCH(config-router)#maximum-paths ebgp <i>number</i> |
| Description | number: indicates the number of equivalent jumps supported, ranging from 1 to 32. |

- Configuring IBGP Multipath Load Balancing

| | |
|-------------|---|
| Command | SWITCH(config-router)#maximum-paths ibgp <i>number</i> |
| Description | number: indicates the number of equivalent jumps supported, ranging from 1 to 32. |

- Configuring EIBGP Multipath Load Balancing

Only one command configures multi-path load balancing of EBGp and IBGP at the same time.

| | |
|-------------|---|
| Command | SWITCH(config-router)#maximum-paths eibgp <i>number</i> |
| Description | number: indicates the number of equivalent jumps supported, ranging from 1 to 32. |

- Configuring AS-path Loose Comparison

By default, if two routes are to be combined into an equal-cost route to form multi-path load balancing, all attributes of the AS-path must be completely equal. If you want to reduce the above harsh conditions to form multi-path load balancing, you can achieve this by enabling AS-path loose comparison. AS-path loose comparison only needs to satisfy the condition that the AS-path length and the confederation AS-path length are equal respectively under the premise of the same route multi-path to achieve multi-path load balancing.

| | |
|-------------|--|
| Command | SWITCH(config-router)#bgp bestpath as-path multipath-relax |
| Description | Enable BGP AS-path loose comparison mode |

15.2.10. Configuring Next-hop Update Rrigger

| | |
|-------------|--|
| Command | SWITCH(config-router)#bgp nexthop trigger enable |
| Description | Next-hop update trigger enable configuration |

| | |
|-------------|---|
| Command | SWITCH(config-router)#bgp nexthop trigger delay <i>delay-time</i> |
| Description | Next update trigger time configuration |

15.2.11. Configuring Route Redistribution

- route injection

| | |
|-------------|--|
| Command | SWITCH(config-router)# redistribute { connected isis [area-tag] ospf process-id rip static } [metric value] [metric-type {1 2}] [route-map map-name] [subnets] [tag value] |
| Description | Inject external routes (including static routes/routes of other routing protocols) into the BGP process. |

- Configuring Default Route Injection

| | |
|-------------|--|
| Command | SWITCH(config-router)#default-information originate |
| Description | The default route is injected into BGP and distributed through the protocol. |

15.2.12. Configuring Protocol Parameter

- Configuring the Neighbor Keep-Alive Timer

| | |
|-------------|--|
| Command | SWITCH(config-router)#timer bgp <i>keepalive holdtime</i> |
| Description | keepalive: refers to the period for the peer to keep a valid connection, the unit is seconds, the range is 0-65535, and the default value is 60. During the keepalive period, the protocol will send keepalive |

| | |
|--|--|
| | <p>packets to keep the connection.</p> <p>holdtime: is the period for judging whether the peer is valid, the unit is seconds, the range is 0-65535, and the default value is 180. If the device does not receive the keepalive message from the peer within the holdtime, the peer connection is considered invalid.</p> |
|--|--|

When a BGP connection is established between BGP speakers, the holdtime will be negotiated, and the smaller holdtime will be selected as the effective configuration. The effective value of keepalive will be 1/3 of the effective holdtime value based on the negotiation after holdtime negotiation is completed, compared with the configured keepalive value, and the smaller value of the two is used as the effective configuration of keepalive.

You can also configure keepalive and holdtime values based on BGP peers (groups).

| | |
|-------------|---|
| Command | SWITCH(config-router)#neighbor {address group-name} <i>keepalive holdtime</i> |
| Description | <p>address: The address of the peer.</p> <p>group-name: The name of the peer group.</p> |

- Configuring the Neighbor Reconnection Timer

After the connection between the device and the peer fails, it needs to try to reconnect. You can configure the reconnection timer to specify the reconnection period.

| | |
|-------------|--|
| Command | SWITCH(config-router)#neighbor {address group-name} timer connect <i>connect-retry</i> |
| Description | <p>address: The address of the peer.</p> <p>group-name: The name of the peer group.</p> <p>connect-retry: The reconnection period, in seconds, ranging from 1 to 65535. The default value is 15 seconds.</p> |

- Configuring the Route Advertisement Timer

When a route change occurs locally, the device needs to advertise the updated route to peers (groups). You can configure the route advertisement timer to set the advertisement frequency.

| | |
|-------------|---|
| Command | SWITCH(config-router)#neighbor {address group-name} advertisement-interval <i>interval-time</i> |
| Description | <p>address: The address of the peer.</p> <p>group-name: The name of the peer group.</p> <p>interval-time: The minimum interval for sending routing updates, in seconds, ranging from 1 to 600. The default value is 5 seconds for IBGP peers and 30 seconds for EBGP peers.</p> |

Configure the minimum interval for sending locally originated routing updates.

| | |
|-------------|---|
| Command | SWITCH(config-router)#neighbor {address group-name} as-origination-interval <i>interval-time</i> |
| Description | <p>address: indicates the address of the peer.</p> <p>group-name: indicates the name of the peer group.</p> <p>interval-time: indicates the minimum interval for sending routing updates, in seconds, ranging from 1 to 600. The default value is 1 second.</p> |

15.3. Examples


15.3.1. BGP Basic Configuration

15.3.1.1. Create peer

Need

- 3 devices exchange routes using BGP protocol;
- S1 and S2 establish IBGP neighbors, S1 and S3 establish EBGP neighbors

Networking



Configuration example

- Device S1 configuration steps

Create a BGP process

```
S1#configure terminal
S1(config)#router bgp 100
S1(config-router)#neighbor 10.10.1.2 remote-as 100
S1(config-router)#neighbor 10.10.2.2 remote-as 200
S1(config-router)#network 192.168.1.0/24
```

Configure the ip address of port gigabitEthernet0/1

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/1
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.1.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/2
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.2.1/24
```

Configure the ip address of port gigabitEthernet0/3

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/3
S1(config-if)#no switchport
S1(config-if)#ip address 192.168.1.1/24
```

- Device S2 configuration steps

Create a BGP process

```
S2#configure terminal
S2(config)#router bgp 100
S2(config-router)#neighbor 10.10.1.1 remote-as 100
S2(config-router)#network 192.168.2.0/24
```

Configure the ip address of port gigabitEthernet0/1

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/1
S2(config-if)#no switchport
S2(config-if)#ip address 10.10.1.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/2
S2(config-if)#no switchport
S2(config-if)#ip address 192.168.2.1/24
```

- Device S3 configuration steps

Create a BGP process

```
S3#configure terminal
S3(config)#router bgp 200
S3(config-router)#neighbor 10.10.2.1 remote-as 100
S3(config-router)#network 192.168.3.0/24
```

Configure the ip address of port gigabitEthernet0/1

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/1
S3(config-if)#no switchport
S3(config-if)#ip address 10.10.2.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/2
S3(config-if)#no switchport
S3(config-if)#ip address 192.168.3.1/24
```

- Show result

Device S1:

Display bgp neighbor information and routing table on device S1

```
S1#show ip bgp neighbors
BGP neighbor is 10.10.1.2, remote AS 100, local AS 100, internal link
  BGP version 4, remote router ID 192.168.2.1
  BGP state = Established, up for 00:07:20
  Last read 00:07:20, hold time is 180, keepalive interval is 60 seconds
  Neighbor capabilities:
    Route refresh: advertised and received (old and new)
    Four-octets ASN Capability: advertised and received
    Address family IPv4 Unicast: advertised and received
  Received 12 messages, 0 notifications, 0 in queue
```

Sent 12 messages, 0 notifications, 0 in queue
Route refresh request: received 0, sent 0
Minimum time between advertisement runs is 0 seconds

For address family: IPv4 Unicast
BGP table version 3, neighbor version 3
Index 1, Offset 0, Mask 0x2
Community attribute sent to this neighbor (both)
1 accepted prefixes
4 announced prefixes

Connections established 1; dropped 0
Local host: 10.10.1.1, Local port: 179
Foreign host: 10.10.1.2, Foreign port: 51608
Nexthop: 10.10.1.1

BGP neighbor is 10.10.2.2, remote AS 200, local AS 100, external link
BGP version 4, remote router ID 192.168.3.1
BGP state = Established, up for 00:07:20
Last read 00:07:19, hold time is 180, keepalive interval is 60 seconds
Neighbor capabilities:
Route refresh: advertised and received (old and new)
Four-octets ASN Capability: advertised and received
Address family IPv4 Unicast: advertised and received
Received 12 messages, 0 notifications, 0 in queue
Sent 12 messages, 0 notifications, 0 in queue
Route refresh request: received 0, sent 0
Minimum time between advertisement runs is 30 seconds

For address family: IPv4 Unicast
BGP table version 3, neighbor version 3
Index 2, Offset 0, Mask 0x4
Community attribute sent to this neighbor (both)
1 accepted prefixes
4 announced prefixes

Connections established 1; dropped 0
Local host: 10.10.2.1, Local port: 58948
Foreign host: 10.10.2.2, Foreign port: 179
Nexthop: 10.10.2.1
Last Reset: , due to BGP Notification received
Notification Error Message: (Cease/Other Configuration Change.)

S1#

S1#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

*** - candidate default**

IP Route Table for VRF "default"

C 10.10.1.0/24 is directly connected, gigabitEthernet0/1
C 10.10.2.0/24 is directly connected, gigabitEthernet0/2
C 192.168.1.0/24 is directly connected, gigabitEthernet0/3
B 192.168.2.0/24 [200/0] via 10.10.1.2, gigabitEthernet0/1, 00:07:24
B 192.168.3.0/24 [20/0] via 10.10.2.2, gigabitEthernet0/2, 00:07:24
C 192.168.101.0/24 is directly connected, gigabitEthernet0/24

Gateway of last resort is not set

S1#

Device S2:

Display bgp neighbor information and routing table on device S2

S2#show ip bgp neighbors

BGP neighbor is 10.10.1.1, remote AS 100, local AS 100, internal link

BGP version 4, remote router ID 10.10.1.1

BGP state = Established, up for 00:08:33

Last read 00:08:32, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 115 messages, 0 notifications, 0 in queue

Sent 108 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 0 seconds

For address family: IPv4 Unicast

BGP table version 10, neighbor version 10

Index 1, Offset 0, Mask 0x2

Community attribute sent to this neighbor (both)

4 accepted prefixes

1 announced prefixes

Connections established 4; dropped 3

Local host: 10.10.1.2, Local port: 51608

Foreign host: 10.10.1.1, Foreign port: 179

Nexthop: 10.10.1.2

S2#

S2#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

*** - candidate default**

IP Route Table for VRF "default"

C 10.10.1.0/24 is directly connected, gigabitEthernet0/1

B 192.168.1.0/24 [200/0] via 10.10.1.1, gigabitEthernet0/1, 00:08:35

C 192.168.2.0/24 is directly connected, gigabitEthernet0/2

Gateway of last resort is not set

S2#

Device S3:

Display bgp neighbor information and routing table on device S3

S3#show ip bgp neighbors

BGP neighbor is 10.10.2.1, remote AS 100, local AS 200, external link

BGP version 4, remote router ID 10.10.1.1

BGP state = Established, up for 00:09:09

Last read 00:09:08, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 125 messages, 0 notifications, 0 in queue

Sent 114 messages, 3 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 30 seconds

For address family: IPv4 Unicast

BGP table version 5, neighbor version 4

Index 1, Offset 0, Mask 0x2

Community attribute sent to this neighbor (both)

4 accepted prefixes

1 announced prefixes

Connections established 4; dropped 3

Local host: 10.10.2.2, Local port: 179

Foreign host: 10.10.2.1, Foreign port: 58948

NextHop: 10.10.2.2

Last Reset: 00:10:40, due to BGP Notification received

Notification Error Message: (Cease/Other Configuration Change.)

S3#

S3#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

*** - candidate default**

IP Route Table for VRF "default"

C 10.10.2.0/24 is directly connected, gigabitEthernet0/1

B 192.168.1.0/24 [20/0] via 10.10.2.1, gigabitEthernet0/1, 00:09:11

B 192.168.2.0/24 [20/0] via 10.10.2.1, gigabitEthernet0/1, 00:09:11

C 192.168.3.0/24 is directly connected, vlan200

Gateway of last resort is not set


S3#

15.3.1.2. Create peer group

Need

- **S1, S2, S3, S4, 4 devices use BGP protocol to exchange routes;**
- **S1, S2, S3 establish IBGP neighbors; S1 and S4 establish EBGP neighbors;**
- **Create a peer group on S3**

Networking



Configuration example

- Device S1 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/1
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.1.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/2
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.2.1/24
```

Configure the ip address of port gigabitEthernet0/3

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/3
S1(config-if)#no switchport
S1(config-if)#ip address 192.168.1.1/24
```

Configure the ip address of port gigabitEthernet0/4

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/4
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.3.1/24
```

Create a BGP process and peer group, the peer group is named peer-group-test

```
S1#configure terminal
S1(config)#router bgp 1000
S1(config-router)#neighbor peer-group-test peer-group
```

```
S1(config-router)#neighbor peer-group-test remote-as 1000
S1(config-router)#neighbor peer-group-test next-hop-self
S1(config-router)#neighbor 10.10.1.2 peer-group peer-group-test
S1(config-router)#neighbor 10.10.2.2 peer-group peer-group-test
S1(config-router)#neighbor 10.10.3.2 remote-as 2000
S1(config-router)#network 192.168.1.0/24
S1(config-router)#network 10.10.1.0/24
S1(config-router)#network 10.10.2.0/24
S1(config-router)#network 10.10.3.0/24
```

- Device S2 configuration steps

Create a BGP process

```
S2#configure terminal
S2(config)#router bgp 1000
S2(config-router)#neighbor 10.10.1.1 remote-as 1000
S2(config-router)#network 192.168.2.0/24
```

Configure the ip address of port gigabitEthernet0/1

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/1
S2(config-if)#no switchport
S2(config-if)#ip address 10.10.1.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/2
S2(config-if)#no switchport
S2(config-if)#ip address 192.168.2.1/24
```

- Device S3 configuration steps

Create a BGP process

```
S3#configure terminal
S3(config)#router bgp 200
S3(config-router)#neighbor 10.10.2.1 remote-as 100
S3(config-router)#network 192.168.3.0/24
```

Configure the ip address of port gigabitEthernet0/1

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/1
S3(config-if)#no switchport
S3(config-if)#ip address 10.10.2.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/2
S3(config-if)#no switchport
S3(config-if)#ip address 192.168.3.1/24
```

- Device S4 configuration steps

Create a BGP process


```
S4#configure terminal
S4(config)#router bgp 2000
S4(config-router)#neighbor 10.10.3.1 remote-as 1000
S4(config-router)#network 192.168.4.0/24
```

Configure the ip address of port gigabitEthernet0/1

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/1
S4(config-if)#no switchport
S4(config-if)#ip address 10.10.3.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/2
S4(config-if)#no switchport
S4(config-if)#ip address 192.168.4.1/24
```

- Show result

Device S1:

Display bgp neighbor information and routing table on device S1

```
S1#show ip bgp neighbors
BGP neighbor is 10.10.1.2, remote AS 1000, local AS 1000, internal link
Member of peer-group peer-group-test for session parameters
  BGP version 4, remote router ID 10.10.1.2
  BGP state = Established, up for 00:05:53
  Last read 00:05:52, hold time is 180, keepalive interval is 60 seconds
  Neighbor capabilities:
    Route refresh: advertised and received (old and new)
    Four-octets ASN Capability: advertised and received
    Address family IPv4 Unicast: advertised and received
  Received 10 messages, 0 notifications, 0 in queue
  Sent 10 messages, 0 notifications, 0 in queue
  Route refresh request: received 0, sent 0
  Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast
  BGP table version 4, neighbor version 4
  Index 1, Offset 0, Mask 0x2
  peer-group-test peer-group member
  NEXT_HOP is always this router
  Community attribute sent to this neighbor (both)
  1 accepted prefixes
  5 announced prefixes

Connections established 1; dropped 0
Local host: 10.10.1.1, Local port: 43269
Foreign host: 10.10.1.2, Foreign port: 179
```

Nexthop: 10.10.1.1

BGP neighbor is 10.10.2.2, remote AS 1000, local AS 1000, internal link

Member of peer-group peer-group-test for session parameters

BGP version 4, remote router ID 192.168.3.1

BGP state = Established, up for 00:05:51

Last read 00:05:50, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 10 messages, 0 notifications, 0 in queue

Sent 11 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast

BGP table version 4, neighbor version 4

Index 2, Offset 0, Mask 0x4

peer-group-test peer-group member

NEXT_HOP is always this router

Community attribute sent to this neighbor (both)

1 accepted prefixes

5 announced prefixes

Connections established 1; dropped 0

Local host: 10.10.2.1, Local port: 179

Foreign host: 10.10.2.2, Foreign port: 41039

Nexthop: 10.10.2.1

BGP neighbor is 10.10.3.2, remote AS 2000, local AS 1000, external link

BGP version 4, remote router ID 192.168.4.1

BGP state = Established, up for 00:05:10

Last read 00:05:09, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 10 messages, 0 notifications, 0 in queue

Sent 9 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 30 seconds

For address family: IPv4 Unicast

BGP table version 4, neighbor version 3
Index 3, Offset 0, Mask 0x8
Community attribute sent to this neighbor (both)
1 accepted prefixes
6 announced prefixes

Connections established 1; dropped 0
Local host: 10.10.3.1, Local port: 179
Foreign host: 10.10.3.2, Foreign port: 57299
Next hop: 10.10.3.1
Last Reset: , due to BGP Notification received
Notification Error Message: (Cease/Other Configuration Change.)

S1#

S1#

S1#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

C 10.10.1.0/24 is directly connected, gigabitEthernet0/1
C 10.10.2.0/24 is directly connected, gigabitEthernet0/2
C 10.10.3.0/24 is directly connected, gigabitEthernet0/4
C 192.168.1.0/24 is directly connected, gigabitEthernet0/3
B 192.168.2.0/24 [200/0] via 10.10.1.2, gigabitEthernet0/1, 00:05:56
B 192.168.3.0/24 [200/0] via 10.10.2.2, gigabitEthernet0/2, 00:05:54
B 192.168.4.0/24 [20/0] via 10.10.3.2, gigabitEthernet0/4, 00:05:13

Gateway of last resort is not set

S1#

Device S2:

Display bgp neighbor information and routing table on device S2

S2#show ip bgp neighbors

BGP neighbor is 10.10.1.1, remote AS 1000, local AS 1000, internal link

BGP version 4, remote router ID 10.10.1.1

BGP state = Established, up for 00:06:47

Last read 00:06:02, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received
Received 14 messages, 0 notifications, 0 in queue
Sent 10 messages, 0 notifications, 0 in queue
Route refresh request: received 0, sent 0
Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast
BGP table version 2, neighbor version 1
Index 1, Offset 0, Mask 0x2
Community attribute sent to this neighbor (both)
5 accepted prefixes
1 announced prefixes

Connections established 1; dropped 0
Local host: 10.10.1.2, Local port: 179
Foreign host: 10.10.1.1, Foreign port: 43269
Next hop: 10.10.1.2

S2#

S2#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP
O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default

IP Route Table for VRF "default"

| | |
|---|--|
| C | 10.10.1.0/24 is directly connected, gigabitEthernet0/1 |
| B | 10.10.2.0/24 [200/0] via 10.10.1.1, gigabitEthernet0/1, 00:06:50 |
| B | 10.10.3.0/24 [200/0] via 10.10.1.1, gigabitEthernet0/1, 00:06:37 |
| B | 192.168.1.0/24 [200/0] via 10.10.1.1, gigabitEthernet0/1, 00:06:50 |
| C | 192.168.2.0/24 is directly connected, gigabitEthernet0/2 |
| B | 192.168.4.0/24 [200/0] via 10.10.1.1, gigabitEthernet0/1, 00:06:06 |

Gateway of last resort is not set

S2#

Device S3:

Display bgp neighbor information and routing table on device S3

S3#show ip bgp neighbors

BGP neighbor is 10.10.2.1, remote AS 1000, local AS 1000, internal link
BGP version 4, remote router ID 10.10.1.1
BGP state = Established, up for 00:10:10
Last read 00:09:27, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 19 messages, 0 notifications, 0 in queue

Sent 15 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast

BGP table version 2, neighbor version 1

Index 1, Offset 0, Mask 0x2

Community attribute sent to this neighbor (both)

5 accepted prefixes

1 announced prefixes

Connections established 1; dropped 0

Local host: 10.10.2.2, Local port: 41039

Foreign host: 10.10.2.1, Foreign port: 179

Next hop: 10.10.2.2

S3#

S3#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

B 10.10.1.0/24 [200/0] via 10.10.2.1, gigabitEthernet0/1, 00:10:11

C 10.10.2.0/24 is directly connected, gigabitEthernet0/1

B 10.10.3.0/24 [200/0] via 10.10.2.1, gigabitEthernet0/1, 00:10:00

B 192.168.1.0/24 [200/0] via 10.10.2.1, gigabitEthernet0/1, 00:10:11

C 192.168.3.0/24 is directly connected, vlan200

B 192.168.4.0/24 [200/0] via 10.10.2.1, gigabitEthernet0/1, 00:09:29

Gateway of last resort is not set

S3#

Device S4:

Display bgp neighbor information and routing table on device S4

S4#show ip bgp neighbors

BGP neighbor is 10.10.3.1, remote AS 1000, local AS 2000, external link

BGP version 4, remote router ID 10.10.1.1
BGP state = Established, up for 00:10:14
Last read 00:10:13, hold time is 180, keepalive interval is 60 seconds
Neighbor capabilities:
Route refresh: advertised and received (old and new)
Four-octets ASN Capability: advertised and received
Address family IPv4 Unicast: advertised and received
Received 17 messages, 0 notifications, 0 in queue
Sent 15 messages, 0 notifications, 0 in queue
Route refresh request: received 0, sent 0
Minimum time between advertisement runs is 30 seconds

For address family: IPv4 Unicast
BGP table version 2, neighbor version 1
Index 1, Offset 0, Mask 0x2
Community attribute sent to this neighbor (both)
6 accepted prefixes
1 announced prefixes

Connections established 1; dropped 0
Local host: 10.10.3.2, Local port: 57299
Foreign host: 10.10.3.1, Foreign port: 179
Next hop: 10.10.3.2
Last Reset: , due to BGP Notification received
Notification Error Message: (Cease/Other Configuration Change.)

S4#

S4#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP
O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default

IP Route Table for VRF "default"

| | |
|---|---|
| B | 10.10.1.0/24 [20/0] via 10.10.3.1, gigabitEthernet0/1, 00:10:18 |
| B | 10.10.2.0/24 [20/0] via 10.10.3.1, gigabitEthernet0/1, 00:10:18 |
| C | 10.10.3.0/24 is directly connected, gigabitEthernet0/1 |
| B | 192.168.1.0/24 [20/0] via 10.10.3.1, gigabitEthernet0/1, 00:10:18 |
| B | 192.168.2.0/24 [20/0] via 10.10.3.1, gigabitEthernet0/1, 00:10:18 |
| B | 192.168.3.0/24 [20/0] via 10.10.3.1, gigabitEthernet0/1, 00:10:18 |
| C | 192.168.4.0/24 is directly connected, gigabitEthernet0/2 |

Gateway of last resort is not set


S4#

15.3.2. Route Reflector Configuration

Need

- 4 devices exchange routes using BGP protocol;
- S1 acts as a route reflector, and S2, S3, and S4 act as clients;

Networking



Configuration example

- Device S1 configuration steps

Configure the ip address of port gigabitEthernet0/1

S1#configure terminal

S1(config)#interface gigabitEthernet0/1

S1(config-if)#no switchport

S1(config-if)#ip address 10.10.1.1/24

Configure the ip address of port gigabitEthernet0/2

S1#configure terminal

S1(config)#interface gigabitEthernet0/2

S1(config-if)#no switchport

S1(config-if)#ip address 10.10.2.1/24

Configure the ip address of port gigabitEthernet0/4

S1#configure terminal

S1(config)#interface gigabitEthernet0/4

S1(config-if)#no switchport

S1(config-if)#ip address 10.10.3.1/24

Create a BGP process with reflector and client

S1#configure terminal

S1(config)#router bgp 1000

S1(config-router)#neighbor 10.10.1.2 remote-as 1000

```
S1(config-router)#neighbor 10.10.1.2 route-reflector-client
S1(config-router)#neighbor 10.10.2.2 remote-as 1000
S1(config-router)#neighbor 10.10.2.2 route-reflector-client
S1(config-router)#neighbor 10.10.3.2 remote-as 1000
S1(config-router)#neighbor 10.10.3.2 route-reflector-client
S1(config-router)#network 10.10.1.0/24
S1(config-router)#network 10.10.2.0/24
S1(config-router)#network 10.10.3.0/24
```

- Device S2 configuration steps

Create a BGP process

```
S2#configure terminal
S2(config)#router bgp 100
S2(config-router)#neighbor 10.10.1.1 remote-as 100
S2(config-router)#network 192.168.2.0/24
```

Configure the ip address of port gigabitEthernet0/1

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/1
S2(config-if)#no switchport
S2(config-if)#ip address 10.10.1.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/2
S2(config-if)#no switchport
S2(config-if)#ip address 192.168.2.1/24
```

- Device S3 configuration steps

Create a BGP process

```
S3#configure terminal
S3(config)#router bgp 200
S3(config-router)#neighbor 10.10.2.1 remote-as 100
S3(config-router)#network 192.168.3.0/24
```

Configure the ip address of port gigabitEthernet0/1

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/1
S3(config-if)#no switchport
S3(config-if)#ip address 10.10.2.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/2
S3(config-if)#no switchport
S3(config-if)#ip address 192.168.3.1/24
```

- Device S4 configuration steps

Create a BGP process

```
S4#configure terminal
```



```
S4(config)#router bgp 1000
S4(config-router)#neighbor 10.10.3.1 remote-as 1000
S4(config-router)#network 192.168.4.0/24
```

Configure the ip address of port gigabitEthernet0/1

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/1
S4(config-if)#no switchport
S4(config-if)#ip address 10.10.3.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/2
S4(config-if)#no switchport
S4(config-if)#ip address 192.168.4.1/24
```

- Show result

Device S1:

Display bgp neighbor information and routing table on device S1

```
S1#show ip bgp neighbors
BGP neighbor is 10.10.1.2, remote AS 1000, local AS 1000, internal link
  BGP version 4, remote router ID 10.10.1.2
  BGP state = Established, up for 00:06:08
  Last read 00:06:07, hold time is 180, keepalive interval is 60 seconds
  Neighbor capabilities:
    Route refresh: advertised and received (old and new)
    Four-octets ASN Capability: advertised and received
    Address family IPv4 Unicast: advertised and received
  Received 11 messages, 0 notifications, 0 in queue
  Sent 11 messages, 0 notifications, 0 in queue
  Route refresh request: received 0, sent 0
  Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast
  BGP table version 3, neighbor version 3
  Index 1, Offset 0, Mask 0x2
  Route-Reflector Client
  NEXT_HOP is always this router
  Community attribute sent to this neighbor (both)
  1 accepted prefixes
  5 announced prefixes

Connections established 1; dropped 0
Local host: 10.10.1.1, Local port: 46298
Foreign host: 10.10.1.2, Foreign port: 179
Nexthop: 10.10.1.1
Last Reset:          , due to BGP Notification received
```

Notification Error Message: (Cease/Other Configuration Change.)

BGP neighbor is 10.10.2.2, remote AS 1000, local AS 1000, internal link

BGP version 4, remote router ID 192.168.3.1

BGP state = Established, up for 00:06:13

Last read 00:06:12, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 11 messages, 0 notifications, 0 in queue

Sent 12 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast

BGP table version 3, neighbor version 3

Index 2, Offset 0, Mask 0x4

Route-Reflector Client

NEXT_HOP is always this router

Community attribute sent to this neighbor (both)

1 accepted prefixes

5 announced prefixes

Connections established 1; dropped 0

Local host: 10.10.2.1, Local port: 179

Foreign host: 10.10.2.2, Foreign port: 48706

Nexthop: 10.10.2.1

Last Reset: , due to BGP Notification received

Notification Error Message: (Cease/Other Configuration Change.)

BGP neighbor is 10.10.3.2, remote AS 1000, local AS 1000, internal link

BGP version 4, remote router ID 192.168.4.1

BGP state = Established, up for 00:05:58

Last read 00:05:57, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 11 messages, 0 notifications, 0 in queue

Sent 11 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast

BGP table version 3, neighbor version 2

Index 3, Offset 0, Mask 0x8

Route-Reflector Client

NEXT_HOP is always this router

Community attribute sent to this neighbor (both)

1 accepted prefixes

5 announced prefixes

Connections established 1; dropped 0

Local host: 10.10.3.1, Local port: 179

Foreign host: 10.10.3.2, Foreign port: 42775

Nexthop: 10.10.3.1

Last Reset: , due to BGP Notification received

Notification Error Message: (Cease/Other Configuration Change.)

S1#

S1#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

C 10.10.1.0/24 is directly connected, gigabitEthernet0/1

C 10.10.2.0/24 is directly connected, gigabitEthernet0/2

C 10.10.3.0/24 is directly connected, gigabitEthernet0/4

C 192.168.1.0/24 is directly connected, gigabitEthernet0/3

B 192.168.2.0/24 [200/0] via 10.10.1.2, gigabitEthernet0/1, 00:06:09

B 192.168.3.0/24 [200/0] via 10.10.2.2, gigabitEthernet0/2, 00:06:14

B 192.168.4.0/24 [200/0] via 10.10.3.2, gigabitEthernet0/4, 00:05:59

Gateway of last resort is not set

S1#

Device S2:

Display bgp neighbor information and routing table on device S2

S2#show ip bgp neighbors

BGP neighbor is 10.10.1.1, remote AS 1000, local AS 1000, internal link

BGP version 4, remote router ID 192.168.1.1

BGP state = Established, up for 00:03:00

Last read 00:02:49, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)
Four-octets ASN Capability: advertised and received
Address family IPv4 Unicast: advertised and received
Received 11 messages, 0 notifications, 0 in queue
Sent 6 messages, 0 notifications, 0 in queue
Route refresh request: received 0, sent 0
Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast
BGP table version 2, neighbor version 1
Index 1, Offset 0, Mask 0x2
Community attribute sent to this neighbor (both)
5 accepted prefixes
1 announced prefixes

Connections established 1; dropped 0
Local host: 10.10.1.2, Local port: 179
Foreign host: 10.10.1.1, Foreign port: 46298
Nexthop: 10.10.1.2

S2#

S2#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP
O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default

IP Route Table for VRF "default"

| | |
|---|---|
| C | 10.10.1.0/24 is directly connected, gigabitEthernet0/1 |
| B | 10.10.2.0/24 [200/0] via 10.10.1.1, gigabitEthernet0/1, 00:03:03 |
| B | 10.10.3.0/24 [200/0] via 10.10.1.1, gigabitEthernet0/1, 00:03:03 |
| C | 192.168.2.0/24 is directly connected, gigabitEthernet0/2 |
| B | 192.168.3.0/24 [200/0] via 10.10.2.2 (recursive via 10.10.1.1), 00:02:57 |
| B | 192.168.4.0/24 [200/0] via 10.10.3.2 (recursive via 10.10.1.1), 00:02:53 |

Gateway of last resort is not set

S2#

Device S3:

Display bgp neighbor information and routing table on device S3

S3#show ip bgp neighbors

BGP neighbor is 10.10.2.1, remote AS 1000, local AS 1000, internal link
BGP version 4, remote router ID 192.168.1.1

BGP state = Established, up for 00:03:50
Last read 00:03:34, hold time is 180, keepalive interval is 60 seconds
Neighbor capabilities:
Route refresh: advertised and received (old and new)
Four-octets ASN Capability: advertised and received
Address family IPv4 Unicast: advertised and received
Received 12 messages, 0 notifications, 0 in queue
Sent 7 messages, 0 notifications, 0 in queue
Route refresh request: received 0, sent 0
Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast
BGP table version 2, neighbor version 1
Index 1, Offset 0, Mask 0x2
Community attribute sent to this neighbor (both)
5 accepted prefixes
1 announced prefixes

Connections established 1; dropped 0
Local host: 10.10.2.2, Local port: 48706
Foreign host: 10.10.2.1, Foreign port: 179
Nexthop: 10.10.2.2

S3#

S3#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP
O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default

IP Route Table for VRF "default"

| | |
|---|---|
| B | 10.10.1.0/24 [200/0] via 10.10.2.1, gigabitEthernet0/1, 00:03:53 |
| C | 10.10.2.0/24 is directly connected, gigabitEthernet0/1 |
| B | 10.10.3.0/24 [200/0] via 10.10.2.1, gigabitEthernet0/1, 00:03:53 |
| B | 192.168.2.0/24 [200/0] via 10.10.1.2 (recursive via 10.10.2.1), 00:03:47 |
| C | 192.168.3.0/24 is directly connected, vlan200 |
| B | 192.168.4.0/24 [200/0] via 10.10.3.2 (recursive via 10.10.2.1), 00:03:38 |

Gateway of last resort is not set

S3#

Device S4:

Display bgp neighbor information and routing table on device S4

S4#show ip bgp neighbors

BGP neighbor is 10.10.3.1, remote AS 1000, local AS 1000, internal link

BGP version 4, remote router ID 192.168.1.1

BGP state = Established, up for 00:04:14

Last read 00:04:13, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 12 messages, 0 notifications, 0 in queue

Sent 7 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast

BGP table version 2, neighbor version 1

Index 1, Offset 0, Mask 0x2

Community attribute sent to this neighbor (both)

5 accepted prefixes

1 announced prefixes

Connections established 1; dropped 0

Local host: 10.10.3.2, Local port: 42775

Foreign host: 10.10.3.1, Foreign port: 179

Nexthop: 10.10.3.2

S4#

S4#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

*** - candidate default**

IP Route Table for VRF "default"

B 10.10.1.0/24 [200/0] via 10.10.3.1, gigabitEthernet0/1, 00:04:19

B 10.10.2.0/24 [200/0] via 10.10.3.1, gigabitEthernet0/1, 00:04:19

C 10.10.3.0/24 is directly connected, gigabitEthernet0/1

B 192.168.2.0/24 [200/0] via 10.10.1.2 (recursive via 10.10.3.1), 00:04:13

B 192.168.3.0/24 [200/0] via 10.10.2.2 (recursive via 10.10.3.1), 00:04:13

C 192.168.4.0/24 is directly connected, gigabitEthernet0/2

Gateway of last resort is not set


S4#

15.3.3. AS confederation configuration

Need

- 4 devices exchange routes using BGP protocol;
- S1, S2, and S3 are in the same confederation, S1 and S2 establish IBGP neighbors, and S1 and S3 establish EBGP neighbors;
- S4 establishes an EBGP neighbor relationship with the confederation where S1 is located;

Networking



Configuration example

- Device S1 configuration steps

Configure the ip address of port gigabitEthernet0/1

S1#configure terminal

S1(config)#interface gigabitEthernet0/1

S1(config-if)#no switchport

S1(config-if)#ip address 10.10.1.1/24

Configure the ip address of port gigabitEthernet0/2

S1#configure terminal

S1(config)#interface gigabitEthernet0/2

S1(config-if)#no switchport

S1(config-if)#ip address 10.10.2.1/24

Configure the ip address of port gigabitEthernet0/4

S1#configure terminal

S1(config)#interface gigabitEthernet0/4

S1(config-if)#no switchport

S1(config-if)#ip address 10.10.3.1/24

Create a BGP process and configure confederation.

The AS number is 1000, the confederation number is 111, the AS number of the EBGP within the confederation is 2000, and the AS number of the EBGP outside the confederation is 222.

```
S1#configure terminal
S1(config)#router bgp 1000
S1(config-router)#bgp confederation identifier 111
S1(config-router)#bgp confederation peers 2000
S1(config-router)#neighbor 10.10.1.2 remote-as 1000
S1(config-router)#neighbor 10.10.2.2 remote-as 2000
S1(config-router)#neighbor 10.10.3.2 remote-as 222
S1(config-router)#network 10.10.1.0/24
S1(config-router)#network 10.10.2.0/24
S1(config-router)#network 10.10.3.0/24
```

- Device S2 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/1
S2(config-if)#no switchport
S2(config-if)#ip address 10.10.1.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/2
S2(config-if)#no switchport
S2(config-if)#ip address 192.168.2.1/24
```

Create a BGP process

```
S2#configure terminal
S2(config)#router bgp 1000
S2(config-router)#bgp confederation identifier 111
S2(config-router)#neighbor 10.10.1.1 remote-as 1000
S2(config-router)#network 192.168.2.0/24
```

- Device S3 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/1
S3(config-if)#no switchport
S3(config-if)#ip address 10.10.2.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/2
S3(config-if)#no switchport
S3(config-if)#ip address 192.168.3.1/24
```

Create a BGP process

The AS number is 2000, the confederation number is 111, and the EBGp AS number in the confederation is 1000. It is necessary to establish a fully connected neighbor relationship with all devices in the confederation.

```
S3#configure terminal
S3(config)#router bgp 2000
S3(config-router)#bgp confederation identifier 111
```



```
S3(config-router)#neighbor 10.10.1.2 remote-as 1000
S3(config-router)#neighbor 10.10.2.1 remote-as 1000
S3(config-router)#network 192.168.3.0/24
```

- Device S4 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/1
S4(config-if)#no switchport
S4(config-if)#ip address 10.10.3.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/2
S4(config-if)#no switchport
S4(config-if)#ip address 192.168.4.1/24
```

Create a BGP process

The AS number is 222, and a neighbor relationship needs to be established with the device 10.10.3.1 whose AS number is 111 (actually the AS number of the confederation).

```
S4#configure terminal
S4(config)#router bgp 222
S4(config-router)#neighbor 10.10.3.1 remote-as 111
S4(config-router)#network 192.168.4.0/24
```

- Show result

Device S1:

Display bgp neighbor information and routing table on device S1

```
S1#show ip bgp neighbors
BGP neighbor is 10.10.1.2, remote AS 1000, local AS 1000, internal link
  BGP version 4, remote router ID 10.10.1.2
  BGP state = Established, up for 02:43:59
  Last read 02:43:58, hold time is 180, keepalive interval is 60 seconds
  Neighbor capabilities:
    Route refresh: advertised and received (old and new)
    Four-octets ASN Capability: advertised and received
    Address family IPv4 Unicast: advertised and received
  Received 1316 messages, 0 notifications, 0 in queue
  Sent 1326 messages, 1 notifications, 0 in queue
  Route refresh request: received 0, sent 0
  Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast
  BGP table version 16, neighbor version 16
  Index 1, Offset 0, Mask 0x2
  Community attribute sent to this neighbor (both)
  1 accepted prefixes
  5 announced prefixes
```

Connections established 2; dropped 1

Local host: 10.10.1.1, Local port: 46323

Foreign host: 10.10.1.2, Foreign port: 179

Nexthop: 10.10.1.1

Last Reset: 02:44:35, due to BGP Notification received

Notification Error Message: (Cease/Other Configuration Change.)

BGP neighbor is 10.10.2.2, remote AS 2000, local AS 1000, external link

BGP version 4, remote router ID 192.168.3.1

Neighbor under common administration

BGP state = Established, up for 02:39:32

Last read 02:39:31, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 1308 messages, 1 notifications, 0 in queue

Sent 1312 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 30 seconds

For address family: IPv4 Unicast

BGP table version 16, neighbor version 16

Index 2, Offset 0, Mask 0x4

Community attribute sent to this neighbor (both)

1 accepted prefixes

5 announced prefixes

Connections established 2; dropped 1

Local host: 10.10.2.1, Local port: 59371

Foreign host: 10.10.2.2, Foreign port: 179

Nexthop: 10.10.2.1

Last Reset: 02:40:09, due to BGP Notification received

Notification Error Message: (Cease/Other Configuration Change.)

BGP neighbor is 10.10.3.2, remote AS 222, local AS 111, external link

BGP version 4, remote router ID 192.168.4.1

BGP state = Established, up for 02:33:58

Last read 02:33:57, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 184 messages, 0 notifications, 0 in queue
Sent 187 messages, 0 notifications, 0 in queue
Route refresh request: received 0, sent 0
Minimum time between advertisement runs is 30 seconds

For address family: IPv4 Unicast
BGP table version 16, neighbor version 16
Index 3, Offset 0, Mask 0x8
Community attribute sent to this neighbor (both)
1 accepted prefixes
5 announced prefixes

Connections established 1; dropped 0
Local host: 10.10.3.1, Local port: 49367
Foreign host: 10.10.3.2, Foreign port: 179
Nexthop: 10.10.3.1

S1#

S1#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP
O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default

IP Route Table for VRF "default"

| | |
|---|--|
| C | 10.10.1.0/24 is directly connected, gigabitEthernet0/1 |
| C | 10.10.2.0/24 is directly connected, gigabitEthernet0/2 |
| C | 10.10.3.0/24 is directly connected, gigabitEthernet0/4 |
| C | 192.168.1.0/24 is directly connected, gigabitEthernet0/3 |
| B | 192.168.2.0/24 [200/0] via 10.10.1.2, gigabitEthernet0/1, 02:44:03 |
| B | 192.168.3.0/24 [200/0] via 10.10.2.2, gigabitEthernet0/2, 02:39:36 |
| B | 192.168.4.0/24 [20/0] via 10.10.3.2, gigabitEthernet0/4, 02:34:02 |

Gateway of last resort is not set

S1#

S1#show ip bgp

BGP table version is 16, local router ID is 192.168.1.1

Status codes: s suppressed, d damped, h history, * valid, > best, i - internal,
S Stale

Origin codes: i - IGP, e - EGP, ? - incomplete

| Network | Next Hop | Metric | LocPrf | Weight Path |
|---------|----------|--------|--------|-------------|
|---------|----------|--------|--------|-------------|

| | | | | | |
|-----------------|-----------|---|-----|----------|---|
| *> 10.10.1.0/24 | 0.0.0.0 | | 100 | 32768 | i |
| *> 10.10.2.0/24 | 0.0.0.0 | | 100 | 32768 | i |
| *> 10.10.3.0/24 | 0.0.0.0 | | 100 | 32768 | i |
| *>i192.168.2.0 | 10.10.1.2 | 0 | 100 | 0 | i |
| *> 192.168.3.0 | 10.10.2.2 | 0 | 100 | 0 (2000) | i |
| *> 192.168.4.0 | 10.10.3.2 | 0 | | 0 222 | i |

Total number of prefixes 6

S1#

Device S2:

Display bgp neighbor information and routing table on device S2

S2#show ip bgp neighbors

BGP neighbor is 10.10.1.1, remote AS 1000, local AS 1000, internal link

BGP version 4, remote router ID 192.168.1.1

BGP state = Established, up for 02:43:06

Last read 00:11:33, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 1341 messages, 1 notifications, 0 in queue

Sent 1313 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 5 seconds

For address family: IPv4 Unicast

BGP table version 3, neighbor version 2

Index 1, Offset 0, Mask 0x2

Community attribute sent to this neighbor (both)

4 accepted prefixes

1 announced prefixes

Connections established 2; dropped 1

Local host: 10.10.1.2, Local port: 179

Foreign host: 10.10.1.1, Foreign port: 46323

Nexthop: 10.10.1.2

Last Reset: 02:43:42, due to BGP Notification received

Notification Error Message: (Cease/Other Configuration Change.)

S2#

S2#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default

IP Route Table for VRF "default"

C 10.10.1.0/24 is directly connected, gigabitEthernet0/1
B 10.10.2.0/24 [200/0] via 10.10.1.1, gigabitEthernet0/1, 00:11:38
B 10.10.3.0/24 [200/0] via 10.10.1.1, gigabitEthernet0/1, 00:11:35
C 192.168.2.0/24 is directly connected, gigabitEthernet0/2
B 192.168.4.0/24 [200/0] via 10.10.3.2 (recursive via 10.10.1.1), 00:16:53

Gateway of last resort is not set

S2#

S2#show ip bgp

BGP table version is 3, local router ID is 10.10.1.2

Status codes: s suppressed, d damped, h history, * valid, > best, i - internal,
S Stale

Origin codes: i - IGP, e - EGP, ? - incomplete

| Network | Next Hop | Metric | LocPrf | Weight | Path |
|-----------------|-----------|--------|--------|--------|------|
| *>i10.10.1.0/24 | 10.10.1.1 | 0 | 100 | 0 | i |
| *>i10.10.2.0/24 | 10.10.1.1 | 0 | 100 | 0 | i |
| *>i10.10.3.0/24 | 10.10.1.1 | 0 | 100 | 0 | i |
| *> 192.168.2.0 | 0.0.0.0 | | 100 | 32768 | i |
| *>i192.168.4.0 | 10.10.3.2 | 0 | 100 | 0 222 | i |

Total number of prefixes 5

S2#

Device S3:

Display bgp neighbor information and routing table on device S3

S3#show ip bgp neighbors

BGP neighbor is 10.10.1.2, remote AS 1000, local AS 2000, external link

BGP version 4, remote router ID 0.0.0.0

Neighbor under common administration

BGP state = Connect

Last read , hold time is 180, keepalive interval is 60 seconds

Received 0 messages, 0 notifications, 0 in queue

Sent 0 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 30 seconds

For address family: IPv4 Unicast

BGP table version 2, neighbor version 0

Index 1, Offset 0, Mask 0x2

Community attribute sent to this neighbor (both)

0 accepted prefixes

0 announced prefixes

Connections established 0; dropped 0

Next connect timer due in 1 seconds

BGP neighbor is 10.10.2.1, remote AS 1000, local AS 2000, external link

BGP version 4, remote router ID 192.168.1.1

Neighbor under common administration

BGP state = Established, up for 02:36:36

Last read 00:09:10, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 203 messages, 0 notifications, 0 in queue

Sent 185 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 30 seconds

For address family: IPv4 Unicast

BGP table version 2, neighbor version 1

Index 3, Offset 0, Mask 0x8

Community attribute sent to this neighbor (both)

5 accepted prefixes

1 announced prefixes

Connections established 1; dropped 0

Local host: 10.10.2.2, Local port: 179

Foreign host: 10.10.2.1, Foreign port: 59371

Nexthop: 10.10.2.2

S3#

S3#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

B 10.10.1.0/24 [200/0] via 10.10.2.1, gigabitEthernet0/1, 00:09:41

```

C    10.10.2.0/24 is directly connected, gigabitEthernet0/1
B    10.10.3.0/24 [200/0] via 10.10.2.1, gigabitEthernet0/1, 00:09:13
B    192.168.2.0/24 [200/0] via 10.10.1.2 (recursive via 10.10.2.1 ), 00:14:44
C    192.168.3.0/24 is directly connected, vlan200
B    192.168.4.0/24 [200/0] via 10.10.3.2 (recursive via 10.10.2.1 ), 00:14:44

```

Gateway of last resort is not set

S3#

S3#show ip bgp

BGP table version is 2, local router ID is 192.168.3.1

Status codes: s suppressed, d damped, h history, * valid, > best, i - internal,

S Stale

Origin codes: i - IGP, e - EGP, ? - incomplete

| Network | Next Hop | Metric | LocPrf | Weight Path |
|-----------------|-----------|--------|--------|----------------|
| *> 10.10.1.0/24 | 10.10.2.1 | 0 | 100 | 0 (1000) i |
| *> 10.10.2.0/24 | 10.10.2.1 | 0 | 100 | 0 (1000) i |
| *> 10.10.3.0/24 | 10.10.2.1 | 0 | 100 | 0 (1000) i |
| *> 192.168.2.0 | 10.10.1.2 | 0 | 100 | 0 (1000) i |
| *> 192.168.3.0 | 0.0.0.0 | | 100 | 32768 i |
| *> 192.168.4.0 | 10.10.3.2 | 0 | 100 | 0 (1000) 222 i |

Total number of prefixes 6

S3#

Device S4:

Display bgp neighbor information and routing table on device S4

S4#show ip bgp neighbors

BGP neighbor is 10.10.3.1, remote AS 111, local AS 222, external link

BGP version 4, remote router ID 192.168.1.1

BGP state = Established, up for 02:30:24

Last read 00:08:38, hold time is 180, keepalive interval is 60 seconds

Neighbor capabilities:

Route refresh: advertised and received (old and new)

Four-octets ASN Capability: advertised and received

Address family IPv4 Unicast: advertised and received

Received 192 messages, 1 notifications, 0 in queue

Sent 181 messages, 0 notifications, 0 in queue

Route refresh request: received 0, sent 0

Minimum time between advertisement runs is 30 seconds

For address family: IPv4 Unicast

BGP table version 2, neighbor version 1

Index 1, Offset 0, Mask 0x2

Community attribute sent to this neighbor (both)

5 accepted prefixes
1 announced prefixes

Connections established 1; dropped 0
Local host: 10.10.3.2, Local port: 179
Foreign host: 10.10.3.1, Foreign port: 49367
Next hop: 10.10.3.2
Last Reset: 02:31:15, due to BGP Notification received
Notification Error Message: (OPEN Message Error/Bad Peer AS.)

S4#

S4#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP
O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default

IP Route Table for VRF "default"

B 10.10.1.0/24 [20/0] via 10.10.3.1, gigabitEthernet0/1, 00:09:03
B 10.10.2.0/24 [20/0] via 10.10.3.1, gigabitEthernet0/1, 00:08:40
C 10.10.3.0/24 is directly connected, gigabitEthernet0/1
B 192.168.2.0/24 [20/0] via 10.10.3.1, gigabitEthernet0/1, 02:30:25
B 192.168.3.0/24 [20/0] via 10.10.3.1, gigabitEthernet0/1, 02:30:25
C 192.168.4.0/24 is directly connected, gigabitEthernet0/2

Gateway of last resort is not set

S4#

S4#show ip bgp

BGP table version is 2, local router ID is 192.168.4.1

Status codes: s suppressed, d damped, h history, * valid, > best, i - internal,
S Stale

Origin codes: i - IGP, e - EGP, ? - incomplete

| Network | Next Hop | Metric | LocPrf | Weight | Path |
|-----------------|-----------|--------|--------|--------|-------|
| *> 10.10.1.0/24 | 10.10.3.1 | 0 | | 0 | 111 i |
| *> 10.10.2.0/24 | 10.10.3.1 | 0 | | 0 | 111 i |
| *> 10.10.3.0/24 | 10.10.3.1 | 0 | | 0 | 111 i |
| *> 192.168.2.0 | 10.10.3.1 | 0 | | 0 | 111 i |
| *> 192.168.3.0 | 10.10.3.1 | 0 | | 0 | 111 i |
| *> 192.168.4.0 | 0.0.0.0 | | 100 | 32768 | i |

Total number of prefixes 6


S4#

15.3.4. Multipath Load Balancing Configuration

Need

- 5 devices exchange routes using BGP protocol;
- Construct 2 multi-path load balancing scenarios;

Networking



Configuration example

- Device S1 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/1
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.1.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/2
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.2.1/24
```

Create a BGP process and multi-path load configuration and AS-PATH loose comparison mode

```
S1#configure terminal
S1(config)#router bgp 1000
S1(config-router)#neighbor 10.10.1.2 remote-as 1000
S1(config-router)#neighbor 10.10.2.2 remote-as 1000
S1(config-router)#bgp bestpath as-path multipath-relax
S1(config-router)#maximum-paths ibgp 2
```

- Device S2 configuration steps

Create a BGP process

```
S2#configure terminal
S2(config)#router bgp 1000
S2(config-router)#neighbor 10.10.1.1 remote-as 1000
S2(config-router)#network 10.10.3.0/24
```

Configure the ip address of port gigabitEthernet0/1

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/1
S2(config-if)#no switchport
S2(config-if)#ip address 10.10.1.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/2
S2(config-if)#no switchport
S2(config-if)#ip address 10.10.3.1/24
```

- Device S3 configuration steps

Create a BGP process

```
S3#configure terminal
S3(config)#router bgp 1000
S3(config-router)#neighbor 10.10.2.1 remote-as 1000
S3(config-router)#network 10.10.4.0/24
```

Configure the ip address of port gigabitEthernet0/1

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/1
S3(config-if)#no switchport
S3(config-if)#ip address 10.10.2.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/2
S3(config-if)#no switchport
S3(config-if)#ip address 10.10.4.1/24
```

- Device S4 configuration steps

Create a BGP process

```
S4#configure terminal
S4(config)#router bgp 2000
S4(config-router)#neighbor 10.10.3.1 remote-as 1000
S4(config-router)#network 10.11.0.0/16
```

Configure the ip address of port gigabitEthernet0/1

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/1
S4(config-if)#no switchport
S4(config-if)#ip address 10.10.3.2/24
```

Configure the ip address of port gigabitEthernet0/8

```
S4#configure terminal
```

```
S4(config)#interface gigabitEthernet0/8
S4(config-if)#no switchport
S4(config-if)#ip address 10.11.11.11/16
```

- Device S5 configuration steps

Create a BGP process

```
S5#configure terminal
S5(config)#router bgp 3000
S5(config-router)#neighbor 10.10.4.1 remote-as 1000
S5(config-router)#network 10.11.0.0/16
```

Configure the ip address of port gigabitEthernet0/1

```
S5#configure terminal
S5(config)#interface gigabitEthernet0/1
S5(config-if)#no switchport
S5(config-if)#ip address 10.10.4.2/24
```

Configure the ip address of port gigabitEthernet0/8

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/8
S4(config-if)#no switchport
S4(config-if)#ip address 10.11.12.12/16
```

- Show result

Device S1:

Display bgp neighbor information and routing table on device S1, There are two routes on S1 to 10.11.0.0/16.

```
S1#show ip bgp summary
```

BGP router identifier 192.168.1.1, local AS number 1000

BGP table version is 23

3 BGP AS-PATH entries

0 BGP Community entries

| Neighbor | V | AS | MsgRcvd | MsgSent | TblVer | InQ | OutQ | Up/Down |
|-----------|---|------|---------|---------|--------|-----|------|----------|
| 10.10.1.2 | 4 | 1000 | 1673 | 1678 | 22 | 0 | 0 | 07:44:28 |
| 2 | | | | | | | | |
| 10.10.2.2 | 4 | 1000 | 78 | 79 | 22 | 0 | 0 | 01:01:15 |
| 2 | | | | | | | | |

Total number of neighbors 2

```
S1#
```

```
S1#
```

```
S1#show ip bgp
```

BGP table version is 23, local router ID is 192.168.1.1

Status codes: s suppressed, d damped, h history, * valid, > best, i - internal,

S Stale

Origin codes: i - IGP, e - EGP, ? - incomplete

| Network | Next Hop | Metric | LocPrf | Weight | Path |
|-----------------|-----------|--------|--------|--------|------|
| *> 10.10.1.0/24 | 0.0.0.0 | | 100 | 32768 | i |
| *> 10.10.2.0/24 | 0.0.0.0 | | 100 | 32768 | i |
| *>i10.10.3.0/24 | 10.10.1.2 | 0 | 100 | 0 | i |
| *>i10.10.4.0/24 | 10.10.2.2 | 0 | 100 | 0 | i |
| *>i10.11.0.0/16 | 10.10.3.2 | 0 | 100 | 0 2000 | i |
| * i | 10.10.4.2 | 0 | 100 | 0 3000 | i |

Total number of prefixes 5

S1#

S1#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```

C      10.10.1.0/24 is directly connected, gigabitEthernet0/1
C      10.10.2.0/24 is directly connected, gigabitEthernet0/2
B      10.10.3.0/24 [200/0] via 10.10.1.2, gigabitEthernet0/1, 00:12:05
B      10.10.4.0/24 [200/0] via 10.10.2.2, gigabitEthernet0/2, 00:10:30
B      10.11.0.0/16 [200/0] via 10.10.4.2 (recursive via 10.10.2.2 ),00:10:24
                [200/0] via 10.10.3.2 (recursive via 10.10.1.2 ),00:10:24

```

Gateway of last resort is not set

S1#

15.4. Display Information

S1#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```

C      10.10.1.0/24 is directly connected, gigabitEthernet0/1
C      10.10.2.0/24 is directly connected, gigabitEthernet0/2
B      10.10.3.0/24 [200/0] via 10.10.1.2, gigabitEthernet0/1, 00:12:05
B      10.10.4.0/24 [200/0] via 10.10.2.2, gigabitEthernet0/2, 00:10:30
B      10.11.0.0/16 [200/0] via 10.10.4.2 (recursive via 10.10.2.2 ),00:10:24

```

[200/0] via 10.10.3.2 (recursive via 10.10.1.2),00:10:24

Gateway of last resort is not set

S1#

- Show only BGP routing information

S1#show ip route bgp

IP Route Table for VRF "default"

B 10.10.3.0/24 [200/0] via 10.10.1.2, gigabitEthernet0/1, 00:14:20

B 10.10.4.0/24 [200/0] via 10.10.2.2, gigabitEthernet0/2, 00:12:45

B 10.11.0.0/16 [200/0] via 10.10.4.2 (recursive via 10.10.2.2),00:12:39
[200/0] via 10.10.3.2 (recursive via 10.10.1.2),00:12:39

Gateway of last resort is not set

S1#

- Additional BGP Information

| Command | 作用 |
|-----------------------|--|
| show ip bgp | Displays general information about BGP |
| show ip bgp summary | Display BGP connection summary information |
| show ip bgp neighbors | Display BGP neighbor details |
| show ip bgp paths | Display BGP path information |

16. Configuring IS-IS

16.1. Overview of IS-IS

IS-IS (Intermediate System-to-Intermediate System) is a routing protocol, suitable for dual-environment networks of IP and ISO CLNS, is a scalable, robust, easy-to-use IGP protocol.

IS-IS, as a link state protocol, has the commonality of link state protocols. It discovers and maintains neighbor relationships by sending Hello packets, and advertises its link state by sending protocol datagrams LSP (Link State PDU) to neighbors. IS-IS supports layer 2 routing (layer 1 and layer 2 routing) scheme, all devices in the same layer have the same LSDB, and the LSDB stores the LSPs generated by all devices in the same layer, so that all devices in the same layer know themselves. Depending on the network topology at the level, each device uses the Dijkstra Shortest Path First (SPF) algorithm to optimize route calculation, path selection and achieve fast convergence.

16.2. Configuring

16.2.1. Creating IS-IS Process

To run the IS-IS routing protocol, first create an IS-IS routing process in the global configuration mode. The router isis can carry the parameter Tag, which is a name used to represent the IS-IS routing process. Configure different IS-IS routing processes by adding different tags.

After the IS-IS process is started, a system ID needs to be set for IS-IS to uniquely identify the IS-IS instance in the entire autonomous domain.

System ID and NET in configuration commands can be divided into three parts: area address, System ID, and NSAP identification. The total length is 8-20 bytes.

- The area address identifies the routing domain length of the area and is fixed in the routing domain. Length is 1-13 bytes.
- System IDs are unique within an autonomous system.
- NSAP is a network selector, sometimes called SEL. In IS-IS, SEL is always set to 00 to indicate a router.

In IS-IS, each area can contain one or more area addresses, usually only one area address needs to be configured. When re-dividing the area, it can be achieved by configuring multiple area addresses. When configuring multiple zone addresses in one IS, the system ID part must be the same.

| | |
|-------------|--|
| Command | SWITCH(config)#router isis [<i>tag</i>] SWITCH(config-router)# net <i>NET</i> |
| Description | Create a process and configure a unique ID. |

16.2.2. Enabling IS-IS

| | |
|-------------|---|
| Command | SWITCH(config-if)#ip router isis [<i>tag</i>] |
| Description | Enable the isis function on the interface. tag represents the process name of isis. |

16.2.3. Configuring Protocol Packet Parameter

- Configuring the Hello Packet Interval

| | |
|---------|---|
| Command | SWITCH(config-if)#isis hello-interval { <i>seconds</i> minimal} {level-1 level-2} |
|---------|---|

| | |
|-------------|--|
| Description | <p>hello-interval: is used to set the interval for sending hello packets on the interface. The value of the two ends of the neighbor must be the same.</p> <p>seconds: is the interval value, the unit is seconds, the range is 1-65535, and the default value is 10.</p> <p>minimal: is to set the holdtime to 1, and the value of the hello interval will be calculated by the hello-multiplier. For example, if hello-multiplier is set to 3, and isis hello-interval minimal is set, the value of hello-interval should be 1/3 of a second (333 milliseconds). After the minimal parameter is configured, the number of hello packets exchanged between devices will greatly increase, and the processing burden of the device will also increase greatly. If the device performance is low or the load is already heavy, neighbors may flap.</p> <p>level-1/level-2: indicate different levels. If not selected, the same configuration is applied to different levels.</p> |
|-------------|--|

- Configuring the Multiple of the Hello Packet Holdtime

| | |
|-------------|--|
| Command | SWITCH(config-if)#isis hello-multiplier <i>value</i> [level-1 level-2] |
| Description | <p>value: is used to set the holdtime multiple of the hello packet on the interface, thereby modifying the holdtime value in the hello packet. The holdtime value in the packet is equal to the product of hello-interval and hello-multiplier. The default value is 3.</p> <p>level-1/level-2: indicate different levels. If not selected, the same configuration is applied to different levels.</p> |

- Configuring the Interval for Sending LSP Packets

| | |
|-------------|--|
| Command | SWITCH(config-if)#isis lsp-interval <i>interval</i> |
| Description | <p>interval: is the shortest interval for transmitting LSP packets on the interface, in milliseconds, and the range is 1 - 4294967295.</p> |

- Configuring the LSP Packet Retransmission Interval

| | |
|-------------|---|
| Command | SWITCH(config-if)#isis retransmit-interval <i>interval</i> |
| Description | <p>interval: is the interval for retransmission of LSP packets transmitted on the interface. The unit is seconds, and the range is 1 - 65535.</p> |

- Configuring the LSP Refresh Interval

| | |
|-------------|---|
| Command | SWITCH(config-router)#lsp-refresh-interval <i>seconds</i> |
| Description | <p>second: is used to set the refresh interval of LSP, the unit is second, the range is 1 - 65535. The set value of lsp-refresh-interval must be less than the set value of max-lsp-lifetime.</p> |

- Configuring the Validity Period of LSP Packets

| | |
|-------------|--|
| Command | SWITCH(config-router)#max-lsp-lifetime <i>seconds</i> |
| Description | <p>second: is used to set the valid time of LSP, the unit is second, the range is 1 - 65535. The setting value of max-lsp-lifetime must be greater than the setting value of lsp-refresh-interval.</p> |

- Configuring Ignore LSP Packet Verification

| | |
|---------|---|
| Command | SWITCH(config-router)#ignore-lsp-errors |
|---------|---|

| | |
|-------------|---|
| Description | Used to set checksum errors to ignore LSPs. |
|-------------|---|

- Configuring the Broadcast Interval of CSNP Packets

| | |
|-------------|--|
| Command | SWITCH(config-if)#isis csnp-interval <i>seconds</i> [level-1 level-2] |
| Description | second: is used to set the interval for sending CSNP packets on the interface, in seconds, ranging from 1 to 65535. The default value is 10. If set to 0, it means that CSNP packets are not sent. level-1/level-2: indicate different levels. If not selected, the same configuration is applied to different levels. |

16.2.4. Configuring IS-IS Hierarchical

| | |
|-------------|---|
| Command | SWITCH(config-router)#is-type {level-1 level-1-2 level-2-only} |
| Description | Used to set the hierarchy type of the IS-IS system. level-1 is used to represent routers within an area, level-2-only is used to represent routers between areas, and level-1-2 is used to represent border routers that are both intra-area routers and inter-area routers. |

It is also possible to configure the hierarchy of isis based on the interface.

| | |
|-------------|--|
| Command | SWITCH(config-if)#isis circuit-type {level-1 level-1-2 level-2-only} |
| Description | An interface configured with the isis level can only send protocol packets of the corresponding level. |

16.2.5. Configuring IS-IS Authentication

The ISIS protocol can configure authentication based on interfaces, areas, and routing domains.

- Configuring Interface Authentication

| | |
|-------------|---|
| Command | SWITCH(config-if)# isis <i>password</i> [level-1 level-2] |
| Description | Set the interface's Hello message text authentication password. |

- Configuring Area Authentication

| | |
|-------------|---|
| Command | SWITCH(config-if)# area-password <i>password</i> |
| Description | Set the area (Level-1) plaintext authentication password. |

- Configuring Routing Domain Authentication

| | |
|-------------|---|
| Command | SWITCH(config-if)# domain-password <i>password</i> |
| Description | Set the routing domain (Level-2) plaintext authentication password. |

16.3. Examples


16.3.1. Configuring IS-IS Basic

Need

- 3 devices exchange routes using the ISIS protocol;
- S1 does not advertise the routes of the 10.10.1.1/24 network segment; S2 and S3 advertise all routes of the local machine

- Each device can learn all advertised routes in the autonomous domain
- The HELLO message between S1 and S2 uses plaintext authentication

Networking



1) Configuration example

- Device S1 configuration steps

Create an ISIS process

```
S1#configure terminal
S1(config)#router isis 1
S1(config-router)#net 66.0001.0000.0000.0001.00
```

Configure the ip address of port gigabitEthernet0/1. Because isis is not enabled, this network segment will not be published by the isis protocol.

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/1
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.1.1/24
```

Configure the ip address of port gigabitEthernet0/3 and enable isis.

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/3
S1(config-if)#no switchport
S1(config-if)#ip address 192.168.3.2/24
S1(config-if)#ip router isis 1
```

Configure the IP address of port gigabitEthernet0/4, enable isis, and configure interface authentication.

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/4
S1(config-if)#no switchport
S1(config-if)#ip address 192.168.4.2/24
S1(config-if)#ip router isis 1
S1(config-if)#isis password test-password
```

- Device S2 configuration steps

Create an ISIS process

```
S2#configure terminal
S2(config)#router isis 1
```

```
S2(config-if)#net 66.0001.0000.0000.0002.00
```

Configure the ip address of port gigabitEthernet0/1, enable isis, and configure interface authentication.

```
S2#configure terminal
```

```
S2(config)#interface gigabitEthernet0/1
```

```
S2(config-if)#no switchport
```

```
S2(config-if)#ip address 192.168.4.1/24
```

```
S2(config-if)#ip router isis 1
```

```
S1(config-if)#isis password test-password
```

Configure the ip address of port gigabitEthernet0/2 and enable isis.

```
S2#configure terminal
```

```
S2(config)#interface gigabitEthernet0/2
```

```
S2(config-if)#no switchport
```

```
S2(config-if)#ip address 192.168.2.1/24
```

```
S2(config-if)#ip router isis 1
```

- Device S3 configuration steps

Create an ISIS process

```
S3#configure terminal
```

```
S3(config)#router isis 1
```

```
S3(config-if)#net 66.0001.0000.0000.0002.00
```

Configure the ip address of port gigabitEthernet0/1 and enable isis

```
S3#configure terminal
```

```
S3(config)#interface gigabitEthernet0/1
```

```
S3(config-if)#no switchport
```

```
S3(config-if)#ip address 192.168.3.1/24
```

```
S3(config-if)#ip router isis 1
```

Configure the ip address of port gigabitEthernet0/2 and enable isis

```
S3#configure terminal
```

```
S3(config)#interface gigabitEthernet0/2
```

```
S3(config-if)#no switchport
```

```
S3(config-if)#ip address 192.168.1.1/24
```

```
S3(config-if)#ip router isis 1
```

- Show result

Device S1:

Display routing table on device S1

```
S1#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
C      10.10.1.0/24 is directly connected, gigabitEthernet0/1
```

```
i L1    192.168.1.0/24 [115/20] via 192.168.3.1, gigabitEthernet0/3, 00:01:02
i L1    192.168.2.0/24 [115/20] via 192.168.4.1, gigabitEthernet0/4, 00:00:12
C       192.168.3.0/24 is directly connected, gigabitEthernet0/3
C       192.168.4.0/24 is directly connected, gigabitEthernet0/4
```

Gateway of last resort is not set

S1#

Device S2:

Display routing table on device S2

S2#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
i L1    192.168.1.0/24 [115/30] via 192.168.4.2, gigabitEthernet0/1, 00:00:55
C       192.168.2.0/24 is directly connected, gigabitEthernet0/2
i L1    192.168.3.0/24 [115/20] via 192.168.4.2, gigabitEthernet0/1, 00:08:48
C       192.168.4.0/24 is directly connected, gigabitEthernet0/1
```

Gateway of last resort is not set

S2#

Device S3:

Display routing table on device S3

S3#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
C       192.168.1.0/24 is directly connected, gigabitEthernet0/2
i L1    192.168.2.0/24 [115/30] via 192.168.3.2, gigabitEthernet0/1, 00:01:45
C       192.168.3.0/24 is directly connected, gigabitEthernet0/1
i L1    192.168.4.0/24 [115/20] via 192.168.3.2, gigabitEthernet0/1, 00:10:25
```

Gateway of last resort is not set


S3#

16.3.2. Configuring IS-IS Route Redistribution

Need

- 3 devices exchange routes using the ISIS protocol;
- S1 does not advertise the route of the 10.10.1.1/24 network segment, configure a static route to the 112.0.0./6 network segment, the next hop is 10.10.1.2, and re-advertise this route through the ISIS protocol;
- S2, S3 publish all routes of this machine
- Each device can learn all the advertised routes in the autonomous domain, including the static routes of S1

Networking



Configuration example

Interface IP, ISIS basic configuration see Configuration example in Section 21.3.1 ISIS Basic Configuration. For increasing the static route of S1 and the static route redistribution configuration in the ISIS process.

Configure static routes

S1#configure terminal

S1(config)#ip route 112.0.0.0/6 10.10.1.2

Configure the ip address of port gigabitEthernet0/4 and enable isis

S1#configure terminal

S1(config)#router isis 1

S1(config-router)#redistribute static

- Show result

Device S1:

Display routing table on device S1

S1#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

*** - candidate default**

IP Route Table for VRF "default"

C 10.10.1.0/24 is directly connected, gigabitEthernet0/1

S 112.0.0.0/6 [1/0] via 10.10.1.2, gigabitEthernet0/1

i L1 192.168.1.0/24 [115/20] via 192.168.3.1, gigabitEthernet0/3, 00:01:02

```
i L1    192.168.2.0/24 [115/20] via 192.168.4.1, gigabitEthernet0/4, 00:00:12
C       192.168.3.0/24 is directly connected, gigabitEthernet0/3
C       192.168.4.0/24 is directly connected, gigabitEthernet0/4
```

Gateway of last resort is not set

S1#

Device S2:

Display routing table on device S2

S2#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
i L2    112.0.0.0/6 [115/10] via 192.168.4.2, gigabitEthernet0/1, 00:01:58
i L1    192.168.1.0/24 [115/30] via 192.168.4.2, gigabitEthernet0/1, 00:07:41
C       192.168.2.0/24 is directly connected, gigabitEthernet0/2
i L1    192.168.3.0/24 [115/20] via 192.168.4.2, gigabitEthernet0/1, 00:08:01
C       192.168.4.0/24 is directly connected, gigabitEthernet0/1
```

Gateway of last resort is not set

S2#

Device S3:

Display routing table on device S3

S3#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
i L2    112.0.0.0/6 [115/10] via 192.168.3.2, gigabitEthernet0/1, 00:01:37
C       192.168.1.0/24 is directly connected, gigabitEthernet0/2
i L1    192.168.2.0/24 [115/30] via 192.168.3.2, gigabitEthernet0/1, 00:07:43
C       192.168.3.0/24 is directly connected, gigabitEthernet0/1
i L1    192.168.4.0/24 [115/20] via 192.168.3.2, gigabitEthernet0/1, 00:07:43
```

Gateway of last resort is not set


S3#

16.3.3. Configuring IS-IS Hierarchical

Need

- 4 devices exchange routes using the ISIS protocol;
- S2 and S3 are in the same autonomous domain; S4 is in an autonomous domain; S1 does the IS-IS area route summary;

Networking



Configuration example

- Device S1 configuration steps

Create an ISIS process, and configure S1 to run only at level 2, so that S1 only cares about the topology changes of IS-IS level 2, that is, route changes.

```
S1#configure terminal
S1(config)#router isis 1
S1(config-router)#net 88.0001.0000.0000.0001.00
S1(config-router)#is-type level-2-only
```

Configure the ip address of port gigabitEthernet0/1 and enable isis

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/1
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.1.1/24
S1(config-if)#ip router isis 1
```

Configure the ip address of port gigabitEthernet0/2 and enable isis

```
S1#configure terminal
S1(config)#interface gigabitEthernet0/2
S1(config-if)#no switchport
S1(config-if)#ip address 10.10.2.1/24
S1(config-if)#ip router isis 1
```

- Device S2 configuration steps

Create an ISIS process. Since S1 only runs on level 2 and S3 only runs on level 1, S2 needs to support both level 1 and level 2. The default configuration is to support both level 1 and level 2, so no special configuration is required.

```
S2#configure terminal
```

```
S2(config)#router isis 1
S2(config-router)#net 66.0001.0000.0000.0002.00
```

Configure the ip address of port gigabitEthernet0/1 and enable isis

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/1
S2(config-if)#no switchport
S2(config-if)#ip address 10.10.1.2/24
S2(config-if)#ip router isis 1
```

Configure the ip address of port gigabitEthernet0/2 and enable isis

```
S2#configure terminal
S2(config)#interface gigabitEthernet0/2
S2(config-if)#no switchport
S2(config-if)#ip address 192.168.3.2/24
S2(config-if)#ip router isis 1
```

- Device S3 configuration steps

Create an ISIS process, you need to configure S3 to run only at level 1.

```
S3#configure terminal
S3(config)#router isis 1
S3(config-router)#net 66.0001.0000.0000.0003.00
S3(config-router)# is-type level-1
```

Configure the ip address of port gigabitEthernet0/1 and enable isis

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/1
S3(config-if)#no switchport
S3(config-if)#ip address 192.168.3.1/24
S3(config-if)#ip router isis 1
```

Configure the ip address of port gigabitEthernet0/2 and enable isis

```
S3#configure terminal
S3(config)#interface gigabitEthernet0/2
S3(config-if)#no switchport
S3(config-if)#ip address 192.168.1.1/24
S3(config-if)#ip router isis 1
```

- Device S4 configuration steps

Create an ISIS process, S4 needs to support both level1 and level2. The default configuration is to support both level1 and level2, so no special configuration is required.

```
S4#configure terminal
S4(config)#router isis 1
S4(config-router)#net 66.0001.0000.0000.0004.00
```

Configure the ip address of port gigabitEthernet0/1 and enable isis

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/1
S4(config-if)#no switchport
S4(config-if)#ip address 10.10.2.1/24
S4(config-if)#ip router isis 1
```

Configure the ip address of port gigabitEthernet0/2 and enable isis

```
S4#configure terminal
S4(config)#interface gigabitEthernet0/2
S4(config-if)#no switchport
S4(config-if)#ip address 192.168.2.1/24
S4(config-if)#ip router isis 1
```

- Show result

Device S1:

Display routing table on device S1

```
S1#show isis peer
```

Area 1:

| System Id | Type | Interface | IP Address | State | Holdtime | Circuit |
|-------------------|------|-----------|------------|-------|----------|---------|
| 0000.0000.0002 | L2 | GiE0/1 | 10.10.1.2 | | | 8 |
| 0000.0000.0002.01 | | | | | | |
| 0000.0000.0004 | L2 | GiE0/2 | 10.10.2.2 | | | 28 |
| 0000.0000.0001.03 | | | | | | |

```
S1#
```

```
S1#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
C      10.10.1.0/24 is directly connected, gigabitEthernet0/1
C      10.10.2.0/24 is directly connected, gigabitEthernet0/2
i L2   192.168.2.0/24 [115/20] via 10.10.2.2, gigabitEthernet0/2, 00:13:10
i L2   192.168.3.0/24 [115/20] via 10.10.1.2, gigabitEthernet0/1, 00:13:35
```

Gateway of last resort is not set

```
S1#
```

Device S2:

Display routing table on device S2

```
S2#show isis peer
```

Area 1:

| System Id | Type | Interface | IP Address | State | Holdtime | Circuit |
|-------------------|------|-----------|-------------|-------|----------|---------|
| 0000.0000.0001 | L2 | GiE0/1 | 10.10.1.1 | | | 27 |
| 0000.0000.0002.01 | | | | | | |
| 0000.0000.0003 | L1 | GiE0/2 | 192.168.3.1 | | | 8 |
| 0000.0000.0003.01 | | | | | | |

S2#

S2#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

C 10.10.1.0/24 is directly connected, gigabitEthernet0/1

i L2 10.10.2.0/24 [115/20] via 10.10.1.1, gigabitEthernet0/1, 00:14:37

i L1 192.168.1.0/24 [115/20] via 192.168.3.1, gigabitEthernet0/2, 00:14:04

i L2 192.168.2.0/24 [115/30] via 10.10.1.1, gigabitEthernet0/1, 00:13:49

C 192.168.3.0/24 is directly connected, gigabitEthernet0/2

Gateway of last resort is not set

S2#

Device S3:

Display routing table on device S3

S3#show isis peer

Area 1:

| System Id | Type | Interface | IP Address | State | Holdtime | Circuit |
|----------------|------|-----------|-------------|-------|----------|-------------------|
| 0000.0000.0002 | L1 | GiE0/1 | 192.168.3.2 | Up | 28 | 0000.0000.0003.01 |

S3#

S3#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

Gateway of last resort is 192.168.3.2 to network 0.0.0.0

i*L1 0.0.0.0/0 [115/10] via 192.168.3.2, gigabitEthernet0/1, 02:39:19

i L1 10.10.1.0/24 [115/20] via 192.168.3.2, gigabitEthernet0/1, 00:15:36

C 192.168.1.0/24 is directly connected, gigabitEthernet0/2

C 192.168.3.0/24 is directly connected, gigabitEthernet0/1

S3#

Device S4:

Display routing table on device S4

S4#show isis peer

Area 1:

| System Id | Type | Interface | IP Address | State | Holdtime | Circuit |
|-------------------|------|-----------|------------|-------|----------|---------|
| 0000.0000.0001 | L2 | GiE0/1 | 10.10.2.1 | | | 8 |
| 0000.0000.0001.03 | | | | | | |

S4#

S4#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

i L2 10.10.1.0/24 [115/20] via 10.10.2.1, gigabitEthernet0/1, 00:15:57
C 10.10.2.0/24 is directly connected, gigabitEthernet0/1
C 192.168.2.0/24 is directly connected, gigabitEthernet0/2
i L2 192.168.3.0/24 [115/30] via 10.10.2.1, gigabitEthernet0/1, 00:15:47

Gateway of last resort is not set

S4#

16.4. Display Information

- Show Routing Information

S2#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

C 10.10.1.0/24 is directly connected, gigabitEthernet0/1
i L2 10.10.2.0/24 [115/20] via 10.10.1.1, gigabitEthernet0/1, 00:14:37
i L1 192.168.1.0/24 [115/20] via 192.168.3.1, gigabitEthernet0/2, 00:14:04
i L2 192.168.2.0/24 [115/30] via 10.10.1.1, gigabitEthernet0/1, 00:13:49
C 192.168.3.0/24 is directly connected, gigabitEthernet0/2

Gateway of last resort is not set

S2#

- Show Only IS-IS Routing Information

S2#show ip route isis

IP Route Table for VRF "default"

i L2 10.10.2.0/24 [115/20] via 10.10.1.1, gigabitEthernet0/1, 00:20:03

i L2 112.0.0.0/6 [115/10] via 10.10.1.1, gigabitEthernet0/1, 00:20:03

i L1 192.168.1.0/24 [115/20] via 192.168.3.1, gigabitEthernet0/2, 00:19:30

i L2 192.168.2.0/24 [115/30] via 10.10.1.1, gigabitEthernet0/1, 00:19:15

Gateway of last resort is not set

S2#

- Additional IS-IS Information

| Command | 作用 |
|---------------------|---|
| show isis tag | Displays brief information about the processes corresponding to IS-IS |
| show isis topology | Display IS-IS topology information |
| show isis database | Display IS-IS database information |
| show isis interface | Display information about IS-IS interfaces |
| show isis peer | Display IS-IS neighbor information |

17. Configuring RIP

17.1. Overview of RIP

RIP (Routing Information Protocol) is a routing protocol that uses the distance vector algorithm and is mainly used in small networks. There are two versions, RIPv1 and RIPv2, respectively (RIPv1 is defined in RFC 1058, and RIPv2 is defined in RFC 2453). The RIP protocol packet is based on the UDP protocol, and the UDP port number is 520. RIPv1 packets are generally in the form of broadcast packets; RIPv2 packets are in the form of multicast packets, and the multicast address is 224.0.0.9.

The RIP protocol sends out update packets every 30 seconds. If the router does not receive a routing update packet from the peer end in 180 seconds, the machine will mark all routes from the peer device as unreachable. If the update message is not received after that, the routes advertised by the peer device may be deleted from the routing table.

RIP's routing metric refers to the number of hops used to measure the distance to a destination. The hop count of the directly connected network is marked as 0, the reachable network hop count of each device is 1; the hop count of the unreachable network is 16.

The RIP routing process will only send update packets to the network interface associated with the process.

17.2. Configuring

17.2.1. Creating RIP Process

| | |
|-------------|---|
| Command | SWITCH(config)#router rip SWITCH(config-router)# network IP(A.B.C.D) MASK(A.B.C.D) |
| Description | To run the RIP routing protocol, you need to create a RIP routing process and associate the corresponding network with the RIP routing process. router rip: is to create a RIP routing process. network: indicates the routing information of the associated network advertised by the ripCommand to the outside world, and also indicates that the protocol advertisement and routing information update are performed only on the interface corresponding to the associated network. IP and MASK: indicates the address range. |

17.2.2. Configuring RIP Packet Update Unicast Announcement

| | |
|-------------|--|
| Command | SWITCH(config)#router rip SWITCH(config-router)# neighbor IP(A.B.C.D) |
| Description | RIP routing protocols usually use broadcast or multicast packets for interaction, but can also support the configuration of packet update unicast advertisement to use unicast packets to update routing information. For example, this configuration is required in non-broadcast networks. |

17.2.3. Configuring RIP Version

The product supports versions 1 and 2 of RIP. Version 2 supports authentication, route aggregation, and key management.

By default the product can receive version 1 and version 2 RIP packets, but will only send version 1 packets.

The product supports data packets of the RIP version that are specified to be received and sent based on the whole machine or specified based on ports.

The whole machine specifies the RIP version:

| | |
|---------|---------------------------|
| Command | SWITCH(config)#router rip |
|---------|---------------------------|

| | |
|-------------|---|
| | SWITCH(config-router)# version {1 2} |
| Description | This Command can be used to specify that the device only receives and sends packets of the specified version. |

Specify the RIP version sent based on the port:

| | |
|-------------|--|
| Command | SWITCH(config-if)# ip rip send version {1 2} {1 2} |
| Description | You can use this Command to specify that the port only sends packets of the specified version. |

Specify the received RIP version based on the port:

| | |
|-------------|--|
| Command | SWITCH(config-if)# ip rip receive version {1 2} {1 2} |
| Description | You can use this Command to specify that the port only sends packets of the specified version. |

17.2.4. Configuring Route Redistribution

| | |
|-------------|--|
| Command | SWITCH(config-router)# redistribute {bgp connected isis [area-tag] ospf process-id rip static} [metric value] [metric-type {1 2}] [route-map map-name] [subnets] [tag value] |
| Description | This Command is used to configure the import of external routes (including other OSPF processes/static routes/routes of other routing protocols) to the OSPF process on the ASBR. |

17.2.5. Configuring Route Aggregation

When a subnet route traverses the network boundary of a classful route, the subnet route can be aggregated into a classful network route, which can improve the scalability and effectiveness of the network. This can greatly reduce the size of the routing table. RIP version 2 automatically performs route aggregation by default, but version 1 does not support this function.

| | |
|-------------|---|
| Command | SWITCH(config)#router rip SWITCH(config-router)#[no] auto-summary |
| Description | auto-summary: indicates that automatic route aggregation is enabled. no: indicates that automatic route aggregation is disabled. |

17.2.6. Configuring Split Horizon

Due to its own mechanism, the distance vector routing protocol often causes routing loops when multiple devices are connected to an IP broadcast type network. The split horizon mechanism is used to avoid the formation of routing loops.

The split horizon mechanism optimizes the exchange of routing information between multiple devices by preventing certain routing information from being advertised from the interface that has learned the routing information. However, for non-broadcast multi-access networks (such as X.25 networks, frame relay networks, etc.), this mechanism cannot learn complete routing information because advertisements are blocked, so it is not suitable for enabling split horizon.

Poison reversal is an improved mechanism of split horizon technology. When split horizon with poison reversal is enabled, the interface that has learned the corresponding routing information will still advertise the routing information, but will set the metric attribute in the routing information. In this way, after receiving this kind of routing information, the peer end will immediately discard the route without waiting for its aging time, which will speed up the convergence of the route.

Split horizon is configured in interface mode.

| | |
|---------|--|
| Command | SWITCH(config-if)#[no] ip rip split-horizon {poisoned-reverse} |
|---------|--|

| | |
|-------------|--|
| Description | split-horizon: indicates that the horizontal split of the rip is enabled. poisoned-reverse: indicates poison reverse. |
|-------------|--|

17.2.7. Configuring RIP Authentication

RIPv1 does not support authentication configuration, and RIPv2 supports authentication configuration. Authentication configuration needs to be configured on the corresponding interface.

Device supports two authentication methods: plaintext authentication and MD5 authentication. The default authentication method is plaintext authentication.

The authentication key is created by associating the key chain. Use the key chain global configuration **Configuring the key chain**.

| | |
|-------------|--|
| Command | SWITCH(config-if)#ip rip authentication mode {text md5} SWITCH(config-if)#no ip rip authentication mode |
| Description | Apply keychain, enable RIP authentication and configure interface RIP authentication. text: plaintext authentication. md5: MD5 authentication. |

Configuring to use keychain for authentication.

| | |
|-------------|---|
| Command | SWITCH(config-if)#ip rip authentication key-chain <i>key-chain-name</i> SWITCH(config-if)#no ip authentication key-chain |
| Description | Configure rip to use the corresponding keychain for authentication. key-chain-name: Keychain name. |

Configuring keystring

| | |
|-------------|--|
| Command | SWITCH(config)# key chain <i>key-chain-name</i> SWITCH(config-keychain)# key <i>key-id</i> SWITCH(config-keychain-key)# key-string <i>key-text</i> SWITCH(config-keychain-key)# accept-lifetime <i>start-time</i> { infinite <i>end-time</i> duration <i>seconds</i> } SWITCH(config-keychain-key)# send-lifetime <i>start-time</i> { infinite <i>end-time</i> duration <i>seconds</i> } SWITCH(config-keychain-key)# end SWITCH# show key chain |
| Description | key-chain-name: Keychain name. key-id: key id. key-text: key string accept-lifetime: Configure the lifetime of the key in the receive direction. send-lifetime: Configure the lifetime of the key in the sending direction. |

17.2.8. Configuring RIP Timer

There are three timers in the RIP protocol (all in seconds):

Route update timer: This timer is used to define the interval for the device to send route update packets. The default interval is 30 seconds.

Route invalidation timer: This timer is used to define how long the route in the routing table is not updated before it becomes invalid. The default period is 180 seconds.

Route clearing timer: This timer is used to set the time after which invalid routes are cleared from the routing table. The default period is 120 seconds.

| | |
|-------------|--|
| Command | SWITCH(config)#router rip SWITCH(config-router)#timer basic update-time invalid-time flush-timer |
| Description | update-time: Indicates the route update time. invalid-time: Indicates the route invalid time. flush-time: Indicates the route clearing time. |

17.2.9. Configuring RIP Source Address Verification

By default, the RIP protocol will check the source address of the received routing update packet. For the packet with an invalid source address, the protocol will discard the packet. The criterion for judgment is whether the source address of the received packet is the same as that of the received packet. The IP address of the receiving interface is in the same network, and the function can be disabled through configuration.

| | |
|-------------|--|
| Command | SWITCH(config)#router rip SWITCH(config-router)#[no] validate-update-source |
| Description | no: Indicates that source address verification is disabled. |

17.2.10. Configuring the Interface

In passive interface mode, the port can be configured to only learn RIP routes without advertising RIP routes.

| | |
|-------------|---|
| Command | SWITCH(config)#router rip SWITCH(config-router)#[no] passive-interface {default interface-name} |
| Description | no: Indicates that the passive interface is closed. default: Indicates that it applies to all interfaces. interface-name: Indicates that the application is on the specified interface. |

In interface mode, the interface can be specified to allow/disable the receiving/sending of rip packets.

| | |
|-------------|---|
| Command | SWITCH(config-if)#[no] ip rip {send receive} enable |
| Description | send: Indicates the sending of rip packets. receive: Indicates the reception of rip packets. |

17.2.11. Configuring Supernet Routing

A supernet route is a route whose mask length is less than the natural mask length. Since RIP version 1 does not support receiving supernet routes, if the interface of the RIP version 1 routing device is interconnected with the RIP version 2 routing device, when the version 1 device receives the updated version with the supernet route, it will change the routing information to the interface. The subnet mask is ignored, which will cause route learning errors. In order to be compatible with such situations, the device supports configuring the interface to prohibit sending supernet route advertisements.

| | |
|-------------|--|
| Command | SWITCH(config-if)#[no] ip rip send supernet-routes |
| Description | no: means that the sending of supernet routes is prohibited. |

Note: Ports that only receive version 1 packets do not support receiving supernet routes, and ports that only send version 1 packets will not send supernet routes. Interfaces that support version 2 support both sending and interface supernet routes; Routes are not automatically aggregated.

17.2.12. Configuring Default Route Advertisement

A default route can be generated based on the interface-specified route update message. You can also specify that only the default route is passed without advertising other routes.

| | |
|-------------|--|
| Command | SWITCH(config-if)#ip rip default-information {originate only} [metric metric-value] SWITCH(config-if)#no ip rip default-information |
| Description | originate: Indicates that in addition to advertising the default route, other routes are also advertised. only: Indicates that only the default route of this interface is advertised, and other routes are not advertised. |

Note: Between the “default-information” configured in the RIP process and the “ip rip default-information” configured under the interface, the interface configuration has a higher priority than the RIP process configuration, that is, if both exist, the default route configured under the interface is advertised.


17.3. Examples

17.3.1. Configuring RIP Routing

Need

- Routing between all devices automatically adapts to network changes.
- The switch connected to the external network receives routes advertised by the external network, but does not advertise routes to the external network.
- Routes with subnet masks can be advertised.

Networking



Configuration example

- Device S1 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
```



```
SWITCH(config-if)#ip address 10.10.1.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 112.10.1.1/24
```

Configure the RIP process

Enable the rip process and configure the RIP version to version 2 so that routes with subnet masks can be advertised.

Since the gigabitEthernet0/2 port of S1 is connected to the external network, in order to meet the requirement of receiving external network routes but not advertising routes to the external network, you need to configure the gigabitEthernet0/2 port as a passive interface.

The internal network needs to learn specific subnet routes, so the default route aggregation needs to be turned off.

```
SWITCH(config)#router rip
SWITCH(config-router)#version 2
SWITCH(config-router)#passive-interface gigabitEthernet0/2
SWITCH(config-router)#no auto-summary
```

Associated Network

```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0
SWITCH(config-router)#network 112.10.1.1 255.255.255.0
```

- Device S2 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 100.10.1.1/16
```

Configure the RIP process

Enable the rip process and configure the RIP version to version 2 so that routes with subnet masks can be advertised.

The internal network needs to learn specific subnet routes, so the default route aggregation needs to be turned off.

```
SWITCH(config)#router rip
SWITCH(config-router)#version 2
SWITCH(config-router)#no auto-summary
```

Associated Network

```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0
SWITCH(config-router)#network 100.10.1.1 255.255.0.0
```

- Device S3 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
```

```
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.3/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 192.168.1.1/24
```

Configure the RIP process

Enable the rip process and configure the RIP version to version 2 so that routes with subnet masks can be advertised.

The internal network needs to learn specific subnet routes, so the default route aggregation needs to be turned off.

```
SWITCH(config)#router rip
SWITCH(config-router)#version 2
SWITCH(config-router)#no auto-summary
```

Associated Network

```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0
SWITCH(config-router)#network 192.168.1.0 255.255.255.0
```

- Show result

Device S1:

Display routing table on device S1

```
SWITCH#show ip route
Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP
       O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
       * - candidate default

IP Route Table for VRF "default"
C       10.10.1.0/24 is directly connected, gigabitEthernet0/1
R       100.10.0.0/16 [120/1] via 10.10.1.2, gigabitEthernet0/1, 00:17:08
C       112.10.1.0/24 is directly connected, gigabitEthernet0/2
R       192.168.1.0/24 [120/1] via 10.10.1.3, gigabitEthernet0/1, 00:18:07
```

Gateway of last resort is not set

Device S2:

Display routing table on device S2

```
SWITCH#show ip route
Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP
       O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
       * - candidate default
```

IP Route Table for VRF "default"

```
C    10.10.1.0/24 is directly connected, gigabitEthernet0/1
C    100.10.0.0/16 is directly connected, gigabitEthernet0/2
R    112.10.1.0/24 [120/1] via 10.10.1.1, gigabitEthernet0/1, 00:18:57
R    192.168.1.0/24 [120/1] via 10.10.1.3, gigabitEthernet0/1, 00:19:59
```

Gateway of last resort is not set

Device S3:

Display routing table on device S3

SWITCH#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
C    10.10.1.0/24 is directly connected, gigabitEthernet0/1
R    100.10.0.0/16 [120/1] via 10.10.1.2, gigabitEthernet0/1, 00:19:26
R    112.10.1.0/24 [120/1] via 10.10.1.1, gigabitEthernet0/1, 00:19:23
C    192.168.1.0/24 is directly connected, gigabitEthernet0/2
```

Gateway of last resort is not set

SWITCH#


17.3.2. Configuring RIP Unicast Advertisement

Need

Three LAN switches S1, S2, S3:

- S1 can learn the routes of S2 and S3
- S3 can learn the routes of S1 and S3
- S2 cannot learn routes from S3

Networking



Configuration example

- Device S1 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 192.168.10.1/24
```

Configure the RIP process

Enable the rip process and configure the RIP version to version 2 so that routes with subnet masks can be advertised.

Since the gigabitEthernet 0/2 port of S1 is connected to the external network, in order to meet the needs of receiving external network routes but not advertising routes to the external network, you need to configure the gigabitEthernet 0/2 port as a passive interface.

The internal network needs to learn specific subnet routes, so the default route aggregation needs to be turned off.

```
SWITCH(config)#router rip
SWITCH(config-router)#version 2
SWITCH(config-router)#passive-interface gigabitEthernet0/2
SWITCH(config-router)#no auto-summary
```

Associated Network

```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0
SWITCH(config-router)#network 192.168.10.0 255.255.255.0
```

- Device S2 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
```

```
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 192.168.20.1/24
```

Configure the RIP process

Enable the rip process and configure the RIP version to version 2 so that routes with subnet masks can be advertised.

The internal network needs to learn specific subnet routes, so the default route aggregation needs to be turned off.

```
SWITCH(config)#router rip
SWITCH(config-router)#version 2
SWITCH(config-router)#no auto-summary
```

Associated Network

```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0
SWITCH(config-router)#network 192.168.20.0 255.255.0.0
```

- Device S3 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.3/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 192.168.3.1/24
```

Configure the RIP process

Enable the rip process and configure the RIP version to version 2 so that routes with subnet masks can be advertised.

The internal network needs to learn specific subnet routes, so the default route aggregation needs to be turned off.

```
SWITCH(config)#router rip
SWITCH(config-router)#version 2
SWITCH(config-router)#no auto-summary
```

Associated Network

```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0
SWITCH(config-router)#network 192.168.30.0 255.255.255.0
```

Configuring passive ports and specifying neighbors

To meet the requirement that S2 cannot learn the routes of S3, the S3 device needs to be configured with a passive interface, and the neighbor to learn the route must be S1.

```
SWITCH(config-router)#passive-interface gigabitEthernet0/1
SWITCH(config-router)#neighbor 10.10.1.1
```

- Show result

Device S1:

Display routing table on device S1, with routes from S2 and S3.

SWITCH#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

*** - candidate default**

IP Route Table for VRF "default"

C 10.10.1.0/24 is directly connected, gigabitEthernet0/1

C 192.168.10.0/24 is directly connected, gigabitEthernet0/2

R 192.168.20.0/24 [120/1] via 10.10.1.2, gigabitEthernet0/1, 02:50:16

R 192.168.30.0/24 [120/1] via 10.10.1.3, gigabitEthernet0/1, 02:51:29

Gateway of last resort is not set

SWITCH#

Device S2:

Display routing table on device S2, since S3 does not advertise routes to S2, it can be seen that there are no routes advertised by S3.

SWITCH#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

*** - candidate default**

IP Route Table for VRF "default"

C 10.10.1.0/24 is directly connected, gigabitEthernet0/1

R 192.168.10.0/24 [120/1] via 10.10.1.1, gigabitEthernet0/1, 00:22:08

C 192.168.20.0/24 is directly connected, gigabitEthernet0/2

Gateway of last resort is not set

SWITCH#

Device S3:

Display routing table on device S3, with routes from S1 and S2.

SWITCH#show ip route

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

*** - candidate default**

IP Route Table for VRF "default"

```
C    10.10.1.0/24 is directly connected, gigabitEthernet0/1
R    192.168.10.0/24 [120/1] via 10.10.1.1, gigabitEthernet0/1, 01:14:04
R    192.168.20.0/24 [120/1] via 10.10.1.2, gigabitEthernet0/1, 01:13:47
C    192.168.30.0/24 is directly connected, gigabitEthernet0/2
C    192.168.101.0/24 is directly connected, vlan100
```

Gateway of last resort is not set

SWITCH#


17.3.3. Configuring RIP Default Route

Need

Three LAN switches S1, S2, S3:

- Three switches can learn routes from each other
- S2 advertises default route to S1, S3

Networking



Configuration example

- Device S1 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.10.1/24
```

Configure the RIP process

Enable the rip process and configure the RIP version to version 2 so that routes with subnet masks can be advertised.

Since the gigabitEthernet 0/2 port of S1 is connected to the external network, in order to meet the needs of receiving external network routes but not advertising routes to the external network, you need to configure the gigabitEthernet 0/2 port as a passive interface.

The internal network needs to learn specific subnet routes, so the default route aggregation needs to be turned off.

```
SWITCH(config)#router rip
```

```
SWITCH(config-router)#version 2
SWITCH(config-router)#no auto-summary
```

Associated Network

```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0
SWITCH(config-router)#network 10.10.10.0 255.255.255.0
```

- Device S2 configuration steps

Configure the ip address of port gigabitEthernet0/1, designated to advertise the default route, with a metric of 3

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.2/24
SWITCH(config-if)#ip rip default-information originate metric 3
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.20.1/24
```

Configure the RIP process

Enable the rip process and configure the RIP version to version 2 so that routes with subnet masks can be advertised.

The internal network needs to learn specific subnet routes, so the default route aggregation needs to be turned off.

```
SWITCH(config)#router rip
SWITCH(config-router)#version 2
SWITCH(config-router)#no auto-summary
```

Associated Network

```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0
SWITCH(config-router)#network 10.10.20.0 255.255.255.0
```

- Device S3 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.3/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.30.1/24
```

Configure the RIP process

Enable the rip process and configure the RIP version to version 2 so that routes with subnet masks can be advertised.

The internal network needs to learn specific subnet routes, so the default route aggregation needs to be turned off.

```
SWITCH(config)#router rip
SWITCH(config-router)#version 2
SWITCH(config-router)#no auto-summary
```

Associated Network


```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0
```

```
SWITCH(config-router)#network 10.10.30.0 255.255.255.0
```

- Show result

Device S1:

Display routing table on device S1, with routes from S2 and S3.

```
SWITCH#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

Gateway of last resort is 10.10.1.2 to network 0.0.0.0

```
R*    0.0.0.0/0 [120/3] via 10.10.1.2, gigabitEthernet0/1, 00:00:38
```

```
C     10.10.1.0/24 is directly connected, gigabitEthernet0/1
```

```
C     10.10.10.0/24 is directly connected, gigabitEthernet0/2
```

```
R     10.10.20.0/24 [120/1] via 10.10.1.2, gigabitEthernet0/1, 00:11:08
```

```
R     10.10.30.0/24 [120/1] via 10.10.1.3, gigabitEthernet0/1, 00:10:27
```

```
SWITCH#
```

Device S2:

Display routing table on device S2, since S3 does not advertise routes to S2, it can be seen that there are no routes advertised by S3

```
SWITCH#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

```
C     10.10.1.0/24 is directly connected, gigabitEthernet0/1
```

```
R     10.10.10.0/24 [120/2] via 10.10.1.1, gigabitEthernet0/1, 00:12:07
```

```
C     10.10.20.0/24 is directly connected, gigabitEthernet0/2
```

```
R     10.10.30.0/24 [120/1] via 10.10.1.3, gigabitEthernet0/1, 00:10:47
```

Gateway of last resort is not set

```
SWITCH#
```

Device S3:

Display routing table on device S3, with routes from S1 and S2.

```
SWITCH#show ip route
```

Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP

O - OSPF, IA - OSPF inter area

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2

E1 - OSPF external type 1, E2 - OSPF external type 2

i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area

* - candidate default

IP Route Table for VRF "default"

Gateway of last resort is 10.10.1.2 to network 0.0.0.0

R* 0.0.0.0/0 [120/1] via 10.10.1.2, gigabitEthernet0/1, 00:03:06

C 10.10.1.0/24 is directly connected, gigabitEthernet0/1

R 10.10.10.0/24 [120/1] via 10.10.1.1, gigabitEthernet0/1, 00:01:18

R 10.10.20.0/24 [120/1] via 10.10.1.2, gigabitEthernet0/1, 00:07:56

C 10.10.30.0/24 is directly connected, gigabitEthernet0/2


SWITCH#

17.3.4. Configuring RIP Authentication

Need

- The two devices are interconnected, run the RIP routing protocol, and use the MD5 authentication method.

Networking



Configuration example

- Device S1 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.1/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.10.1/24
```

Configure the RIP process

Enable the rip process and configure the RIP version to version 2 so that routes with subnet masks can be advertised.

```
SWITCH(config)#router rip
SWITCH(config-router)#version 2
SWITCH(config-router)#passive-interface gigabitEthernet0/2
SWITCH(config-router)#no auto-summary
```

Associated Network

```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0
SWITCH(config-router)#network 10.10.10.1 255.255.255.0
```

configure keystring

```
SWITCH(config)#key chain rip-key
SWITCH(config-keychain)#key 1
SWITCH(config-keychain-key)#key-string test-password
SWITCH(config-keychain-key)#end
SWITCH#
```

Enable RIP authentication

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#ip rip authentication mode md5
SWITCH(config-if)#ip rip authentication key-chain rip-key
SWITCH(config-if)#end
```

- Device S2 configuration steps

Configure the ip address of port gigabitEthernet0/1

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.1.2/24
```

Configure the ip address of port gigabitEthernet0/2

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#no switchport
SWITCH(config-if)#ip address 10.10.20.1/16
```

Configure the RIP process

Enable the rip process and configure the RIP version to version 2 so that routes with subnet masks can be advertised.

```
SWITCH(config)#router rip
SWITCH(config-router)#version 2
SWITCH(config-router)#no auto-summary
```

Associated Network

```
SWITCH(config-router)#network 10.10.1.0 255.255.255.0
SWITCH(config-router)#network 10.10.20.1 255.255.0.0
```

configure keystring

```
SWITCH(config)#key chain rip-key
SWITCH(config-keychain)#key 1
```

```
SWITCH(config-keychain-key)#key-string test-password
SWITCH(config-keychain-key)#end
SWITCH#
```

Enable RIP authentication

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#ip rip authentication mode md5
SWITCH(config-if)#ip rip authentication key-chain rip-key
SWITCH(config-if)#end
```

- Show result

If the keys at both ends are inconsistent, the route cannot be synchronized. show ip rip peerCommand can view the increase of Received bad packets received.

Otherwise, the routes can be synchronized normally.

17.4. Display Information

- Show Routing Information

```
SWITCH#show ip route
Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP
       O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
       * - candidate default

IP Route Table for VRF "default"
Gateway of last resort is 10.10.1.2 to network 0.0.0.0

R*    0.0.0.0/0 [120/1] via 10.10.1.2, gigabitEthernet0/1, 00:03:06
C     10.10.1.0/24 is directly connected, gigabitEthernet0/1
R     10.10.10.0/24 [120/1] via 10.10.1.1, gigabitEthernet0/1, 00:01:18
R     10.10.20.0/24 [120/1] via 10.10.1.2, gigabitEthernet0/1, 00:07:56
C     10.10.30.0/24 is directly connected, gigabitEthernet0/2
SWITCH#
```

- Show Only RIP Routing Information

```
SWITCH#show ip route rip
IP Route Table for VRF "default"
R     10.10.30.0/24 [120/1] via 10.10.1.3, gigabitEthernet0/1, 00:44:29
R     192.168.101.0/24 [120/1] via 10.10.1.3, gigabitEthernet0/1, 00:44:29

Gateway of last resort is not set
SWITCH#
```

- Additional RIP Information

| Command | 作用 |
|-----------------------|---|
| show ip rip database | Display RIP database |
| show ip rip external | Display RIP republished routing information |
| show ip rip interface | Display RIP-related interface information |
| show ip rip peer | Display RIP peer information |


1 Configuring VRRP

1.1 Overview of VRRP

VRRP (Virtual Router Redundancy Protocol) combines several routing devices to form a virtual routing device, and uses the IP address of the virtual routing device as the user's default gateway to communicate with the external network. When the gateway device fails, the VRRP mechanism can elect a new gateway device to take over the data traffic, thereby ensuring reliable network communication.

This device only supports VRRPv2 function.

Network topology



Term Definition

- **VRRP Router:** A device running the VRRP protocol, which may belong to one or more virtual routers, such as RouterA and RouterB.
- **Virtual Router:** Also known as VRRP backup group, it consists of a Master device and multiple Backup devices, and is used as the default gateway for hosts in a shared LAN. For example, RouterA and RouterB together form a virtual router.
- **Master router (Virtual Router Master):** a VRRP device that is responsible for forwarding packets, such as RouterA.

- **Backup router (Virtual Router Backup):** a group of VRRP devices that do not undertake forwarding tasks. When the master device fails, they will become the new master device through election, such as RouterB.
- **VRID:** The ID of the virtual router. For example, the VRID of the virtual router composed of RouterA and RouterB is 1.
- **Virtual IP Address:** The IP address of the virtual router. A virtual router can have one or more IP addresses, which are configured by the user. For example, the virtual IP address of the virtual router composed of RouterA and RouterB is 10.1.1.10/24.
- **IP Address Owner:** If a VRRP device uses the virtual router IP address as the real interface address, the device is called the IP address owner. If the IP address owner is available, it will normally become the Master. For example, RouterA, the IP address of its interface is the same as the IP address of the virtual router, both 10.1.1.10/24, so it is the owner of the IP address of this VRRP backup group.
- **Virtual MAC Address:** The MAC address generated by the virtual router based on the virtual router ID. A virtual router has a virtual MAC address in the format: 00-00-5E-00-01-{VRID}(VRRP for IPv4); 00-00-5E-00-02-{VRID}(VRRP for IPv6). When the virtual router responds to ARP requests, use the virtual MAC address instead of the real MAC address of the interface. For example, the VRID of the virtual router composed of RouterA and RouterB is 1, so the MAC address of this VRRP backup group is 00-00-5E-00-01-01.

1.2 Configuring

- **Creating/Deleting VRRP Group**

| | |
|-------------|--|
| Command | SWITCH(config)# vrrp router <1-255> SWITCH(config)#no vrrp router <1-255> |
| Description | Global configuration mode. Create/delete VRRP group. |

- **Associating VRRP Interface**

| | |
|-------------|---|
| Command | SWITCH(config-vrrp)#interface IFNAME SWITCH(config-vrrp)#no interface |
| Description | VRRP group configuration mode. Configure/delete the Layer 3 interface associated with the VRRP group. Support SVI ports, such as vlan1; do not support Layer 2 ports, such as gigabitEthernet0/1 that is not configured as a Layer 3 port. |

- **Configuring VRRP Virtual Address**

| | |
|-------------|--|
| Command | SWITCH(config-vrrp)#virtual-ip A.B.C.D {master backup} SWITCH(config-vrrp)#no virtual-ip |
| Description | VRRP group configuration mode. The virtual address is the virtual router gateway address. Configuring the master role must ensure that the virtual IP is the interface IP associated with the group. |

- **Enabling/disabling VRRP Group**

| | |
|-------------|--|
| Command | SWITCH(config-vrrp)#enable SWITCH(config-vrrp)#no enable |
| Description | VRRP group configuration mode. Before enabling a VRRP group, you must configure the associated interface and virtual address. |

- Configure/Delete VRRP Priority

| | |
|-------------|--|
| Command | SWITCH(config-vrrp)#priority <1-255> SWITCH(config-vrrp)#no priority |
| Description | VRRP group configuration mode.Optional configuration. Priority 0 is reserved by the system for special use; a priority value of 255 is reserved for IP address owners. By default, the priority of the backup router is 100.The larger the value, the higher the priority. |

- Configuring VRRP Group Notifications Interval

| | |
|-------------|--|
| Command | SWITCH(config-vrrp)#advertisement-interval <1-10> SWITCH(config-vrrp)#no advertisement-interval |
| Description | VRRP group configuration mode. Optional configuration, the unit is seconds, the default is 1. |

- Configuring Preemptive Mode

| | |
|-------------|---|
| Command | SWITCH(config-vrrp)#preempt-mode on SWITCH(config-vrrp)#no preempt-mode |
| Description | VRRP group configuration mode. Optional configuration, preemption is enabled by default. |

- Configuring Authentication Function

| | |
|-------------|--|
| Command | SWITCH(config-vrrp)#authentication text LINE SWITCH(config-vrrp)#no authentication |
| Description | VRRP group configuration mode. Optional configuration, default authentication-free mode. VRRPv1 supports authentication-free mode, simple key authentication mode, and md5 authentication mode, but does not improve security; VRRPv2 is compatible with v1 authentication mode; VRRPv3 cancels the security field. It is not recommended to configure the authentication function on the device. |

- Configuring Circuit Failover

| | |
|-------------|--|
| Command | SWITCH(config-vrrp)#circuit-failover IFNAME <1-253> SWITCH(config-vrrp)#no circuit-failover |
| Description | VRRP group configuration mode. |

Optional configuration, the line failover function is not enabled by default.

After the configuration, the VRRP group will monitor the configured line, and once a line failure is found, it will re-elect the protocol by adjusting the configured priority offset.

1.3 Examples


1.3.1 Load Balance Scenario

Requirement

- Under normal circumstances, dual gateways share user traffic equally.
- When the gateway device fails alone, the user can still access the external network .

Network Diagram

Figure 1 VRRP Load Balancing Scenario



Typical configuration example

R3:

```
SWITCH(config)# vlan 300
SWITCH(config)# interface vlan300
SWITCH(config-if)# ip address 192.168.3.300/24
SWITCH(config)# ip route 0.0.0.0 0.0.0.0 192.168.3.1
```

R1:

```
SWITCH(config)# vlan 100,200,300
SWITCH(config)# interface gigabitEthernet0/1
SWITCH(config-if)# switchport access vlan 300
SWITCH(config)# interface gigabitEthernet0/10
SWITCH(config-if)# switchport mode trunk
SWITCH(config-if)# switchport trunk allow-vlan 100,200
```

```

SWITCH(config)#interface vlan100
SWITCH(config-if)# ip address 192.168.1.100/24
SWITCH(config)#interface vlan200
SWITCH(config-if)# ip address 192.168.2.100/24
SWITCH(config)#interface vlan300
SWITCH(config-if)# ip address 192.168.3.100/24
SWITCH(config)# vrrp router 1
SWITCH(config-vrrp)# interface vlan100
SWITCH(config-vrrp)# virtual-ip 192.168.1.1 backup
SWITCH(config-vrrp)# circuit-failover vlan300
SWITCH(config-vrrp)# enable
SWITCH(config)# vrrp router 2
SWITCH(config-vrrp)# interface vlan200
SWITCH(config-vrrp)# virtual-ip 192.168.2.1 backup
SWITCH(config-vrrp)# circuit-failover vlan300
SWITCH(config-vrrp)# priority 90
SWITCH(config-vrrp)# enable
SWITCH(config)# vrrp router 3
SWITCH(config-vrrp)# interface vlan300
SWITCH(config-vrrp)# virtual-ip 192.168.3.1 backup
SWITCH(config-vrrp)# circuit-failover gigabitEthernet0/10
SWITCH(config-vrrp)# enable

```

R2:

```

SWITCH(config)# vlan 100,200,300
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)# switchport access vlan 300
SWITCH(config)#interface gigabitEthernet0/10
SWITCH(config-if)# switchport mode trunk
SWITCH(config-if)# switchport trunk allow-vlan 100,200
SWITCH(config)#interface vlan100
SWITCH(config-if)# ip address 192.168.1.200/24
SWITCH(config)#interface vlan200
SWITCH(config-if)# ip address 192.168.2.200/24
SWITCH(config)#interface vlan300
SWITCH(config-if)# ip address 192.168.3.200/24
SWITCH(config)# vrrp router 1
SWITCH(config-vrrp)# interface vlan100
SWITCH(config-vrrp)# virtual-ip 192.168.1.1 backup
SWITCH(config-vrrp)# circuit-failover vlan300
SWITCH(config-vrrp)# priority 90
SWITCH(config-vrrp)# enable
SWITCH(config)# vrrp router 2
SWITCH(config-vrrp)# interface vlan200

```

```

SWITCH(config-vrrp)# virtual-ip 192.168.2.1 backup
SWITCH(config-vrrp)# circuit-failover vlan300
SWITCH(config-vrrp)# enable
SWITCH(config)# vrrp router 3
SWITCH(config-vrrp)# interface vlan300
SWITCH(config-vrrp)# virtual-ip 192.168.3.1 backup
SWITCH(config-vrrp)# circuit-failover gigabitEthernet0/10
SWITCH(config-vrrp)# priority 90
SWITCH(config-vrrp)# enable

```


1.3.2 MSTP+VRRP+OSPFScenario

Requirement

- Under normal circumstances, dual gateways share user traffic equally.
- When the gateway device fails alone, the user can still access the external network .
- When both uplink and downlink links fail at the same time, users can still access the external network.

Network Diagram

Figure2 MSTP+VRRP+OSPF Scenario



R1/S1/S2 use OSPF Layer 3 redundancy, S1 and S2 are interconnected through trunk ports, and the others are interconnected through Layer 3 ports

```

router ospf
network 2.2.1.0.0.0.0.255 area 0
network 2.2.2.0.0.0.0.255 area 0
network 3.3.1.0.0.0.0.255 area 0

```

The priority of VLAN 200 of S1 is reduced by ipospf cost 10, the default cost=0; VLAN 100 of S2 is also reduced

Data channel vlan 100 and 200, corresponding to MSTP instance 1 and 2 respectively

S1/S2 implements load balancing for VLAN 100 and 200 respectively through VRRP

S1/S2 monitor the status of their respective uplink ports, and lower the priority to give up the role of master when abnormal

S1/S2/S3 use MSTP Layer 2 load balancing and are interconnected through trunk ports

S3 is configured with low priority to block S1-S2 by default

The user side connected to S3 uses the access port, and configures VLAN 100 and VLAN 200 respectively. Users under VLAN 100 use the VIP of S1 as the gateway by default and go to the left network; users under VLAN 200 go to the right

Typical configuration example



S3.txt



S2.txt



S1.txt



R1.txt

1.4 Display Information

- Show Vrrp Group Information

```

#show vrrp
----- VRRP 1 -----
ID: 1
State: Master (Enabled)
Virtual IP: 2.2.1.1/24 (Not IP owner)

```

Last Master: 2.2.1.3 (63510s ago)

Interface: vlan100

Priority: 100 (conf.-1)

Advertisement interval: 1 sec

Preempt mode: TRUE

Authentication: none

----- VRRP 2 -----

ID: 2

State: Backup (Enabled)

Virtual IP: 2.2.2.1/24 (Not IP owner)

Last Master: 2.2.2.3 (0s ago)

Interface: vlan200

Priority: 90 (conf.90)

Advertisement interval: 1 sec

Preempt mode: TRUE

Authentication: none

18. Configuring ACL

18.1. Overview of ACL

The ACL Implement packet filtering by configuring matching rules and processing operations for packets. The ACL can effectively prevent illegal users from accessing the network, and can also control traffic and save network resources.

Packet matching rules defined by ACL can also be referenced by other functions that need to differentiate traffic, such as the definition of traffic classification rules in QoS.

The ACL classifies packets through a series of matching conditions, which can be SMAC, DMAC, SIP, DIP, etc. According to the matching conditions, ACLs can be divided into the following types:

Standard IP-based ACL: Make rules based only on the source IP address of the packet.

Extended IP-based ACL: formulate rules based on the source IP address, destination IP address, ETYPE, and protocol of the data packet.

MAC-based ACL: formulate rules based on the source MAC address and destination MAC address of the data packet.

Named ACL: formulating rules is the same as IP-based standard ACL, extended ACL.

18.2. Configuring

- Creating a IP-based Standard ACL

| | |
|-------------|---|
| Command | SWITCH(config)#ip-access-list ACLID {permit deny} {SIPADDR SIPADDRMASK any} SWITCH(config)#no ip-access-list ACLID {permit deny} {SIPADDR SIPADDRMASK any} SWITCH(config)#no ip-access-list ACLID |
| Description | Define a standard IP-based ACL rule by using a source IPv4 address and wildcard. The ACLID is a decimal number from 1 to 99 or 1300 to 1999. Enter deny or permit to specify whether to deny or permit access if conditions are matched. The SIPADDR is the source IPv4 address of the network from which the packet is being sent. The SIPADDRMASK applies wildcard bits to the SIPADDR. The keyword any as an abbreviation for SIPADDR and SIPADDRMASK of 0.0.0.0 255.255.255.255. You do not need to enter a source-wildcard. |

- Creating a IP-based Extended ACL

| | |
|-------------|--|
| Command | SWITCH(config)# ip-access-list ACLID {permit deny} {TYPE} {SIPADDR SIPADDRMASK any} {DIPADDR DIPADDRMASK any} SWITCH(config)#no ip-access-list ACLID {permit deny} TYPE {SIPADDR SIPADDRMASK any} {DIPADDR DIPADDRMASK any} SWITCH(config)# no ip-access-list ACLID |
| Description | Define an extended IP-based ACL rule. The ACLID is a decimal number from 100 to 199 or 2000 to 2699. Enter deny or permit to specify whether to deny or permit the packet if conditions are matched. For TYPE, enter the name or number of an IP protocol: gre, igmp, opcomp, ospf, ip, rsvp, vrrp, pim, tcp, or udp, or an integer in the range 0 to 255 representing an IP protocol number. To match any Internet protocol, use the keyword any. The SIPADDR is the number of the network from which the packet is sent. |

| | |
|--|--|
| | <p>The SIPADDRMASK applies wildcard bits to the SIPADDR.</p> <p>The DIPADDR is the network to which the packet is sent.</p> <p>The DIPADDRMASK applies wildcard bits to the DIPADDR.</p> <p>SIPADDR, SIPADDRMASK, DIPADDR, and DIPADDRMASK can be specified as any, The keyword for 0.0.0.0 255.255.255.255.</p> |
|--|--|

- **Creating a MAC-based ACL**

| | |
|--------------------|---|
| Command | <p>SWITCH(config)#mac-access-list ACLID {permit deny} {SMAC SMACMASK any} {DMAC DMACMASK any}</p> <p>SWITCH(config)#no mac-access-list ACLID {permit deny} {SMAC SMACMASK any} {DMAC DMACMASK any}</p> <p>SWITCH(config)#no mac-access-list ACLID</p> |
| Description | <p>Define an MAC-based ACL rule, specify to permit or deny any source MAC address, a source MAC address with a mask, and any destination MAC address, destination MAC address with a mask.</p> <p>The ACLID is a decimal number from 100 to 199 or 2000 to 2699.</p> <p>SMAC, SMACMASK, DMAC, and DMACMASK can be specified as any, The keyword for 0000.0000.0000 ffff.ffff.ffff.</p> <p>Enter deny or permit to specify whether to deny or permit the packet if conditions are matched.</p> |

- **Creating a Named IP-based Standard ACL**

| | |
|--------------------|---|
| Command | <p>SWITCH(config)#ip-access-list standard ACLNAME {permit deny} {SIPADDR SIPADDRMASK any}</p> <p>SWITCH(config)#no ip-access-list standard ACLNAME {permit deny} {SIPADDR SIPADDRMASK any}</p> <p>SWITCH(config)#no ip-access-list standard ACLNAME</p> |
| Description | <p>Define a standard ACL rule using the ACLNAME, specify one or more conditions denied or permitted to decide if the packet is forwarded or dropped.</p> <p>The SIPADDR is the source IPv4 address of the network from which the packet is being sent.</p> <p>The SIPADDRMASK applies wildcard bits to the SIPADDR.</p> <p>The keyword any as an abbreviation for SIPADDR and SIPADDRMASK of 0.0.0.0 255.255.255.255. You do not need to enter a source-wildcard.</p> |

- **Creating a Named IP-based Extended ACL**

| | |
|--------------------|---|
| Command | <p>SWITCH(config)#ip-access-list extended ACLNAME {permit deny} TYPE {SIPADDR SIPADDRMASK any} {DIPADDR DIPADDRMASK any}</p> <p>SWITCH(config)#no ip-access-list extended ACLNAME {permit deny} TYPE {SIPADDR SIPADDRMASK any} {DIPADDR DIPADDRMASK any}</p> <p>SWITCH(config)#no ip-access-list extended ACLNAME</p> |
| Description | <p>Define a extended ACL rule using the ACLNAME, specify one or more conditions denied or permitted to decide if the packet is forwarded or dropped.</p> <p>For TYPE, enter the name or number of an IP protocol: gre, igmp, opcomp, ospf, ip, rsvp, vrrp, pim, tcp, or udp, or an integer in the range 0 to 255 representing an IP protocol number. To match any Internet protocol, use the keyword any.</p> |

| | |
|--|---|
| | <p>The SIPADDR is the number of the network from which the packet is sent.</p> <p>The SIPADDRMASK applies wildcard bits to the SIPADDR.</p> <p>The DIPADDR is the network to which the packet is sent.</p> <p>The DIPADDRMASK applies wildcard bits to the DIPADDR.</p> <p>SIPADDR, SIPADDRMASK, DIPADDR, and DIPADDRMASK can be specified as any, The keyword for 0.0.0.0 255.255.255.255.</p> |
|--|---|

Note

- ✦ Maximum of 128 rules can be configured under a ACL.
- ✦ The mask is inverted, For example, to match an IP address in the range of 192.168.1.0/24, configure 192.168.1.0 0.0.0.255.
- ✦ For the named ACL, the first character of ACLNAME cannot be a number.
- ✦ When creating an ACL, by default, the end of the ACL contains an implicit deny statement for all packets that it did not find a match for before reaching the end.

• Applying ACL to an Interface

| | |
|-------------|--|
| Command | <p>SWITCH(config-if)#access-group ACLNAME input</p> <p>SWITCH(config-if)#no access-group ACLNAME input</p> |
| Description | Control access to the specified interface. |

Note

- ✦ When an ACL has been applied to a interface, if you need to add or delete a rule, you need to un-apply it from the interface first.

18.3. Examples

Example 1: This example shows how to filter the ingress packets of port gigabitEthernet0/1, and allow the packets whose SIP is 192.168.1.0/24, and discard other packets.

Step 1: Entering ACL rules.

```
SWITCH(config)#ip-access-list permit 192.168.1.0 0.0.0.255
SWITCH(config)#ip-access-list 1 deny any
```

Step 2: Applying ACL to the interface gigabitEthernet0/1.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#access-group 1 in
```

18.4. Display Information

• Display ACL Information

```
SWITCH#show ip-access-list 1
Standard IP access list: 1
    permit 1.1.1.1
    deny any
```

```
SWITCH#show mac-access-list 200
```

```
Extended MAC-ACCESS-LIST: 200
```

```
permit host 0001.0002.0003 any
```


```
deny any any
```


19. Configuring QoS

19.1. Overview of QoS

Typically, networks operate on a best-effort delivery basis, which means that all traffic has equal priority and an equal chance of being delivered in a timely manner. When congestion occurs, all traffic has an equal chance of being dropped. When you configure the QoS feature, you can select specific network traffic, prioritize it according to its relative importance, and use congestion-management and congestion-avoidance techniques to provide preferential treatment. Implementing QoS in your network makes network performance more predictable and bandwidth utilization more effective.

The QoS implementation is based on the Differentiated Services (Diff-Serv) architecture, an emerging standard from the Internet Engineering Task Force (IETF). This architecture specifies that each packet is classified upon entry into the network. The following Figure shows the model of the QoS.



Classification

Classification is the process of distinguishing one kind of traffic from another by examining the fields in the packet. Classification is enabled only if QoS is globally enabled on the switch. By default, QoS is globally disabled, so no classification occurs.

During classification, the switch performs a lookup and assigns a QoS label to the packet. The QoS label identifies all QoS actions to be performed on the packet and from which queue the packet is sent.

The QoS label is based on the DSCP or the CoS value in the packet and decides the queueing and scheduling actions to perform on the packet. The label is mapped according to the trust setting and the packet type.

Trust CoS:

- QoS with CoS label.
- For tagged packets, the CoS uses the CoS information in the tag.
- For packets without tags, the CoS adopts the default CoS value of the port.

Trust DSCP:

- For non-IP packets, the QoS is labeled with CoS; for packets with tags, CoS uses the CoS information in the tag; for packets without tags, the CoS uses the default CoS of the port.
- For IP packets, QoS has a DHCP label; select the DSCP value of the packet.

No trust:

- QoS with CoS label
- CoS adopts the default CoS value of the port.

Policing(Ingress)

The ingress policer meters the given flow and classifies as either in-profile or out-of-profile. Out-of-profile packets may be

discarded or have their QoS attributes remarked.

Marking

After a packet is classified and has a DSCP-based or CoS-based QoS label assigned to it, the marking process can begin.

For packets with CoS labels:

- Use the configured CoS-to-DSCP mapping relationship to generate DSCP values for packets.
- Select the egress queue for the packet through the CoS-to-Queue mapping relationship.

For packets with DSCP labels

- Modify the DSCP value of the packet through the DSCP-to-DSCP mapping relationship.
- Generate a new CoS value for the packet through the DSCP-to-CoS mapping relationship.
- Select the egress queue for the packet through the DSCP-to-Queue mapping relationship.

Queuing and scheduling

Generally, there are 8 queues for QoS exit, which map the 0-7 priority relationship of CoS. The packet enters the corresponding egress queue according to the final marked CoS and CoS-to-Queue relationship. For the priority of packet processing in the egress queue, there are the following algorithms:

- WRR: The weight scheduling algorithm processes the packets in each queue in turn. The weight configuration can be used to change the number of queue packets processed in each cycle. The larger the weight, the higher the queue priority.
- SP: Strict scheduling algorithm, traverse queue 7 to queue 0 in each loop, when the initial processing of the packets in the high-priority queue ends, continue to process the low-priority queue.
- SP+WRR: The combination of WRR and SP, the global WRR mode, supports a specific queue configured as SP mode, and the queue configured as SP mode is a high-priority queue, which is processed first.

Policing(Egress)

The egress policer meters the given flow and classifies as either in-profile or out-of-profile. Out-of-profile packets may be discarded.

19.2. Configuring

● Enabling QoS Globally

| | |
|-------------|--|
| Command | SWITCH(config)#mls qos enable SWITCH(config)#no mls qos |
| Description | Enabling QoS Globally. Default is disabled. |

● Configuring Scheduling algorithm

| | |
|-------------|--|
| Command | SWITCH(config)#mls qos algorithm {sp wrr} |
| Description | Configuring the queue scheduling algorithm, support two modes: wrr and sp. |

● Configuring Queue Wrr-weight

| | |
|-------------|--|
| Command | SWITCH(config)#mls qos wrr-weight <0-7> <0-32> |
| Description | Configure the queue weight. The queue weight is only valid for wrr mode. The default weight of all queues is 1. When in wrr mode, configure the queue weight to 0, the queue will schedule in sp mode. |

● Configuring Trust Mode on the Interface

| | |
|-------------|--|
| Command | SWITCH(config-if)#mls qos trust {cos dscp} SWITCH(config-if)#no mls qos trust |
| Description | <p>Configure the port trust mode, the default is not trust mode.</p> <p>When in no trust mode, the CoS field and DHCP field of the packet will be modified according to the default CoS of the port.</p> <p>When in trust cos mode, the same as the no trust mode for untagged packets, and for tagged packets, use the own CoS of the packet.</p> <p>When configuring trust dscp mode, for ip packets, select the packet with DSCP, and for non-ip packets, the same as trust cos mode.</p> |

- Configuring Default CoS on the interface

| | |
|-------------|--|
| Command | SWITCH(config-if)#mls qos cos <0-7> SWITCH(config-if)#no mls qos cos |
| Description | <p>Configure the default CoS of the port. The default CoS takes effect for the ingress packets without tags.</p> <p>The default port cos is 0.</p> |

- Configuring CoS-to-DSCP Mapping

| | |
|-------------|---|
| Command | SWITCH(config)#mls qos cos-dscp <0-63> <0-63> <0-63> <0-63> <0-63> <0-63> <0-63> <0-63> SWITCH(config)#no mls qos cos-dscp |
| Description | <p>Configure CoS-to-DSCP mapping.</p> <p>Default CoS-to-DSCP mapping: 0-0, 1-8, 2-16, 3-24, 4-32, 5-40, 6-48, 7-56.</p> |

- Configuring CoS-to-Queue Mapping

| | |
|-------------|---|
| Command | SWITCH(config)#mls qos cos-queue <0-7> <0-7> SWITCH(config)#no mls qos cos-queue <0-7> |
| Description | <p>Configure CoS-to-Queue mapping.</p> <p>Default CoS-to-Queue mapping: 0-0, 1-1, 2-2, 3-3, 4-4, 5-5, 6-6, 7-7.</p> |

Note

When the configured port is no trust, trust cos or trust dscp and the port is not ip: the cos-dscp configuration takes effect, modify the packet dscp according to the mapping relationship, and the cos-queue configuration takes effect, modify the packet export queue according to the mapping relationship.

- Configuring DSCP-to-CoS Mapping

| | |
|-------------|--|
| Command | SWITCH(config)#mls qos dscp-cos <0-63> to <0-7> SWITCH(config)#no mls qos dscp-cos |
| Description | <p>Configure DSCP-to-CoS mapping.</p> <p>Default DSCP-to-CoS mapping: <0-7>-0, <8-15>-1, <16-23>-2, <24-31>-3, <32-39>-4, <40-47>-5, <48-55>-6, <56-63>-7.</p> |

- Configuring DSCP-to-DSCP Mapping

| | |
|-------------|--|
| Command | SWITCH(config)#mls qos dscp-mutation <0-63> to <0-63> SWITCH(config)#no mls qos dscp-mutation |
| Description | Configure DSCP-to-DSCP mapping. |

- Configuring DSCP-to-Queue Mapping

| | |
|-------------|---|
| Command | SWITCH(config)#mls qos dscp-queue <0-63> <0-7> SWITCH(config)#no mls qos dscp-queue <0-63> |
| Description | Configure DSCP-to-Queue mapping. Default DSCP-to-Queue mapping: <0-7>-0, <8-15>-1, <16-23>-2, <24-31>-3, <32-39>-4, <40-47>-5, <48-55>-6, <56-63>-7. |

Note

When configuring the port as trust dscp and ip packets: the dscp-cos configuration takes effect, modify the packet dscp according to the mapping relationship, and the dscp-queue configuration takes effect, and modify the packet egress queue according to the mapping relationship. When a colleague configures dscp-dscp at the same time, first perform dscp-dscp conversion, and then perform dscp-cos mapping as a result.

- Creating Class-map

| | |
|-------------|--|
| Command | SWITCH(config)#class-map CNAME SWITCH(config-cmap)# SWITCH(config)#no class-map CNAME |
| Description | Create class-map. After creating a class-map, automatically enter the class-map mode. |

- Configuring Class-map Matching Rule

| | |
|-------------|--|
| Command | SWITCH(config-cmap)# match access-group ACLNAME SWITCH(config-cmap)#no match access-group ACLNAME |
| Description | Configure to match ACL entries for class-map. |

| | |
|-------------|---|
| Command | SWITCH(config-cmap)#match ip-dscp <0-63> SWITCH(config-cmap)#no match ip-dscp |
| Description | Configure to match the DHCP field in the IP packet, up to 64 different DHCP values can be configured. |

| | |
|---------|---|
| Command | SWITCH(config-cmap)#match cos <0-7> SWITCH(config-cmap)#no match cos |
|---------|---|

| | |
|-------------|---|
| Description | Configure to match the CoS field in the packet, up to 8 different CoS values can be configured. |
|-------------|---|

| | |
|-------------|---|
| Command | SWITCH(config-cmap)#match ethertype ETYPE SWITCH(config-cmap)#no match ethertype |
| Description | Configure to match the ethernet protocol type field of the packets. |

| | |
|-------------|---|
| Command | SWITCH(config-cmap)#match {vlan <1-4094> vlan-range <1-4094> to <1-4094>} SWITCH(config-cmap)#no match {vlan vlan-range} |
| Description | Configure to match vlan field in the packet, support range configuration. |

| | |
|-------------|---|
| Command | SWITCH(config-cmap)#match layer4 {tcp udp} {source-port destination-port} VALUE SWITCH(config-cmap)#no match layer4 {tcp udp} {source-port destination-port} VALUE |
| Description | Configure to match Layer 4 port fields of TCP and UDP packets. |

| | |
|-------------|--|
| Command | SWITCH(config-cmap)#match vlan-range <1-4094> to <1-4094> ethertype ETYPE SWITCH(config-cmap)#no match vlan-range |
| Description | Configure to match vlan and etype fields in the packets. |

- Creating Policy-map

| | |
|-------------|---|
| Command | SWITCH(config)#policy-map PNAME SWITCH(config-pmap)# SWITCH(config)#no policy-map PNAME |
| Description | Configure policy-map |

- Attaching Policy-map to Class-map

| | |
|-------------|--|
| Command | SWITCH(config-pmap)# class-map CNAME SWITCH(config-pmap-c)# SWITCH(config-pmap)#no class-map CNAME |
| Description | Attach class-map to policy-map. A policy-map can attach up to 8 class-maps. |

- Configuring Action

| | |
|-------------|---|
| Command | SWITCH(config-pmap-c)#set cos <0-7> SWITCH(config-pmap-c)#no set cos |
| Description | Configure policy action: modify the cos field of packets. |

| | |
|-------------|--|
| Command | SWITCH(config-pmap-c)#set ip-dscp <0-63> SWITCH(config-pmap-c)#no set ip-dscp |
| Description | Configure policy action: modify the ip-dscp field of packets. |

| | |
|-------------|--|
| Command | SWITCH(config-pmap-c)#set vlan <1-4094> SWITCH(config-pmap-c)#no set vlan |
| Description | Configure policy action: modify packet vlan. |

| | |
|-------------|--|
| Command | SWITCH(config-pmap-c)#nest vlan <1-4094> SWITCH(config-pmap-c)#no nest vlan |
| Description | Configure policy action: add external tags to matching packets. |

| | |
|-------------|---|
| Command | SWITCH(config-pmap-c)#police cir <32-1000000> cbs <4-31250> exceed-action drop SWITCH(config-pmap-c)#no police |
| Description | Configure policy action: rate-limit. Cir is the speed limit water line, in kbps. Cbs is burst capacity, unit Kbyte. |

Note

The value of cir is determinable. For example, if the speed limit is 1M, then the value of cir is 1024, but the value of cbs is taken from the empirical value. When the cbs value is set large, the flow peak is higher, and the speed limit is stable, but the average speed may be higher than the speed limit value; when the cbs value is set small, the flow peak is lower, the speed limit fluctuates greatly, and the average speed may be lower than the speed limit value. It is recommended that the cbs configuration take 4 times the value of cir.

● Applying Policy-map on the Interface

| | |
|-------------|---|
| Command | SWITCH(config-if)#service-policy input PNAME SWITCH(config-if)#no service-policy input |
| Description | Apply the policy-map on the interface. Only one policy-map can be applied to an interface. |

● Configuring Ingress Rate-limit on the interface

| | |
|-------------|---|
| Command | SWITCH(config-if)#rate-limit input <64-1000000> <32-16384> SWITCH(config-if)#no rate-limit input |
| Description | Configure port ingress rate limit. |

| | |
|--|---|
| | <p>The first parameter is limit level, in kbps.</p> <p>The second parameter is burst level, in Kbyte.</p> |
|--|---|

- **Configuring Egress Rate-limit on the interface**

| | |
|--------------------|--|
| Command | <pre>SWITCH(config-if)#rate-limit output <64-1000000> <32-16384></pre> <pre>SWITCH(config-if)#no service-policy output</pre> |
| Description | <p>Configure port egress rate limit.</p> <p>The first parameter is limit value, in kbps.</p> <p>The second parameter is burst value, in Kbyte.</p> |

Note

The limit value is determinable. For example, if the speed limit is 1M, then the limit value is 1024, but the burst value is taken from the experience value. When the burst value is large, the flow peak is higher, and the speed limit is stable, but the average rate may be higher than the speed limit value; when the burst value is small, the flow peak is lower, the speed limit fluctuates greatly, and the average rate may be lower than the speed limit value. . It is recommended that the burst configuration be 4 times the limit value.

19.3. Examples

Example 1: This example shows how to Configure ingress and egress rate-limit on the interface.

Step 1: Configuring Ingress rate-limit on interface gigabitEthernet0/1.

```
SWITCH(config-if)#rate-limit input 1024 4096
```

Step 2: Configuring Egress rate-limit on interface gigabitEthernet0/1.

```
SWITCH(config-if)#rate-limit output 1024 4096
```

Example 2: This example shows how to configure flow-based rate-limit.

Step 1: Enable QoS globally.

```
SWITCH(config)#mls qos enable
```

Step 2: Create ACL rule.

```
SWITCH(config)#ip-access-list 1 permit 192.168.64.1
```

Step 3: Create class-map, policy-map, attach ACL to the class-map, attach class-map to the policy-map, and configure the policy-map action.

```
SWITCH(config)#class-map c1
SWITCH(config-cmap)#match access-group 1
SWITCH(config-cmap)#exit
SWITCH(config)#policy-map p1
SWITCH(config-pmap)#class-map c1
SWITCH(config-pmap-c)#police cir 1024 cbs 4096 exceed-action drop
```

Step 4: Apply policy-map to the interface.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#service-policy input p1
```

Example 3: This example shows how to configure port-based QoS service, to Implement preferential forwarding of specific port packets.

Step 1: Enable QoS globally.

```
SWITCH(config)#mls qos enable
```

Step 2: Configure interface gigabitEthernet0/1 and gigabitEthernet0/2 trust cos. Set gigabitEthernet0/1 default CoS to 0. Set gigabitEthernet0/2 default CoS to 2.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#mls qos trust cos
SWITCH(config-if)#mls qos cos 0
SWITCH(config-if)#exit
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#mls qos trust cos
SWITCH(config-if)#mls qos cos 2
```

Step 3: Configure CoS-to-Queue mapping.

```
SWITCH(config)#mls qos cos-queue 0 0
SWITCH(config)#mls qos cos-queue 2 2
```

Step 4: Configure scheduling algorithm wrr.

```
SWITCH(config)#mls qos algorithm wrr
```

Step 5: Configuring queue 2 weight 0.

```
SWITCH(config)#mls qos weight 2 0
```

19.4. Display Information

- Display Scheduling Algorithm and Weight Information

```
SWITCH#show mls qos algorithm
Mls qos algorithm is WRR.
```

| Queue-id | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|----------|---|---|---|---|---|---|---|---|
| Weight | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

- Display CoS-to-DSCP and CoS-to-Queue Mapping Information

```
SWITCH#show mls qos cos-maps
```

```
-----
```

| Cos | Dscp | Queue |
|-------|------|-------|
| ----- | | |
| 0 | 0 | 0 |
| 1 | 8 | 1 |
| 2 | 16 | 2 |
| 3 | 24 | 3 |
| 4 | 32 | 4 |
| 5 | 40 | 5 |
| 6 | 48 | 6 |
| 7 | 56 | 7 |

- Display DSCP-to-CoS, DSCP-to-DSCP and DSCP-to-Queue Mapping Information

```
SWITCH#show mls qos dscp-maps
```

```
-----
```

| Dscp | Cos | Mutation | Queue |
|-------|-----|----------|-------|
| ----- | | | |

| | | | |
|----|---|----|---|
| 0 | 0 | 0 | 0 |
| 1 | 0 | 1 | 0 |
| 2 | 0 | 2 | 0 |
| 3 | 0 | 3 | 0 |
| 4 | 0 | 4 | 0 |
| 5 | 0 | 5 | 0 |
| 6 | 0 | 6 | 0 |
| 7 | 0 | 7 | 0 |
| 8 | 1 | 8 | 1 |
| 9 | 1 | 9 | 1 |
| 10 | 1 | 10 | 1 |
| 11 | 1 | 11 | 1 |
| 12 | 1 | 12 | 1 |
| 13 | 1 | 13 | 1 |
| 14 | 1 | 14 | 1 |
| 15 | 1 | 15 | 1 |

- Display QoS Configuration on the Interfaces

```
SWITCH#show mls qos interfaces
```

```
-----
```

| Interface | Trust mode | Cos |
|-----------|------------|-----|
| ----- | | |

| | | |
|--------|-----|---|
| GiE0/1 | Not | 0 |
| GiE0/2 | Not | 0 |
| GiE0/3 | Not | 0 |
| GiE0/4 | Not | 0 |
| GiE0/5 | Not | 0 |
| GiE0/6 | Not | 0 |
| GiE0/7 | Not | 0 |
| GiE0/8 | Not | 0 |

- Display Class-map Configuration

```
SWITCH#show class-map
```

```
CLASS-MAP-NAME: c1
```

```
Match Cos: 3
```

- Display Policy-map Configuration

```
SWITCH#show policy-map
```

```
POLICY-MAP-NAME: p1
```

```
State: detached
```

```
CLASS-MAP-NAME: c1
```

```
Match Cos: 3
```

```
Police: Mode: SrTCM
```

```
    cir (1024 Kbps)
    cbs (4096 KBytes)
    exceed-action (drop)
```

- Display Rate-limit Configuration on the Interfaces

```
SWITCH#show rate-limit
-----
Interface    In limit  In burst  Out limit  Out burst
-----
GiE0/1       --        --         --         --
GiE0/2       --        --         --         --
GiE0/3       1024     4096      --         --
GiE0/4       --        --         --         --
GiE0/5       --        --         --         --
GiE0/6       --        --         --         --
GiE0/7       --        --         --         --
GiE0/8       --        --         --         --
GiE0/9       --        --         --         --
GiE0/10      --        -         1024      4096
```

20. Configuring DHCP Snooping

20.1. Overview of DHCP Snooping

DHCP snooping (Dynamic Host Configuration Protocol) is a security feature that acts like a firewall between untrusted hosts and trusted DHCP servers. When DHCP snooping is enabled on a VLAN, the system examines DHCP messages sent from untrusted hosts associated with the VLAN and extracts their IP addresses and lease information. This information is used to build and maintain the DHCP snooping database.

DHCP snooping is enabled on a per-VLAN basis. By default, the feature is inactive on all VLANs. You can enable the feature on a single VLAN or a range of VLANs.

Trusted Sources

The DHCP snooping feature determines whether traffic sources are trusted or untrusted. DHCP snooping acts as a guardian of network security by keeping track of valid IP addresses assigned to downstream network devices by a trusted DHCP server. The default trust state of all interfaces is untrusted.

DHCP Snooping Limit Rate

Configure the number of DHCP packets per second that an interface can receive, to reduce or eliminate the impact of DHCP packet attack from this interface.

MAC Address Verification

With DHCP snooping MAC address verification enabled, DHCP snooping verifies that the source MAC address and the client hardware address match in DHCP packets that are received on untrusted ports. The source MAC address is a Layer 2 field associated with the packet, and the client hardware address is a Layer 3 field in the DHCP packet.

Option-82 Insertion

DHCP Option82 option is also called DHCP relay agent information option, one of many dhcp options. The Option82 option is a DHCP option proposed to enhance the security of the DHCP server and improve the IP address allocation strategy. The addition and stripping of options are implemented by the relay component.

DHCP Database

The DHCP snooping feature dynamically builds and maintains the database using information extracted from intercepted DHCP messages. The database contains an entry for each untrusted host with a leased IP address if the host is associated with a VLAN that has DHCP snooping enabled. The database does not contain entries for hosts connected through trusted interfaces. When the ip verify source function is enabled on the interface, database entries act as valid users on the interface.

20.2. Configuring

- Enable DHCP Snooping Globally

| | |
|-------------|---|
| Command | SWITCH(config)#ip dhcp snooping SWITCH(config)#no ip dhcp snooping |
| Description | Enables DHCP snooping globally. |

- Enable DHCP Snooping on Vlans

| | |
|-------------|--|
| Command | SWITCH(config)#ip dhcp snooping vlan VID SWITCH(config)#no ip dhcp snooping vlan VIID |
| Description | Enables DHCP snooping on a VLAN or VLAN range, For example: |

| | |
|--|--|
| | <p>ip dhcp snooping vlan 3-10.</p> <p>By default, DHCP Snooping is enabled on all VLANs.</p> |
|--|--|

- Configuring Trust Resources

| | |
|-------------|--|
| Command | <p>SWITCH (config-if)#ip dhcp snooping trust</p> <p>SWITCH (config-if)#no ip dhcp snooping trust</p> |
| Description | <p>Configures the interface as trusted.</p> <p>By default, All interfaces are untrusted.</p> |

- Enabling Mac Address Verification

| | |
|-------------|--|
| Command | <p>SWITCH (config)#ip dhcp snooping verify mac-address</p> <p>SWITCH (config)#no ip dhcp snooping verify mac-address</p> |
| Description | <p>Enables DHCP snooping MAC address verification.</p> <p>By default is disabled.</p> |

- Configuring Rate Limit on Interface

| | |
|-------------|---|
| Command | <p>SWITCH (config-if)#ip dhcp snooping rate-limit PPS</p> <p>SWITCH (config-if)#no ip dhcp snooping rate-limit</p> |
| Description | <p>Configures DHCP packet rate limiting.</p> <p>PPS range from 0 to 128.</p> <p>If PPS is set to 0, this interface will drop all Incoming DHCP packets.</p> |

Note

- ◆ Due to hardware limitations, for DHCP rate limit, when the limit value is not 0, the software rate limit is used, and when the limit value is 0, the hardware rate limit is used. Software rate limit will consumes CPU resources.
-

- Enabling Option-82 Data Insertion

| | |
|-------------|---|
| Command | <p>SWITCH (config)#ip dhcp snooping information option-82</p> <p>SWITCH (config-if)#no ip dhcp snooping information option-82</p> |
| Description | <p>Enables DHCP option-82 data insertion.</p> |

- Configuring DHCP Snooping Database Write-delay Time

| | |
|-------------|--|
| Command | <p>SWITCH (config)#ip dhcp snooping database write-delay SECONDS</p> <p>SWITCH (config-if)#no ip dhcp snooping database write-delay</p> |
| Description | <p>Configuring DHCP Snooping data to be written to flash at regular intervals</p> <p>SECONDS range from 600 to 86400 by unit second.</p> |

- Trigger DHCP Snooping Database Write-flash

| | |
|---------|--|
| Command | <p>SWITCH (config)#ip dhcp snooping database write-flash</p> |
|---------|--|

| | |
|-------------|---|
| Description | Trigger DHCP Snooping database write-flash. |
|-------------|---|

- Trigger DHCP Snooping Database renew from flash

| | |
|-------------|--|
| Command | SWITCH(config)#ip dhcp snooping database renew |
| Description | Trigger DHCP Snooping database renew from flash. |

- Clear DHCP Snooping Database

| | |
|-------------|---|
| Command | SWITCH#clear ip dhcp snooping database (vlan VLANID interface IFNAME mac-address XXXX.XXXX.XXXX ip-address A.B.C.D flash) |
| Description | Clear DHCP Snooping database based on port, vlan, MAC address, or IP address. Support to clear database in flash. |

20.3. Examples

Example 1: This is an example of DHCP Snooping typical application. The interface of gigabitEthernet0/8 is connected to DHCP server; USER-A obtains IP address by dynamic; There are other DHCP servers in the LAN, which will affect the IP address assignment of USER-A. Diagram as show in the Figure 1-1 below.




Figure 1-1 Typical application of DHCP Snooping Diagram

- Enable DHCP Snooping Globally.

```
SWITCH#configure terminal
SWITCH(config)#ip dhcp snooping
```

- Configuring gigabitEthernet0/8 as Trusted Resource.

```
SWITCH(config)#interface gigabitEthernet0/8
SWITCH(config-if)#ip dhcp snooping trust
```

20.4. Display Information

- Display DHCP Snooping Information

```
SWITCH#show ip dhcp snooping
Ip dhcp snooping           : Enabled
No ip dhcp snooping vlan   : 2-5
```

Verify mac-address : Disabled

Information option-82 : No

database write-delay : 0 seconds

| Interface | Trusted | Rate limit (pps) |
|---------------------|---------|------------------|
| ----- | | |
| gigabitEthernet0/16 | yes | unlimited |

21. Configuring 802.1X Authentication

21.1. Overview of 802.1X Authentication

The IEEE802 LAN/WAN committee proposed the 802.1X protocol to solve the problem of wireless LAN network security. Later, the 802.1X protocol was widely used in Ethernet as a common access control mechanism for LAN ports, mainly to solve the problems of authentication and security in Ethernet.

The 802.1X protocol is a port based network access control protocol. "Port-based network access control" means that, at the port level of the LAN access device, the access to the network resources is controlled through authentication for the connected user equipment.

21.1.1. 802.1X Architecture

The 802.1X system is a typical Client/Server structure, as shown in Figure 1, including three entities: Client, Device and Authentication server.

Figure 1 802.1X Authentication System Architecture



- A client is an entity on a local area network that is authenticated by the device on the other end of the link. The client is generally a user terminal device, and the user can initiate 802.1X authentication by starting the client software. The client must support EAPOL (Extensible Authentication Protocol over LAN).
- The device side is another entity on the local area network that authenticates connected clients. The device side is usually a network device that supports the 802.1X protocol. It provides the client with a port to access the LAN. The port can be a physical port or a logical port.
- The authentication server is an entity that provides authentication services for the device. The authentication server is used for user authentication, authorization and accounting, usually a RADIUS (Remote Authentication Dial-In User Service) server.

21.1.2. 802.1X Authentication Method

The 802.1X authentication system uses EAP (Extensible Authentication Protocol) to realize the exchange of authentication information between the client, the device and the authentication server.

- Between the client and the device, the EAP protocol packets use the EAPOL encapsulation format and are directly carried in the LAN environment.
- There are two ways to exchange information between the device and the RADIUS server. One is that the EAP protocol packet is relayed by the device, and is carried in the RADIUS protocol using the EAPOR (EAP over RADIUS) encapsulation format; the other is that the EAP protocol packet is terminated by the device. Packets with the PAP (Password

Authentication Protocol) or CHAP (Challenge Handshake Authentication Protocol) attribute attribute interact with the RADIUS server for authentication.

21.1.3. 802.1X Basic Concepts

21.1.3.1. Controlled/Uncontrolled Port

The device side provides a port for the client to access the LAN. This port is divided into two logical ports: a controlled port and an uncontrolled port. Any frame arriving at this port is visible on both controlled and uncontrolled ports.


- The uncontrolled port is always in a two-way connection state and is mainly used to transmit EAPOL protocol frames to ensure that the client can always send or receive authentication packets.
- The controlled port is in a bidirectional connection state in the authorized state and is used to transmit service packets; in the unauthorized state, it is forbidden to receive any packets from the client.

21.1.3.2. Authorized/Unauthorized Status

The device uses the authentication server to authenticate the client that needs to access the LAN, and controls the authorization/unauthorized status of the controlled port according to the authentication result (Accept or Reject).

Figure 2 Shows the effect of different authorization states on the controlled port on packets passing through this port. The figure compares the port status of two 802.1X authentication systems. The controlled port of system 1 is in an unauthorized state (equivalent to opening the port switch), and the controlled port of system 2 is in an authorized state (equivalent to closing the port switch).

Figure 2 Effects of Authorization Status on Controlled Ports



The user can control the authorization status of the port through the access control mode configured under the port. The port supports the following three access control modes:

- Forced authorization mode (authorized-force): indicates that the port is always in an authorized state, allowing users to access network resources without authorization.
- Force unauthorized mode (unauthorized-force): Indicates that the port is always in an unauthorized state and does not allow users to authenticate. The device does not provide authentication services for clients accessing through this port.

- **Auto-identification mode (auto):** indicates that the initial state of the port is an unauthorized state, only EAPOL packets are allowed to send and receive, and users are not allowed to access network resources; If the authentication is passed, the port switches to the authorized state, allowing the user to access network resources. This is also the most common case.

21.1.3.3. Controlled Direction

In the unauthorized state, the controlled port can be set as one-way controlled and two-way controlled.

- When two-way control is implemented, the transmission and reception of frames are prohibited;
- When unidirectional control is implemented, receiving frames from the client is prohibited, but sending frames to the client is allowed.

21.1.4. Authentication process for 802.1X


The 802.1X system supports EAP relay mode and EAP termination mode to interact with the remote RADIUS server to complete authentication. The following descriptions of the two authentication methods take the client's initiative to initiate authentication as an example.

21.1.4.1. EAP Relay Mode

This method is specified by the IEEE 802.1X standard, and EAP (Extensible Authentication Protocol) is carried in other high-level protocols, such as EAP over RADIUS, so that the extensible authentication protocol packets can reach the authentication server through complex networks. Generally speaking, the EAP relay mode requires the RADIUS server to support EAP attributes: EAP-Message and Message-Authenticator, which are used to encapsulate EAP packets and protect RADIUS packets carrying EAP-Message respectively.

The following takes EAP-MD5 as an example to introduce the basic business process, as shown in Figure3

Figure3 IEEE 802.1X EAP relay business process of authentication system



The authentication process is as follows:

- 1) When the user needs to access the network, open the 802.1X client program, enter the username and password that have been applied and registered, and initiate a connection request (EAPOL-Start message). At this point, the client program will send a message requesting authentication to the device to start an authentication process.
- 2) After receiving the data frame requesting authentication, the device will send a request frame (EAP-Request/Identity message) to request the user's client program to send the entered username.
- 3) The client program responds to the request from the device and sends the username information to the device through a data frame (EAP-Response/Identity message). The device sends the data frame sent by the client through packet processing (RADIUS Access-Request message) to the authentication server for processing.
- 4) After receiving the username information forwarded by the device, the RADIUS server compares the information with the username table in the database, finds the password information corresponding to the username, and encrypts it with a randomly generated encrypted word. , and also send this encrypted word to the device through the RADIUS Access-Challenge message, and the device forwards it to the client program.
- 5) After receiving the encrypted word (EAP-Request/MD5 Challenge message) from the device, the client program uses the encrypted word to encrypt the password part (this encryption algorithm is usually irreversible) , generate an EAP-Response/MD5 Challenge packet, and send it to the authentication server through the device.

- 6) The RADIUS server compares the received encrypted password information (RADIUS Access-Request message) with the local encrypted password information. If they are the same, the user is considered to be a legitimate user, and the authentication is passed. messages (RADIUS Access-Accept packets and EAP-Success packets).
- 7) After receiving the authentication message, the device changes the port to the authorized state, allowing users to access the network through the port. During this period, the device will monitor the user's online status by periodically sending handshake messages to the client. By default, if the two handshake request packets are not answered by the client, the device will log the user offline, preventing the user from going offline due to abnormal reasons and the device cannot sense it.
- 8) The client can also send an EAPOL-Logoff message to the device to actively request to log off. The device changes the port status from authorized to unauthorized, and sends an EAP-Failure packet to the client.

21.2. Configuring

- Enabling/disabling 802.1X Authentication Globally

| | |
|-------------|--|
| Command | SWITCH(config)# dot1x enable SWITCH(config)#no dot1x enable |
| Description | Enable and disable the 802.1X function globally. |

- Enabling/disabling 802.1X authentication on the Interface

| | |
|-------------|--|
| Command | SWITCH(config-if)# dot1x port-control auto SWITCH(config-if)#no dot1x port-control auto |
| Description | The port enables or disables the 802.1X function. |

- Configuring RADIUS Server

| | |
|-------------|---|
| Command | SWITCH(config)# radius-server host A.B.C.D auth-port <0-65535> acct-port <0-65535> key WORD SWITCH(config)#no radius-server host A.B.C.D |
| Description | Configure authentication server information. The default authentication port is 1812 and the accounting port is 1813. Please ensure that the RADIUS server and the device management address communicate with each other. |

- Configuring EAPOL Protocol Version Number

| | |
|-------------|--|
| Command | SWITCH(config-if)# dot1x protocol-version <1-2> SWITCH(config-if)#no dot1x protocol-version |
| Description | Configure the version number of the EAPOL protocol on the specified port. |

| | |
|--|---------------------------------------|
| | Optional configuration, default is 2. |
|--|---------------------------------------|

- Configuring Authentication Silent Time

| | |
|-------------|---|
| Command | SWITCH(config-if)# dot1x quiet-period <1-65535> SWITCH(config-if)#no dot1x quiet-period |
| Description | Configure the hold time of the HELD state. Optional configuration, the unit is seconds, the default is 60. |

- Configuring the Re-authentication Function

| | |
|-------------|--|
| Command | SWITCH(config-if)# dot1x reauthentication SWITCH(config-if)#no dot1x reauthentication |
| Description | The re-authentication function is enabled on the configuration port. Optional configuration, disabled by default. |

- Configuring the Maximum Number of Re-authentications

| | |
|-------------|--|
| Command | SWITCH(config-if)# dot1x reauthMax <1-10> SWITCH(config-if)#no dot1x reauthMax |
| Description | Configure the maximum number of times for port re-authentication. If the number of re-authentication requests exceeds the limit and there is no response, the port becomes unauthorized. Optional configuration, default 2 times. |

- Configuring to Enable key Transfer Capability

| | |
|-------------|---|
| Command | SWITCH(config-if)# dot1x keytxenabled { disable enable} |
| Description | Configure the port key transfer function. Optional, disabled by default. |

- Configuring Timer Timeout

| | |
|-------------|--|
| Command | SWITCH(config-if)# dot1x timeout {re-authperiod <1-4294967295> server-timeout <1-65535> supp-timeout <1-65535> tx-period <1-65535>} SWITCH(config-if)#no dot1x timeout {re-authperiod server-timeout supp-timeout tx-period} |
| Description | Configure the port timer time. Optional configuration, the default re-authentication period is 3600 seconds, the server timeout is 30 seconds, the client authentication timeout is 30 seconds, and the client request timeout is 30 seconds. |

- **Enabling/disabling MAC Authentication Globally**

| | |
|-------------|--|
| Command | SWITCH(config)# mac-auth enable SWITCH(config)#no mac-auth enable |
| Description | Enable or disable the MAC authentication function globally. |

- **Enabling/disabling MAC Authentication on the Interface**

| | |
|-------------|---|
| Command | SWITCH(config-if)# mac-auth {enable disable} |
| Description | The port enables or disables the MAC authentication function. |

- **Enabling/disabling MAC Authentication Dynamic VLAN Delivery on the Interface**

| | |
|-------------|--|
| Command | SWITCH(config-if)# mac-auth dynamic-vlan-creation {enable disable} |
| Description | The port enables or disables dynamic VLAN delivery of MAC authentication. The current version is not supported. |

- **Configuring MAC Authentication Failure Handling**

| | |
|-------------|--|
| Command | SWITCH(config-if)# mac-auth auth-fail-action {drop-traffic restrict-vlan <2-4094>} |
| Description | Configure the behavior of MAC authentication failure. Optional configuration, default is drop-traffic: drop traffic. The current version is not supported. |

- **Configuring RADIUS Server Death Time**

| | |
|-------------|--|
| Command | SWITCH(config)# radius-server deadtime <0-1440> SWITCH(config)# no radius-server deadtime |
| Description | Configure the RADIUS server death time.During the authentication process, the dead server will be automatically skipped, and the non-dead server will be selected for authentication. Optional configuration, the default is 0 minutes. |

- **Configuring RADIUS Server Default Key**

| | |
|-------------|--|
| Command | SWITCH(config)# radius-server key STRING SWITCH(config)# no radius-server key |
| Description | Configure the RADIUS server default key. Optional configuration. |

- **Configuring RADIUS Server Retransmission Times**

| | |
|-------------|--|
| Command | SWITCH(config)# radius-server retransmit <1-100> SWITCH(config)# no radius-server retransmit |
| Description | Configure the RADIUS server retransmission times. Optional configuration, the default is 3 times. |

- Configuring RADIUS Server Timeout

| | |
|-------------|--|
| Command | SWITCH(config)# radius-server timeout <1- 60> SWITCH(config)# no radius-server timeout |
| Description | Configure the RADIUS server timeout period. Optional configuration, the default is 5 seconds. |

21.3. Examples


21.3.1. 802.1X Port Authentication Scenario

1) Requirement

- Requires authentication of access users on port GigabitEthernet0/3 to control their access to the Internet.
- RADIUS server group IP address 1.1.1.2.
- Set the shared key to be used when the system exchanges packets with the RADIUS server as name.

2) Network Diagram

Figure 4 802.1X Typical network diagram for 802.1x authentication



3) Typical configuration example

Device side:

```

SWITCH(config)#dot1x enable
SWITCH(config)#interface gigabitEthernet0/3
SWITCH(config-if)#dot1x port-control auto

```

```
SWITCH(config-if)#exit
```

```
SWITCH(config)#radius-server host 1.1.1.2 key name
```

Server:

Configure NAS authentication device 1.1.1.1 and communication key name.

Add user account test password test.

The corresponding authentication method needs to be supported, such as EAP-MSCHAPv2

Client:

Enable 802.1X authentication client and log in with account test.

The corresponding authentication method needs to be supported, such as the EAP-MSCHAPv2 method.


21.3.2. MAC Authentication Scenario

1) Requirement

- Requires authentication of access users on port GigabitEthernet0/3 to control their access to the Internet.
- RADIUS server group IP address 1.1.1.2.
- Set the shared key when the system and the RADIUS server exchange messages as name.

2) Network Diagram

Figure 5 Typical network diagram for MAC authentication



3) Typical configuration example

Device side:

```
SWITCH(config)# mac-auth enable
SWITCH(config)#interface gigabitEthernet0/3
SWITCH(config-if)#mac-auth enable
SWITCH(config-if)#exit
SWITCH(config)#radius-server host 1.1.1.2 key name
```

Server:

Configure NAS authentication device 1.1.1.1 and communication key name.

Add the client MAC address as the user account and password to the user database.

Client:

Enable the 802.1X authentication client and log in with any account.

21.4. Display Information

- Show 802.1X Port Authentication Information

```
SWITCH#show dot1x all
802.1X Port-Based Authentication Enabled
RADIUS server address: 1.1.1.2:1812
Next radius message id: 0
RADIUS client address: not configured

802.1X info for interface gigabitEthernet0/6
portEnabled: true - portControl: Auto
portStatus: Unauthorized - currentId: 1
protocol version: 2
reAuthenticate: disabled
reAuthPeriod: 3600
abort:F fail:F start:F timeout:F success:F
PAE: state: Connecting - portMode: Auto
PAE: reAuthCount: 1 - rxRespId: 0
PAE: quietPeriod: 60 - reauthMax: 2 - txPeriod: 30
BE: state: Idle - reqCount: 0 - idFromServer: 0
BE: suppTimeout: 30 - serverTimeout: 30
CD: adminControlledDirections: in - operControlledDirections: in
CD: bridgeDetected: false
KR: rxKey: false
KT: keyAvailable: false - keyTxEnabled: false
```

- Display MAC Authentication Information

```
SWITCH#show bridge
Bridge CVLAN SVLAN BVLAN Port MAC Address FWD Time-out
-----+-----+-----+-----+-----+-----+-----+-----+-----+

```


22. Configuring Port Security

22.1. Overview of Port Security

You can use port security to block input to an Fast Ethernet, or Gigabit Ethernet port when the MAC address of the station attempting to access the port is different from any of the MAC addresses that are specified for that port. Alternatively, you can use port security to filter traffic that is destined to or received from a specific host that is based on the host MAC address.

The maximum number of MAC addresses that you can allocate for each port depends on your network configuration. After you allocate the maximum number of MAC addresses on a port, you can either specify the secure MAC address for the port manually or have the port dynamically configure the MAC address of the connected devices.

When a secure port receives a packet, the source MAC address of the packet is compared to the list of secure source addresses that were manually configured or autoconfigured (learned) on the port. If a MAC address of a device that is attached to the port differs from the list of secure addresses, A violation occurs. Users can set a port to the following two modes to handle a security violation:

Restrict: Drops all packets from insecure hosts, but remains enabled, until the MAC of the host aged out dynamic. You can manually shutdown and no-shutdown the interface to recover from violation.

Shutdown: The shutdown mode option allows you to specify whether the port is to be permanently disabled or disabled for only a specified time. The default is for the port to shut down permanently. You can manually shutdown and no-shutdown the interface to recover from violation.

If you want to convert dynamic security users to static security users, you can enable the sticky function on the port. If the sticky function is enabled, the dynamic users learned on the port will exist as static users. If the configuration is saved, it will still exist after the device restarts.

Note

- ✧ Only support L2 port for port security, such as physical port and L2 AP port.
 - ✧ Only supports configuring port security function in access mode.
 - ✧ Do not support AP member port configuration port security function.
 - ✧ The destination port of the SPAN does not support the port security function.
 - ✧ Does not support the port security function on ports that have been configured with static MAC addresses.
-

22.2. Configuring

● Enable Port Security

| | |
|-------------|---|
| Command | SWITCH(config-if)#switchport port-security SWITCH(config-if)#no switchport port-security |
| Description | Enable Port Security on the interface. |

● Setting the Max Number of Security Mac-address

| | |
|-------------|---|
| Command | SWITCH(config-if)#switchport port-security maximum VALUE SWITCH(config-if)#no switchport port-security maximum |
| Description | The default maximum number of secure addresses is 1 |

| | |
|--|-----------------------------|
| | VALUE range from 1 to 1024. |
|--|-----------------------------|

- Entering a Security Mac-address

| | |
|-------------|--|
| Command | SWITCH(config-if)#switchport port-security mac-address MAC_ADDR SWITCH(config-if)#no switchport port-security mac-address MAC_ADDR |
| Description | Enters a secure MAC address for the interface. If you configure fewer secure MAC addresses than the maximum, the remaining MAC addresses will be dynamically learned. |

- Enable sticky

| | |
|-------------|--|
| Command | SWITCH(config-if)# switchport port-security mac-address sticky SWITCH(config-if)#no switchport port-security mac-address sticky |
| Description | Enable sticky learning on the interface. |

- Configuring Port Security Aging

| | |
|-------------|---|
| Command | SWITCH(config-if)#switchport port-security aging time MINUTES SWITCH(config-if)#no switchport port-security aging time |
| Description | Sets the aging time for the secure port. Valid range for aging_time is from 0 to 1440 minutes. If the time is equal to 0, aging is disabled for this port. |

- Enable Port Security Aging Static Mac-address

| | |
|-------------|--|
| Command | SWITCH(config-if)# switchport port-security aging static SWITCH(config-if)#no switchport port-security aging static |
| Description | enables aging for statically configured secure addresses on this port. |

- Setting the Violation Mode

| | |
|-------------|--|
| Command | SWITCH(config-if)# switchport port-security violation { strict shutdown } SWITCH(config-if)#no switchport port-security violation |
| Description | Sets the violation mode, the action to be taken when a security violation is detected, as one of these: Restrict: A port security violation restricts data and causes the SecurityViolation counter to increment and send an SNMP trap notification. Shutdown: The interface is error-disabled when a security violation occurs. You can manually reenble the by entering the shutdown and no shut down commands. When a secure port is in the error-disabled state, it will recover after errdisable recovery time. |

22.3. Examples

Example 1: This is an example of Port Security typical application. Port Security is enabled on the interface gigabitEthernet0/1, the MAX secure Mac-address of the interface gigabitEthernet0/1 is 3, and we enter 3 secure Mac-address on the interface. When the interface gigabitEthernet0/1 receives a packet, If the SRC MAC-address of the packet differs from the list of secure Mac-addresses, the packet will be dropped.

```
SWITCH(config-if)#switchport port-security
SWITCH(config-if)#switchport port-security maximum 3
SWITCH(config-if)#switchport port-security mac-address 0001.0001.0001
SWITCH(config-if)#switchport port-security mac-address 0001.0001.0002
SWITCH(config-if)#switchport port-security mac-address 0001.0001.0003
```

22.4. Display Information

- Display Interfaces Port Security Brief

```
SWITCH#show port-security brief
```

| interface | mac-address | mac-address | violation | violation |
|-----------|-------------|-------------|-----------|-----------|
| | maximum | count | count | action |
| ----- | | | | |
| GiE0/1 | 10 | 3 | 0 | shutdown |
| GiE0/2 | 1 | 0 | 0 | restrict |
| GiE0/3 | 1 | 0 | 0 | restrict |
| GiE0/4 | 1 | 0 | 0 | restrict |
| GiE0/5 | 1 | 0 | 0 | restrict |
| GiE0/6 | 1 | 0 | 0 | restrict |
| GiE0/7 | 1 | 0 | 0 | restrict |
| GiE0/8 | 1 | 0 | 0 | restrict |

- Display an Interface Port Security Information

```
SWITCH#show port-security interface gigabitEthernet0/1
```

```
Port Security          : Enabled
Maimum MAC Addresses   : 10
Violation Mode         : Shutdown
Aging Time(mins)       : 10
Aging static           : Enabled
Total MAC Addresses    : 3
Configured MAC Addresses : 2
Security Violation Count : 0
Last Violate Address   : --
```

- Display Secure Mac-address

```
SWITCH#show port-security Mac-address
```

| interface | vlan | mac-address | type | left-time(min) |
|-----------|------|----------------|---------|----------------|
| ----- | | | | |
| GiE0/1 | 1 | 0001.0002.0004 | static | 10 |
| GiE0/1 | 1 | 0001.0002.0003 | static | 10 |
| GiE0/1 | 1 | 000e.c6c1.3a03 | dynamic | 10 |

- Display an Interface Secure Mac-address

```
SWITCH#show port-security mac-address interface gigabitEthernet0/1
```

| interface | vlan | mac-address | type | left-time(min) |
|-----------|------|----------------|--------|----------------|
| ----- | | | | |
| GiE0/1 | 1 | 0001.0002.0004 | static | 10 |

| | | | | | |
|--------|---|----------------|---------|----|--|
| GiE0/1 | 1 | 0001.0002.0003 | static | 10 | |
| GiE0/1 | 1 | 000e.c6c1.3a03 | dynamic | 10 | |

23. Configuring Ip Source Guard

23.1. Overview of Ip Source Guard

IP Source Guard is a per-interface traffic filter that permits IP traffic only when the IP address and MAC address of each packet matches one of two sources of IP and MAC address bindings: Entries in the Dynamic Host Configuration Protocol (DHCP) snooping binding table; Static IP source entries that you configure.

Filtering on trusted IP and MAC address bindings helps prevent spoofing attacks, in which an attacker uses the IP address of a valid host to gain unauthorized network access.

Note

- ✧ Only support L2 port for port security, such as physical port and L2 AP port.
 - ✧ Do not support AP member port configuration port security function.
-

23.2. Configuring

- Enabling Ip Source Guard

| | |
|-------------|---|
| Command | SWITCH(config-if)#ip verify source SWITCH(config-if)#no ip verify source |
| Description | Enables IP Source Guard on the interface. |

- Configuring Static Ip Source Binding Entry

| | |
|-------------|--|
| Command | SWITCH(config)# ip source binding XXXX.XXXX.XXXX vlan VALUE A.B.C.D interface IFNAME SWITCH(config)#no ip source binding XXXX.XXXX.XXXX vlan VALUE A.B.C.D interface IFNAME |
| Description | Creates a static IP source binding entry for the current interface. Example: SWITCH(config)# ip source binding 0001.0001.0001 vlan 1 1.1.1.10 interface gigabitEthernet0/1 A single port can be configured with a maximum of 128 entries. |

23.3. Examples

Example 1 : This is an example of Ip Source Guard typical application. Ip Source Guard is enabled on the interface gigabitEthernet0/1, and we enter 3 static binding entries on the interface.

When the interface gigabitEthernet0/1 receives a packet, If the IP address and the MAC address of the packet differs from the list of static entries, the packet will be dropped.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#ip verify source
SWITCH(config)#ip source binding 0001.0001.0001 vlan 1 1.1.1.10 interface gigabitEthernet0/1
SWITCH(config)#ip source binding 0001.0001.0002 vlan 1 1.1.1.11 interface gigabitEthernet0/1
SWITCH(config)#ip source binding 0001.0001.0003 vlan 1 1.1.1.12 interface gigabitEthernet0/1
```

23.4. Display Information

- Display Ip Verify Source Binding Rules

```
SWITCH#show ip verify source
```

| interface | Filter-type | Filter | IP-address | Mac-address | vlan |
|-----------|-------------|--------|------------|----------------|------|
| ----- | | | | | |
| GiE0/1 | Ip | Permit | 1.1.1.1 | 0001.0001.0001 | 1 |
| GiE0/1 | Ip | Deny | All | All | All |
| GiE0/2 | Ip | Deny | All | All | All |

- Display Ip Verify Source Binding Entries on the Interface

```
SWITCH#show ip verify source interface gigabitEthernet0/1
```

| interface | Filter-type | Filter | IP-address | Mac-address | vlan |
|-----------|-------------|--------|------------|----------------|------|
| ----- | | | | | |
| GiE0/1 | Ip | Permit | 1.1.1.1 | 0001.0001.0001 | 1 |
| GiE0/1 | Ip | Deny | All | All | All |

- Display Ip Source Binding Entrys

```
SWITCH#show ip source binding
```

| interface | vlan | IP-address | Mac-address | Lease | Type |
|-----------|------|------------|----------------|----------|--------|
| ----- | | | | | |
| GiE0/1 | 1 | 1.1.1.1 | 0001.0001.0001 | infinite | static |
| GiE0/2 | 1 | 1.1.2.1 | 0001.0002.0001 | infinite | static |

- Display Ip Source Binding Entrys on the Interface

```
SWITCH#show ip source binding interface gigabitEthernet0/1
```

| interface | vlan | IP-address | Mac-address | Lease | Type |
|-----------|------|------------|----------------|----------|--------|
| ----- | | | | | |
| GiE0/1 | 1 | 1.1.1.1 | 0001.0001.0001 | infinite | static |

24. Configuring Arp-check

24.1. Overview of Arp-check

Arp-check is a per-interface traffic filter that permits ARP traffic only when the IP address and MAC address of each packet matches one of two sources of IP and MAC address bindings: Entries in the Dynamic Host Configuration Protocol (DHCP) snooping binding table; Static IP source entries that you configure.

Filtering on trusted IP and MAC address bindings helps prevent spoofing attacks, in which an attacker uses the IP address of a valid host to gain unauthorized network access.

Note

- ✧ Only support L2 port for port security, such as physical port and L2 AP port.
 - ✧ Do not support AP member port configuration port security function.
-

24.2. Configuring

- Enabling Arp-check on the Interface

| | |
|-------------|---|
| Command | SWITCH(config-if)#arp-check SWITCH(config-if)#no arp-check |
| Description | Enables Arp-check on the interface. |

24.3. Examples

Example 1: This is an example of Arp-check typical application. Arp-check is enabled on the interface gigabitEthernet0/1, and we enter 3 static binding entrys on the interface.

When the interface gigabitEthernet0/1 receives a ARP packet, If the IP address and the MAC address of the packet differs from the list of static entrys, the packet will be dropped.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#ip verify source
SWITCH(config-if)#arp-check
SWITCH(config)#ip source binding 0001.0001.0001 vlan 1 1.1.1.10 interface gigabitEthernet0/1
SWITCH(config)#ip source binding 0001.0001.0002 vlan 1 1.1.1.11 interface gigabitEthernet0/1
SWITCH(config)#ip source binding 0001.0001.0003 vlan 1 1.1.1.12 interface gigabitEthernet0/1
```

25. Configuring SNMP Network Management

25.1. Overview of SNMP Network Management

SNMP is the abbreviation of Simple Network Management Protocol, which became a network management standard RFC1157 in August 1988. Up to now, due to the support of this protocol by many manufacturers, SNMP has become the de facto network management standard and is suitable for use in the interconnected environment of multi-manufacturer systems.

Using the SNMP protocol, network administrators can perform information query, network configuration, fault location, and capacity planning for nodes on the network. Network monitoring and management are the basic functions of SNMP.

Currently the following versions of SNMP exist:

SNMPv1: The first official version of the Simple Network Management Protocol, defined in RFC1157.

SNMPv2C: Community-Based SNMPv2 Management Architecture, defined in RFC1901.

SNMPv3: By authenticating and encrypting data, it provides the following security features:

- Make sure that data is not tampered with during transmission.
- Make sure the data is sent from a legitimate data source.
- Encrypt messages to ensure data confidentiality.

25.2. Configuring

• Configuring Communication Community Words

| | |
|-------------|---|
| Command | SWITCH(config)# snmp-server community COMMUNITY { ro } SWITCH(config)# no snmp -server community COMMUNITY |
| Description | Configure/delete SNMP communication community word. ro : read-only identifier, configure the community word as a community word with only read permission; the default configuration is a community word with both read and write permissions. Supports configuring multiple community characters at the same time. |

• Configuring SNMPv3 Views

| | |
|-------------|---|
| Command | SWITCH(config)# snmp -server view NAME {include exclude} OID SWITCH(config)# no snmp -server view name |
| Description | Configure/delete SNMPv3 views; Supports configuring multiple views at the same time, and supports configuring multiple rules for a single view; The system has all and none views by default and cannot be modified |

• Configuring SNMP Groups

| | |
|---------|--|
| Command | SWITCH(config)# snmp -server group NAME {v3 } { noAuthNoPriv authNoPriv authPriv } read RVIEW write WVIEW SWITCH(config)# snmp -server group NAME {v1 v2c} read RVIEW write WVIEW SWITCH(config)# no snmp -server group name |
|---------|--|

| | |
|-------------|--|
| Description | configure/delete SNMP groups; Support to configure multiple groups at the same time; create group information in order to be compatible with the old configuration when configuring the community , usually without additional attention |
|-------------|--|

- Configuring SNMPv3 Users

| | |
|-------------|--|
| Command | SWITCH(config)# snmp -server user NAME group GROUPNAME auth {md5 sha} {AUTHPASS} priv { aes des} PRIVPASS SWITCH(config)# no snmp -server user name |
| Description | configure/delete SNMP users; Support to configure multiple users at the same time; |

- Configuring SNMP Host Notification Server

| | |
|-------------|---|
| Command | SWITCH(config)# snmp -server host IPADDR {informs traps} {v3 } { noAuthNoPriv authNoPriv authPriv } user NAME SWITCH(config)# snmp -server host IPADDR {informs traps} {v1 v2c} community NAME SWITCH(config)# no snmp -server hostname _ |
| Description | configure/delete SNMP server; Support to configure multiple servers at the same time; |

25.3. Examples

Requirements: The IP address of the SNMP network management server is 2.2.2.2, and the read-write communication group word is unified as public.

- Enter the global configuration mode configuration:

```
SWITCH#
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH( config)#snmp-server community public
SWITCH( config)#snmp-server 2.2.2.2 community public
SWITCH( config)#
```

Case requirements: The IP address of the SNMP network management server is 2.2.2.2, SNMPv3 is used, the user test password is 12345678, the encryption key is 87654321; the authentication algorithm MD5, the encryption algorithm DES

```
SWITCH#
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH( config)# snmp -server group test v3 authPriv read all write all
SWITCH( config)# snmp -server user test group test auth MD5 12345678 priv DES 87654321
SWITCH( config)# snmp -server host 2.2.2.2 informs v3 authPriv user test
```

26. Configuring RMON

26.1. Overview of RMON

SNMP is the most widely used network management protocol in the Internet. The collection and statistics of network communication information are realized through the agent software embedded in the device. The management software obtains the information by sending query signals to the MIB of the agent through polling, and realizes the management of the network through the obtained information. The management software sends queries to the proxy MIB by means of a query to obtain this information and manages the network through the information obtained. Although the MIB counter records the sum of the statistics, it does not allow historical analysis of the day-to-day communication situation. In order to provide a comprehensive view of the flow and traffic changes over the day, web hosting software requires continuous poll to analyze the status of the network through the information available.

Polling with SNMP has two distinct disadvantages:

- Occupies a lot of network resources. In a large-scale network, a large number of network communication packets will be generated by polling, which will cause network congestion and even cause network congestion. Therefore, SNMP is not suitable for managing large-scale networks. , not suitable for recycling large amounts of data, such as routing table information.
- The task of collecting data in SNMP polling is done by the network administrator through the network management software. If the network administrator monitors more than 3 network segments, it may occur that the network is overloaded due to the heavy burden. A situation in which a manager is unable to complete a task.

In order to improve the availability of management information, reduce the burden of management stations, and meet the needs of network administrators to monitor the performance of multiple network segments, IETF developed RMON to solve the limitations of SNMP in the expanding distributed interconnection. The monitoring function of the data traffic of the network segment and even the entire network. The following are the features of RMON:

- SNMP is the basis for the realization of RMON, and RMON is the enhancement of SNMP functions.
RMON is implemented based on the SNMP architecture and is compatible with the existing SNMP framework. It is still composed of the network management workstation NMS and the agent running on each network device. Since RMON does not use another set of mechanisms, which are shared between NMS and SNMP, network managers do not need additional learning and are therefore simpler to achieve.
- RMON enables SNMP to monitor remote network devices more effectively and proactively, and provides an efficient means for monitoring the operation of the network.

The RMON protocol stipulates that the managed device can automatically send Trap information when the alarm threshold is reached, so the management device does not need to obtain the value of the MIB variable through polling multiple times for comparison. The purpose of efficiently managing large interconnected networks.

RMON allows multiple monitors, and monitors can collect data in the following two ways:

- Through a dedicated RMON Probe (detector), the NMS directly obtains management information from the RMON Probe and controls network resources. In this way, all the information of the RMON MIB can be obtained.
- Embed RMON Agent directly into network devices, making them network devices with RMON Probe function. The NMS uses SNMP to exchange data information with it and collect network management information. This method is limited by device resources and generally cannot obtain all the data of the RMON MIB. Basically, only four groups (alarms, events, history, and statistics) are collected.

Our equipment adopts the second method and implements the RMON Agent function on the equipment. Through this function, the management device can obtain information such as overall traffic, error statistics, and performance statistics on the network segment connected to the managed network device interface, thereby realizing network monitoring.

26.2. Rationale

Before configuring RMON, you need to understand the basic concepts of the four groups of statistics, history, alarms, and events defined by the RMON specification.

RMON features

RMON mainly implements statistics and alarm functions, and is used for remote monitoring and management of managed devices by management devices in the network.

The RMON statistics function can be implemented through the RMON statistics group or the RMON history group, which are divided into Ethernet statistics functions and historical statistics functions.

- Historical statistics function (corresponding to the historical group in the RMON MIB): The system periodically samples and collects network status statistics and stores them for subsequent processing. The system will periodically collect statistics on various traffic information, including bandwidth utilization, number of error packets and total number of packets.
- Ethernet statistics function (corresponding to the statistics group in the RMON MIB): The system collects basic statistics about each network being monitored. The system will continuously count the traffic of a certain network segment and the distribution of various types of packets, or the number of error frames of various types, the number of collisions, etc. The system will keep track of all traffic information on a regular basis, including bandwidth utilization, erroneous packages and total packages.

The RMON alarm function includes the event definition function and the alarm threshold setting function. The RMON alarm function is realized by the combination of these two sub-functions.

- Event definition function (corresponding to the event group in the RMON MIB): The event group controls the events and prompts from the device, and provides all events generated by the RMON Agent. When an event occurs, it can record logs or send Trap to the network management station.
- Set the alarm threshold function (corresponding to the alarm group in the RMON MIB): The system monitors the specified alarm variable (the OID corresponding to any alarm object). After the user pre-defines a set of thresholds and sampling time for the specified alarm, the system will obtain the value of the specified alarm variable according to the defined time period. When the value of the alarm variable is greater than or equal to the upper threshold, an upper alarm

event will be triggered; When the value of the variable is less than or equal to the lower limit threshold, a lower limit alarm event is triggered. RMON Agent will record the above monitored status as a log or send Trap to the network management station.

Multiple RMON groups are defined in the RMON specification (RFC2819), and the device implements four groups of statistics, history, alarm, and events supported in the public MIB. These groups are introduced separately below.

- Statistics group

The statistics group specifies that the system will continuously collect statistics on various traffic information of the Ethernet interface, and store the statistical results in the Ethernet statistics table (etherStatsTable) for the management device to view at any time. Statistics include the number of network collisions, the number of CRC check error packets, the number of data packets that are too small (or too large), the number of broadcast and multicast packets, the number of bytes received, and the number of received packets.

After the statistics entry is successfully created on the specified interface, the statistics group collects statistics on the number of packets on the current interface, and the statistics result is a continuous accumulated value.

- History group

The history group periodically collects network status statistics and stores them for subsequent processing.

The history group contains two tables:

- historyControlTable: It is mainly used to set control information such as sampling interval time.
- etherHistoryTable: It is mainly used to store the historical data collected by the historical group on a regular basis for network status statistics, and to provide network administrators with historical data on network segment traffic, error packets, broadcast packets, utilization, and collision times and other statistical information.

- Event group

The event defined by the event group is used in the alarm group configuration item and the extended alarm group configuration item. When the monitoring object reaches the alarm condition, the event will be triggered. RMON event management is to add events to the specified row of the event table and define how the events are handled:

- log: only send logs
- trap: only send trap messages to NMS
- log-trap: send both logs and trap messages to NMS
- none: do nothing

- Alarm group

Alarm groups allow monitoring of a predefined set of thresholds for alarm variables (which can be arbitrary objects in the local MIB). After the user defines the alarm table item (alarmTable), the system will obtain the value of the monitored alarm variable according to the defined time period. When the value of the alarm variable is greater than or equal to the upper limit threshold, an upper limit alarm event will be triggered; If the value is less than or equal to the lower limit threshold, a lower limit alarm event is triggered, and the alarm management will perform corresponding processing according to the definition of the event.

26.3. Configuring

- Configuring Statistics Group

| | |
|-------------|---|
| Command | SWITCH(config)# rmon statistics <1-65535> interface IFNAME {owner OWNERNAME } SWITCH(config-if)# no rmon statistics <1-65535> |
| Description | configure/delete statistics group. <1-65535>: Group index. IFNAME : interface name. OWNERNAME : owner information. |

- Configuring History Group

| | |
|-------------|---|
| Command | SWITCH(config)# rmon history <1-65535> interface IFNAME buckets <1-65535> interval <1-3600> {owner OWNERNAME } SWITCH(config-if)# no rmon history <1-65535> |
| Description | configure/delete history group. <1-65535>: Group index. IFNAME : interface name. <1-65535>: History bucket size. <1-3600>: Recording period; the unit is seconds. OWNERNAME : owner information. |

- Configuring Event Groups

| | |
|-------------|---|
| Command | SWITCH(config)# rmon event <1-65535> {description DESCRIPTION } {log trap COMMUNITY log-trap COMMUNITY none} {owner OWNERNAME } SWITCH(config-if)# no rmon event <1-65535> |
| Description | configure/delete event groups. <1-65535>: Group index. DESCRIPTION: Event description. COMMUNITY: Trap communication group word. OWNERNAME: owner information. |

- Configuring an Alarm Group

| | |
|-------------|---|
| Command | SWITCH(config)# rmon alarm <1-65535> object STRING <1-65535> {absolute delta} rising-threshold <1-2147483645> <1-65535> falling-threshold <1-2147483645> <1-65535> {owner OWNERNAME } SWITCH(config-if)# no rmon alarm <1-65535> |
| Description | Configure/delete alarm groups. <1-65535>: Group index. STRING: OID of alarm monitoring; for example, 1.3.6.1.2.1.2.2.1.10.1 indicates the number of bytes received by monitoring interface 1. <1-65535>: Monitoring period; the unit is seconds. |

| | |
|--|---|
| | <p><1-2147483645>: Rising Threshold.</p> <p><1-65535>: Rising event index; corresponds to the index in the event group.</p> <p><1-2147483645>: Falling Threshold.</p> <p><1-65535>: Fall event index; corresponds to the index in the event group.</p> <p>OWNERNAME: owner information.</p> |
|--|---|

- Configuring the Upper Limit of Log Entries

| | |
|-------------|---|
| Command | <p>SWITCH(config)# rmon max-log <1-65535></p> <p>SWITCH(config-if)# no rmon max-log</p> |
| Description | <p>Configure/reset the upper limit of log entries.</p> <p><1-65535>: Number of entries.</p> <p>The log here refers to the log generated by the event group, not the system log.</p> <p>The default upper limit is 100; when the number of logs generated exceeds the limit of entries, the old logs will be deleted according to the generation time to maintain the upper limit.</p> |

26.4. Examples

Requirements

The IP address of the SNMP network management server is 2.2.2.2, and the community word for read and write communication is public.

The network management server needs to query the traffic of port 1 of the device through rmon

The network management server needs to monitor the input traffic of port 1 of the device through rmon. The cycle is 10 seconds. Once the number of input bytes changes by more than 1MB (1000000B), an alarm is triggered and a log is recorded.

Configuration steps

Initialize the network management configuration

```

SWITCH#
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH(config)#snmp-server community public
SWITCH(config)#snmp-server 2.2.2.2 community public
SWITCH(config)#

```

Configure the rmon statistics group (the following rmon configurations can be configured on the NMS through the MIB)

```
SWITCH(config)# rmon statistics 1 interface gigabitEthernet0/1 owner abc
```

Configure rmon events and alarm groups (the following rmon configurations can be configured on the NMS through MIB)

```

SWITCH(config)# rmon event 1 log-trap public owner abc
SWITCH(config)# rmon alarm 1 object 1.3.6.1.2.1.2.2.1.10.1 10 delta rising-threshold 1000000 1
falling-threshold 1000000 1

```

26.5. Display Information

- Show Event Group LSog

```
SWITCH#show rmon log
```

```
event 1 log 226 time 2304 desc
```

```
event 1 log 227 time 2314 desc
```

```
event 1 log 228 time 2324 desc
```

```
event 1 log 229 time 2334 desc
```

```
event 1 log 230 time 2344 desc
```

```
event 1 log 231 time 2354 desc
```

```
event 1 log 232 time 2364 desc
```

```
event 1 log 233 time 2374 desc
```

```
.....
```

27. Configuring IO

27.1. Overview of IO

略。

27.2. Configuring

- Configuring IO Output Level

| | |
|----|---|
| 命令 | SWITCH(config)# io-ctrl ID level (high low) |
| 描述 | <p>You can lookup the ID from show io-ctrl summary information.</p> <p>High: High level.</p> <p>Low: Low level.</p> <p>This command is supported by the output IOs.</p> |

27.3. Examples

略

27.4. Display Information

- Display IO Information

| | | | | |
|-----------------------------|-----------|-------|----------|-----------|
| SWITCH#show io-ctrl summary | | | | |
| ioid | direction | level | capacity | direction |
| ----- | | | | |
| 1 | output | high | output | |
| 2 | input | high | input | |

28. Configuring AAA

28.1. Overview of AAA

AAA is the abbreviation of Authentication Authorization and Accounting, which provides for authentication, authorization and accounting function into the configuration of the consistency framework.

AAA provides the following services in a modular fashion:

- **Authentication:** Verify whether the user can obtain access rights. Optionally use RADIUS protocol, TACACS+ protocol or Local (local) and so on. Identity authentication is a method of identifying a user's identity before allowing access to the network and network services.
- **Authorization:** Which services are available to authorized users. AAA authorization is achieved by defining a series of attribute pairs, these attribute pairs describe the operations that the user is authorized to perform. These attribute pairs can be stored on a network device or remotely on a secure server.
- **Accounting:** record the user's use of network resources. When AAA accounting is enabled, the network device starts to send user usage of network resources. Each accounting record is composed of attribute pairs and stored on a secure server. These records can be read and analyzed by special software, so as to realize accounting, statistics and tracking of users' use of network resources.

Using AAA has the following advantages:

- Flexibility and controllability.
- Scalability.
- Standardized Certification.
- Multiple backup systems.

AAA has the following relevant standards:

RFC2865 Remote Authentication Dial In User Service (RADIUS). C. Rigney, S. Willens, A. Rubens, W. Simpson. June 2000. (Format: TXT, HTML).

RFC2866 RADIUS Accounting. C. Rigney. June 2000. (Format: TXT, HTML).

RFC8907 The Terminal Access Controller Access-Control System Plus (TACACS+) Protocol. T. Dahm, A. Ota, DC Medway Gash, D. Carrel, L. Grant. September 2020.

28.2. Configuring

- Enabling/disabling AAA Function Globally

| | |
|-------------|---|
| Command | SWITCH(config)# aaa new-model SWITCH(config)# no aaa new-model |
| Description | Globally enable or disable the AAA function. |

- Configuring AAA Server Group

| | |
|-------------|---|
| Command | <p>SWITCH(config)# aaa group server (radius) (default NAME)</p> <p>SWITCH(config) # aaa group server (tacacs +) (default NAME)</p> <p>SWITCH(config)# no aaa group server (radius tacacs +) (default NAME)</p> |
| Description | <p>Server group configuration.</p> <p>Optional.</p> <p>By default there is no server group configuration and no server method is used.</p> |

- Configuring AAA Server

| | |
|-------------|--|
| Command | <p>SWITCH(config-gs-rad)# server ABCD (auth-port <1-65535>) (acct-port <1-65535>) (key STRING)</p> <p>SWITCH(config-gs-tac)# server ABCD (port <1-65535>) (key STRING)</p> <p>SWITCH(config-gs-rad)# no server ABCD</p> <p>SWITCH(config-gs-tac)# no server ABCD</p> |
| Description | <p>server group mode .</p> <p>Configure RADIUS, TACACS + server information, including basic IP address, port information, shared key</p> <p>Optional.</p> <p>Note: Due to implementation restrictions, the current radius accounting port number is always the authentication port number + 1, and the configuration is invalid.</p> |

- Configuring Server Group Timeout

| | |
|-------------|---|
| Command | <p>SWITCH(config-gs-rad)# timeout <1-120></p> <p>SWITCH(config-gs-tac)# timeout <1-120></p> <p>SWITCH(config-gs-rad)# no timeout</p> <p>SWITCH(config-gs-tac)# no timeout</p> |
| Description | <p>server group mode .</p> <p>Configure the timeout period for servers in the group.</p> <p>Optional.</p> |

- Configuring Group Service Information Fields

| | |
|-------------|--|
| Command | <p>SWITCH(config-gs-tac)# service NAME</p> <p>SWITCH(config-gs-tac)# no service</p> |
| Description | <p>TACACS+ server group mode .</p> <p>Configure the service information in the group.</p> <p>Optional.</p> |

- **Configuring AAA Method Information**

| | |
|-------------|--|
| Command | <p>SWITCH(config)# aaa (authentication authorization accounting) (login ssh web dot1x command) default {group (radius tacacs+ NAME) local none}</p> <p>SWITCH(config)#no aaa (authentication authorization accounting) (login ssh web dot1x command) default</p> |
| Description | <p>Global configuration mode.</p> <p>Configure AAA method information.</p> <p>Optional. Local authentication is used by default.</p> <p>Note: The username (such as admin) that exists on the machine also needs to be provided during the none authentication, otherwise an error may occur.</p> |

- **Configuring Remote User Information**

| | |
|-------------|--|
| Command | <p>SWITCH(config)# username NAME remote</p> <p>SWITCH(config)#no username NAME</p> |
| Description | <p>Global configuration mode.</p> <p>Configure remote user information.</p> <p>Optional.</p> <p>Note: If the login authentication of the remote method is configured, but the remote user information is not configured on the device side, it may cause the user to pass the authentication and be unable to use it normally due to the lack of the local environment!</p> |

28.3. Examples


28.3.1. SSH Login Authentication Using Tacacs+ Method

1) Requirements

- See the description of the network diagram

4) Network diagram

Figure 1 Typical networking diagram for SSH through tacacs+ server authentication and accounting



Description: none

5) Typical configuration example

Switch:

```

SWITCH(config)# aaa new-model
SWITCH(config)# aaa group server tacacs+ default
SWITCH(config-gs-tac)# server 2.2.2.106 key testkey123
SWITCH(config-gs-tac)# exit
SWITCH(config)# aaa authentication ssh default group tacacs+
SWITCH(config)# aaa accounting ssh default group tacacs+
SWITCH(config)# username test remote
  
```

Device IP configuration and ssh configuration refer to the corresponding chapters in the configuration documentation, which are omitted here.


28.3.2. Use the None Method to Perform Serial Port Login

2) Requirements

- See the description of the network diagram

3) Network diagram

Figure2 Typical network diagram of serial port using none authentication and accounting



4) Typical configuration example

Refer to the network diagram

28.4. Display Information


- None

29. Configuring Serial Device Server

29.1. Overview of Serial Device Server

The serial device server is used to connect serial devices to the Ethernet. The serial device server supports bidirectional conversion and transmission of network data and serial data.


Serial device server work in tcp-client mode, as shown in figure below.



Serial device server work in tcp-client mode

Serial device server in tcp-client mode provides client connections for TCP network servers. it actively initiate a connection and connect to the server to realize the interaction between serial device and tcp server. The Tcp/ip and serial data are transparently transmitted in both directions. The serial device server supports to establish multiple TCP Clients to connect to different Tcp Server.

Serial device server work in tcp-server mode, as show in figure below.



Serial device server work in tcp-server mode

In TCP Server mode, the module monitors the local port, accepts and establishes a connection for data communication when a connection request is sent. Used for communication with TCP clients within a local area network. It is suitable for scenarios where there is no server in the LAN and there are multiple computers or mobile phones requesting data from the module.

29.2. Configuring

- Entering Serial Port Config Mode

| | |
|-------------|--|
| Command | SWITCH(config)#serial port NPORT |
| Description | NPORT: serial port server port number, which can be viewed through show serial port all summary. |

- Clearing all Config on a Serial Port

| | |
|-------------|--|
| Command | SWITCH(config)#no serial port NPORT |
| Description | NPORT: serial port server port number, which can be viewed through show serial port all summary. |

- Configuring Operation Mode

| | |
|-------------|--|
| Command | SWITCH(config-serial-port)#operation mode (tcp-client tcp-server) |
| Description | Tcp-client: tcp client operation mode. Tcp-server: tcp server operation mode. Support no operation mode command, return to disabled state. |

- Configuring Tcp-client

| | |
|-------------|--|
| Command | SWITCH(config-serial-port)# tcp-client CLIENTID remote-address A.B.C.D remote-port L4-PORT (! local-port L4-PORT) |
| Description | CLIENTID: <1 4>, support to create 4 clients. A.B.C.D: IPv4 addresses L4-PORT: Layer 4 port number Local-port is an optional configuration, the default system automatically assigns. |

- Configuring Tcp-server

| | |
|-------------|--|
| Command | SWITCH(config-serial-port)# tcp-server local-port L4-PORT |
| Description | L4-PORT: Layer 4 port number To configure tcp-server mode, the local-port parameter must be configured. |

- Configuring Tcp-server Max Connection

| | |
|-------------|---|
| Command | SWITCH(config-serial-port)# tcp-server connection max CMAX |
| Description | CMAX: The maximum number of connections in tcp-server mode, the default is 1. |

- Configuring Tcp Alive-check Time

| | |
|-------------|--|
| Command | SWITCH(config-serial-port)# tcp alive-check time SECONDS |
| Description | SECONDS: If there is no data interaction during this time period, start alive detection Range: <10-300>, in seconds This parameter is supported in both Tcp-client and tcp-server modes. |

- Configuring Rtu Baud-rate

| | |
|-------------|---|
| Command | SWITCH(config-serial-port)# serial baud-rate (300 1200 9600 19200 38400 57600 115200) |
| Description | Default baud rate is 115200. |

- Configuring Rtu Data-bits

| | |
|-------------|--|
| Command | SWITCH(config-serial-port)# serial data-bits (7 8) |
| Description | Default data is bit 8. |

- Configuring Rtu Parity

| | |
|-------------|--|
| Command | SWITCH(config-serial-port)# serial parity (none odd even mark space) |
| Description | Default check digit none. |

- Configuring Rtu Stop-bits

| | |
|-------------|--|
| Command | SWITCH(config-serial-port)# serial stop-bits (1 2) |
| Description | Default stop bit is 1. |

- Configuring Packet Length Max

| | |
|-------------|---|
| Command | SWITCH(config-serial-port)# serial packet length LENGTH |
| Description | The length of the serial data packet. If the length exceeds the LENGTH value, it will be packetized and forwarded to the network. LENGTH: range from 0 to 1460, default value is 1460. |

- Configuring Packet Interval

| | |
|-------------|--|
| Command | SWITCH(config-serial-port)# serial packet interval MILLISECONDS |
| Description | If the interval between bytes before and after the serial port data exceeds MILLISECONDS, the last byte of data is regarded as the new header byte. MILLISECONDS: range from 1 to 1000, default value is 10, in milliseconds. |


- Configuring Fifo

| | |
|-------------|---|
| Command | SWITCH(config-serial-port)# serial fifo length LENGTH |
| Description | Serial data bits are transmitted at low speed, and data is transferred from the network end to the serial port to increase the fifo to improve the forwarding capability LENGTH: range from 0 to 128, default value is 64. |

29.3. Examples

29.3.1. Example for Tcp-client

The following examples shows how to configure the serial device server work in tcp-client mode, As show in Figure below.



Serial device server work in tcp-client mode


In this case, IP address of TCP Server is 192.168.64.1, local port number is 2000. We need to configure the serial port server to work in tcp-clent mode, configure tcp-client 1 to connect to the target TCP Server, and the local port is dynamically generated by the system.

The serial parameters are all in default.

```
SWITCH(config)#serial port 1
SWITCH(config-serial-port)#operation mode tcp-client
SWITCH(config-serial-port)#tcp-client 1 remote-address 192.168.64.1 remote-port 2000
SWITCH(config-serial-port)#tcp-client 2 remote-address 192.168.64.2 remote-port 2001
```

29.3.2. Example for Tcp-server

The following examples shows how to configure the serial device server work in tcp-server mode, As show in Figure below.



Serial device server work in tcp-server mode

In this case, we need to configure the serial device server to work in tcp-server mode, configure the local port number 2000, configure the maximum number of connections to 3.

TCP Client A/B/C access to server.

The serial parameters are all in default.

```
SWITCH(config)#serial port 1
SWITCH(config-serial-port)#operation mode tcp-server
SWITCH(config-serial-port)#tcp-server local-port 2000
SWITCH(config-serial-port)#tcp-server connection max 3
```

TCP Client A/B/C transmits data stream to serial device, and will not forward it between clients. when serial device transmits, the data stream will broadcast a copy on each client.

29.4. Display Information

- Display serial port summary

```
SWITCH#show serial port 1 summary
```

| | | |
|-----------------------|---|-------------------|
| Operation mode | : | tcp-client |
| Tcp client 1 | : | 192.168.64.1:2000 |
| Tcp client 2 | : | -- |
| Tcp client 3 | : | -- |
| Tcp client 4 | : | -- |
| Tcp server local port | : | -- |

Tcp server connection max : 1
Tcp alive-check time : 30
Serial baud-rate : 115200
Serial data-bits : 8
Serial parity : none
Serial stop-bits : 1
Serial packet length : 1460
Serial packet interval : 10
Serial fifo length : 64

- Display serial port status

SWITCH#show serial port 1 status

| Port | entity | Status | Remote | Local |
|-------|--------------|--------|-------------------|----------------------|
| ----- | | | | |
| 1 | tcp client 1 | link | 192.168.64.1:1024 | 192.168.64.100:47188 |

- Display serial port statistic

SWITCH#show serial port 1 statistic

Net Octets Rx : 5824
Net Packets Rx : 728
Net Octets Tx : 5120
Net Packets Tx : 834
Serial Octets Rx : 5120
Serial Packets Rx : 834
Serial Octets Tx : 5824
Serial Packets Tx : 728
Net Connect Up/Down times : 1
Serial Overload Drop Packets : 0

30. Configuring USB

30.1. Overview of USB

Universal Serial Bus (USB), jointly formulated by computer companies and communication companies such as Intel, Compaq, Digital, IBM, Microsoft, NEC and Northern Telecom in 1995, and gradually formed an industry standard.

As a high-speed serial bus, the high transmission speed of the USB bus can meet the application environment requirements of high-speed data transmission, and the bus also has the advantages of simple power supply, convenient installation and configuration, simple expansion ports, diversified transmission methods, and compatibility. Good (backward compatibility after product upgrade) and other advantages.

This device supports the following functions based on USB: configuration import, configuration export, product firmware upgrade, system log export. The USB device can only be used as a storage device, and the function can be completed through CLI commands. It can also be set through the configuration file in the USB device, and the configuration function is automatically completed after the USB device is inserted.

This document mainly introduces operations such as configuration import, configuration export, product firmware upgrade, and system log export through CLI commands.

30.2. Configuring

- Installing USB Device

| | |
|-------------|---|
| Command | SWITCH#usb install UID |
| Description | Install the USB device. You can view the online usb device and obtain the UID information by the show usb command. |

- Removing USB Device

| | |
|-------------|---|
| Command | SWITCH#usb remove UID |
| Description | Uninstall the USB device. You can view the online usb device and obtain the UID information by the show usb command. |

- Importing Configuration

| | |
|-------------|--|
| Command | SWITCH#copy usb FILE startup-config |
| Description | Copy FILE from USB device to override startup-config file in the system. |

- Exporting Configuration

| | |
|-------------|--|
| Command | SWITCH# copy startup-config usb DIR |
| Description | Copy the startup-config file to the DIR directory of the USB device. |

- Firmware Upgrade

| | |
|-------------|--|
| Command | SWITCH# upgrade usb FILE |
| Description | System firmware upgrade, use FILE in USB device as firmware. |

- Exporting Syslog

| | |
|-------------|--|
| Command | SWITCH# copy log syslog usb DIR |
| Description | Copy the system log file to the DIR directory of the USB device. |

30.3. Examples

30.3.1. Example of Import Configuration

This example shows how to import configuration from USB device. The configuration file startup.conf is saved in the USB device, and the USB device is inserted.

Configuring steps:

Step 1: Check the USB device is online.

```
SWITCH#show usb
```

| Uid | Status | Installed | system | Total size(1K) | Used size(1K) | Dir |
|-------|--------|-----------|--------|----------------|---------------|-----|
| ----- | | | | | | |
| 0 | online | no | -- | -- | -- | -- |

Step2: Install the USB device and get the information of the USB device after loading, such as Dir path.

```
SWITCH#usb install 0
```

```
SWITCH#show usb
```

| Uid | Status | Installed | system | Total size(1K) | Used size(1K) | Dir |
|-------|--------|-----------|--------|----------------|---------------|-------|
| ----- | | | | | | |
| 0 | online | yes | vfat | 15343616 | 105488 | /usb0 |

Step 3: View the files in the USB device Dir path.

```
SWITCH#ls /usb0
```

```
System Volume Information  startup.conf
```

Step4: Import configuration.

```
SWITCH#copy usb /usb0/startup.conf startup-config
```

```
Copy Success
```

Step5: Restart the device to confirm that the configuration is imported successfully.

30.3.2. Example of Export Configuration

This example shows how to export configuration to the USB device. The USB device is inserted.

Configuring steps:

Step 1: Check the USB device is online.

```
SWITCH#show usb
```

| Uid | Status | Installed | system | Total size(1K) | Used size(1K) | Dir |
|-------|--------|-----------|--------|----------------|---------------|-----|
| ----- | | | | | | |
| 0 | online | no | -- | -- | -- | -- |

Step2: Install the USB device and get the information of the USB device after loading, such as Dir path.

```
SWITCH#usb install 0
```

```
SWITCH#show usb
```

| Uid | Status | Installed | system | Total size(1K) | Used size(1K) | Dir |
|-------|--------|-----------|--------|----------------|---------------|-------|
| ----- | | | | | | |
| 0 | online | yes | vfat | 15343616 | 105488 | /usb0 |

Step 3: Export configuration.

```
SWITCH#copy startup-config usb /usb0
```

Copy Success

Step 4: View the files in the USB device Dir path to confirm that the operation was successful.

```
SWITCH#ls /usb0
```

System Volume Information startup.conf

30.3.3. Example of Firmware Upgrade

This example shows how to upgrade firmware by USB device. The firmware file firmware.bin is saved in the USB device, and the USB device is inserted.

Configuring steps:

Step 1: Check the USB device is online.

```
SWITCH#show usb
```

| Uid | Status | Installed | system | Total size(1K) | Used size(1K) | Dir |
|-----|--------|-----------|--------|----------------|---------------|-----|
| 0 | online | no | -- | -- | -- | -- |

Step2: Install the USB device and get the information of the USB device after loading, such as Dir path.

```
SWITCH#usb install 0
```

```
SWITCH#show usb
```

| Uid | Status | Installed | system | Total size(1K) | Used size(1K) | Dir |
|-----|--------|-----------|--------|----------------|---------------|-------|
| 0 | online | yes | vfat | 15343616 | 105488 | /usb0 |

Step 3: View the files in the USB device Dir path.

```
SWITCH#ls /usb0
```

System Volume Information firmware.bin

Step 4: Upgrade firmware.

```
SWITCH# upgrade usb /usb0/firmware.bin
```

Step 5: After the execution is completed, the prompt "Reboot system to finish upgrade?" pops up, enter 'y' to restart the device to complete the upgrade operation.

30.3.4. Example of Export Syslog

This example shows how to export syslog to USB device. The USB device is inserted.

Configuring steps:

Step 1: Check the USB device is online.

```
SWITCH#show usb
```

| Uid | Status | Installed | system | Total size(1K) | Used size(1K) | Dir |
|-----|--------|-----------|--------|----------------|---------------|-----|
| 0 | online | no | -- | -- | -- | -- |

Step2: Install the USB device and get the information of the USB device after loading, such as Dir path.

```
SWITCH#usb install 0
```

```
SWITCH#show usb
```

| Uid | Status | Installed | system | Total size(1K) | Used size(1K) | Dir |
|-----|--------|-----------|--------|----------------|---------------|-------|
| 0 | online | yes | vfat | 15343616 | 105488 | /usb0 |

Step 3: Export syslog to USB device.

```
SWITCH#copy log syslog usb /usb0
```

Step 4: View the files in the USB device Dir path to confirm that the operation was successful.

SWITCH#ls /usb0

System Volume Information syslog

30.4. Display Information

- Show USB

| Uid | Status | Installed | system | Total size(1K) | Used size(1K) | Dir |
|-------|--------|-----------|--------|----------------|---------------|-------|
| ----- | | | | | | |
| 0 | online | yes | vfat | 15343616 | 105488 | /usb0 |

31. Fault Diagnosis

31.1. Ping/tracerout

- ping

| | |
|-------------|---|
| Command | SWITCH#ping {ip IPADDR ipv6 IPV6ADDR} |
| Description | Ping a remote host through IP. |

- traceroute

| | |
|-------------|---|
| Command | SWITCH# traceroute {ip IPADDR ipv6 IPV6ADDR } |
| Description | Trace the path that packets take through the network. |

31.2. Display Port Optical Module DDM Information

- Show interface opticaatl-transceiver information

Display the information of the optical/copper module inserted in the optical port.

| | |
|-------------|--|
| Command | SWITCH#show interface {IFNAME } optical-transceiver {info } |
| Description | If no interface-id is specified, the module information of all ports will be displayed. If info is not specified, the DDM information of the port module will be displayed, and if specified, the complete module information (basic information, alarm information, manufacturer information) will be displayed. |

DDM information display elements are as follows:

| Key Word | Description |
|----------|--|
| Temp | The temperature of the module, in °C, accurate to 1°C. |
| Voltage | The voltage of the module, the unit is V, accurate to 0.01V. |
| Bias | The current of the module, in mA, accurate to 0.01mA. |
| RX power | The received optical power of the module, in dBm, accurate to 0.01dBm. |
| TX power | The transmit optical power of the module, in dBm, accurate to 0.01dBm. |
| OK | normal, no intervention required. |
| WARN | Alarm, indicating that the allowable range of the device is exceeded, and attention should be paid to. |
| ALARM | Abnormal, indicating that the device's allowable state is seriously exceeded and immediate intervention is required. |
| ABSENT | Absent. |
| NA | Port not supported/module not supported. |

| | |
|---------|-----------|
| TIMEOUT | Time out. |
| ERR | Mistake. |

Display all port module DDM information

| SWITCH#show interface optical-transceiver | | | | | |
|---|--------|----------|-----------|-----------|----------|
| Port | Temp | Voltage | Bias | RX power | TX power |
| | [C] | [V] | [mA] | [dBm] | [dBm] |
| ----- | | | | | |
| GiE0/9 | 42(OK) | 3.20(OK) | 32.34(OK) | -3.98(OK) | 1.64(OK) |
| GiE0/10 | ABSENT | ABSENT | ABSENT | ABSENT | ABSENT |
| GiE0/11 | ABSENT | ABSENT | ABSENT | ABSENT | ABSENT |
| GiE0/12 | ABSENT | ABSENT | ABSENT | ABSENT | ABSENT |

- Display the overall information of the port optical module/copper module

Error message:

| Key Word | Description |
|---------------------------------------|--|
| Transceiver absent! | Failed to get information, maybe the module is not in place. |
| Get transceiver info timeout! | Timeout to get information, need to get it again. |
| Port doesn't support get module info! | The port does not support getting module information. |

Basic Information

| Key Word | Description |
|-------------------------------|----------------------------------|
| Transceiver Type | module type. |
| Connector Type | Interface Type. |
| Wavelength(nm) | Wavelength. |
| Link Length | Supported link lengths. |
| Digital Diagnostic Monitoring | Whether to support DDM function. |
| Vendor Serial Number | Module serial number. |

Warning Information

| Key Word | Description |
|--|--|
| RX Channel loss of signal | Received signal loss. |
| RX Channel power high | High received optical power alarm. |
| RX Channel power low | Low received optical power alarm. |
| TX Channel fault | Send Error. |
| TX Channel bias high | Bias current high alarm. |
| TX Channel bias low | Bias current low alarm. |
| TX Channel power high | Sending high optical power alarm. |
| TX Channel power low | Sending low optical power alarm. |
| Temperature high | High temperature alarm. |
| Temperature low | Low temperature alarm. |
| Voltage high | High voltage alarm. |
| Voltage low | Low voltage alarm. |
| None | no alarm. |
| This module doesn't support getting alarm! | The module does not support getting alarm information. |

Manufacturer information

| Key Word | Description |
|--------------------|------------------------------|
| Vendor Name | Manufacturer Names. |
| Vendor OUI | Manufacturer OUI. |
| Vendor Part Number | Manufacturer part number. |
| Vendor Revision | Manufacturer version number. |
| Manufacturing Date | Production Date. |

| | |
|----------|----------------|
| | |
| Encoding | encoding type. |

Displays overall information about a single port module

```
SWITCH#show interface gigabitEthernet0/9 optical-transceiver info
```

```
#####
```

```
gigabitEthernet0/9
```

```
+-----+
|Transceiver base information:      |
+-----+
|Transceiver Type   : 1000BASE-ZX-SFP      |
|Connector Type    : LC                   |
|Wavelength(nm)    : 1550                 |
|Link Length       :                      |
|  SMF fiber       :                      |
|  -- 80km         :                      |
|Digital Diagnostic Monitoring : YES        |
|Vendor Serial Number      : WT1703230031  |
+-----+
|Transceiver current alarm information:      |
+-----+
|None                                         |
+-----+
|Transceiver vendor information:             |
+-----+
|Vendor Name       : OEM                   |
|Vendor OUI        : 000000                |
|Vendor Part Number : SFP-GE-ZX-SM1550     |
|Vendor Revision   : V2                   |
|Manufacturing Date : 2017-03-25           |
|Encoding          : 8B10B                 |
+-----+
```

```
SWITCH#
```

Displays overall information for all port blocks

```
SWITCH#show interface optical-transceiver info
```

```
#####
```

```
gigabitEthernet0/9
```

```
+-----+
|Transceiver base information:      |
+-----+
|Transceiver Type   : 1000BASE-ZX-SFP      |
|Connector Type    : LC                   |
|Wavelength(nm)    : 1550                 |
```

```

|Link Length      :                               |
|   SMF fiber                                           |
|   -- 80km                                             |
|Digital Diagnostic Monitoring : YES                   |
|Vendor Serial Number      : WT1703230031             |
+-----+
|Transceiver current alarm information:                 |
+-----+
|None                                                         |
+-----+
|Transceiver vendor information:                         |
+-----+
|Vendor Name      : OEM                                   |
|Vendor OUI       : 000000                               |
|Vendor Part Number : SFP-GE-ZX-SM1550                 |
|Vendor Revision  : V2                                   |
|Manufacturing Date : 2017-03-25                       |
|Encoding         : 8B10B                               |
+-----+
#####
                        gigabitEthernet0/10
+-----+
|Transceiver base information:                           |
+-----+
|Transceiver Type   : 1000BASE-GT-SFP                   |
|Connector Type     : Unknown or unspecified            |
|Wavelength(nm)     : 16652                             |
|Link Length      :                                     |
|   Cable Assembly copper                               |
|   -- 100m                                             |
|Digital Diagnostic Monitoring : NO                     |
|Vendor Serial Number      : MTC100046                 |
+-----+
|Transceiver current alarm information:                 |
+-----+
This module doesn't support getting alarm!
|This module doesn't support getting alarm!             |
+-----+
|Transceiver vendor information:                         |
+-----+
|Vendor Name      : OEM                                   |
|Vendor OUI       : 000000                               |
|Vendor Part Number : SFP-T-CBTX                       |
|Vendor Revision  : F                                   |

```

```
|Manufacturing Date : 2014-10-01 |
|Encoding : 8B10B |
+-----+
#####
gigabitEthernet0/11
Get result error(Maybe Transceiver absent)!
#####
gigabitEthernet0/12
Get result error(Maybe Transceiver absent)!
SWITCH#
```

31.3. Dying Gasp

Dying Gasp is referenced in section 7.1.2.5.3 of ITU-T Recommendation G.991.2 (12/2003) as the Power Status bit. The networking devices rely on a temporary back-up power supply on a capacitor, that allows for a graceful shutdown and the generation of the dying-gasp message. This temporary power supply is designed to last from 10 to 20 milliseconds to perform these tasks.

In addition to the dying-gasp message, the power-down device will also send a trap message to the smmp server.

| Node | data |
|-----------|-----------------------------------|
| Mib files | DOT3-OAM-MIB.mib |
| oid | 1, 3, 6, 1, 2, 1, 158, 1, 6, 1, 4 |
| value | dyingGaspEvent(257) |

- Enable dying-gasp

| | |
|-------------|--|
| Command | SWITCH(config)#dying-gasp enable SWITCH(config)#no dying-gasp |
| Description | Enable dying gasp function |

LOG messages

For example:” Device 00:d0:f8:c8:23:12 power down.”