

Switch

Software Configuration Guide

Software version: Release 7.4.x

Release Notes: June 16, 2025

Contents

1. System Management	7
1.1. Command Line Interface Mode	7
1.2. Management IP Address	7
1.3. Backup/Restore Configuration	8
1.4. Clearing Log	9
1.5. System Warm Restart	9
1.6. Local User and Privilege Management	9
1.7. Login Management	10
1.8. System Hostname Configuration	13
1.9. Firmware Upgrade	13
1.10. System Data And Time Configuration	14
2. Configuring Ethernet Interface	15
2.1. Overview of Interface Types	15
2.2. Configuring	15
2.3. Examples	17
2.4. Display Information	17
3. Configuring Storm Control	19
3.1. Overview of Storm Control	19
3.2. Configuring	19
3.3. Examples	19
3.4. Display information	19
4. Configuring SPAN	20
4.1. Overview of SPAN	20
4.2. Configuring	20
4.3. Examples	21
4.4. Display Information	23
5. Configuring Port Aggregation	24
5.1. Overview of Port Aggregation	24
5.2. Overview of LACP	24
5.3. Configuring	24
5.4. Examples	25
5.5. Display information	25
6. Configuring PoE	28
6.1. Overview of PoE	28
6.2. Configuring	28
6.3. Examples	30
6.4. Display Information	30
7. Log Management	32
7.1. Log Management Overview	32
7.2. Configuring	32
7.3. Examples	33
7.4. Display Information	33
8. Configuring VLAN	35
8.1. Overview of VLAN	35
8.2. Configuring	35
8.3. Display Information	36

9. Configuring QinQ	37
9.1. Overview of QinQ	37
9.2. Configuring	38
9.3. Examples	39
9.4. Display Information	41
10. Configuring ERPS	42
10.1. Overview of ERPS	42
10.2. Introduction to ERPS Rationale	42
10.3. Configuring	44
10.4. Examples	45
10.5. Display Information	48
11. Configuring IGMP Snooping	50
11.1. Overview of IGMP Snooping	50
11.2. Configuring	50
11.3. Examples	51
11.4. Display Information	51
12. Configuring Spanning Tree Protocol	53
12.1. Overview of Spanning Tree Protocol	53
12.2. Configuring	74
12.3. Examples	77
12.4. Display Information	79
13. Configuring MAC Address	80
13.1. Overview of MAC Address	80
13.2. Configuring	80
13.3. Examples	82
13.4. Display Information	82
14. Configuring LLDP	84
14.1. Overview of LLDP	84
14.2. Configuring	86
14.3. Examples	89
14.4. Display Information	89
15. Configuring LOOP-DETECT	91
15.1. Overview of LOOP-DETECT	91
15.2. Configuring	91
15.3. Examples	92
15.4. Display Information	93
16. Configuring GVRP	94
16.1. Overview of GVRP	94
16.2. Configuring	95
16.3. Examples	96
16.4. Display Information	97
17. Configuring Voice VLAN	99
17.1. Voice VLAN Overview	99
17.2. Configuring	100
17.3. Examples	101

17.4. Display Information	103
18. Configuring VLAN Classifier	105
18.1. VLAN Classifier Function Overview	105
18.2. Configuring	105
18.3. Examples	106
18.4. Display Information	107
19. Configuring L3	108
19.1. Overview of L3	108
19.2. Configuring	109
19.3. Examples	111
19.4. Display Information	112
20. Configuring IPv6 Addresses	114
20.1. Overview of Ipv6 Address	114
20.2. IPv6 Address	114
20.3. IPv6 Message Format	115
20.4. Configuration Notes	116
20.5. Configuring	116
20.6. Examples	117
20.7. Display Information	117
21. Configuring the DHCP Client	118
21.1. Overview of DHCP Client	118
21.2. Configuration Notes	118
21.3. Configuring	118
21.4. Examples	118
21.5. Display Information	118
22. Configuring ACL	120
22.1. Overview of ACL	120
22.2. Configuring	120
22.3. Examples	124
22.4. Display Information	125
23. Configuring QoS	126
23.1. Overview of QoS	126
23.2. Configuring	127
23.3. Examples	130
23.4. Display Information	130
24. Configuring DHCP Snooping	133
24.1. Overview of DHCP Snooping	133
24.2. Configuring	133
24.3. Examples	135
24.4. Display Information	135
25. Configuring 802.1X Authentication	137
25.1. Overview of 802.1X Authentication	137
25.2. Configuring	140
25.3. Examples	142
25.4. Display Information	143
26. Configuring Port Security	144

26.1. Overview of Port Security	144
26.2. Configuring	144
26.3. Examples	145
26.4. Display Information	145
27. Configuring Ip Source Guard	147
27.1. Overview of Ip Source Guard	147
27.2. Configuring	147
27.3. Examples	147
27.4. Display Information	147
28. Configuring ARP-security	149
28.1. Overview of Function	149
28.2. Configuring	149
28.3. Examples	149
28.4. Display Information	150
29. Configuring Dos Protection	151
29.1. Overview of Dos Protection	151
29.2. Configuring	151
29.3. Examples	153
29.4. Display Information	153
30. Configuring DHCP Relay	155
30.1. DHCP Relay Overview	155
30.2. Configuring	155
30.3. Examples	157
30.4. Display Information	159
31. Configuring SNMP Network Management	161
31.1. Overview of SNMP Network Management	161
31.2. Configuring	161
31.3. Examples	162
32. Configuring RMON	163
32.1. Overview of RMON	163
32.2. Rationale	163
32.3. Configuring	164
32.4. Examples	165
32.5. Display Information	166
33. Configure sFlow	167
33.1. Overview	167
33.2. Principle	167
33.3. Configuration commands	168
33.4. Examples	169
33.5. Display Information	169
34. Configuring DHCP Server	170
34.1. Overview of DHCP Server	170
34.2. Configuring	170
34.3. Examples	172
34.4. Display Information	174
35. Configuring AAA	176

35.1. Overview of AAA	176
35.2. Configuring	176
35.3. Examples	177
36. Configuring DNS	179
36.1. Overview of DNS	179
36.2. Configuring	179
36.3. Examples	179
36.4. Display Information	180
37. Configuring SSH	182
37.1. Overview of SSH	182
37.2. Configuring	182
1.2. Examples	185
1.3. Display Information	190
38. Fault Diagnosis	193
38.1. Ping/tracerout	193
38.2. Port Optical Module	193
38.3. Dying Gasp	197
38.4. Cable Detect	197
39. Configuring EFM	199
39.1. Overview of EFM	199
39.2. Configuring	200
39.3. Examples	203
39.4. Display Information	205
40. Configuring Relay Warning	209
40.1. Overview	209
40.2 Configuration	210
40.3. Examples	215
41. Configuring Serial Device Server	219
41.1. Overview of Serial Device Server	219
41.2. Configuring	219
41.3. Examples	222
41.4. Display Information	224

1. System Management

1.1. Command Line Interface Mode

The command line interface is divided into many different modes, The commands available to you depend on which mode you are currently in. Enter a question mark (?) at the system prompt to obtain a list of commands available for each command mode.

Table following describes the main command modes, how to access each one, the prompt you see in that mode, and how to exit the mode. The examples in the table use the hostname SWITCH.

Table Command Mode Summary

Mode	Prompt	Enter Or Exit	About This Mode
User Exec	SWITCH>	Enter exit to quit	Use this mode to: Perform basic tests. Display system information. When a user at level 0-14 logs in to the device, they first enter the exec mode.
Privileged Mode	SWITCH#	While in user EXEC mode, enter the enable command. Enter disable to exit.	Use this mode to: Exec network utilities. Display module information. System management operation. When a user at level 15 logs in to the device, they first enter the privileged mode.
Global Configuration	SWITCH(config)#	While in Privileged mode, enter the configuration terminal command. Enter exit or end to return.	Use this mode to: configure parameters that apply to the entire switch.
Interface Configuration	SWITCH(config-if)#	While in global configuration mode, enter interface command (with a specific interface). Enter exit or end to return.	Use this mode to: configure parameters for the Ethernet ports.

1.2. Management IP Address

1.2.1. Configuring

- Manually Assigning IPv4 Information

Command	SWITCH(config)# management vlan VLANID ip address IPADDR/MASKLEN gateway IPADDR SWITCH(config)# no management vlan
Description	Manually assigning switch management IPv4 information.

- Configuring DHCP-Based IPv4 Information Autoconfiguration

Command	SWITCH(config)# management vlan VLANID ip address dhcp SWITCH(config)# no management vlan
Description	Configuring DHCP-Based IPv4 information autoconfiguration.

- Manually Assigning IPv6 Information

Command	SWITCH(config)# management vlan VLANID ipv6 address IPV6ADDR/MASKLEN gateway IPV6ADDR SWITCH(config)# no management vlan
Description	Manually assigning switch management IPv6 information.

- Configuring DHCP-Based IPv6 Information Autoconfiguration

Command	SWITCH(config)# management vlan VLANID ipv6 address dhcp SWITCH(config)# no management vlan
Description	Configuring DHCP-Based IPv6 information autoconfiguration.

- Display IP Information

Command	SWITCH# show management summary
Description	Display IP information.

1.2.2. Examples

Example 1: Manually assigning IPv4 information.

The following examples shows how to configure management IPv4 address, The management VLAN is 1, the management IP is 192.168.64.200/24, and the gateway address is 192.168.64.1.

Manually assigning IPv4 information:

```
SWITCH#configure terminal
SWITCH(config)#management vlan 1 ip address 192.168.64.200/24 gateway 192.168.64.1
```

Display IP information:

```
SWITCH#show management summary
Management interface with ipv4:
Type:      Static
Vlan:      1
Ip address: 192.168.64.200/24
Gateway:   192.168.64.1
```

1.3. Backup/Restore Configuration

1.3.1. Configuring

- Backup Configuration

Command	SWITCH#write
Description	Save your entries in the configuration file.

- Restore Configuration

Command	SWITCH# copy default-config startup-config SWITCH# reload
Description	Restore the system default configuration, which will take effect after the device restarts.

- Configuration Import By TFTP

Command	SWITCH# copy tftp tftp://A.B.C.D/FILE startup-config SWITCH# reload
Description	A.B.C.D: remote tftp server ip address FILE: File name of configuration Import the remote configuration into the device through the tftp protocol, replacing the existing configuration. Take effect after device restart.

- Configuration Export By TFTP

Command	SWITCH# copy startup-config tftp tftp://A.B.C.D/FILE
Description	A.B.C.D: remote tftp server ip address FILE: File name of configuration Through the tftp protocol, the configuration is saved to the specified folder of the remote tftp server.

- Configuration Import By FTP

Command	SWITCH# copy ftp ftp://A.B.C.D/FILE startup-config SWITCH# reload
Description	A.B.C.D: remote ftp server ip address FILE: File name of configuration Import the remote configuration into the device through the ftp protocol, replacing the existing configuration. Take effect after device restart.

- Configuration Export By FTP


Command	SWITCH# copy startup-config ftp ftp://A.B.C.D/FILE
Description	A.B.C.D: remote ftp server ip address FILE: File name of configuration Through the ftp protocol, the configuration is saved to the specified folder of the remote ftp server.

1.3.2. Examples

Example 1: Export the configuration to the folder specified by the remote tftp server, the file name is startup.conf.

Environment construction:

The remote PC starts the tftp server and selects the tftp current directory.



The IP address of the remote PC is 192.168.64.1, and the management IP of the switch is configured as 192.168.64.100, and the remote PC can be pinged. Execute the configuration export command:

```

SWITCH#
SWITCH# copy startup-config tftp tftp://192.168.64.1/startup.conf
  % Total    % Received % Xferd  Average Speed   Time    Time     Time  Current
                                 Dload  Upload  Total  Spent    Left  Speed
100 1230    0    0 100 1230    0 151k  ---:--:--  ---:--:--  ---:--:--  240k
100 1230    0    0 100 1230    0 144k  ---:--:--  ---:--:--  ---:--:--  144k
Copy Success

```

In the test directory of the remote PC, you can view the newly created startup.conf file.

Example 2: Import the configuration file startup.conf under the folder specified by the remote ftp server into the device.

Environment construction:

Start the ftp server on the remote PC, select the current directory of ftp, and place the startup.conf file.



The IP address of the remote PC is 192.168.64.1, and the switch management IP is configured as 192.168.64.100, and the remote PC can be pinged. Execute the configuration import command:

```

SWITCH#
SWITCH# #copy ftp tftp://192.168.64.1/startup.conf startup-config
Enter Username:xxxxxx
Enter Password:xxxxxx
  % Total    % Received % Xferd  Average Speed   Time    Time     Time  Current
                                 Dload  Upload  Total  Spent    Left  Speed
100  973 100  973    0    0 42572    0  ---:--:--  ---:--:--  ---:--:-- 48650
Copy Success

```

After the configuration is imported, restart to take effect.

1.4. Clearing Log

- Clearing system log

Command	SWITCH# clear logging
Description	Clear system log

1.5. System Warm Restart

- System Warm Restart

Command	SWITCH# reload
Description	System warm restart.

1.6. Local User and Privilege Management

By assigning different privileges to users and defining different privilege levels for different functions, you can control user access to network devices.

The command line interface of network devices is divided into 16 levels of privileges from 0 to 15 for users. Users of different levels are allowed to execute different commands. The smaller the number, the lower the level of privilege, with 0 being the lowest level and 15 being the highest level. Levels 0 to 1 are called ordinary user levels, which do not allow configuration of the device by default. Levels 2 to 15 are called privileged user levels, which allow configuration of the device. Level 15 is the administrator user level, which supports all management behaviors.

1.6.1. Configuring

- Add and Delete Users, Modify User Password, Modify User Privileges

Command	SWITCH(config)# username NAME { privilege <0-15>} { algorithm-type (md5 sha256 sha512)} { password LINE} SWITCH(config)# no username NAME
Description	If the user NAME does not exist, add a new user; if it exists, modify the user's password; The device comes with a factory default user "admin" and password "admin", which supports password modification and deletion operations; User and password length is 0-32 bytes; The password is displayed in encrypted form; Password characters are case sensitive; Delete operation does not support deleting the user itself; to delete an online user, you must first kick the user offline; Create a user. If there is no privilege information, the default privilege level 15 is used; If there is no algorithm type, sha256 is used by default

- Configuring Command Line Privileges

Command	SWITCH(config)# privilege {config exec show} level <0-15> command STRING SWITCH(config)# no privilege {config exec show} { level <0-15>} command STRING
Description	Configuring command line privileges The device supports command permission configuration in exec, show, and config mode Privilege configuration range <0-15>

- Configuring Line Vty Privilege

Command	SWITCH(config)# line vty 0 SWITCH(config-line)# privilege level <0-15> SWITCH(config-line)# no privilege level
Description	Configure privilege for line vty The default privilege is 15 If the user logs in to the vty, the actual user privilege are the smaller value of the user privilege and the line vty privilege. Only takes effect when AAA is enabled

- Configure the Enable Password

Command	SWITCH(config)# enable password {level VALUE } LINE SWITCH(config)# no enable password {level VALUE }
Description	Configure corresponding passwords for different enable levels. If a level is not password protected, users with lower level privilege are not allowed to upgrade privilege to that level by enable command.

1.6.2. Display Information

- Display the Default Privilege and Configuration Privilege of the Command Lline in Each Mode

```
SWITCH#show privilege commands exec
Command           Default privilege  Current privilege
clock              15                 15
configure          10                 10
copy               15                 15
disable            0                  0
enable             0                  0
errdisable         10                 10
more               15                 15
password           15                 15
ping               10                 10
reload             15                 15
scp                15                 15
sftp               15                 15
telnet             10                 10
terminal           0                  0
traceroute         10                 10
upgrade            15                 15
usb                15                 15
write              15                 15
```

1.7. Login Management

1.7.1. Configuring

1.7.1.1. Service Enablement Management

- Configure and Enable WEB Management

Command	SWITCH(config)# web-server enable { all http https } SWITCH(config)# no web-server enable
Description	Configure and enable WEB management. Default disabled state. Support IPv4 and IPv6.

- Configure and Enable Telnet Management

Command	SWITCH(config)# telnet-server enable SWITCH(config)# no telnet-server enable
Description	Configure and enable telnet management. Default disabled state. Support IPv4 and IPv6.

- Configure and Enable SSH Management

Command	SWITCH(config)# ssh-server enable SWITCH(config)# no ssh-server enable
Description	Configure and enable SSH management. Default disabled state. Support IPv4 and IPv6.

1.7.1.2. ACL Applied to Services

- IPv4 ACL Applied to Services

Command	SWITCH(config)# ip { telnet ssh http https } access-class {<1-199> <1300-2699> ACLNAME} SWITCH(config)# no ip { telnet ssh http https } access-class
Description	IPv4 ACL is applied to telnet, ssh, http, https services. Users who meet the ACL permit rules are allowed to access the device, otherwise users cannot access the device.

- IPv6 ACL Applied to Services

Command	SWITCH(config)# ipv6 { telnet ssh http https } access-class { ACLNAME } SWITCH(config)# no ipv6 { telnet ssh http https } access-class
Description	IPv6 ACL is applied to telnet, ssh, http, https services. Users who meet the ACL permit rules are allowed to access the device, otherwise users cannot access the device.

1.7.1.3. ACL Applied to Vty

- ACL Applied to Vty

Command	SWITCH(config-line)# access-class {<1-199> <1300-2699> ACLNAME } in SWITCH(config-line)# no access-class {<1-199> <1300-2699> ACLNAME } in
Description	ACL applied to vty. For telnet, ssh servers on vty. Users who meet the ACL permit rules are allowed to login by this line.

1.7.1.4. Service Management Based on Line

- Configure Services Supported on Line Vty

Command	SWITCH(config-line)# transport input { telnet ssh all none } SWITCH(config-line)# no transport input
Description	Configure services supported on vty. telnet: only supports telnet service. ssh: only supports ssh service. all: supports telnet and ssh services. none: No services are supported. Supports telnet and ssh services by default.

1.7.1.5. Authentication Failure Management

- Enable Silent After Multiple Authentication Failures

Command	SWITCH(config)# password authen-fail block SWITCH(config)# no password authen-fail block
Description	Enable the silent function after multiple authentication failures. It is disabled by default.

- Configuring Silent Parameters

Command	SWITCH(config)# password authen-fail retry-interval INTERVAL retry-time RETRY_S block-time TIME SWITCH(config)# no password authen-fail retry-interval
Description	INTERVAL: The interval between multiple authentications, range <1 60>, default 5, unit: minutes RETRY_S: Number of consecutive authentication failures, range <1 60>, default 5 TIME: silent time, range <1 1440>, default 10, unit: minutes

- Resuming a User From Silent State

Command	SWITCH# password authen-fail unblock {all username NAME }
Description	Resuming a user from silent state

1.7.1.6. Other Commands

- Configuring user online timeout

Command	SWITCH(config-line)# exec-timeout MINUTES {SECONDS}
Description	Configure in the line vty/console view MINUTES: Timeout minutes, range <0 - 35791>, setting to 0 means no timeout SECONDS: Timeout seconds, range <0 - 2147483>

- Kick Online Users Offline

Command	SWITCH# clear line { vty console } LINE
Description	Vty represents the remote login user. Console represents the serial port login user. LINE information can be viewed in the show users command. Kicking the user itself is not supported.

- Show Online User Commands

```
SWITCH#show users
Type   Line  User           Idle      Host
con    0     admin         00:00:03  --
vty    0     admin         00:00:11  192.168.64.1
```

Users display elements are as follows:

Field	illustrate
Type	console or vty
Line	console: fixed 0 vty : 0-7
User	username
Idle	Time in idle state, if the timeout time is exceeded, the terminal automatically exits.
Host	Login user ip address

1.7.2. Examples

1.7.2.1. Example of Configuring ACL Application on Service

Case 1 : The device enables the telnet service. Only users with the IP address 192.168.64.100 are allowed to access the device through telnet, and other users are denied access.

```
SWITCH(config)#telnet-server enable
SWITCH(config)#ip-access-list standard 1
SWITCH(config-std-acl)#permit host 192.168.64.100
SWITCH(config-std-acl)#exit
SWITCH(config)#ip telnet access-class 1
```

1.7.2.2. Service Management Configuration Case Based on Line

Case 1 : The device enables the telnet service, and the device only allows one user to log in to the device through telnet at the same time.

```
SWITCH(config)#telnet-server enable
SWITCH(config)#line vty 1 7
SWITCH(config-line)#transport input none
```

1.7.2.3. Authentication failure Management Configuration Example

Case 1 : If a user fails to log in three times in a row within 5 minutes, the system will be silent for 1 minute.

Configuration:

```
SWITCH(config)# password authen-fail block
SWITCH(config)# password authen-fail retry-interval 5 retry-time 3 block-time 1
```

Check:

```
SWITCH#show password authen-fail
Configuration:
Authen-fail : Enabled
Retry interval: 5 (minutes)
Retry times: 3
```

Block time: 1 (minutes)

Username admin:
1970-01-01 00:46:48 RHOST

1.8. System Hostname Configuration

- Configuring Hostname

Command	SWITCH(config)# hostname WORD
Description	The name must consist of printable characters and the length cannot exceed 63 bytes. This configuration takes effect immediately.


1.9. Firmware Upgrade

- Firmware Upgrade

Command	SWITCH# upgrade firmware tftp://SERVER/FILENAME
Description	You need to build a TFTP server on the terminal, and ensure the two-way interconnection between the terminal and the device network. SERVER: TFTP server IP and the relative address of the server window and the firmware upgrade file. FILENAME: Firmware upgrade file. The firmware upgrade process will take 5-6 minutes, reboot the device to complete the firmware upgrade. Do not power off the device during the upgrade process.


Example 1: The following examples shows firmware upgrade via tftp.

Step 1: As shown in the figure below, SWITCH-A is the device to be upgraded, and the telnet function is enabled; USER-A is the host on the same network segment in the LAN, and USER-B is the management device in the LAN, both of which can log in to SWITCH-A by telnet.



Firmware upgrade connection diagram

Step 2: Select USER-B to perform the version upgrade operation. Open the TFTP server on USER-B and place the upgrade file [FIRMWARENAME].bin in the Y:/workspace directory. TFTP server as shown in the figure below.



TFTP Server

Step 3: USER-B telnet logs in to SWITCH-A and executes the upgrade command in privileged mode. Upgrade information as shown in the figure below.

```

SWITCH#upgrade firmware tftp://192.168.64.1/lite-release-6.2.0.bin
% Total    % Received % Xferd  Average Speed   Time    Time     Current
           Dload  Upload   Total     Spent    Left     Speed
100 82.1M    0 82.1M    0    0 1091k    0  ---:--:--  0:01:17  ---:--:-- 1093k
100 82.1M    0 82.1M    0    0 1091k    0  ---:--:--  0:01:17  ---:--:-- 1091k
Un-packet install file, this will last about 60 seconds.
Read configure from config file.
Validation.
Check upgrade file success.
Start erase and write bin to flash, this will last about 120 seconds.
Erasing 128 Kibyte @ d7e0000 -- 100 % complete
Reboot system to finish upgrade? (y/n): █

```

Upgrade Information

Step 4: After the upgrade is over, select "y" to restart the device to complete the upgrade, select "n" to continue running the device, and the upgrade operation will be completed after restart.

1.10. System Data And Time Configuration

● Setting the System Clock

Command	SWITCH# clock set HH:MM:SS DAY MON YEAR
Description	Setting the system clock. For example: Clock set 15:30:00 1 october 2017.

● Setting NTP Server

Command	SWITCH(config)# ntp server {A.B.C.D ipv6 X.X::X.X host NAME }
Description	Configure the IP/IPv6 address or hostname of the NTP server.After the configuration is complete, if the device and the server are connected to the network, the device will automatically synchronize the time information from the server. It takes about 4-8 minutes to complete the time synchronization for the first time.

● Setting Time zone

Command	SWITCH(config)# clock timezone ZONE
Description	Configure the system time zone. The default timezone is UTC. Supports standard time zone configuration, such as Shanghai time zone keyword "Shanghai", Hong Kong time zone keyword "Hong_Kong", etc.

● Display System Clock

Command	SWITCH# show clock
Description	Display system clock.

● Display NTP Status

Command	SWITCH# show ntp status
Description	Display ntp status.

2. Configuring Ethernet Interface

2.1. Overview of Interface Types

The interfaces of switch can be divided into the following two categories: Layer 2 interfaces and Layer 3 interfaces.

L2 interface, Including common physical ports (Switch Port) and aggregate ports (Port Channel).

Switch Port consists of a single physical port on the device and only support Layer 2 switching. The port can be an Access Port, Hybrid Port or a Trunk Port.

Port Channel is formed by the aggregation of multiple physical member ports. We can bundle multiple physical links together to form a simple logical link, which we call an aggregate port. For Layer 2 switching, the aggregation port can superimpose the bandwidth of multiple ports to expand the link bandwidth.

L3 interface, Here mainly refers to the SVI port.

SVI is a switching virtual interface, a logical interface used to implement Layer 3 switching. SVI can be used as the local management interface, through which the administrator can manage the device. You can create an SVI with the interface vlan interface configuration command, and then assign an IP address to the SVI to establish routing between VLANs.

2.2. Configuring

- Interface Range Mode

Command	SWITCH(config)# interface IFNAME_RANGE
Description	Specify the range of interfaces to be configured, and enter interface-range configuration mode. When there are multiple range combinations, separate them with ',' without spaces. For example, the command interface range gigabitEthernet 0/1-4, gigabitEthernet 0/9-12 is a valid range. You can use the interface range command to configure up to five port ranges; Each interface-range must consist of the same port type.

- Adding a Description for an Interface

Command	SWITCH(config-if)# description DESC
Description	Add a description (up to 80 characters) for an interface.

- Shutdown the Interface

Command	SWITCH(config-if)# shutdown SWITCH(config-if)# no shutdown
Description	Shut down an interface.

- Configuring Interface Speed

Command	SWITCH(config-if)# speed {10 100 1000 auto} SWITCH(config-if)# no speed
Description	Enter auto to enable the interface to autonegotiate speed with the connected device. If you use the 10, 100, or the 1000 keywords with the auto keyword, the port autonegotiates only at the specified speeds;

- Configuring Interface Duplex Mode

Command	SWITCH(config-if)# duplex {auto full half} SWITCH(config-if)# no duplex
Description	Enable half-duplex mode (for interfaces operating only at 10 or 100 Mbps). You cannot configure half-duplex mode for interfaces operating at 1000 Mbps

Attention:

◆ When both speed and duplex exit auto mode, port auto-negotiation is disabled.

- Configuring Interface Flowcontrol

Flow control enables connected Ethernet ports to control traffic rates during congestion by allowing congested nodes to pause link operation at the other end. If one port experiences congestion and cannot receive any more traffic, it notifies the other port by sending a pause frame to stop sending until the condition clears. Upon receipt of a pause frame, the sending device stops sending any data packets, which prevents any loss of data packets during the congestion period.

Command	SWITCH(config-if)# flowcontrol {on off }
---------	---

Description	Configure the flow control mode for the port. on: The port cannot send pause frames but can operate with an attached device that is required to or can send pause frames; the port can receive pause frames. off: Flow control does not operate in either direction. In case of congestion, no indication is given to the link partner, and no pause frames are sent or received by either device.
-------------	--

- **Configuring Interface MTU**

When a port performs high-throughput data exchange, it may encounter a frame larger than the Ethernet standard frame length, which is called a jumbo frame.

The user can control the maximum frame length that the port is allowed to send and receive by setting the MTU of the port.

Frames received or forwarded by the port, if the length exceeds the set MTU, will be discarded.

Due to chip limitations, the MTU value only supports even numbers. If the user configures an odd number, the device will auto-align to even. For example, if the MTU is configured as 127, it actually works as 128.

Command	SWITCH(config-if)# mtu LENGTH SWITCH(config-if)# no mtu
Description	Change the MTU size for the interface on the switch. The range is 46 to 10222 bytes; the default is 1500 bytes.

- **Configuring SFP Interface Mode**

Command	SWITCH(config-if)# port mode { sgmii 2500base-x 1000base-x 10gbase-x auto } SWITCH(config-if)# no port mode
Description	1000Bbase-x: The port operate at 1000Mbps, full-duplex only. sgmii: Enables connection to external copper transceivers. 2500base-x: The port operate at 2.5G, full-duplex only. 10gbase-x: The port operate at 10G, full-duplex only. auto: Automatic mode, supporting port rate adaptation. Only supports configuration on physical ports, default auto mode.

- **Configuring Interface Medium Type**

If a port can be configured both fiber and copper medium types, you can only use one of them. Once the medium type is determined, configure the properties of the port, such as duplex, flow control, and rate, which all refer to the properties of the currently selected type of port.

Command	SWITCH(config-if)# medium { copper fiber auto [prefer (copper fiber)] } SWITCH(config-if)# no medium
Description	Configuring interface medium type. Default is auto mode, prefer copper. Copper: Indicates the choice of copper medium type. Fiber: Indicates the choice of fiber medium type. Auto: Indicates the adaptive port media type, Determine whether it is an copper or fiber port based on the access medium, prefer copper. Auto prefer copper: Indicates the adaptive port media type, When both fiber and copper are connected, prefer the copper port. Auto prefer fiber: Indicates the adaptive port media type, When both fiber and copper are connected, prefer the fiber port. No operation restores the media type to copper.

- **Configuring Interface Isolate**

In some situations, you need to prevent Layer 2 (L2) connectivity between end devices on a switch, you can use the isolate function.

When some ports are set as isolated ports, the isolated ports cannot communicate with each other, the isolated port and the non-isolated port can communicate normally, and the non-isolated port and the non-isolated port can communicate normally.

Command	SWITCH(config-if)# switchport isolate SWITCH(config-if)# no switchport isolate
Description	Setting the port as an isolated port.

- **Configuring Interface Auto negotiation**

Command	SWITCH(config-if)# autoneg on SWITCH(config-if)# no autoneg
Description	Configure port auto-negotiation on and off. Only applicable to 1000M optical port, If this command is configured on other ports, it prompts failure. Default is on. By show interface brief command, You can view the auto-negotiation status of the link up

2.3. Examples

- Enter gigabitEthernet0/1 Interface Configuration Mode:

```
SWITCH#
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#
```

- Configure the Port Description Information as "TEST_A"

```
SWITCH(config-if)#description TEST_A
```

- No Shutdown Port

```
SWITCH(config-if)#no shutdown
```

- Setting the Port Speed 100M, Duplex Full, and Flowcontrol On

```
SWITCH(config-if)#speed 100
SWITCH(config-if)#duplex full
SWITCH(config-if)#flowcontrol on
```

- Setting the Port MTU value 1024

```
SWITCH(config-if)#mtu 1024
```

2.4. Display Information

- Display Brief Information of All Ports

```
SWITCH#show interface brief
```

```
-----
Ethernet  Type  Status  Reason  Speed  Duplex  Flowcontrol  Autoneg  Port
Interface                                     Ch #
-----
GiE0/1    ETH  down    none    --     --     --           --       --
GiE0/2    ETH  up      none    1000M  FULL    OFF          ON       --
GiE0/3    ETH  down    none    --     --     --           --       --
GiE0/4    ETH  down    none    --     --     --           --       --
GiE0/5    ETH  down    none    --     --     --           --       --
GiE0/6    ETH  down    none    --     --     --           --       --
GiE0/7    ETH  down    none    --     --     --           --       --
GiE0/8    ETH  up      none    100M   FULL    OFF          ON       --
GiE0/9    ETH  down    none    --     --     --           --       --
GiE0/10   ETH  down    none    --     --     --           --       --
GiE0/11   ETH  down    none    --     --     --           --       --
GiE0/12   ETH  down    none    --     --     --           --       --
-----
```

- Display Single Port Configuration and Status

```
SWITCH#show interface gigabitethernet0/1
Interface gigabitethernet0/1
Hardware is eth current hw addr: 0050.4c82.89a0
Physical:0050.4c82.89a0
Description: test_a
Index 1 metric 0 mtu 1024 speed-unknown duplex-unknown flowcontrol-unknown
Port mode is invalid
<up>
vrf binding: not bound
Bandwidth -8
Input packets 0677, bytes 072690,
Multicast packets 0327 broadcast packets 0350 fcs error 00 undersizeerrors 00
oversizeerrors 00
Output packets 00, bytes 00,
Multicast packets 00 broadcast packets 00
```

- Display Port Packet Statistics

```
SWITCH#show interface gigabitEthernet0/1 counters
Interface gigabitEthernet16/1
```

```
Good Octets Tx      : 1914949
Good Octets Rx      : 0
Bad Octets Rx       : 0
Mac Tx Err Pkts    : 0
Good Packets Tx     : 1913
Good Packets Rx     : 0
Bad Packets Rx      : 0
Broadcast Packet Tx : 24
Broadcast Packets Rx : 0
Multicast Packet Tx : 55
Multicast Packets Rx : 0
pkts_64_octets     : 285
pkts_65_127_octets : 263
pkts_128_255_octets : 42
pkts_256_511_octets : 36
pkts_512_1023_octets : 91
pkts_1024_max_octets : 1196
Excessive Collisions : 0
UnRecg MAC Cntl Pkts Rx : 0
Flow Ctrl Pkts Sent : 0
Flow Ctrl Pkts Recvd : 0
Drop Events        : 0
Undersized Pkts Recvd : 0
Fragments Recvd    : 0
Oversized Pkts Recvd : 0
Jabber Pkts Recvd  : 0
mac_rcv_error      : 0
Bad CRC            : 0
Collisions         : 0
Late Collisions    : 0
Bad Flow Ctrl Recv : 0
```

- **Display Port Isolation Configuration**

```
SWITCH#show switchport isolate
interface      config
GiE0/1         isolated
GiE0/2         normal
GiE0/3         normal
GiE0/4         normal
GiE0/5         normal
GiE0/6         normal
GiE0/7         normal
GiE0/8         normal
GiE0/9         normal
GiE0/10        normal
```

3. Configuring Storm Control

3.1. Overview of Storm Control

Storm control prevents traffic on a LAN from being disrupted by a broadcast, multicast, or unicast storm on one of the physical interfaces. A LAN storm occurs when packets flood the LAN, creating excessive traffic and degrading network performance. Errors in the protocol-stack implementation, mistakes in network configurations, or users issuing a denial-of-service attack can cause a storm.

Storm control uses bandwidth as a percentage of the total available bandwidth of the port that can be used by the broadcast, multicast, or unicast traffic, to measure traffic activity. because of hardware limitations and the way in which packets of different sizes are counted, threshold percentages are approximations.

3.2. Configuring

- Configuring Storm Control

Command	SWITCH(config-if)# storm-control { broadcast multicast unicast all unicast-broadcast multicast-broadcast } level LINE SWITCH(config-if)# no storm-control
Description	Configure broadcast, multicast, or unicast storm control. By default, storm control is disabled. If you set the threshold to the maximum value (100 percent), no limit is placed on the traffic. If you set the threshold to 0.0, traffic on that port is blocked. The range is 0.00 to 100.00. Support adaptive port rate change. Unicast only containing unknown unicast packets.

3.3. Examples

Example 1: Configure the unknown multicast storm control on port gigabitEthernet0/1 to 10% of the total bandwidth.

Step 1: Specify the interface gigabitEthernet0/1 to be configured, and enter interface configuration mode.

```
SWITCH#  
SWITCH#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
SWITCH(config)#interface gigabitEthernet0/1  
SWITCH(config-if)#
```

Step 2: Configure the unknown multicast storm control on port gigabitEthernet0/1 to 10%.

```
SWITCH(config-if)#storm-control multicast level 10
```

3.4. Display information

- Display All Port Storm Control Configurations


```
SWITCH#show storm-control  
Port          BcastLevel    McastLevel    Unicastlevel  
GiE0/1        100.00%       10.00%        100.00%  
GiE0/2        100.00%       100.00%       100.00%  
GiE0/3        100.00%       100.00%       100.00%  
GiE0/4        100.00%       100.00%       100.00%  
GiE0/5        100.00%       100.00%       100.00%  
GiE0/6        100.00%       100.00%       100.00%  
GiE0/7        100.00%       100.00%       100.00%  
GiE0/8        100.00%       100.00%       100.00%  
GiE0/9        100.00%       100.00%       100.00%  
GiE0/10       100.00%       100.00%       100.00%  
GiE0/11       100.00%       100.00%       100.00%  
GiE0/12       100.00%       100.00%       100.00%
```

4. Configuring SPAN

4.1. Overview of SPAN

You can analyze network traffic passing through ports by using SPAN (Local Switched Port Analyzer) to send a copy of the traffic to another port on the switch that has been connected to a network analyzer or other monitoring or security device. SPAN copies traffic received or sent (or both) on source ports to a destination port for analysis.


SPAN does not affect the switching of network traffic on the source ports. You must dedicate the destination port for SPAN use.



Example of SPAN configuration

SPAN supports a session entirely within one switch. all source ports and destination ports are in the same switch.

RSPAN (Remote Switch Port Analyzer, remote port mirroring) is an extension of SPAN . The remote mirroring source port and destination port can span multiple network devices. The principle of remote mirroring is that the source device, intermediate device and destination device create a Remote VLAN, and all ports participating in the session must be added to the Remote VLAN. The mirrored message is broadcast in the Remote VLAN, so that the mirrored message is transmitted from the source port of the source device to the destination port of the destination device.



Example of RSPAN configuration

SPAN /RSPAN is based on session management, and the source port and destination port of SPAN are configured in the session. In a session, there can be only one destination port, but multiple source ports can be configured at the same time.

4.2. Configuring

- Creating a Session

Command	SWITCH(config)# monitor session SESSION-ID SWITCH(config)# no monitor session SESSION-ID
Description	Create a SPAN session, create a session and enter session mode at the same time For session-id, the range is 1 to 7

- Configuring Session Description

Command	SWITCH(config-monitor)# description DESC
Description	Configure the session descriptor , which supports a maximum of 32 characters.

- Configuring Session Mode

Command	SWITCH(config-monitor)# remote {source destination} SWITCH(config-monitor)# no remote
---------	--

Description	Configuring Session Mode The default is local mirror Source: source device of remote mirroring Destination : destination device of the remote mirroring
-------------	--

Illustrate

- ◆ Changing the session mode will cause the source and destination configurations to be deleted

● Configuring SPAN/RSPAN Source Interfaces

Command	SWITCH(config-monitor)# source interface IFNAME { both rx tx } SWITCH(config-monitor)# no source interface IFNAME { both rx tx }
Description	Create/delete source interfaces Both: monitors the ingress and egress directions of the interface Rx: monitors the ingress direction of the interface Tx: monitors the egress direction of the interface

● Configuring SPAN/RSPAN Source VLAN

Command	SWITCH(config-monitor)# source vlan <1-4094> rx SWITCH(config-monitor)# no source vlan <1-4094>
Description	Create/delete source VLAN Vlan supports range mode, for example: source vlan 20-25 rx Supports monitoring of up to 8 source VLANs

Illustrate

- ◆ The source VLAN can be configured in at most one session.
- ◆ The source VLAN and source interface cannot coexist, whether in the same session or across different sessions.

● Configuring the SPAN Destination Interface

Command	SWITCH(config-monitor)# destination interface IFNAME { switch } SWITCH(config-monitor)# no destination interface IFNAME
Description	Create/delete SPAN destination interface Switch: destination interface participates in forwarding

● Configuring the RSPAN Destination Interface

Command	SWITCH(config-monitor)# destination interface IFNAME remote-vlan <1-4094> { switch } SWITCH(config-monitor)# no destination interface IFNAME
Description	Create/delete RSPAN destination interface Switch: destination interface participates in forwarding When the session type is remote-destination, switch is a required option.

Illustrate

- ◆ Only one RSPAN can be configured on a device.
- ◆ It is not recommended to add common interfaces to the Remote VLAN.
- ◆ The remote VLAN cannot be within the range of the source VLAN.

4.3. Examples

Case 1

SPAN based on interface mirroring: This example Use interface gigabitEthernet0/8 to monitor the ingress packets of gigabitEthernet0/1 and the ingress/egress packets of gigabitEthernet0/2. Set the monitoring session name to "TRAFFIC_MONITOR".

Step 1: Create session.

```
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH(config)#monitor session 1
SWITCH(config-monitor)#
```

Step 2: Configuring session description.

```
SWITCH(config-monitor)#description TRAFFIC_MONITOR
```

Step 3: Configuring session source interfaces.

```
SWITCH(config-monitor)#source interface gigabitEthernet0/1 rx
SWITCH(config-monitor)#source interface gigabitEthernet0/2 both
```

Step 4: Configuring session destination interface.

```
SWITCH(config-monitor)#destination interface gigabitEthernet0/8
```

Case 2

SPAN based on VLAN mirroring : Use interface gigabitEthernet0/8 to monitor the ingress packets of VLAN 1 , and set the monitoring session name to "TRAFFIC_MONITOR_VLAN " .

- Enter global mode and establish a session:

```
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH(config)#monitor session 1
SWITCH(config-monitor)#
```

- Configure the session description to "TRAFFIC_MONITOR_VLAN "

```
SWITCH(config-monitor)#description TRAFFIC_MONITOR_VLAN
```

- Configuring the session source interface


```
SWITCH(config-monitor)#source vlan 1 rx
```

- Configure the session destination interface

```
SWITCH(config-monitor)#destination interface gigabitEthernet0/8
```

Case 3

RSPAN mirroring : Use the interface gigabitEthernet0/8 of the remote device SWITCH-C to monitor the rx packets of the ininterface gigabitEthernet0/1 of the local device SWITCH-A . The remote-vlan is 1000, and the intermediate device supports the packets broadcast of VLAN1000 .



Configure SWITCH-A:

- Enter global mode and establish a session:

```
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH(config)#monitor session 1
SWITCH(config-monitor)#
```

- Configure the session description to "TRAFFIC_MONITOR_SOURCE "

```
SWITCH(config-monitor)#description TRAFFIC_MONITOR_SOURCE
```

- Configuring session mode

```
SWITCH(config-monitor)#remote source
```

- Configuring the session source interface

```
SWITCH(config-monitor)#source interface gigabitEthernet0/1 rx
```

- Configure the session destination interface

```
SWITCH(config-monitor)#destination interface gigabitEthernet0/8 remote-vlan
1000
```

Configure SWITCH-B:

- Create VLAN 1000

```
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH(config)# vlan 1000
```

- The interface is configured as a trunk port.

```
SWITCH(config)# interface gigabitEthernet0/1-2
SWITCH(config-if)#switchport mode trunk
```

Configure SWITCH-C:

- Create VLAN 1000

```
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH(config)# vlan 1000
```

- Enter global mode and establish a session:

```
SWITCH#configure terminal
```

```
Enter configuration commands, one per line. End with CNTL/Z.
```

```
SWITCH(config)#monitor session 1
```

```
SWITCH(config-monitor)#
```

- Configure the session description to "TRAFFIC_MONITOR_DESTINATION "

```
SWITCH(config-monitor)#description TRAFFIC_MONITOR_DESTINATION
```

- Configure session mode

```
SWITCH(config-monitor)# remote destination
```

- Configure the session destination interface

```
SWITCH(config-monitor)#destination interface gigabitEthernet0/8 remote-vlan  
1000 switch
```

```
SWITCH(config-monitor)#exit
```

- Configure the VLAN of the destination interface

```
SWITCH(config)#interface gigabitEthernet 0/8
```

```
SWITCH(config-if)#switchport access vlan 1000
```

4.4. Display Information

- Display Session of SPAN

```
SWITCH#show monitor session 1  
session 1  
-----  
description      : TRAFFIC_MONITOR  
type             : span  
source intf      :  
  tx only        :  
  rx only        : gigabitEthernet0/1  
  both           : gigabitEthernet0/2  
  
source VLANs     :  
  rx only        :  
  
destination intf : gigabitEthernet0/8  
switch           : false
```


- Display Session of RSPAN

```
SWITCH#show monitor session 1  
session 1  
-----  
description      : TRAFFIC_MONITOR_SOURCE  
type             : remote-source  
  
source intf      :  
  tx only        :  
  rx only        : gigabitEthernet0/1  
  both           :  
  
source VLANs     :  
  rx only        :  
destination intf : gigabitEthernet0/8  
remote vlan      : 1000  
switch           : false
```

5. Configuring Port Aggregation

5.1. Overview of Port Aggregation

Port aggregation provides fault-tolerant high-speed links between switches, routers, and servers. You can use it to increase the bandwidth between the wiring closets and the data center, and you can deploy it anywhere in the network where bottlenecks are likely to occur. Port aggregation provides automatic recovery for the loss of a link by redistributing the load across the remaining links. If a link fails, port aggregation redirects traffic from the failed link to the remaining links in the channel without intervention. Port aggregation consists of individual Fast Ethernet or Gigabit Ethernet links bundled into a single logical link called channel, as shown in Figure below.



Each Channel can consist of up to eight compatibly configured Ethernet ports. All ports in each Channel must be configured as Layer 2 ports. The number of Channels is limited to 12.

You can configure an Channel in one of these modes: Manual(Static), Active(LACP), or Passive(LACP).

5.2. Overview of LACP

LACP (Link Aggregation Control Protocol) based on the IEEE802.3ad standard is a dynamic link aggregation protocol. If a port enables the LACP, the port will send LACPDU message to announce its system priority, system MAC, port priority, port number and operation key, etc. After the connected device receives the LACP message from the peer end, it compares the system priorities of the two ends according to the system ID in the message. On the side with the higher system ID priority, the ports in the aggregation group are set to be in the aggregation state according to the order of port ID priority from high to low, and the updated LACP message is sent out. It will also set the corresponding port to the aggregation state, so that the two sides can reach the same agreement when the port exits or joins the aggregation group.

After the LACP member interface link is bound, periodic LACP packet exchange will be carried out. When no LACP packet is received for a period of time, it is considered that the packet reception timed out, the member interface link is unbound, and the port is in a state of non-forwarding again. There are two modes of timeout here: long timeout mode and short timeout mode. In the long timeout mode, the port sends a packet every 30 seconds. If it does not receive a packet from the peer for 90 seconds, it will be in a packet receiving timeout. ; In the short timeout mode, the port sends a packet every 1 second. If it does not receive a packet from the peer for 3 seconds, it is in the packet receiving timeout.




Figure Typical LACP application

As shown Figure, switch A and switch B are connected together through 3 ports. We set the system priority of switch A to 61440, and set the system priority of switch B to 4096. Enable LACP link aggregation on the three directly connected ports of switches A and B.

After receiving the LACP message from the peer, switch B finds that its system ID has a higher priority (switch B has a higher system priority than switch A), so it follows the order of port ID priority (in the case of the same port priority) , in the order of port numbers from small to large) set ports 4, 5, and 6 to be in the aggregation state.

After switch A receives the updated LACP packet from switch B, it finds that the system ID of the peer end has a higher priority, and set the ports 1, 2, and 3 to the aggregation state.

5.3. Configuring

- Configuring Layer 2 Channels

Command	SWITCH(config-if)#channel-group ID mode manual SWITCH(config-if)#channel-group ID mode {active passive}
---------	--

	SWITCH(config-if)# no channel-group
Description	Assign the port to a channel group, and specify the mode. For ID, the range is 1 to 12.

Note

- ◆ When the first port is added to the aggregation port, a PO port is actively created, and the default attribute of the PO port is the first port attribute.
- ◆ For Layer 2 Channels:
 - Ports with different native VLANs cannot form an EtherChannel.

● Configuring LACP System Priority

Command	SWITCH(config)# lACP system-priority SYSTEM-PRIORITY SWITCH(config)# no lACP system-priority
Description	The system priority range is 1 to 65535, the default value is 32768. All dynamic link groups of a device can only have one LACP system priority. Modifying this value will affect all aggregation groups on the switch.

● Configuring LACP Interface Priority

Command	SWITCH(config-if)# lACP port-priority PORT-PRIORITY SWITCH(config-if)# no lACP port-priority
Description	The interface priority range is 1 to 65535, the default value is 32768.

● Configuring LACP Timeout Mode

Command	SWITCH(config-if)# lACP timeout {long short} SWITCH(config-if)# no lACP timeout
Description	In long mode, the interval for sending LACP protocol packets is 30S, and the timeout is 90S. In short mode, the interval for sending LACP protocol packets is 1S, and the timeout is 3S. Default is in long mode.

● Configuring Load-balance Method

Command	SWITCH(config)# port-channel load-balance {dst-ip dst-mac dst-port src-dst-ip src-dst-mac src-dst-port src-ip src-mac src-port} SWITCH(config)# no port-channel load-balance
Description	Configure an Channel load-balancing method. The default is src-mac. Select one of these load-distribution methods: <ul style="list-style-type: none"> • dst-ip: Load distribution is based on the destination IP address. • dst-mac: Load distribution is based on the destination MAC address of the incoming packet. • Dist-port: Load distribution is based on the destination L4-port of the incoming packet • src-dst-ip: Load distribution is based on the source-and-destination IP address. • src-dst-mac: Load distribution is based on the source-and-destination MAC address. • src-dst-port: Load distribution is based on the source-and-destination L4-port of the incoming packet. • src-ip: Load distribution is based on the source IP address. • src-mac: Load distribution is based on the source-MAC address of the incoming packet.

5.4. Examples

Example 1: This example shows how to assign the ports to a channel, and set load-balance method.

- Assign the gigabitEthernet0/5, gigabitEthernet0/6 to PO 1, set load-balance to src-ip:

```
SWITCH(config)#interface gigabitEthernet0/5
SWITCH(config-if)#channel-group 1 mode manual
SWITCH(config-if)#exit
SWITCH(config)#interface gigabitEthernet0/6
SWITCH(config-if)#channel-group 1 mode manual
SWITCH(config-if)#exit
SWITCH(config)#port-channel load-balance src-ip
```

5.5. Display information

- Display Channels Configuration and Status

```
SWITCH#show port-channel
Load balance: Source and Destination Mac address
```

```
Interface po3
  Type: static
  Member:
    gigabitEthernet0/18    link down    Disable
```

```
Interface po8
  Type: LACP
  Member:
    gigabitEthernet0/19    link up      Enable
    gigabitEthernet0/17    link up      Enable
```

```
SWITCH#show port-channel 8
Interface po8
  Type: LACP
  Member:
    gigabitEthernet0/19    link up      Enable
    gigabitEthernet0/17    link up      Enable
```

```
SWITCH#show port-channel load-balance
Source and Destination Mac address
```

- Display LACP Summary

```
SWITCH#show lacp summary
% Aggregator po8 1008
% Aggregator Type: Layer2
% Admin Key: 0008 - Oper Key 0008
% Link: gigabitEthernet0/17 (17) sync: 1 status: Bundled
% Link: gigabitEthernet0/19 (19) sync: 1 status: Bundled
```

```
SWITCH#show lacp detail
% Aggregator po8 1008
% Aggregator Type: Layer2
% Mac address: 74:b9:eb:ee:25:46
% Admin Key: 0008 - Oper Key 0008
% Actor LAG ID- 0x8000,74-b9-eb-ee-25-46,0x0008
% Receive link count: 2 - Transmit link count: 2
% Individual: 0 - Ready: 1
% Partner LAG ID- 0x8000,00-01-a0-00-10-10,0x0032
% Link: gigabitEthernet0/17 (17) sync: 1 status: Bundled
% Link: gigabitEthernet0/19 (19) sync: 1 status: Bundled
```

```
SWITCH#show lacp 8
% Aggregator po8 1008 Admin Key: 0008 - Oper Key 0008
% Partner LAG ID: 0x8000,00-01-a0-00-10-10,0x0032
% Partner Oper Key 0050
```

```
SWITCH#show lacp sys-id
% System 8000,74-b9-eb-ee-25-46
```

```
SWITCH#show lacp port gigabitEthernet0/19
% LACP link info: gigabitEthernet0/19 - 19
% LAG ID: 0x8000,74-b9-eb-ee-25-46,0x0008
% Partner oper LAG ID: 0x8000,00-01-a0-00-10-10,0x0032
% Actor Port priority: 0x8000 (32768)
% Admin key: 0x0008 (8) Oper key: 0x0008 (8)
% Physical admin key:(1)
% Receive machine state : Current
% Periodic Transmission machine state : Slow periodic
% Mux machine state : Collecting/Distributing
% Oper state: ACT:1 TIM:0 AGG:1 SYN:1 COL:1 DIS:1 DEF:0 EXP:0
% Partner oper state: ACT:1 TIM:0 AGG:1 SYN:1 COL:1 DIS:1 DEF:0 EXP:0
```

```
% Partner link info: admin port 0
% Partner oper port: 20
% Partner admin LAG ID: 0x0000-00:00:00:00:0000
% Admin state: ACT:1 TIM:0 AGG:1 SYN:0 COL:0 DIS:0 DEF:1 EXP:0
% Partner admin state: ACT:0 TIM:0 AGG:1 SYN:0 COL:0 DIS:0 DEF:1 EXP:0
% Partner system priority - admin:0x0000 - oper:0x8000
% Partner port priority - admin:0x0000 - oper:0x8000
% Aggregator ID: 1008
```


- **Display Only One Channel Information**

```
SWITCH#show int po8
Interface po8
  Hardware is AGG Current HW addr: 74b9.ebee.2546
  Logical:(not set)
  Port Mode is access
  interface configure:
    medium-fiber mtu 1526 speed-auto duplex-auto flowcontrol-off autonego-off
  interface status:
    link-up bandwidth-2g
  Aggregate Members:(LACP)
    gigabitEthernet0/19    link up      Enable
    gigabitEthernet0/17    link up      Enable
  input packets:
    Good Octets Rx         : 18986
    Good Packets Rx        : 104
    Broadcast Packets Rx   : 0
    Multicast Packets Rx   : 104
  ouput packets:
    Good Octets Tx         : 38529
    Good Packets Tx        : 359
    Broadcast Packet Tx    : 4
    Multicast Packet Tx    : 355
  un-normal packets:
    Drop Events            : 0
    Undersized Pkts Recvd  : 0
    Oversized Pkts Recvd  : 0
    Bad CRC                 : 0
```

6. Configuring PoE

6.1. Overview of PoE

Power over Ethernet (PoE) is a technology that transmits both electrical power and network data over an ethernet cable. With PoE, each Ethernet interface of LAN switches can supply power to devices like VoIP phones, IP cameras or security cameras, and wireless access points (AP), As shown in the figure below.



PoE powersupply diagram

The PoE device like LAN switches that are supplying power is called Power Sourcing Equipment (PSE). The power that is supplying is in Direct Current (DC) form.

PoE (Power over Ethernet) Standards:

PoE : IEEE 802.3af standard that supplies up to 15 watts of DC power from PSE and 12.95 watts from PD due to losses on an ethernet cable. It uses two pairs of wires like CAT3 or CAT5 cables as a medium.

PoE+: IEEE 802.3at standard that supplies power up to 30 watts of DC power from PSE and 25.5 watts from PD due to losses on an ethernet cable. It is also using two pairs of wires like CAT5 or higher as a medium.

UPoE(Universal PoE): IEEE 802.3bt standard that supplies power up to 60 watts of DC power from PSE and 51 watts from PD due to losses on an ethernet cable. It uses four pairs of wire as a medium.

UPoE+(Universal PoE +): IEEE 802.3bt standard that supplies power up to 100 watts of DC power from PSE and 71.3 watts from PD due to losses on an ethernet cable. It is also using four pairs of ethernet cabling as a medium.

6.2. Configuring

6.2.1. Enabling Port Powersupply

Command	SWITCH (config-if)# poe enable SWITCH (config-if)# no poe enable
Description	Default port power supply enabled.

6.2.2. Configuring Port Priority

Users can configure the interface power supply priority of the PoE switch. The priority from high to low is: high, medium, and low. When the overall power of the PoE switch is insufficient, the ports with lower priority will be powered off first.

The port priorities of the same priority are arranged in the order of port numbers, and the priority of ports with smaller port numbers is higher. For example, the priority of port gi0/1 is higher than that of port gi0/2. Ports with the same priority and newly inserted ports will not affect the power supply of PDs that are already powered. Ports with different priorities are not affected by this feature, and ports with high priority can preempt ports with low priority.

Command	SWITCH (config-if)# poe priority (low medium high) SWITCH (config-if)# no poe priority
Description	Set port power supply priority. The port default priority is low.

6.2.3. Configuring Port PD Description

Command	SWITCH (config-if)# poe pd-description DESC SWITCH (config-if)# no poe pd-description
Description	Configure the PD description of the interface. The parameter is a string, up to 32 characters supported.

6.2.4. Configuring Port Max Power

Users can limit the maximum output power of the port by configuring the maximum power of the port. When the power supplied of the port exceeds the maximum power value, the port will be powered off and the port state turn to be abnormal.

Command	SWITCH (config-if)# poe max-power VALUE SWITCH (config-if)# no poe max-power
Description	Set the maximum power of the port in watts. For AF/AT ports, the maximum port power range is 1-30. For BT ports, the maximum port power range is 1-90.

6.2.5. Enabling Port Legacy

Command	SWITCH (config-if)# poe legacy SWITCH (config-if)# no poe legacy
Description	Configuring a port to enable and disable compatibility mode. Using this command on a port that is not connected to a PD device may cause the peer device to be powered on and burned by mistake. Please ensure that the port is connected to a PD device when using this command.

6.2.6. Configuring Port Pd-detect Mode

The pd-detect function is to solve the situation that the PD load equipment receives power normally, but the actual work is abnormal. When an abnormal PD load is detected, the port stops external power supply, and the load is powered on again in about 10 seconds. There are two ways of pd-detect

By-flow: Port flow detection. For power supply ports, if there is no data interaction for a long time, the load status is considered abnormal. Specific time user configurable.

By-ping: The device actively sends a ping request. If the load responds normally, the status is considered normal. If there is no response for many times, the load status is considered abnormal.

Command	SWITCH (config-if)# poe pd-detect mode (by-flow by-ping IPADDR) SWITCH (config-if)# no poe pd-detect mode
Description	Configure to enable and disable the port pd-detect function, and configure the detection mode. By-flow: flow-based load detection. By-ping: load detection based on ping requests. IPADD: In by-ping mode, the IP address of the PD load.

- Configuring Port Pd-detect Parameters

After the pd-detect function is enabled on the port, it will detect immediately. Therefore, if the detection interval is configured as 60 seconds and the number of detections is 5 times, the fifth detection will be completed in about 240 seconds.

Command	SWITCH (config-if)# poe pd-detect parameter interval VALUE times VALUE SWITCH (config-if)# no poe pd-detect parameter
Description	Configuring Port PD Self-Detection Parameters. Interval VALUE: detection interval, range 5-60 seconds, default 60 seconds. Times VALUE: detection times, range 3-30 times, default 5 times.

6.2.7. Enabling Port Force On

For some load devices, the power supply is unstable. The forced power supply mode of the port can be configured to maintain the stable power supply of the port to the load.

To configure the port to force power supply, you need to disable the port power supply enablement first.

Command	SWITCH (config-if)# poe force on SWITCH (config-if)# no poe force on
Description	Configure Port Forced Power Supply. The default port force power supply is closed.

6.2.8. Configuring the External Powersupply

Command	SWITCH(config)# poe powersupply POWER SWITCH(config)# no poe powersupply
Description	The default power calculation method: the product of the number of PoE power supply ports and the single port 15.4W. POWER: range 0-999.9, unit W. If the configured power is less than the current device power consumption, power off the PD device on the port with the lower priority, and the port priority is a higher priority with a smaller port ID.

6.2.9. Configuring Reserved Power

Considering that the power consumption of the PD device fluctuates, there is a risk of damage to the device due to the overload of the PoE switch. The switch provides a command to set the reserved power of the PoE system to protect the PoE switch from having power "rich" all the time, and avoid this phenomenon from happening.

Command	SWITCH (config)# poe power-reserved VALUE SWITCH (config)# no poe power-reserved
Description	Set the percentage of reserved power to the total system power, ranging from 0% to 50%. The system's reserved power defaults to 0%.

6.2.10. Configuring Power Alarm Level

When the system power consumption is greater than the alarm waterline power, the system outputs alarm log.

Command	SWITCH (config)# poe power-alarm VALUE SWITCH (config)# no poe power-alarm
Description	Configure the power alarm threshold of the system, the range is 50-99, the unit is percentage, the default is off, not supported.

6.3. Examples

6.3.1. Case For Port Pd-detect

Port gi0/1 is connected to the camera load. If the port does not capture packet traffic within 5 minutes, it is considered that the camera load is working abnormally, and the camera needs to be restarted to return to normal.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#poe enable
SWITCH(config-if)#poe pd-detect mode by-flow
SWITCH(config-if)#poe pd-detect parameter interval 60 times 6
```

6.3.2. Case For Port Force On

Port gi0/1 is connected to the AP load, and the port is powered off at irregular intervals, and then powered on again.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#no poe enable
SWITCH(config-if)#poe force on
```

6.3.3. Case For Port Priority

The system power is insufficient. It is necessary to ensure that the loads of ports gi0/1 and gi0/2 are powered on every time the device is powered off and restarted.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#poe priority high
SWITCH(config-if)#exit
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#poe priority high
```

6.4. Display Information

6.4.1. Display Power Supply Information

```
SWITCH#show poe powersupply
Power supply           : 123.2W
Power reserved         : 0%
Power available:       : 123.2W
Power consume          : 44.1W
Power management      : energy-saving
Temperature             : 45.2 (C)
Powered ports         : 2
Power alarm:           : --
```

The meaning of the displayed information:

Power supply	The total power of the power supply, in W, with one decimal place reserved.
Power reserved	System reserve power percentage.
Power available	The available power of the system, in W, with one decimal place reserved.
Power consume	The actual power consumption of the system, in W, with one decimal place reserved.
Power management	Power management mode, currently only supports energy-saving mode.
Temperature	Temperature of the PoE chip.

Powered ports	Number of power-on ports.
Power alarm	System alarm power percentage.

6.4.2. Display All Port Information

```
SWITCH#show poe interfaces
Interface  enable  status  reason      class  icut (mA)  power (W)
-----
GiE0/1    YES     OFF     short       4      --         --
GiE0/2    YES     OFF     --          -      --         --
GiE0/3    YES     OFF     --          -      --         --
GiE0/4    YES     OFF     --          -      --         --
GiE0/5    YES     OFF     --          -      --         --
GiE0/6    YES     ON      --          4      270.2     14.0
GiE0/7    YES     OFF     --          -      --         --
GiE0/8    YES     OFF     --          -      --         --
```

The meaning of the displayed information:

Interface	Port name, abbreviated.
Enable	Whether the port enables external power supply, YES or NO.
Status	Port power supply status, ON or OFF.
Reason	The reason why the port is not powered on normally: Power management: Insufficient power. unknown: unknown hardware problem.
Class	PD classification registration.
Icut	Current value, unit mA, keep one decimal place.
Power	Power value, unit W, keep one decimal place.

6.4.3. Display Single Port Information

```
SWITCH#show poe interface gigabitEthernet0/1
Description      : --
Enabled          : YES
Status           : ON
Reason:         : --
Class            : 4
Icut             : 260.5
Power            : 14.2
Max-power       : --
Priority         : low
Legacy:         : Disabled
Pd-detect mode  : --
Pd-detect interval : 60
Pd-detect times : 5
```

The meaning of the displayed information

Description	PoE port descriptor information.
Enabled	Whether the port enables external power supply, YES or NO.
Status	Port power supply status, ON or OFF.
Reason	The reason why the port is not powered on normally: Power management: Insufficient power. unknown: unknown hardware problem.
Class	PD classification registration.
Icut	Current value, unit mA, keep one decimal place.
Power	Power value, unit W, keep one decimal place.
Max-power	Port maximum power supply, unit W.
Priority	Port power supply priority, Low, Medium, High.
Legacy	Whether to enable non-standard detection, Enabled, Disabled.
Pd-detect mode	PD self-detection mode, By-flow, By-ping, --. For example: By-ping (192.168.3.4).
Pd-detect interval	PD detection interval.
Pd-detect times	PD detection times.

7. Log Management

7.1. Log Management Overview

During the operation of the device, various status changes will occur, such as link status UP, DOWN, etc., and some events such as processing exceptions will also be encountered.

The syslog provides a series of services. When the status changes or an event occurs, fixed-format messages will be automatically generated, and these messages will be recorded on the device log file. It can be displayed on the console port and remote login terminal, and can also be sent to 1-3 groups of log servers on the network for administrators to analyze network conditions and locate problems.

In order to facilitate administrators to read and manage log messages, these log messages can be classified according to the priority of the log information.

7.2. Configuring

7.2.1. Configure Console Log Level

Command	SWITCH(config)# logging console {<0-7>} SWITCH(config)# no logging console
Description	Configure console log output level Default level is 6 When executing the no command, the log will not be output on the console. Execute logging console, no level parameters, configured as default level 6

7.2.2. Configure Terminal Log Level

- Configure Terminal Log Level

Command	SWITCH(config) # logging monitor {<0-7>} SWITCH(config)# no logging monitor
Description	Configure terminal log output level Default level is 6 When executing the no command, the log will not be output Execute logging monitor, no level parameters, configured to the default level 6

- Enable Terminal Output Log

Command	SWITCH# terminal monitor SWITCH# terminal no monitor
Description	Enable log output on the terminal By default, the terminal does not output log When executing the no command, the terminal does not output log

7.2.3. Configure Remote Server

- Configure Remote Server

Command	SWITCH(config)# logging server {<second third>} {A.B.C.D ipv6 XX::XX } udp-port <1-65535> SWITCH(config)# no logging server {<second third>}
Description	Configure remote server Supports up to 3 remote server configurations Support remote server UDP protocol port configuration, range <1-65535> When no UDP protocol port parameters are configured, the default port number is 514

- Configure the Log Level Sent to the Remote Server

Command	SWITCH(config) # logging trap {<0-7>} SWITCH(config)# no logging trap
Description	Configure the level of logs sent to the server Default level is 6 When executing the no command, no logs will be sent to the server. Execute logging trap , no level parameters, configured as default level 6

- Configure the Rate Limit for Sending Server Logs

Command	SWITCH(config) #logging rate-limit interval <1-30> burst <1-1000> SWITCH(config)# no logging rate-limit
Description	Configure the rate at which the device sends logs to the remote server Interval is the time range, the default is 6, the range is <1-30>, the unit is seconds burst is the maximum number of logs that can be sent within the time range, the default is 60, the range is <1-1000> By default, up to 60 sys logs can be sent to the server every 6 seconds

7.2.4. Configure the Logging Buffer

Command	SWITCH(config) #logging buffer <64-4096> SWITCH(config)# no logging buffer
Description	Configure log storage entries, log storage starts from device startup Default number of storage entries is 1024 The range is <64-4096>

7.2.5. Clear Log

Command	SWITCH# clear logging
Description	Clear syslog

7.3. Examples

Case 1 : The device sent syslog to the remote server, the device IP is 1 92.168.1.240 , the remote server IP is 1 92.168.1.33 ,UDP port number is 10514.

Configure the remote server on the device:

```
SWITCH(config)# logging server 192.168.1.33 udp-port 10514
```

The device generates syslog information:

```
*1970 Jan 01 14:19:34 SWITCH %HAL-4: Interface gigabitEthernet0/1 changed state to down
```

Monitor syslog information on the remote server:

```
LOCAL7.warn: *1970 Jan 1 14:19:34 SWITCH %HAL-4: Interface gigabitEthernet0/1 changed state to down
```

7.4. Display Information

- Display Logs Stored in Device

Command	SWITCH# show logging
Description	Show all syslog stored in device

- Display Logs Stored in Device of Last entries

Command	SWITCH# show logging last <1 4096>
Description	Show last specific number of logs stored in device

- Display Log Configuration Information

Command	SWITCH# show logging summary
Description	Display log configuration information

```
SWITCH#show logging summary
Summary of logging configuration:
  Logging console      : 6
  Logging monitor     : 6
```

```

Logging trap          : 6
Logging buffer       : 1024

Server:
  Ip address         : 192.168.1.33
  Udp port           : 10514

Server second        : Disabled

Server third         : Disabled

Rate-limit:
  Interval           : 1 seconds
  Burst              : 2

```

Field	Illustrate
Logging console	Log console output control <0-7>: Indicates the log level Disabled: Indicates no console output
Logging monitor	Log terminal line output control <0-7>: Indicates the log level Disabled: Indicates that it is not output in terminal line
Logging trap	Log trap remote server output control <0-7>: Indicates the log level Disabled: Indicates not sending to the remote server
Logging buffer	Log storage entries, log storage starts from device startup <64-4096>: Indicate max log storage entries
Server Server second Server third	Server, currently supports 3 servers
Ip address Ipv6 address	Ipv4, ipv6 address information
Udp port	UDP port information
Rate-limit	Speed limit for sending logs to remote server
Interval	Speed limit effective time range
Burst	Speed limit value within interval time

8. Configuring VLAN

8.1. Overview of VLAN

A VLAN is a switched network that is logically segmented by function, project team, or application, without regard to the physical locations of the users. VLANs have the same attributes as physical LANs, but you can group end stations even if they are not physically located on the same LAN segment. Any switch port can belong to a VLAN, and unicast, broadcast, and multicast packets are forwarded and flooded only to end stations in the VLAN. Each VLAN is considered a logical network, and packets destined for stations that do not belong to the VLAN must be forwarded through a router or a switch supporting fallback bridging. The port link types of Ethernet switches can be divided into three types: Access, Trunk, and Hybrid. These three ports will be processed differently when they join VLAN and forward packets.

Access: An access port can belong to one VLAN and is manually assigned to that VLAN.

Trunk: A trunk port is a member of all VLANs by default, but membership can be limited by configuring the allowed-VLAN list. A trunk port have a native vlan, the switch forwards untagged traffic in the native VLAN configured for the port. The native VLAN is VLAN 1 by default.

Hybrid: A hybrid port is a member of all VLANs by default, but membership can be limited by configuring the allowed-VLAN list. A hybrid port allow users to configure traffic of a vlan forwards tagged or untagged. A trunk port has a hybrid vlan, The hybrid VLAN is VLAN 1 by default.

8.2. Configuring

- Creating VLAN

Command	SWITCH(config)#vlan (<vlan-id> <vlan-range>) SWITCH(config)#no vlan (<vlan-id> <vlan-range>)
Description	Create a VLAN, vlan-id 1-4094, vlan-range example: 2-10.

- Configuring the Interface as an Access Port

Command	SWITCH(config)# interface IFNAME SWITCH(config-if)# switchport mode access
Description	Configure the interface port mode access.

Command	SWITCH(config-if)# switchport access vlan VLANID SWITCH(config-if)# no switchport access vlan
Description	Specify the default VLAN of the interface, which is used if the interface is access mode. Default vlan is 1.

- Configuring the Interface as a Trunk Port

Command	SWITCH(config)# interface IFNAME SWITCH(config-if)# switchport mode trunk
Description	Configure the interface port mode trunk.

Command	SWITCH(config-if)# switchport trunk allowed vlan { all VLAN_LIST none } SWITCH(config-if)# no switchport trunk allowed vlan VLAN_LIST
Description	Configure the list of VLANs allowed on the trunk, which is used if the interface is trunk mode. All: Adds all VLANs in available in the VLAN table, New VLANs added to the VLAN table are added automatically. None: Removes all VLANs. VLAN_LIST: It will manually set the Allowed VLAN list, if it belongs to ALL, the Allowed VLAN list will be cleared first, and then the new VLAN list will be added; vlan-list parameter is either a single VLAN number from 1 to 4094 or a range of VLANs described by two VLAN numbers, the lower one first, separated by a hyphen. Do not enter any spaces between comma-separated VLAN parameters or in hyphen-specified ranges. Only created VLANs can be added to the Allowed VLAN list; when a VLAN is deleted, the corresponding VLAN in the Allowed VLAN list will be automatically deleted. All VLANs are allowed by default.

Command	SWITCH(config-if)# switchport trunk native vlan VLANID SWITCH(config-if)# no switchport trunk native vlan
Description	Configure the VLAN that is sending and receiving untagged traffic on the trunk port. For VLANID, the range is 1 to 4094. Native VLAN has nothing to do with whether the Allowed VLAN contains this VLAN, or

	even whether the VLAN is created. Default vlan is 1.
--	---

Note:

◆ The default VLAN ID of the trunk port of the local device must be the same as the default VLAN ID of the trunk port of the connected device, otherwise the packets of the default VLAN will not be transmitted correctly.

- Configure the Interface as a Hybrid Port

Command	SWITCH(config)# interface IFNAME SWITCH(config-if)# switchport mode hybrid
Description	Configure the interface port mode hybrid.

Command	SWITCH(config-if)# switchport hybrid allowed vlan { all VLAN_LIST none} SWITCH(config-if)# no switchport hybrid allowed vlan VLAN_LIST
Description	Configure the list of VLANs allowed on the trunk, which is used if the interface is hybrid mode. All: Adds all VLANs in available in the VLAN table, New VLANs added to the VLAN table are added automatically. None: Removes all VLANs. VLAN_LIST: It will manually set the Allowed VLAN list, If it belongs to ALL , the Allowed VLAN list will be cleared first, and then the new VLAN list will be added; vlan-list parameter is either a single VLAN number from 1 to 4094 or a range of VLANs described by two VLAN numbers, the lower one first, separated by a hyphen. Do not enter any spaces between comma-separated VLAN parameters or in hyphen-specified ranges. Only created VLANs can be added to the Allowed VLAN list; when a VLAN is deleted, the corresponding VLAN in the Allowed VLAN list will be automatically deleted. All VLANs are allowed by default.

Command	SWITCH(config-if)# switchport hybrid vlan VLANID SWITCH(config-if)# no switchport hybrid vlan
Description	Configure the default VLAN that is sending and receiving untagged traffic on the hybrid port. For VLANID, the range is 1 to 4094. Native VLAN has nothing to do with whether the Allowed VLAN contains this VLAN, or even whether the VLAN is created. Default vlan is 1.

Command	SWITCH(config-if)# switchport hybrid untagged vlan VLAN_LIST SWITCH(config-if)# no switchport hybrid untagged vlan VLAN_LIST
Description	Configure the list of untagged VLANs, which is used if the interface is hybrid mode. The default VLAN must be untagged output, therefore, it is not maintained by the untagged VLAN list. By default the untagged VLAN list is empty. The Untagged VLAN list must be in the Allowed VLAN list of the Hybrid port, Therefore, when a VLAN is deleted from the Allowed VLAN, it will also be deleted from the Untagged VLAN list. Since the untagged VLAN list does not maintain the default VLAN, if a VLAN in the previous list is set as the default VLAN, it will be deleted from the untagged VLAN list.

Note

◆ The default VLAN ID of the hybrid port of the local device must be the same as the default VLAN ID of the hybrid port of the connected device, otherwise the packets of the default VLAN will not be transmitted correctly.

8.3. Display Information

Displays the VLAN table, includes VLAN VID, VLAN status, VLAN member ports, and VLAN configuration information.

- Display VLAN Information

VLAN ID	Name	State	H/W Status	Member ports
				(u)-Untagged, (t)-Tagged
=====				
1	default	ACTIVE	Up	gigabitEthernet0/2(u) gigabitEthernet0/3(u)

9. Configuring QINQ

9.1. Overview of QINQ

QINQ technology also known as Stacked VLAN. The standard is derived from IEEE 802.1ad, which means that the public network VLAN Tag of a service provider network is encapsulated before the user packet enters the service provider network, and the private network user VLAN Tag in the user packet is regarded as data, so that the packet carries Two-layer VLAN tag traversal of service provider network.

In the metropolitan area network, a large number of VLANs are required to isolate users. The 4094 VLANs supported by the IEEE 802.1Q protocol are far from meeting the requirements. Through the double-layer Tag encapsulation of QINQ technology, in the service provider network, the packets are only transmitted according to the unique outer VLAN Tag allocated on the public network, so that the VLANs of different private network users can be reused, and the number of VLAN tags available to users is expanded. At the same time, it provides a simple Layer 2 VPN function, so QINQ technology is actually a VLAN VPN technology.

In addition to QINQ, common VLAN VPN technologies also include VLAN Mapping. The only difference between the two is that QINQ is for stacking VLANs, and VLAN Mapping is for VLAN mapping.

9.1.1. VLAN Stacking

VLAN Stacking: From the user network to the provider network, a single-layer tag becomes a double-layer tag, and the C-Tag remains in the packet as an inner-layer tag; reverse, from a double-layer tag to a single-layer tag.

VLAN Stacking QINQ is divided into three categories:

- Type A: Basic QINQ, which is enabled and disabled based on the interface. When an interface with basic QINQ enabled receives a packet, it is treated as an un-tagged packet. On the basis of the original packet, a VLAN tag of the default VLAN of the port is added.
- Type B: Flexible QINQ based on C-tag, according to the C-VLAN Tag on the user side, according to the configured mapping policy, an S-VLAN tag is added to the original packet. There are two optional configuration methods for this type of QINQ, and only one of them can be selected. One way is to configure the mapping relationship between C-VLAN and S-VLAN directly on the interface; the other way is to configure VLAN VPN globally (which includes the mapping relationship between C-VLAN and S-VLAN), and then associate the VPN on the interface. When using the same mapping policy for multiple interfaces, generally choose the latter configuration method. For this type of QINQ, if the packets received by the interface are un-tagged, the C-tag is the default VLAN Tag of the interface.
- Class C: ACL-based flexible QINQ, adding outer tags according to the configured traffic policy. The configuration of this type of QINQ is placed in the "QOS" module. For details, please refer to the "Configuring QOS" chapter. The policy pair between Policy-map and Class-map: "nest vlan <1-4094>" is used to configure ACL-based Flexible QINQ.

The above three types of QINQ can be enabled at the same time on the same port, and their priority relationship is: Type C > Type B > Type A.

9.1.2. VLAN Mapping

VLAN Mapping: From the user network to the provider network, it is still a single-layer Tag, but the C-Tag becomes S-Tag; in reverse, from S-Tag to C-Tag.

VLAN Mapping is divided into 1:1 VLAN Mapping and 1:N VLAN Mapping (the reverse is N:1). Currently, only 1:1 VLAN Mapping is supported. VLAN Mapping is configured by configuring VLAN VPN globally, and then associating VPN on interface. VLAN Mapping only takes effect on tag packets, which is very different from the QINQ function.

The following points should be noted when configuring QINQ and VLAN Mapping.

VLAN Mapping takes effect only for tagged packets. Upstream, original packets must carry tags to implement CVLAN-to-SVLAN mapping; for downstream, the VLAN output rule on downlink interfaces must be tag output to implement SVLAN-to-SVLAN mapping. Mapping of CVLANs.

Note

Only physical interfaces support the configuration of QINQ and VLAN Mapping, but aggregated interfaces do not

When using the QINQ function or the VLAN Mapping function, it needs to be used in conjunction with the VLAN configuration. In the input and output directions, the filtering function of the VLAN, and the rules for whether the VLAN carries tags are all subject to the VLAN configuration. Specific requirements are as follows:

- Both CVLAN and SVLAN need to be added to the allow list of the downlink interface (connected to the Customer network), otherwise the flow will be filtered.
- The SVLAN needs to be added to the allow list of the uplink interface (connected to the provider network), otherwise the flow will be filtered.
- For QINQ, on the downlink interface, SVLAN should be configured with untag output, so as to strip the outer tag of QINQ downstream.
- For VLAN-Map, since it only takes effect for untag packets, for downlink interfaces, SVLAN should be configured with tag output, otherwise the downstream flow cannot complete the mapping from SVLAN to CVLAN.

The globally configured VLAN VPN is either used for VLAN Stacking (QINQ) or VLAN Mapping, but not

both.

VLAN Mapping only supports 1:1 mapping. Therefore, if there are VLAN VPNs with N:1 mapping, they cannot be associated with the interface as the VPN of VLAN mapping. Similarly, if the VPN has been associated with the interface as the VLAN mapping, the mapping relationship cannot change to N:1.

The mapping relationship of VLAN Mapping must be consistent globally. Therefore, different interfaces can only be associated with the same VLAN VPN.

On the same interface, if you need to apply VLAN Mapping and QINQ at the same time, it should be noted that the two functions need to control different CVLANs and SVLANs. The specific constraints are as follows.

- If VLAN Mapping is used together with basic QINQ, the basic QINQ will take effect and VLAN Mapping will be invalid.
- If VLAN Mapping and flexible QINQ are used together, if a flow passes through the SVLAN mapped by VLAN Mapping and can be used as CVLAN to match the mapping policy of flexible QINQ, the final packet will take effect with flexible QINQ, adding SVLAN as external Layer TAG, the inner layer TAG remains unchanged (not the VLAN mapped by VLAN Mapping).
- Due to the above constraints, when two applications are enabled on the same interface, it is necessary to pay attention that the VLANs controlled by the two do not overlap. Invalid.

For Type B QINQs, you can either choose to configure the mapping policy directly under the interface, or choose to associate with VPN, but cannot be configured at the same time.

9.2. Configuring

- Creating VLAN VPN

Command	SWITCH(config)# vlan-vpn VPN-NAME SWITCH(config)# no vlan-vpn VPN-NAME
Description	There can be multiple VPNs in the system, and each VPN maintains the mapping relationship between independent CVLANs and SVLANs. A VPN will only actually take effect when applied to an interface. A VPN can be applied to VLAN Stacking (QINQ) or VLAN Mapping, but only one of the two can be selected.

- Adding VPN Mapping Relations

Command	SWITCH(config-vlan-vpn)# cvlan VLAN_LIST svlan VLANID SWITCH(config-vlan-vpn)# no cvlan VLAN_LIST SWITCH(config-vlan-vpn)# no cvlan
Description	The valid range of VLAN_LIST and VLANID is <1,4094>, VLAN_LIST supports standard multi-vlan representation method ("-" and "," and combination of both). no cvlan without any parameters, clear all the mapping relationships in the VPN.

- Configuring Port-based QINQ

Command	SWITCH(config-if)# switchport vlan-stacking basic SWITCH(config-if)# no switchport vlan-stacking basic
Description	After basic QINQ is enabled, all incoming packets from this interface match the QINQ rules, and the mapped SVLAN is the default VLAN ID of the interface.

- Configuring Mapping Relationship of QINQ on the interface

Command	SWITCH(config-if)# switchport vlan-stacking cvlan VLAN_LIST svlan VLANID SWITCH(config-if)# no switchport vlan-stacking cvlan VLAN_LIST SWITCH(config-if)# no switchport vlan-stacking cvlan
Description	Similar to the mapping relationship configuration under VPN. Only when the interface is not associated with a VPN, can the mapping relationship be configured directly.

- Attaching QINQ VPN on the Interface

Command	SWITCH(config-if)# switchport vlan-stacking vpn VPN-NAME SWITCH(config-if)# no switchport vlan-stacking vpn
Description	An interface can only be associated with one VPN. The VPN association configuration can be performed only when the interface is not configured with a mapping relationship.

- Clearing QINQ Configuration on the Interface

Command	SWITCH(config-if)# no switchport vlan-stacking
Description	Equivalent to three commands: no switchport vlan-stacking basic no switchport vlan-stacking cvlan no switchport vlan-stacking vpn

- Attaching VLAN Mapping VPN on the Interface

Command	SWITCH(config-if)# switchport vlan-mapping vpn VPN-NAME SWITCH(config-if)# no switchport vlan-mapping
Description	VLAN mapping configured on different interfaces must be associated with the same VPN. And the mapping relationship in the corresponding VPN must be 1:1.

9.3. Examples

Example 1: This example shows how to configure L2 VPN service.

Service Provider provides VPN for Enterprise A and Enterprise B:

- Enterprise A and enterprise B belong to different VLANs on the public network, and communicate through their own public network VLANs.
- The VLANs in enterprise A and enterprise B are transparent to the public network, and the user VLANs in enterprise A and enterprise B can be reused without conflict.
- Tunnel encapsulates a layer of VLAN Tag of Native VLAN to user data packets. In the public network, user data packets are transmitted in the native VLAN, which does not affect the use of VLANs in different enterprise user networks, and implements a simple Layer 2 VPN.




Illustration:

- Customer A1, Customer A2, Customer B1 and Customer B2 are the edge devices of the network where enterprise user A and enterprise user B are located, respectively. Provider A and Provider B are edge devices of the service provider network, and enterprise A and enterprise B access the public network through the edge devices of the provider.
- The VLAN range of the office network used by enterprise A is VLAN 1-100.
- The VLAN range of the office network used by enterprise B is VLAN 1-200.

ProviderA and ProviderB are completely symmetrical and have exactly the same configuration:

- Configuring VLAN

```
SWITCH(config)#vlan 2-200
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 1-100
SWITCH(config-if)#switchport trunk native vlan 10
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk native vlan 10
SWITCH(config-if)#interface gigabitEthernet0/5
SWITCH(config-if)#switchport mode trunk
```

- Configuring Base QINQ

```
SWITCH(config)#interface gigabitEthernet0/1-2
SWITCH(config-if)#switchport vlan-stacking basic
SWITCH(config-if)#exit
```

Example 2: This example shows how to Implement Layer 2 VPN and service flow management based on Flexible QINQ.

Basic QinQ can only encapsulate user data packets in the outer tag of a native VLAN, that is, the encapsulation of the outer tag depends on the native VLAN of the tunnel port. Flexible QinQ provides flexible encapsulation of external tags (S-Tags) of service providers (ISPs) according to the tags of user packets (ie C-Tags), so as to flexibly implement VPN transparent transmission and service flow QoS policies.

- Broadband Internet access and IPTV services are an important part of the services carried by the MAN. The MAN service provider network divides VLANs for different service flows to differentiate management, and provides QoS policy settings for these VLANs. You can use QinQ based on C-Tag on the edge device of the service provider to encapsulate the relevant VLAN of the user's business flow, and use the QoS policy of the service provider network for guaranteed transmission while transparent transmission.
- Unified VLAN planning is implemented between enterprise branches, and important services and general services are in different VLAN ranges. The enterprise network can use the flexible QinQ based on C-Tag to transparently transmit the internal services of the company, and can also use the

service provider network. The QoS strategy of the company gives priority to ensuring the data transmission of important services.

As shown in the figure below, the client devices in the metropolitan area network are aggregated through the corridor switches in the community, and broadband Internet access and IPTV services are differentiated by assigning different VLANs to enjoy different QoS service policies.

- In the public network, different service flows of broadband Internet access and IPTV are transmitted in different VLANs to realize transparent transmission of user services.
- The ISP network sets the QoS policy for VLAN, and the corresponding VLAN can be encapsulated for the user service on the edge device of the service provider, so that the IPTV service is transmitted preferentially in the ISP network.




Illustration:

- CE1 and CE2 are edge devices that connect to the user's network, and PE1 and PE2 are edge devices that the provider serves on the network.
- VLAN 1-100 and VLAN 101-200 on CE1 and CE2 devices are the broadband Internet service flow for users, and the IPTV service flow for users.
- PE1 and PE2 devices package different s-tags for vlans of different businesses to distinguish different business data. VLAN 1-100 package VLAN100, vlan101-200 package VLAN200.

PE1 and PE2 are configured exactly the same:

- Configuring VLAN

```

SWITCH(config)#vlan 2-200
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#switchport mode hybrid
SWITCH(config-if)#switchport hybrid untagged vlan 100,200
SWITCH(config-if)#switchport hybrid vlan 100
SWITCH(config-if)#interface gigabitEthernet0/2
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#exit
  
```

- Configuring Flexible QINQ

```

SWITCH(config)#vlan-vpn isp
SWITCH(config-vlan-vpn)# cvlan 1-100 svlan 100
SWITCH(config-vlan-vpn)# cvlan101-200 svlan 200
SWITCH(config-vlan-vpn)# interface gigabitEthernet0/1
SWITCH(config-if)#switchport vlan-stacking vpn isp
SWITCH(config-if)#exit
  
```

Example 3: This example shows how to Implement Layer 2 VPN and service flow management based on VLAN Mapping.

Similar to Case 2, the broadband Internet access service and the IPTV service of the user are distinguished. For example, the broadband Internet access service is VLAN2, and the IPTV service is VLAN3. In the ISP network, VLAN200 and VLAN300 are respectively used to represent broadband Internet access services and IPTV services. All ports 1-10 of the PE device are connected to the CE device, and the uplink interface is gigabitEthernet0/11.

PE1 and PE2 are configured exactly the same:

- Configuring VLAN

```

SWITCH(config)#vlan2-3,200,300
SWITCH(config)#interface gigabitEthernet0/1-10
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#interface gigabitEthernet0/11
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#exit
  
```

- Configuring VLAN Mapping

```

SWITCH(config)#vlan-vpn isp-map
SWITCH(config-vlan-vpn)#cvlan 2 svlan 200
SWITCH(config-vlan-vpn)#cvlan 3 svlan 300
SWITCH(config-vlan-vpn)#interface gigabitEthernet0/1-10
  
```

```
SWITCH(config-if)#switchport vlan-mapping vpn isp-map
SWITCH(config-if)#exit
```

9.4. Display Information

- Display a VPN Information

```
SWITCH#show vlan-vpn test
-----
VLAN VPN: test
Class: vlan-stacking
Mapping attributes:
  cvlan 1-25,73,75-80 svlan 3
  cvlan 200 svlan 4
Applied interfaces:
  gigabitEthernet0/17
  gigabitEthernet0/18
```

- 2) Display all VPN Information

```
SWITCH#show vlan-vpn
-----
VLAN VPN: test
Class: vlan-stacking
Mapping attributes:
  cvlan 1-25,73,75-80 svlan 3
  cvlan 200 svlan 4
Applied interfaces:
  gigabitEthernet0/17
  gigabitEthernet0/18
-----
VLAN VPN: test-map1
Class: vlan-mapping
Mapping attributes:
  cvlan 100 svlan 1
  cvlan 200 svlan 2
  cvlan 800 svlan 8
  cvlan 900 svlan 9
Applied interfaces:
  gigabitEthernet0/18
  gigabitEthernet0/19
-----
VLAN VPN: test1
Class: unkown
Mapping attributes:
  cvlan 800 svlan 8
  cvlan 900 svlan 9
Applied interfaces:
  empty!
```


10. Configuring ERPS

10.1. Overview of ERPS

ERPS (Ethernet Ring Protection Switching) was developed by ITU, also known as G.8032. It is a link layer protocol specifically applied to Ethernet. It can prevent the broadcast storm caused by the data loop when the Ethernet ring network is complete, and can quickly restore the communication between each node on the ring network when a link on the Ethernet ring is disconnected.

At present, the technology to solve the Layer 2 network loop problem is STP. STP is more mature to use, but its convergence time is longer (seconds). ERPS is a link layer protocol that is specially applied to Ethernet and has a faster rate than STP for convergence, up to 50ms.

ERPS typical scenario:




10.2. Introduction to ERPS Rationale

ERPS is a standard ring network protocol dedicated to the Ethernet link layer, with the ERPS ring as the basic unit. Only two ports on each layer 2 switch can be added to the same ERPS ring. In the ERPS, in order to prevent network loop, a break-down mechanism can be launched, blocking the RPL owner port and eliminating the ring route. When the ring connection fails, the equipment running the ERPS protocol can quickly forward the blocked port, make the link protection replacement, and restore link communication between various nodes on the ring network. This section mainly presents the rationale for the implementation of ERPS under the basic network based on the normal ->link failure->link recovery process (including protection switch operations).

Link OK


As shown in the diagram below, the equipment on the ring consisting of SwitchA~SwitchE is in good condition.

To prevent loops, ERPS first blocks the RPL owner port. If the RPL neighbor port is configured, the port will also be blocked, and other ports can forward traffic normally.



Link Failure

As shown in the diagram, when the link between SwitchD and SwitchE fails, the ERPS protocol starts the protection switching mechanism, blocks the ports on both ends of the faulty link, and then forward the RPL owner port, and the two ports resume user traffic. receiving and sending, thus ensuring uninterrupted traffic.



Link Restore

After the link returns to normal, if the ERPS ring is configured in revert mode, the device where the RPL owner port resides will block the traffic on the RPL link again, and the faulty link will be used again to transmit user traffic.

10.3. Configuring

- Creating Ring

Command	SWITCH(config)# erps ring <1-255> east-interface IFNAME west-interface IFNAME SWITCH(config)# no erps ring <1-255>
Description	Create/delete ERPS ring. The ERPS ring is made up of the same set of VLAN and interconnected layer 2 switch, which is the basic unit of the ERPS protocol and needs to be configured on each device in the ring. The ring number is the unique identifier for the ERPS ring.

- Creating ERPS Instance

Command	SWITCH(config)# erps instance NAME SWITCH(config)# no erps instance NAME
Description	Create/remove ERPS instances; Create an instance to go into instance configuration mode. For the layer 2 switch operating an ERPS protocol, VLAN transmitting ERPS and data articles must be mapped into a protective instance so that ERPS protocol can be forwarded or blocked in accordance with their blocking principles. Otherwise, user traffic could cause broadcast storms in a ring network that could make the network unavailable.

- Associating ERPS Instances and Rings

Command	SWITCH(config-erps-inst)# ring <1-255>
Description	Configure the corresponding relationships between ERPS instances and rings.

- Configuring ERPS Instance Level

Command	SWITCH(config-erps-inst)# level <0-7>
Description	Configure ERPS instance level.

- Configuring RPL Roles in ERPS Instance

Command	SWITCH(config-erps-inst)# rpl-role NAME
Description	Configure the ERPS instance RPL role; An ERPS ring has only one RPL owner port, which is determined by user configuration. The RPL owner port is blocked from forwarding user traffic to prevent loops in the ERPS ring.

- Configuring Raps VLAN for Instance

Command	SWITCH(config-erps-inst)# vlan <1-4094> raps-channel SWITCH(config-erps-inst)# no raps-channel
Description	Configuration/delete raps VLAN for ERPS instances; Each ERPS ring must be configured with a raps VLAN. Different ERPS rings cannot use the same raps VLAN ID.

- Configuring MST Instance

Command	SWITCH(config-erps-inst)# protected-mst-instance <0-255>
Description	Configure MST Instance; The relationship between VLAN and Instance can be configured in MST mode, after STP mode be set to MSTP, refer to STP configuration for more details; by default, all VLANs belong to Instance 0; the default value is 0. Note: Multi-instance is currently not supported in intersecting rings!

- Configuring Intersecting Sub-ring Block Port

Command	SWITCH(config-erps-inst)# sub-ring block (east-interface west-interface)
Description	Configure the ERPS instance as a sub-ring instance and specify a sub-ring block port.

- Configuring Sub-ring Virtual Channels and Non-virtual Channels

Command	SWITCH(config-erps-inst)# virtual-channel attached-to-instance NAME SWITCH(config-erps-inst)# non-virtual-channel
---------	--

Description	Configure the type of ERPS intersecting sub-ring: virtual channel and associated main ring; or non-virtual channel type. Note: The position displayed by this command in show running-config must be after the displayed position of the associated instance. Normally only need to ensure that the sub-ring ID and instance name are larger than the main ring ID and instance name.
-------------	--

- Configuring ERPS Revert Mode

Command	SWITCH(config-erps-inst)# revertive non-revertive
Description	Configure ERPS revertive/non-revertive.

- Configuring ERPS Timer Parameters


Command	SWITCH(config-erps-inst)# (wtr-timer (<1-12> default) holdoff-timer (<0-100> default) guard-timer (<1-200> default))
Description	Configure ERPS timer parameters. <1-12>: in minutes; revert time after recovery, default is 5 minutes. <0-100>: in 100 milliseconds; hold time before port forwarding, the default is 0, direct forwarding without delay. <1-200>: in 10 milliseconds; protection window when state changes, avoid receiving messages from previous state leading to protocol errors, default is 50: 500 ms. guard-timer parameters limit network size. It is conservatively recommended that when there are more than 300 nodes in the ring network, directly configure this parameter to the maximum value to avoid the failure of old packets to be discarded due to the large network size; no special configuration is required for nodes within 300 nodes.

- Configuring ERPS Logging

Command	SWITCH(config)# erps logging SWITCH(config)# no erps logging
Description	Configure ERPS logging.

10.4. Examples

1. Single-ring case requirements: As shown in the figure, the configuration blocks the direct links of S1 and S2 by default, and restores the link in time to ensure the availability of the network in case of failure. Where the data VLANs are 1, 2 and 3.



S1/S2:

- Enter global configuration mode, create ERPS and set related parameters, command reference list

below:

Create vlan 2,3;vlan 1 default exists

```
SWITCH(config)#vlan 2,3
```

Change the interface mode to trunk. By default, trunk mode will add all data vlans and management vlans to the interface for forwarding.

```
SWITCH(config)#interface gigabitEthernet0/9-10
```

```
SWITCH(config-if)#switchport mode trunk
```

Create ERPS ring 1

```
SWITCH(config)#erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
```

Create ERPS instance 1, associated with ring 1, and associated details configuration

```
SWITCH(config)#erps instance 1
```

```
SWITCH(config-erps-inst)#ring 1
```

```
SWITCH(config-erps-inst)#rpl-role non-owner
```

```
SWITCH(config-erps-inst)#vlan 1000 raps-channel
```

S3:


- Enter global configuration mode, create ERPS and set related parameters, command reference list

below:

```
SWITCH(config)#Vlan 2,3
SWITCH(config)#interface gigabitEthernet0/9,gigabitEthernet0/10
SWITCH(config-if)#switchport mode trunk
SWITCH(config)#Erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
SWITCH(config)#Erps instance 1
SWITCH(config-erps-inst)#ring 1
SWITCH(config-erps-inst)#rpl-role owner east
SWITCH(config-erps-inst)#vlan 1000 raps-channel
```

2. Intersection ring case requirements

As shown in the following topology, S1, S2, S3, and S4 form intersecting rings, and the data vlans are 1, 2, 3, and 4. It is required to achieve fast convergence when a single point of failure occurs in each ring; a maximum of two faults can occur in the network Points (different rings), without user disconnection, to achieve optimal reliability.



Typical configuration examples:

S1:

```
Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 1
  ring 1
  vlan 1000 raps-channel

Erps ring 2 east gigabitEthernet0/9 west gigabitEthernet0/11
Erps instance 2
  ring 2
  sub-ring block east-interface
  vlan 1100 raps-channel
  virtual-channel attached-to-instance 1
```

S2:

```
Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 1
  ring 1
  vlan 1000 raps-channel
```

```
Erps ring 2 east gigabitEthernet0/12 west gigabitEthernet0/10
Erps instance 2
ring 2
sub-ring block west-interface
vlan 1100 raps-channel
virtual-channel attached-to-instance 1
```

S3:

```
Vlan 2,3,4
interface gigabitEthernet0/5-6
switchport mode trunk
Erps ring 1 east gigabitEthernet0/5 west gigabitEthernet0/6
Erps instance 1
ring 1
rpl-role owner east
vlan 1000 raps-channel
```


S4:

```
Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 2 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 2
ring 2
rpl-role owner east
vlan 1100 raps-channel
```

3. Tangent ring case requirements

The topology diagram is shown below. S1 is located in the central computer room, which can be supervised and maintained by the administrator in real time, and has high reliability; S2-S5 are distributed in various deployment points, in order to improve the reliability of the network and avoid the occurrence of single-link external connection. The single-point failure risk is avoided, and the single-machine failure risk that may occur in a dual-link external connection is avoided, and the dual-link external connection is used to form a ring network.

It is required that each ring network can converge quickly when a single point of failure occurs to avoid user network interruption.



Typical configuration examples:

S1:

```
Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 1
ring 1
vlan 1000 raps-channel

Erps ring 2 east gigabitEthernet0/11 west gigabitEthernet0/12
Erps instance 2
ring 2
```

```
vlan 1100 raps-channel
```

S2:

```
Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 1 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 1
  ring 1
  rpl-role owner east
vlan 1000 raps-channel
```

S3:

```
Vlan 2,3,4
interface gigabitEthernet0/5-6
switchport mode trunk
Erps ring 1 east gigabitEthernet0/5 west gigabitEthernet0/6
Erps instance 1
  ring 1
vlan 1000 raps-channel
```

S4:

```
Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 2 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 2
  ring 2
  rpl-role owner east
  rpl-role owner east
```

S5:

```
Vlan 2,3,4
interface gigabitEthernet0/9-12
switchport mode trunk
Erps ring 2 east gigabitEthernet0/9 west gigabitEthernet0/10
Erps instance 2
  ring 2
vlan 1100 raps-channel
```

10.5. Display Information

- Show ERPS Ring Information

```
SWITCH#show erps ring 1

Ring      : 1
=====
Bridge    : 1
East      : gigabitEthernet0/23
West      : gigabitEthernet0/24
ERP Inst :1, 2,
SWITCH#
```

- Show ERPS Instances

```
SWITCH#
SWITCH#show erps instance 1
Name      : 1
Protected MST Instance: 0
Protected VLANs      : 1
State      : ERPS_ST_IDLE
Last Priority      : RAPS-NR-RB
Phy Ring      : 1
Role         : NON-OWNER
East Link      : Link_Unblocked(up) (78-A9-12-12-13-12, 1)
West Link      : Link_Unblocked(up) (78-A9-12-12-13-12, 1)
TCN Propagation : Disabled
Attached      : -
```

Attached To : -
Virtual ID : -:-

```
-----  
      Channel      |      Interface  
(LEVL, VID, RID) | (east,ver) , (west,ver)  
=====
```

(0, 1000, 1)		(gigabitEthernet0/23, V=1), (gigabitEthernet0/24, V=1)
--------------	--	--

```
=====
```

Wait-To-Restore : 5 mins
Hold Off Timer : 0 secs
Guard Timer : 500 ms
Wait-To-Block : 5500 ms
Protection Type : Revertive
SWITCH#

11. Configuring IGMP Snooping


11.1. Overview of IGMP Snooping

IGMP Snooping is a short term for Internet Group Management Protocol Snooping, a mechanism running on a layer 2 device for managing and controlling multicast groups.


A Layer 2 device running IGMP Snooping analyzes the received IGMP packets, establishes a mapping relationship between ports and MAC multicast addresses, and forwards multicast data according to the mapping relationship. When the Layer 2 device does not run IGMP Snooping, the multicast data is broadcast at Layer 2; when the Layer 2 device runs IGMP Snooping, the multicast data of the known multicast group will not be broadcast at Layer 2, but at Layer 2.

As shown in the figure below, when the Layer 2 multicast device does not run IGMP Snooping, the IP multicast packets are broadcast in the VLAN; when the Layer 2 multicast device runs IGMP Snooping, the IP multicast packets are only sent to the group members recipient.

Multicast transmission process without IGMP Snooping enabled



Multicast transmission process with IGMP Snooping enabled



11.2. Configuring

● Enabling IGMP Snooping

Command	SWITCH(config)# igmp snooping SWITCH(config)# no igmp snooping
Description	Enable/disable IGMP Snooping function; disabled by default. Global configuration mode.

● Configuring IGMP Snooping Upstream Ports

Command	SWITCH(config-if)# igmp snooping mrouter interface IFNAME SWITCH(config-if)# no igmp snooping mrouter interface IFNAME
Description	Configure/delete IGMP Snooping upstream port; optional configuration. SVI interface mode.

● Configuring IGMP Snooping Static Groups

Command	SWITCH(config-if)# igmp snooping static-group IPADDR source IPADDR interface IFNAME SWITCH(config-if)# no igmp snooping static-group IPADDR source IPADDR interface IFNAME
Description	Configure/delete IGMP Snooping static group; optional configuration. SVI interface mode.


● Configuring IGMP Snooping Fast Leave

Command	SWITCH(config-if)# igmp snooping fast-leave SWITCH(config-if)# no igmp snooping fast-leave
---------	---

Description	Configure/delete IGMP Snooping fast leave function; optional configuration. SVI interface mode.
-------------	---

11.3. Examples

Simplified topology:



Basic configuration /roles: (top down)

server:

During the test, VLC is used as the multicast server to provide the multicast service: udp://225.0.0.1:1234, the server IP is 3.3.3.10

router:

Run the multicast routing protocol and enable IGMP, and use Ruijie S57 Layer 3 switch to simulate the test. The main configurations are as follows:

Enable multicast routing

```
ip multicast-routing
```

Configure the uplink port, connect to the server, here is simply to select the PIM dense mode, the actual network scale is large, and the multicast use is less, it is recommended to use the sparse mode

```
interface GigabitEthernet 0/23
no switchport
no ip proxy-arp
ip pim dense-mode
ip address 3.3.3.3 255.255.255.0
```

Configure the downlink port. The PIM dense mode is simply selected here. The actual network scale is large and the multicast usage is small. It is recommended to use the sparse mode

```
interface VLAN 1
no ip proxy-arp
ip pim dense-mode
ip address 2.2.2.1 255.255.255.0
```

SWITCH:

Multicast can be enabled

```
igmp snooping
```

Client:

Watch server multicast video through udp://225.0.0.1:1234, IP 2.2.2.10

11.4. Display Information

- View IGMP Snooping Multicast Groups

```
SWITCH#show igmp snooping groups
```

- Viewing IGMP Snooping Interface Information

```
SWITCH#show igmp snooping interface {ifname}
```

Example:

```
IGMP Snooping information for vlan1
IGMP Snooping enabled
Snooping Querier none
IGMP Snooping other querier timeout is 255 seconds
Group Membership interval is 260 seconds
IGMPv2 fast-leave is disabled
IGMPv1/v2 Report suppression enabled
IGMPv3 Report suppression enabled
Router port detection using IGMP Queries
Number of router-ports: 2
Number of Groups: 2
Number of Joins: 891
```

```
Number of Leaves: 4
Active Ports:
  gigabitEthernet0/1
  gigabitEthernet0/2
```

- **Viewing IGMP Snooping Routing Port Information**

```
SWITCH#show igmp snooping mrouter vlan1
Example:
SWITCH#show igmp snooping mrouter vlan1
VLAN Interface IP-address Expires
1 gigabitEthernet0/18(dynamic) 2.2.2.1 00:03:34
  gigabitEthernet0/20(static) -- --
```

- **Viewing IGMP Snooping Interface Statistics**

```
SWITCH#show igmp snooping statistics interface vlan1
IGMP Snooping statistics for vlan1
Group Count : 2
IGMP reports received : 893
IGMP leaves received : 4
IGMPv1 query warnings : 0
IGMPv2 query warnings : 456
IGMPv3 query warnings : 0
```

12. Configuring Spanning Tree Protocol

12.1. Overview of Spanning Tree Protocol

Spanning Tree Protocol is a Layer 2 management protocol that eliminates Layer 2 loops by selectively blocking redundant links in the network, and also has the function of link backup.

Like the development process of many protocols, the Spanning Tree Protocol is constantly updated with the development of the network, from the original STP (Spanning Tree Protocol, Spanning Tree Protocol) to RSTP (Rapid Spanning Tree Protocol, Rapid Spanning Tree Protocol), to the latest MSTP (Multiple Spanning Tree Protocol).

Comparison of three spanning tree protocols:

Spanning Tree Protocol	Features	Application Scenario
STP	Form a loop-free tree, resolve broadcast storms and implement redundant backup. Slow convergence.	There is no need to distinguish user or service traffic, all VLANs share a spanning tree.
RSTP	Form a loop-free tree, resolve broadcast storms and implement redundant backup. Convergence is fast.	
MSTP	Form a loop-free tree, resolve broadcast storms and implement redundant backup. Convergence is fast. Multiple spanning trees implement load balancing among VLANs, and traffic of different VLANs is forwarded according to different paths.	It is necessary to distinguish user or service traffic and implement load balancing. Different VLANs forward traffic through different spanning trees, and each spanning tree is independent of each other.

12.1.1. STP

12.1.1.1. Requirement Background

STP is a protocol for eliminating loops in local area networks. Devices running this protocol discover loops in the network by exchanging information with each other, and appropriately block certain ports to eliminate loops. Due to the continuous growth of LAN scale, Spanning Tree Protocol has become one of the most important LAN protocols.




Figure2- 1 Schematic diagram of typical local area network

In the network shown in Figure2- 1, the following two situations will occur:

1. Network unavailable due to broadcast storm.

The loop generates a broadcast storm, which can make the network unavailable. Assume that the STP protocol is not enabled on the switch device. If ServerA sends a broadcast request, then the broadcast packet will be received by the port port1 of the other two switching devices, and broadcast from the port port2 respectively, and then the port port2 will receive another switching device. The broadcast packets are forwarded from the ports port1 of the two switching devices respectively. Repeatedly, the entire network resources will be exhausted and the network will be paralyzed and unavailable.

2. MAC address table flapping caused MAC address table entries to be destroyed.

Even unicast packets may cause confusion in the MAC address table entries of the switching device, thus destroying the MAC address table of the switching device.

Assuming that there is no broadcast storm in the network shown, ServerA sends a unicast packet to ServerB. If ServerB is temporarily removed from the network at this time, then the MAC address entry about ServerB on the switching device will also be changed. been deleted. At this time, the unicast packet sent by ServerA to ServerB will be received by port 1 of switching device S1. Since there is no corresponding MAC address forwarding entry on S1, the unicast packet will be forwarded to port 2. Then the port port2 of the switching device S2 receives the unicast message sent from the peer port2 port, and then sends it out from port1. At the same time, the port port1 of the switching device S2 will also receive the unicast message sent by ServerA to ServerB, and then send it out from port2. So repeatedly, on the two switching devices, since the unicast packets from host A are continuously received from ports port1

and port2, the switching device will constantly modify its own MAC address entries. , thus causing the MAC address table to jitter. If this goes on, the MAC address entry will eventually be destroyed.

12.1.1.2. Basic Concepts

- One Root Bridge

For an STP network, there is only one root bridge in the entire network, which is the logical center of the entire network, but not necessarily the physical center. The root bridge changes dynamically according to changes in the network topology.

After the network converges, the root bridge will generate and send configuration BPDUs at certain time intervals. Other devices will only process the packets and communicate the topology change records to ensure topology stability.

- Two metrics

The generation calculation of spanning tree has two basic metrics: ID and path cost.

ID

ID is divided into: BID (Bridge ID) and PID (Port ID).

BID: Bridge ID

The IEEE 802.1D standard stipulates that the BID is composed of the bridge priority (Bridge Priority) and the bridge MAC address. BID bridge priority occupies the upper 16 bits, and the remaining lower 48 bits are the MAC address.

In an STP network, the device with the smallest bridge ID will be elected as the root bridge.

PID: Port ID

PID consists of two parts, the upper 4 bits are the port priority, and the lower 12 bits are the port number.

PID is only useful for selecting the designated port in some cases.

Path cost

Path Cost is a port variable and a reference value used by the STP protocol to select links. The STP protocol selects the 'stronger' link by calculating the path cost, blocks the redundant links, and prunes the network into a loop-free tree network structure.

In an STP network, the path cost from a port to the root bridge is the accumulation of the path costs of the outgoing ports on the bridges it passes through. This value is called the Root Path Cost.

- Three-element election

From ring network topology to tree structure, there are generally three elements: root bridge, root port and designated port. The following three elements are introduced in combination with Figure2- 2.




Figure2- 2 STP network structure

Root Bridge RB

The root bridge is the bridge with the smallest bridge ID, and the smallest BID is selected by configuring the BPDU protocol packets interactively.

Root Port RP

The so-called root port is the port with the least path cost to the root bridge. The root port is responsible for forwarding data to the root bridge. The selection criteria of this port are determined based on the cost of the root path. Among all STP-enabled ports on a device, the one with the lowest root path cost is the root port. Obviously, there is only one root port on a device running the STP protocol, and there is no root port on the root bridge.

Designated Port (Designated Port)

See Table2- 1 for the description of the designated bridge and designated port.

Table2- 1 Meaning of Designated Bridge and Designated Port

Classification	Specify bridge	Designated port
Device	A device directly connected to this machine and responsible for forwarding configuration messages to this machine	The designated bridge's port that forwards configuration BPDUs to the device
LAN	The device responsible for forwarding configuration	The designated bridge's port that forwards configuration BPDUs to the

Classification	Specify bridge	Designated port
	messages to this network segment	LAN

As shown in , AP1, AP2, BP1, BP2, CP1, and CP2 represent the ports of devices S1, S2, and S3, respectively.

S1 forwards configuration messages to S2 through port AP1, then the designated bridge of S2 is S1, and the designated port is port AP1 of S1.

There are two devices connected to the local area network LAN: S2 and S3. If S2 is responsible for forwarding configuration messages to the LAN, the designated bridge of the LAN is S2, and the designated port is the BP2 of S2.




Figure2- 3 Designated Bridge and Designated Port Diagram

Once the root bridge, root port, and designated port are elected successfully, the entire tree topology is established. After the topology is stable, only the root port and the designated port forward traffic, and other non-root and non-designated ports are in the blocking state. They only receive STP protocol packets and do not forward user traffic.

- Four comparison principles

STP election has four comparison principles to form a message priority vector: < root bridge ID, root path cost, sending device BID, sending port PID>.

The main information of this port carried in the configuration BPDU is shown in Table2-2.

Table2-2 Four Important Information Fields

Field Content	Brief Description
Root Bridge ID	There is exactly one root per STP network.
Root path cost	The distance from the port sending the configuration BPDU to the root bridge determines the path cost to the root bridge.
Sender BID	The BID of the device that sent the configuration BPDU.
PID	PID of the port that issued the configuration BPDU.

Other devices in the STP network will compare the fields described in table after receiving the configuration BPDU message. The four basic comparison principles are as follows:

Minimum BID: used to elect the root bridge. Select the smallest BID according to the root bridge ID field between devices running the STP protocol.

Minimum root path cost: used to select root ports on non-root bridges. On the root bridge, the root path cost from each port to the root bridge is 0.

Minimum sender BID: When a device running the STP protocol wants to select a root port among two or more ports with the same root path cost, it is calculated by the STP protocol, and the received configuration message will be selected. The port with the smaller sender's BID. As shown in Figure2-2, assuming that the BID of S2 is smaller than the BID of S3, if the root path costs in the BPDUs received by ports A and B of S4 are equal, then port B will become the root port .

Minimum PID: When the root path cost is the same, the port with the smallest PID is not blocked, but the port with the larger PID value is blocked. The PID only works in the case shown in Figure2-4, the PID of port A of S1 is smaller than the PID of port B, because in the BPDUs received on the two ports, the root path overhead, sending exchange The device BIDs are the same, so the basis for eliminating the loop is only the PID.




Figure2-4 Topology applied to PID for comparison


● Five Port States

The port status on the device running the STP protocol is shown in Table2-3.

Table2-3 STP Port Status

Port Status	Purpose	Description
Forwarding	The port both forwards user traffic and processes BPDUs.	Only the root port or the designated port can enter the Forwarding state.
Learning	The device will build a MAC address table based on the received user traffic, but will not forward user traffic.	Transition state, add Learning state to prevent temporary loops.
Listening	Determine the port role. The root bridge, root port and designated port will be elected.	Transition state.
Blocking	The port only receives and processes BPDUs and does not forward user traffic.	The final state of the blocked port.
Disabled	The port not only does not process BPDUs, but also does not forward user traffic.	The port status is Down.

The port state migration mechanism is shown in .



- 1 The port is initialized or enabled, and enters the Blocking state.
- 2 The port is selected as the root or designated port, and enters the Listening state.
- 3 When the time for keeping the port in a temporary state is reached, the port enters the Learning or Forwarding state. The port is selected as the root or designated port.
- 4 The port is not the root or designated port, and enters the blocking state.
- 5 The port is disabled or the link fails.

Figure2-5 STP port state transition diagram

For STP, the following 3 parameters affect port status and port convergence.

1. Hello Time

The time interval at which the device running the STP protocol sends the configuration message BPDU, which is used by the device to detect whether the link is faulty. The device will send hello packets to surrounding devices every Hello Time to confirm whether the link is faulty.

When the network topology is stable, the modification of this timer will only take effect after the root bridge is modified. The new root bridge will populate the appropriate fields in outgoing BPDUs to pass the timer modification information to other non-root bridges. But when the topology changes, the sending of TCN BPDUs is not managed by this timer.

2. Forward Delay

Delay time for device state transition. A link failure will cause the network to recalculate the spanning tree, and the structure of the spanning tree will change accordingly. However, the new configuration message

obtained by recalculation cannot immediately spread to the entire network. If the newly selected root port and designated port start data forwarding immediately, it may cause a temporary loop. For this reason, STP adopts a state transition mechanism. The newly selected root port and designated port can enter the forwarding state after 2 times of the Forward Delay. Configuration messages are propagated throughout the network, preventing temporary loops.

Forward Delay Timer refers to the respective durations of a port in the Listening and Learning states. The default is 15 seconds. The Listening state lasts for 15 seconds, followed by the Learning state for another 15 seconds. Ports in these two states do not forward user traffic, which is exactly what STP is used to avoid temporary loops.

3. Max Age

The aging time of BPDU packets of the port can be manually changed by commands on the root bridge. Max Age can be guaranteed to be consistent in the entire network by configuring the transmission of BPDU packets. After the non-root bridge device in the network running the STP protocol receives the configuration BPDU message, the Message Age and Max Age in the message will be compared:

If Message Age is less than or equal to Max Age, the non-root bridge device continues to forward configuration BPDUs.

If Message Age is greater than Max Age, the configuration BPDU will be aged out. The non-root bridge device directly discards the configuration BPDU. It can be considered that the network diameter is too large and the root bridge connection fails.

If the configuration BPDU is sent by the root bridge, the Message Age is 0. Otherwise, Message Age is the total time from the root bridge to the BPDU received by the current bridge, including transmission delay, etc. In the actual implementation, when BPDU packets pass through a bridge, the Message Age is increased by 1.

12.1.1.3. Message Format

Information such as bridge ID, path cost, and port ID were introduced in the previous chapters, all of which are transmitted via BPDU protocol packets.

The configuration BPDU is a heartbeat message. As long as the port is enabled with STP, the configuration BPDU will be sent from the designated port at the interval specified by the Hello Time timer.

TCN BPDUs are sent when the device detects that the network topology has changed.

BPDUs are encapsulated in Ethernet data frames, the destination MAC is multicast MAC: 01-80-C2-00-00-00, the Length/Type field is the MAC data length, followed by LLC header, LLC is followed by the BPDU header. The Ethernet data frame format is shown in Figure2-6.




Figure2-6 Ethernet Data Frame Format

● Configuring BPDU

Most commonly referred to as BPDUs refer to configuration BPDUs.

During initialization, each bridge actively sends configuration BPDUs. But after the network topology is stable, only the root bridge actively sends configuration BPDUs, and other bridges trigger to send their own configuration BPDUs after receiving configuration BPDUs from upstream. The length of the configuration BPDU must be at least 35 bytes, including parameters such as bridge ID, path cost, and port ID. Only when at least one of the sender's BID or port PID is different from the receiving port of the bridge, the BPDU will be processed, otherwise it will be discarded. This avoids processing BPDUs with the same port information.

The configuration BPDU will be generated in the following 3 cases:

1. As long as the port is enabled with STP, the configuration BPDU will be sent from the designated port at the interval specified by the Hello Time timer.
2. When the root port receives a configuration BPDU, the device where the root port is located will copy a configuration BPDU to each of its designated ports.
3. When the designated port receives a configuration BPDU that is worse than its own, it will immediately send its own BPDU to the downstream device.

The basic format of the configuration BPDU message is shown in Table2-4.

Table2-4 BPDU basic format

Field	bytes	Description
Protocol Identifier	2	Always 0.
Protocol Version Identifier	1	Always 0.
BPDU Type	1	Current BPDU type: 0x00: Configure BPDU. 0x80: TCN BPDU.
Flags	1	Network topology change flag: Lowest bit = TC (Topology Change) flag. Highest bit=TCA (Topology Change Acknowledgment, Topology Change Acknowledgment) flag.
Root Identifier	8	The BID of the current root bridge.

Field	bytes	Description
Root Path Cost	4	The total cost of this port to the root bridge.
Bridge Identifier	8	BID of this switching device.
Port Identifier	2	Port ID for sending this BPDU.
Message Age	2	The message age of this BPDU. If the configuration BPDU is sent by the root bridge, the Message Age is 0. Otherwise, Message Age is the total time from the root bridge to the BPDU received by the current bridge, including transmission delay, etc. In the actual implementation, when BPDU packets pass through a bridge, the Message Age is increased by 1.
Max Age	2	Message aging age.
Hello Time	2	The time interval between sending two adjacent BPDUs.
Forward Delay	2	Controls the duration of the Listening and Learning states.

The flag field is shown in Figure2-7, only the highest and lowest bits are used in STP.




Figure2-7 Flags field format

- TCN BPDU

TCN BPDU content is relatively simple, only the first 3 fields listed in Table2-4: protocol number, version and type. The type field is a fixed value of 0x80, and the length is only 4 bytes.

TCN BPDU refers to sending a topology change notification to the upstream when the downstream topology changes, until the root node. TCN BPDU will be generated in the following two cases:

1. The port status changes to Forwarding status.
2. The designated port receives the TCN BPDU, copies the TCN BPDU and sends it to the root bridge.

12.1.1.4. Topology Calculation

After all devices in the network enable the STP protocol, each device considers itself to be the root bridge. At this point, each device only sends and receives configuration BPDUs without forwarding user traffic, and all ports are in the Listening state. After all devices exchange configuration BPDUs, they perform election work to elect the root bridge, root port and designated port.

BPDU interaction process

As shown in Figure2-8, the quadruple marked with <> represents the root bridge ID (S1_MAC and S2_MAC represent the BIDs of two devices in the figure), the accumulated root path cost, An ordered group consisting of sender BID and sending port PID. The configuration BPDU will be sent at the interval specified by the Hello Timer.




Figure2-8 Initial Information Interaction

Basic process of STP algorithm implementation

- Initial state

Because each bridge thinks it is the root bridge, in the BPDU sent by each port, the root bridge field uses its own BID, and the Root Path Cost field is accumulated to the root bridge. Overhead, the sender BID is its own BID, and the port PID is the port ID of the port that sent the BPDU.

- Select root bridge

When the network is initialized, all STP devices in the network consider themselves to be the 'root bridge', and the root bridge ID is its own device ID. By exchanging configuration messages, devices compare root bridge IDs, and the device with the smallest root bridge ID in the network is selected as the root bridge.

- Select root port and designated port

The selection process of root port and designated port is shown in Table2-5.

Table2-5 Root port and designated port selection process

Step	Process
1	The non-root bridge device will set the port that receives the optimal configuration message (the selection process of the optimal configuration message is shown in Table2-6) as the root port

Step	Process
2	The device calculates a designated port configuration message for each port according to the configuration message of the root port and the path cost of the root port: Replace the root bridge ID with the root bridge ID of the configuration message of the root port; The root path cost is replaced by the root path cost of the root port configuration message plus the path cost corresponding to the root port; Replace the sender's BID with the ID of its own device; Replace the sending port PID with the own port ID.
3	The device compares the calculated configuration message with the role-pending port's own configuration message: If the calculated configuration message is better, the port is determined to be the designated port, and its configuration message is also replaced by the calculated configuration message and sent out periodically; If the port's own configuration message is better, the port's configuration message will not be updated and the port will be blocked. This port will no longer forward data, and will only receive and not send configuration messages.

Table2-6 Optimal configuration message selection process

Step	Process
1	Each port compares the received configuration message with its own configuration message: If the received configuration message has a lower priority, it will be discarded directly, and its own configuration message will not be processed; If the received configuration message has a higher priority, replace the content of the configuration message with the content of the configuration message.
2	The device compares the configuration messages of all ports and selects the optimal configuration message.

STP algorithm implementation example

Once the root bridge, root port and designated port are elected successfully, the whole tree topology is established. The following describes the specific process of implementing the STP algorithm with an example.




Figure2-9 STP algorithm implementation process networking diagram and calculated topology
As shown in the figure, the priorities of DeviceA, DeviceB, and DeviceC are 0, 1, and 2, respectively. The path cost of the links between DeviceA and DeviceB, between DeviceA and DeviceC, and between DeviceB and DeviceC 5, 10 and 4 respectively.

Initial state of each device

The initial state of each device is shown in the table below.

Table2-7 Initial state of each device

Device	Port Name	Port configuration message < Root bridge ID, cumulative root path cost, sender BID, sender port PID>
DeviceA	Port A1	<0,0,0,Port A1>
	Port A2	<0,0,0,Port A2>
DeviceB	Port B1	<1,0,1,Port B1>
	Port B2	<1,0,1,Port B2>
DeviceC	Port C1	<2,0,2,Port C1>

Device	Port Name	Port configuration message < Root bridge ID, cumulative root path cost, sender BID, sender port PID>
	Port C2	<2,0,2,Port C2>

Comparison process and results of each device

The comparison process and results of each device are shown in the table below.

Table2- 8 STP topology calculation process and results

Device	Comparison process	Configuration message of port after comparison
DeviceA	<p>Port A1 received the configuration message of Port B1 <1, 0, 1, Port B1>, and found that its configuration message < 0, 0, 0, Port A1> was better, so it throw away.</p> <p>Port A2 receives the configuration message <2, 0, 2, Port C1> of Port C1, and finds that its configuration message < 0, 0, 0, Port A2> is better, so it throw away.</p> <p>DeviceA finds that both the root bridge and the designated bridge in the configuration messages of its ports are itself, so it thinks that it is the root bridge, and the configuration messages of each port do not make any changes, and then periodically send out Send configuration message.</p>	<p>Port A1: <0, 0, 0, Port A1> Port A2: <0, 0, 0, Port A2></p>
DeviceB	<p>Port B1 receives the configuration message of Port A1 <0,0,0,Port A1>, and finds that it is better than its own configuration message <1,0,1,Port B1>, so Update your own configuration message.</p> <p>Port B2 receives the configuration message of Port C2 <2, 0, 2, Port C2>, and finds that its configuration message < 1, 0, 1, Port B2> is better, so it throw away.</p>	<p>Port B1: <0, 0, 0, Port A1> Port B2: <1, 0, 1, Port B2></p>
	<p>DeviceB compares the configuration messages of its own ports and finds that the configuration messages of Port B1 are optimal, so this port is determined as the root port, and its configuration messages remain unchanged.</p> <p>DeviceB calculates the configuration message <0, 5, 1, Port B2> of the designated port for Port B2 according to the configuration message and path cost of the root port, and then matches the configuration message of Port B2 itself < 1, 0, 1, and Port B2> are compared, and it is found that the calculated configuration message is better, so Port B2 is determined as the designated port, and its configuration message is also replaced with the calculated configuration message and sent out periodically. .</p>	<p>Root port B1: <0, 0, 0, Port A1> Designated port B2: <0, 5, 1, Port B2></p>
DeviceC	<p>Port C1 receives the configuration message of Port A2 <0,0,0,Port A2>, and finds that it is better than its own configuration message <2,0,2,Port C1>, so Update your own configuration message.</p> <p>Port C2 receives the configuration message <1, 0, 1, Port B2> before the update of Port B2, and finds that it is better than its own configuration message < 2, 0, 2, Port C2> , so update your own configuration message.</p>	<p>Port C1 :<0, 0, 0, Port A2> Port C2: <1, 0, 1, Port B2></p>
	<p>DeviceC compares the configuration messages of its own ports and finds that the configuration messages of Port C1 are optimal, so the port is determined as the root port, and its configuration messages remain unchanged.</p> <p>DeviceC calculates the configuration message <0, 10, 2, Port C2> of the designated port for Port C2 according to the configuration message and path cost of the root port, and then matches the configuration message of Port C2 itself < 1, 0, 1, Port B2> compare and find that the calculated configuration message is better, so Port C2 is determined as the designated</p>	<p>Root port C1: <0, 0, 0, Port A2> Designated port C2: <0, 10, 2, Port C2></p>

Device	Comparison process	Configuration message of port after comparison
	port, and its configuration message is also replaced with the calculated configuration message.	
	Port C2 received the updated configuration message <0, 5, 1, Port B2> from Port B2, and found that it is better than its own configuration message <0, 10, 2, Port C2> , so update your own configuration message. Port C1 receives the configuration message <0, 0, 0, Port A2> periodically sent by Port A2, and finds that it is the same as its own configuration message, so it discards it.	Port C1 :<0, 0, 0, Port A2> Port C2: <0, 5, 1, Port B2>
	DeviceC compares the root path cost 10 of Port C1 (the root path cost 0 in the received configuration message + the path cost 10 of the link where the port is located) and the root path cost 9 of Port C2 (received The root path cost in the configuration message is 5 + the path cost of the link where this port is located 4). It is found that the latter is smaller, so the configuration message of Port C2 is better, so Port C2 is determined as the root port, and its configuration message remains unchanged. DeviceC calculates the configuration message <0, 9, 2, Port C1> of the designated port for Port C1 according to the configuration message and path cost of the root port, and then matches the configuration message of Port C1 itself < 0, 0, 0, Port A2> compared, and found that its own configuration message is better, so Port C1 is blocked, and its configuration message remains unchanged. From now on, Port C1 will no longer forward data until a new situation that triggers spanning tree calculation occurs, such as the link between DeviceB and DeviceC is down.	Blocking port C1: <0, 0, 0, Port A2> Root port C2: <0, 5, 1, Port B2>

After the topology is stable, the root bridge still sends configuration BPDUs according to the interval specified by the Hello Timer. Non-root bridge devices receive configuration BPDUs from the root port and forward them through the designated port. If it receives a configuration BPDU with a higher priority than itself, the non-root bridge device will update the configuration BPDU information stored on its corresponding port according to the information carried in the received configuration BPDU.

STP topology change

The STP topology change processing process is shown in the figure below.




Figure 2- 10 TCN sending and TC flooding

After the network topology changes, the downstream device will continuously send TCN BPDUs to the upstream device.

After the upstream device receives the TCN BPDU message from the downstream device, only the designated port processes the TCN BPDU message. Other ports may also receive TCN BPDUs, but will not process them.

The upstream device will set the TCA bit of the Flags in the configuration BPDU message to 1, and then send it to the downstream device to tell the downstream device to stop sending TCN BPDU messages.

The upstream device copies a TCN BPDU and sends it to the root bridge.

Repeat steps 1, 2, 3, and 4 until the root bridge receives a TCN BPDU.

The root bridge sets the TC and TCA bits of the Flags in the configuration BPDU message to 1 and sends it to notify the downstream device to delete the bridge MAC address entry directly.

12.1.2. RSTP

12.1.2.1. Requirement Background

The 802.1w standard released by the IEEE in 2001 defines the Rapid Spanning Tree Protocol (RSTP), which is based on the STP protocol and makes more detailed modifications and additions to the original STP protocol.

STP deficiencies

Although the STP protocol can solve the loop problem, the slow convergence of the network topology affects the quality of user communication. If the topology in the network changes frequently, the network will also lose connectivity frequently, resulting in frequent interruption of user communication, which is unbearable for users.

The disadvantages of STP are as follows:

STP does not distinguish port status and port role in detail, which is not conducive to beginners' learning and deployment.

The quality of a network protocol often depends on whether the protocol distinguishes each situation carefully.

From the user's point of view, there is no difference between the Listening, Learning and Blocking states, and they also do not forward user traffic.

From the perspective of usage and configuration, the most essential difference between ports is not the state of the port, but the role the port plays.

The root port and the designated port can both be in the Listening state or both in the Forwarding state.

The STP algorithm is a passive algorithm. It relies on the timer to wait to determine the topology change, and the convergence speed is slow.

The STP algorithm requires that in a stable topology, the root bridge actively sends out configuration BPDUs, and other devices process them and spread them throughout the STP network. This is also one of the main reasons for slow topology convergence.

RSTP improves STP

According to the insufficiency of STP, RSTP deletes 3 port states, adds 2 new port roles, and fully decouples port attributes according to state and role; in addition, RSTP also adds some corresponding Enhanced features and protection measures to achieve network stability and rapid convergence, simplifies the understanding and deployment of Spanning Tree Protocol by adding port roles.




Figure2- 11 Port Role Schematic

As shown in the figure above, there are four types of RSTP port roles: root port, designated port, alternate port and backup port.

The functions of the root port and the designated port are the same as those defined in the STP protocol.

The description of the alternate port and the backup port is as follows:

From the perspective of configuring BPDUs:

Alternate port is a port that is blocked due to learning configuration BPDUs sent by other bridges.

The backup port is the port that is blocked due to learning the configuration BPDUs sent by itself.

From a user traffic perspective:

The Alternate port provides an alternate switchable path from the designated bridge to the root, acting as a backup port for the root port.

The Backup port acts as a backup of the designated port, providing another backup path from the root bridge to the corresponding network segment.

The process of assigning roles to all ports in an RSTP network is the process of topology convergence.

Repartition of port state

RSTP state specification reduces the original 5 states to 3. Divided according to whether the port forwards user traffic and learns the MAC address:

If the user traffic is not forwarded and the MAC address is not learned, the port state is Discarding state.

If the user traffic is not forwarded but the MAC address is learned, the port state is the Learning state.

If both user traffic is forwarded and the MAC address is learned, the port state is the Forwarding state.

As shown in Table2-9, the new port state is compared with the port state specified by STP. Port status and

port role are not necessarily related. The table shows the port status that various port roles can have.
Table2-9 STP and RSTP Port Status Role Correspondence Table

STP port status	RSTP port status	The role of the port in the topology
Forwarding	Forwarding	Include root port, designated port
Learning	Learning	Include root port, designated port
Listening	Discarding	Include root port, designated port
Blocking	Discarding	Include Alternate port, Backup port
Disabled	Discarding	Include Disable port

The change of the configuration BPDUs makes full use of the Flag field in the STP protocol message and clarifies the port role.

In addition to ensuring that the format of the BPDU is basically the same as the STP format, RSTP has made some minor changes:

Type field, the configuration BPDUs type is no longer 0 but 2, so the device running STP will discard the RSTP configuration BPDUs when it receives it.

Flags field, using the original reserved middle 6 bits, so the changed configuration BPDUs is called RST BPDUs, as shown in the following figure.




Figure2- 12 RSTP Flag field format

- The processing of configuration BPDUs has changed
- Transmission frequency of configuration BPDUs

After the topology is stable, the root bridge sends configuration BPDUs at the interval specified by the Hello Timer. Other non-root bridge devices will trigger configuration BPDUs after receiving the configuration BPDUs sent by the upstream device. This method makes the calculation of the STP protocol complicated and slow. RSTP has been improved, that is, after the topology is stable, no matter whether the non-root bridge device receives the configuration BPDUs from the root bridge or not, the non-root bridge device still follows the interval specified by Hello Timer. Sending a configuration BPDUs, this behavior is entirely autonomous for each device.

- Shorter BPDUs timeout

If a port does not receive a configuration BPDUs from an upstream device within 3 consecutive Hello Time, the device considers that the negotiation with this neighbor has failed. Instead of waiting for a Max Age like STP.

- Process inferior BPDUs

When a port receives an RST BPDUs from an upstream designated bridge, the port will compare its own stored RST BPDUs with the received RST BPDUs.

If the priority of the RST BPDUs stored by the port is higher than that of the received RST BPDUs, the port will directly discard the received RST BPDUs and immediately respond to its own stored RST BPDUs. When the upstream device receives the RST BPDUs responded by the downstream device, the upstream device will immediately update its stored RST BPDUs according to the corresponding fields in the received RST BPDUs.

Therefore, RSTP processing inferior BPDUs no longer relies on any timer to solve topology convergence through timeout, thus speeding up topology convergence.

- fast convergence
- Proposal/Agreement mechanism

After a port is elected as the designated port, in STP, the port will wait at least one Forward Delay (Learning) time before transitioning to the Forwarding state. In RSTP, this port will first enter the Discarding state, and then quickly enter the Forward state through the Proposal/Agreement mechanism. This mechanism must be used on point-to-point full-duplex links.

Proposal/Agreement mechanism is referred to as P/A mechanism.

- Root port fast switching mechanism

If a root port in the network fails, the optimal alternate port in the network will become the root port and enter the Forwarding state. Because there must be a designated port on the network segment connected through this alternate port that can lead to the root bridge.

Introduction of edge ports

In RSTP, if a designated port is located at the edge of the entire network, that is, it is no longer connected to other switching devices, but directly connected to terminal devices. This port is called an edge port.

The edge port does not receive and process configuration BPDUs, and does not participate in RSTP operations. It can go to the Forwarding state directly from Disable without experiencing delay, just like disabling STP on the port. But once the edge port receives the configuration BPDUs, it loses the edge port

attributes, becomes a normal STP port, and recalculates the spanning tree, which causes network flapping.

- protection function

The protection functions provided by RSTP are shown in the table below.

Table2- 10 Protection function

Protection function	Scene	Principle
BPDU Protection	On switching devices, the ports directly connected to non-switching devices such as user terminals (such as PCs) or file servers are usually configured as edge ports. Normally, edge ports will not receive RST BPDUs. If someone forges an RST BPDU to maliciously attack a switching device, when an edge port receives an RST BPDU, the switching device will automatically set the edge port as a non-edge port and recalculate the spanning tree, causing network flapping .	After the BPDU protection function is enabled on the switching device, if the edge port receives an RST BPDU, the edge port will be error-down, but the edge port attributes will remain unchanged, and the network management system will be notified at the same time.
Root Protection	Due to the misconfiguration of the maintenance personnel or the malicious attacks in the network, the legitimate root bridges in the network may receive RST BPDUs with higher priority, so that the legitimate root bridges lose their root status, thus causing the network topology Incorrect change of structure. This illegal topology change will cause traffic that should have passed through the high-speed link to be pulled to the low-speed link, causing network congestion.	For the designated port with root protection function enabled, its port role can only remain as designated port. Once a designated port with the root protection function enabled receives a RST BPDU with a higher priority, the port state will enter the Discarding state and will no longer forward packets. After a period of time (usually twice the Forward Delay), if the port has not received RST BPDUs with higher priority, the port will automatically return to the normal Forwarding state. Description: Root protection can only be configured on designated ports.

12.1.2.2. Technical Principles

Proposal/Agreement mechanism

The purpose is to make a designated port enter the Forwarding state as soon as possible. As shown in the figure below, a new link has been added between the root bridge S1 and S2. In the current state, the other ports p2 of S2 are alternate ports, p3 is the designated port and is in the forwarding state, and p4 is the edge port.




Figure2- 13 Proposal/Agreement Process Diagram

After the new link is successfully connected, the P/A mechanism negotiation process is as follows:

1. Both ports p0 and p1 will immediately become designated ports and send RST BPDUs.
2. The p1 port of S2 received a better RST BPDU, and immediately realized that it would become the root port, not the designated port, and stopped sending RST BPDUs.
3. P0 of S1 enters the Discarding state, so the proposal is set to 1 in the sent RST BPDU.

4. S2 receives the RST BPDU with proposal sent by the root bridge, and starts to set all its own ports into the sync variable.
5. p2 has been blocked and the state remains unchanged; p4 is an edge port and does not participate in the operation; so only the non-edge designated port p3 needs to be blocked.
6. After both p2 and p3 enter the Discarding state, the synced variable of the port is set, and the synced of the root port p1 is also set, so the response RST BPDU with the Agreement bit set is returned to S1. This RST BPDU carries the same information as the BPDU sent by the root bridge just now, except that the Agreement bit is set (the Proposal bit is cleared).
7. When S1 determines that this is a response to the proposal just sent, port p0 immediately enters the Forwarding state.

The downstream device continues the P/A negotiation process.

In fact, for STP, the selection of the designated port can be completed very quickly. The main speed bottleneck is: in order to avoid loops, it is necessary to wait long enough to make the port status of the entire network all determined, that is Says that all ports must wait for at least one Forward Delay before forwarding. The main purpose of RSTP is to eliminate this bottleneck by blocking its own non-root ports to ensure that there will be no loops. Using the P/A mechanism speeds up the upstream port's transition to the Forwarding state.

RSTP topology change processing

There is only one criterion for detecting topology changes in RSTP: a non-edge port migrates to the Forwarding state.

Once a topology change is detected, the following processing will be performed:

Start a TC While Timer for all non-edge designated ports of this switching device. The timer value is twice the Hello Time.

During this time, clear the MAC addresses learned on all ports.

At the same time, a RST BPDU is sent out from the non-edge port, with TC set. Once the TC While Timer times out, stop sending RST BPDUs.

After receiving the RST BPDU, other switching devices clear all ports to learn the MAC address, except the port that received the RST BPDU. Then also start the TC While Timer for all non-edge designated ports and root ports, and repeat the above process.

In this way, a flood of RST BPDUs will occur in the network.

RSTP and STP interoperability

RSTP can interoperate with STP, but the advantages of RSTP such as fast convergence will be lost at this time.

When a network segment has both STP and RSTP switching devices, the STP switching device will ignore RSTP BPDUs. The switching device running RSTP receives the configuration BPDU sent by the switching device running STP on a port, and after two Hello Time times, it switches its port to STP working mode and sends the configuration BPDU , thus enabling interoperability.

12.1.3. MSTP

12.1.3.1. Requirement Background

RSTP has been improved on the basis of STP to achieve rapid network topology convergence. But RSTP and STP still have the same defect: because all VLANs in the LAN share a spanning tree, load balancing of data traffic between VLANs cannot be achieved, and the link will not carry any traffic after it is blocked. traffic, resulting in wasted bandwidth, and may also cause some VLAN packets to fail to be forwarded.




Figure2- 14 STP/RSTP defect diagram

In the network shown above, STP or RSTP is applied in the local area network. The spanning tree structure is represented by a dotted line in the figure, and S6 is the root switching device. The links between S2 and S5 and between S1 and S4 are blocked. Except for the links marked 'VLAN2' or 'VLAN3' in the figure, the corresponding VLAN packets are allowed to pass through. The packets of VLAN2 and VLAN3 are not allowed to pass through.

ServerA and ServerB belong to VLAN2, because the link between S2 and S5 is blocked, and the link between S3 and S6 does not allow packets from VLAN2 to pass, so ServerA and ServerB cannot communicate with each other. communicate with each other.

In order to make up for the shortcomings of STP and RSTP, the 802.1S standard released by IEEE in 2002 defines MSTP. MSTP is compatible with STP and RSTP, which can not only converge quickly, but also provide multiple redundant paths for data forwarding to achieve load balancing of VLAN data during data forwarding.

A switching network is divided into multiple regions through MSTP, and multiple spanning trees are formed

in each region, and the spanning trees are independent of each other. Each spanning tree is called a Multiple Spanning Tree Instance (MSTI), and each region is called an MST Region (MST Region: Multiple Spanning Tree Region).




Figure2- 15 Multiple spanning trees in the MST region

As shown in the figure above, MSTP connects VLAN and MSTI by setting the VLAN mapping table (that is, the correspondence table between VLAN and MSTI). Each VLAN can only correspond to one MSTI, that is, the data of the same VLAN can only be transmitted in one MSTI, and one MSTI may correspond to multiple VLANs.

After calculation, two spanning trees are finally generated:

MSTI1 uses S4 as the root switching device to forward packets of VLAN2.

MSTI2 uses S6 as the root switching device to forward packets of VLAN3.

In this way, all VLANs can communicate with each other, and packets of different VLANs are forwarded along different paths, realizing load balancing.

12.1.3.2. Basic Concepts

MSTP Network

As shown in the figure below, the MSTP network contains one or more MST regions (MST Regions), and each MST Region contains one or more MSTIs. MSTI is composed of switching equipment running STP/RSTP/MSTP. MSTI is a tree network formed by all switching equipment running STP/RSTP/MSTP after MSTP protocol calculation.




Figure2- 16 MSTP Network Diagram

MST Region

The MST region is a Multiple Spanning Tree Region, which consists of multiple switching devices in the switching network and the network segments between them. Devices in the same MST region have the following characteristics:

- MSTP is enabled.
- Has the same region name.
- Has the same VLAN to Spanning Tree instance mapping configuration.
- Has the same MSTP revision level configuration.

A LAN can have multiple MST regions, and the MST regions are physically connected directly or indirectly. Users can divide multiple switching devices into the same MST region through MSTP configuration commands.

As shown in the figure below, MST Region D0 consists of switching devices S1, S2, S3 and S4, and there are 3 MSTIs in the region.




Figure2- 17 Basic Concept Diagram of MST Region

VLAN mapping table

VLAN mapping table is an attribute of MST region, which describes the mapping relationship between VLAN and MSTI.

As shown in the figure above, the VLAN mapping table of MST region D0 is:

VLAN1 maps to MSTI1

VLAN2 and VLAN3 are mapped to MSTI2

The rest of the VLANs are mapped to MSTI0

Regional Root

Regional Root is divided into IST (Internal Spanning Tree) regional root and MSTI regional root.

The IST regional root is shown in Figure2- 19. In B0, C0 and D0, the switching device closest to the total root (CIST Root) in the IST spanning tree is the IST regional root.

Multiple spanning trees can be generated in one MST region, and each spanning tree is called an MSTI. The MSTI regional root is the root of each multiple spanning tree instance. As shown in Figure2- 18, different MSTIs in the region have their own regional root.




Figure2- 18 MSTI basic concept diagram

MSTIs are independent of each other, and MSTIs can correspond to one or more VLANs. But a VLAN can only correspond to one MSTI.

Master Bridge

The Master Bridge, also known as the IST Master, is the switching device closest to the root in the region. S1 as in

Figure2- 17.

If the master root is in the MST region, then the master root is the master bridge for this region.

CIST Root




Figure2- 19 MSTP network basic concept diagram

As shown above, the total root is the root bridge of CIST (Common and Internal Spanning Tree). The total root is a device in area A0.

CST

Common Spanning Tree (CST) is a spanning tree that connects all MST regions in a switched network. If each MST region is regarded as a node, the CST is a spanning tree calculated and generated by these nodes through the STP or RSTP protocol.

As shown in Figure2- 19, thicker lines connect fields to form CST.

IST

Internal Spanning Tree IST (Internal Spanning Tree) is a spanning tree in each MST region.

IST is a special MSTI, the ID of MSTI is 0, usually called MSTI0.

IST is a fragment of CIST in the MST region.

As shown in Figure2- 19, the thinner lines in the region connect all switching devices in the region to form the IST.

CIST

Common and Internal Spanning Tree CIST is calculated and generated by STP or RSTP protocol, connecting all switching devices in a single spanning tree in a switching network.

As shown in Figure2- 19, the IST plus CST of all MST regions constitutes a complete spanning tree, namely CIST.

SST

There are two cases of forming a single spanning tree SST (Single Spanning Tree):

A switching device running STP or RSTP can only belong to one spanning tree.

There is only one switching device in the MST region, and this switching device constitutes a single spanning tree.

As shown in Figure2- 19, the switching device in B0 is a single spanning tree.

Port role

MSTP adds 2 new ports based on RSTP. MSTP has 7 port roles: root port, designated port, alternate port, backup port, edge port, master port and regional edge port.

The functions of root port, designated port, alternate port, backup port and edge port are the same as those defined in RSTP protocol. All port roles defined in MSTP are shown in the following table.

Table2- 11 Port Role

Port Role	Description
Root port	On a non-root bridge, the port closest to the root bridge is the root port of this switch. The root switch device has no root port. The root port is responsible for forwarding data to the root of the tree. As shown in Figure2- 20, S1 is the root bridge, CP1 is the root port of S3, and BP1 is the root port of S2.
Designated port	For a switching device, its designated port is the port that forwards BPDUs to downstream switching devices. As shown in Figure2- 20, AP2 and AP3 are designated ports of S1, and CP2 is designated port of S3.
Alternate port	From the perspective of sending configuration BPDUs, the alternate port is a port that is blocked by learning configuration BPDUs sent by other bridges. From a user traffic perspective, the Alternate port provides another switchable path from the designated bridge to the root, acting as a backup port to the root port. As shown in Figure2- 20, BP2 is an alternate port.
Backup port	From the perspective of sending configuration BPDUs, the Backup port is a port that is blocked by learning the configuration BPDUs sent by itself. From the perspective of user traffic, the Backup port acts as a backup of the designated port, providing another backup path from the root node to the leaf node.

Port Role	Description
	As shown in Figure2- 20, CP3 is the backup port.
Master port	<p>The master port is the port on the shortest path among all paths connecting the MST region to the general root. It is the port on the switching device that connects the MST region to the general root.</p> <p>The master port is the only way for packets in the region to go to the master root.</p> <p>The master port is a special regional edge port. The role of the master port on the CIST is the root port, and the role of the master port on other instances is the master port.</p> <p>As shown in Figure2-21, the switching devices S1, S2, S3, S4 and the links between them constitute an MST region, and the port AP1 of the S1 switching device is in all ports in the region to the total root The path cost is the least, so AP1 is the master port.</p>
Regional Edge Port	<p>A regional edge port is a port located at the edge of an MST region and connected to other MST regions or SSTs.</p> <p>When performing MSTP calculations, the role of the regional edge port on the MSTI is the same as the role of the CIST instance. That is, if the role of the edge port on the CIST instance is the Master port (the port on the shortest path among all paths connecting the region and the general root), then its role on all MSTIs in the region is also the Master port.</p> <p>As shown in Figure2- 21, AP1, DP1 and DP2 in the MST region are directly connected to other regions, and they are all regional edge ports in this MST region.</p> <p>The role of regional edge ports on spanning tree instances is the same as on CIST. For example, in Figure2- 21, AP1 is the regional edge port, and its role in the CIST is the master port, then the role of AP1 in all spanning tree instances in the MST region is the master port.</p>
Edge Port	<p>If the designated port is located at the edge of the entire region and is no longer connected to any switching device, this port is called an edge port.</p> <p>Edge ports are generally connected directly to user terminal equipment.</p> <p>After the MSTP function is enabled on a port, the automatic edge port detection function will be enabled by default. When the port does not receive BPDUs within (2 × Hello Timer + 1) seconds, the port will be automatically set to Edge port, otherwise set to non-edge port.</p>




Figure2- 20 Root Port, Designated Port, Alternate Port and Backup Port Schematic




Figure2- 21 Master Port and Regional Edge Port Diagram

MSTP port status

The port state defined by MSTP is the same as that defined in the RSTP protocol, as shown in the following table.

Table2- 12 Port Status

Port Status	Description
Forwarding	In this state, the port both forwards user traffic and receives/sends BPDUs.
Learning	This is a transitional state. Under Learning, the switching device will build a MAC address table according to the received user traffic, but will not forward the user traffic, so it is called the learning state. The port in the Learning state receives/sends BPDUs and does not forward user traffic.
Discarding	The port in Discarding state only receives BPDU packets.

Port status and port role are not necessarily related. The following table shows the port status that various port roles can have.

Table2- 13 Port Status and Port Role Correspondence Table

Port Status	Root Port/Master Port	Designated port	Regional Edge Port	Alternate port	Backup port
Forwarding	Yes	Yes	Yes	No	No
Learning	Yes	Yes	Yes	No	No
Discarding	Yes	Yes	Yes	Yes	Yes

Yes: indicates the port support status. No: indicates that the port is not supported.

12.1.3.3. Message Format

MSTP uses Multiple Spanning Tree Bridge Protocol Data Unit (MST BPDU) as the basis for spanning tree calculation. MST BPDUs are used to calculate spanning tree topology, maintain network topology, and communicate topology change records.

The difference between configuration BPDUs defined in STP, RST BPDUs defined in RSTP, MST BPDUs defined in MSTP, and TCN BPDUs is shown in the following table.

Table2- 14 Four BPDU Difference Comparison

Version	Type	Name
0	0x00	Configuration BPDU
0	0x80	TCN BPDU
2	0x02	RST BPDU
3	0x02	MST BPDU

MSTP message format

The structure of the MST BPDU is shown in the figure below.

	Octet
Protocol Identifier	1-2
Protocol Version Identifier	3
BPDU Type	4
CIST Flags	5
CIST Root Identifier	6-13
CIST External Path Cost	14-17
CIST Regional Root Identifier	18-25
CIST Port Identifier	26-27
Message Age	28-29
Max Age	30-31
Hello Time	32-33
Forward Delay	34-35
Version 1 Length=0	36
Version 3 Length	37-38
MST Configuration Identifier	39-89
CIST Internal Root Path Cost	90-93
CIST Bridge Identifier	94-101
CIST Remaining Hops	102
MSTI Configuration Messages (may be absent)	103-39+Version 3 Length

MST special fields

Figure2- 22 MST BPDU structure

Whether it is an intra-region MST BPDU or an inter-region MST BPDU, the first 36 bytes are the same as the RST BPDU.

Starting from the 37th byte is an MSTP-specific field. The last MSTI configuration information field consists of several MSTI configuration information groups concatenated.

The main information in the MST BPDU is shown in the table below.

Table2- 15 Main information description in MST BPDU

Field Content	bytes	Description
Protocol Identifier	2	Protocol identifier.
Protocol Version Identifier	1	Protocol version identifier, STP is 0, RSTP is 2, MSTP is 3.
BPDU Type	1	BPDU type: 0x00: Configuration BPDU of STP 0x80: STP TCN BPDU (Topology Change Notification BPDU) 0x02: RST BPDU (Rapid Spanning-Tree BPDU) or MST BPDU (Multiple Spanning-Tree BPDU)
CIST Flags	1	CIST flag field.
CIST Root Identifier	8	CIST 's total root exchange device ID.
CIST External Path Cost	4	The CIST external path cost refers to the cumulative path cost from the MST region to which this switching device belongs to the MST region to which the CIST root switching device belongs. CIST external path cost is calculated based on link bandwidth.
CIST Regional Root Identifier	8	Indicates the ID of the regional root switching device on the CIST, that is, the IST master ID. If the root is in this region, the CIST Regional Root Identifier is the same as the CIST Root Identifier.
CIST Port Identifier	2	The designated port ID of this port in IST.
Message Age	2	BPDU lifetime.
Max Age	2	The maximum lifetime of a BPDU packet. If the timeout expires, the link to the root switching device is considered to be faulty.
Hello Time	2	Hello timer, the default is 2 seconds.
Forward Delay	2	Forward Delay timer, the default is 15 seconds.

Field Content	bytes	Description
Version Length 1	1	Version1 BPDU length, the value is fixed to 0.
Version Length 3	2	Version3 length of BPDU.
MST Configuration Identifier	51	MST configuration identifier, indicating the label information of the MST region, including 4 fields.
CIST Internal Root Path Cost	4	CIST internal path cost refers to the cumulative path cost from this port to the IST Master switching device. CIST internal path cost is calculated based on link bandwidth.
CIST Bridge Identifier	8	Indicates the ID of the designated switching device on the CIST.
Indicates the remaining hops of the BPDU in the CIST.	1	The remaining hops of the BPDU in the CIST.
MSTI Configuration Messages(may be absent)	16	MSTI configuration information. The configuration information of each MSTI occupies 16 bytes. If there are n MSTIs, it occupies n×16 bytes.

The maximum number of BPDUs that the port can send within each Hello Time is configurable. Hello Time is used by the Spanning Tree Protocol to periodically send configuration messages to maintain the stability of the spanning tree. If the switching device does not receive a BPDU within a period of time, it will recalculate the spanning tree due to message timeout. When a switching device becomes the root switching device, the switching device will send BPDUs at the interval of the set value. The non-root switching device adopts the Hello Time value set by the root switching device.

12.1.3.4. Topology Calculation

MSTP rationale

MSTP can divide the entire Layer 2 network into multiple MST regions, and CST is generated between each region through calculation. In the region, multiple spanning trees are generated by calculation, and each spanning tree is called a multiple spanning tree instance. where instance 0 is called IST, and the other multiple spanning tree instances are MSTI. MSTP, like STP, uses configuration messages to calculate spanning tree, but the configuration messages carry the configuration information of MSTP on the device.

priority vector

Both MSTI and CIST are calculated from priority vectors, which are included in the MST BPDU. The switching devices exchange MST BPDUs with each other to generate MSTI and CIST.

- Introduction to Priority Vectors

The priority vector participating in the CIST calculation is:

< Root Switch ID, External Path Cost, Regional Root ID, Internal Path Cost, Designated Switch ID, Designated Port ID, Receive Port ID >

The priority vector participating in MSTI calculation is:

< Regional Root ID, internal path cost, designated switching device ID, designated port ID, receiving port ID >

The priority of the vectors in parentheses decreases from left to right.

The following table explains each priority vector.

Table2- 16 Vector Description

Vector Name	Description
Root Switch Device ID	The root switch ID is used to select the root switch in CIST. Root Switch ID = Priority(16bits) + MAC(48bits). Where Priority is the priority of MSTI0.
External Path Cost (ERPC)	Path cost from the regional root of CIST to the total root. The external path cost stored on all switching devices in the MST region is the same. If the CIST root switching device is in the region, the external path cost stored on all switching devices in the region is 0.
Regional Root ID	Regional Root ID is used to select the regional root in MSTI. Regional Root ID = Priority(16bits) + MAC(48bits). Where Priority is the priority of MSTI0.

Vector Name	Description
Internal Path Cost (IRPC)	The path cost of this bridge to reach the regional root. The internal path cost stored by the regional edge port is greater than the internal path cost stored by the non-regional edge port.
Specify switch device ID	The designated switching device of the CIST or MSTI instance is the nearest upstream bridge from this bridge to the regional root. If this bridge is the general root or regional root, specify the switching device as itself.
Specify port ID	Specify the port on the switching device that is connected to the root port on this device. Port ID = Priority(4 digits) + Port number(12 digits). The port priority must be an integer multiple of 16.
Receive port ID	The port that received the BPDU. Port ID = Priority(4 digits) + Port number(12 digits). The port priority must be an integer multiple of 16.

- Comparison Principle

Comparing the same vector, the vector with the smallest value has the highest priority.

The priority vector comparison principle is as follows.

First, compare the root swap device ID.

If the root switch device ID is the same, then compare the external path cost.

If the external path cost is the same, then compare the regional root ID.

If the regional root ID is still the same, compare the internal path costs.

If the internal path is still the same, then compare the designated switch ID.

If the designated switch device ID is still the same, then compare the designated port ID.

If the designated port ID is still the same, then compare the receiving port ID.

If the configuration message contained in the BPDU received by the port is better than the configuration message saved on the port, the configuration message originally saved on the port is replaced by the newly received configuration message. The port also updates the global configuration message saved by the switching device. On the contrary, the newly received BPDU is discarded.

- Calculation of CIST

After comparing the configuration messages, select a switching device with the highest priority in the entire network as the root of the CIST. MSTP generates IST through calculation in each MST region; at the same time, MSTP treats each MST region as a single switching device, and generates CST between MST regions through calculation. CST and IST constitute the CIST of the entire switching device network.

- Calculation of MSTI

In the MST region, MSTP generates different spanning tree instances for different VLANs according to the mapping relationship between VLANs and spanning tree instances. Each spanning tree is calculated independently, and the calculation process is similar to that of STP.

Characteristics of MSTI:

Each MSTI calculates its own spanning tree independently and does not interfere with each other.

The spanning tree calculation method of each MSTI is basically the same as that of STP.

The spanning tree for each MSTI can have different roots and different topologies.

Each MSTI sends BPDUs within its own spanning tree.

The topology of each MSTI is determined by command configuration.

The spanning tree parameters can be different for each port on different MSTIs.

Each port can have different roles and states on different MSTIs.

In a network running MSTP protocol, a VLAN packet will be forwarded along the following path:

In the MST region, forward along its corresponding MSTI.

Forwarding along CST between MST regions.

- MSTP handling of topology changes

MSTP topology change processing is similar to RSTP topology change processing, please refer to RSTP topology change processing.

12.1.3.5. Fast Convergence




Figure2- 23 P/A of MSTP Mechanism

As shown in the figure above, in MSTP, the P/A mechanism works as follows:

The upstream device sends a Proposal message requesting fast migration. After the downstream device

receives it, it sets the port connected to the upstream device as the root port, and blocks all non-edge ports. The upstream device continues to send Agreement packets. After the downstream device receives it, the root port changes to the Forwarding state.

The downstream device responds to the Agreement message. After the upstream device receives it, it sets the port connected to the downstream device as the designated port, and the designated port enters the Forwarding state.

12.1.4. Standard Specification

The protocol specifications related to spanning tree are:

- IEEE 802.1D: Media Access Control (MAC) Bridges
- IEEE 802.1w:Part 3: Media Access Control (MAC) Bridges—Amendment 2: Rapid Reconfiguration
- IEEE 802.1s: Virtual Bridged Local Area Networks—Amendment 3: Multiple Spanning Trees

12.2. Configuring

12.2.1. Default Configuration

Parameters	Default
Working mode	RSTP mode
Status	Global disabled, enabled on all ports
Device priority	32768
Port Priority	128
Calculation method of path cost	Dot1t, the IEEE 802.1t standard
Forward Delay Time	1500 centiseconds (15 seconds)
Hello Time	200 centiseconds (2 seconds)
Max Age Time	2000 centiseconds (20 seconds)

12.2.2. Configure STP Mode and Status

- Configure STP Mode

Command	SWITCH(config)# spanning-tree mode <stp rstp mstp>
Description	stp: Spanning tree protocol(IEEE 802.1d) rstp: Rapid spanning tree protocol(IEEE 802.1w) mstp: Multiple spanning tree protocol(IEEE 802.1s) The default is rstp mode. After the mode is switched, the spanning tree protocol is disabled by default and needs to be re-enabled. Global configuration mode.

- Enable Spanning Tree Protocol

Command	SWITCH(config)# spanning-tree enable SWITCH(config)# no spanning-tree enable
Description	Enable/disable STP function; default disabled. Global configuration mode.

12.2.3. Configure STP Election Parameters

- Configure Device Priority

Command	SWITCH(config)# spanning-tree priority <0-61440> SWITCH(config)# no spanning-tree priority SWITCH(config)# spanning-tree instance <1-63> priority <0-61440> SWITCH(config)# no spanning-tree instance <1-63> priority
Description	Configure/delete STP system priority; default 32768. Optional configuration. Global configuration mode.

- Configure Port Priority

Command	SWITCH(config-if)# spanning-tree priority <0-240> SWITCH(config-if)# spanning-tree instance <1-63> priority <0-240>
Description	Configure port STP priority; default 128. Optional configuration. Interface configuration mode.

- Configure Port Path Cost

Command	SWITCH(config-if)# spanning-tree path-cost <1-20000000> SWITCH(config-if)# no spanning-tree path-cost
Description	Configure/reset path cost of port; optional configuration. Interface configuration mode.

12.2.4. Configure Topology Convergence Parameters

- Configure Hello Time

Command	SWITCH(config)# spanning-tree hello-time <1-10> SWITCH(config)# no spanning-tree hello-time
Description	Configure/reset the BPDU packet period, in seconds; the default is 2s. Optional configuration. Global configuration mode.

- Configure Forward-Delay Time

Command	SWITCH(config)# spanning-tree forward-time <4-30> SWITCH(config)# no spanning-tree forward-time
Description	Config/reset STP port forwarding state delay time, in seconds; default is 15s. Optional configuration. Global configuration mode.

- Configure Max-Age Time

Command	SWITCH(config)# spanning-tree max-age <6-40> SWITCH(config)# no spanning-tree max-age
Description	Configure/reset the lifetime of BPDU packets, in seconds; the default is 20s. Optional configuration. Hello Time, Forward-Delay Time, Max-Age Time need to follow the conditions: $2 * (\text{Hello Time} + 1.0 \text{ seconds}) \leq \text{Max-Age Time} \leq 2 * (\text{Forward-Delay} - 1.0 \text{ seconds})$, otherwise it may lead to topology instability. The longest path of the STP/RSTP network is affected by this parameter. The default longest path is 20 devices. When there are more than 20 devices, the configuration needs to be modified (forward-delay 21s, max-age 40s can be configured), the maximum support for the longest path is 40. Global configuration mode.

- Configure Max-Hops

Command	SWITCH(config)# spanning-tree max-hops <1-40> SWITCH(config)# no spanning-tree max-hops
Description	Configure/reset the maximum hop count for BPDU packets; the default is 20. Optional configuration. The longest path of the MSTP network is affected by this parameter. When there are more than 20 devices, the configuration needs to be modified, and the maximum is 40. MSTP is compatible with the max-age function, you need to adjust the max-age parameter at the same time, refer to the corresponding command. Global configuration mode.

12.2.5. Configure Edge Port

- Configure Edge Port

Command	SWITCH(config-if)# spanning-tree <edgeport autoedge> SWITCH(config-if)# no spanning-tree <edgeport autoedge>
Description	Configure/delete the port Edge Port; if configured as edgeport, it means that the device directly connected to the port is not a bridge device and can be forwarded quickly; if configured as autoedge, it means that the port automatically identifies whether it is an edge port according to BPDU; it is disabled by default; Select configuration. Interface configuration mode.

- Open Portfast

Command	SWITCH(config-if)# spanning-tree portfast SWITCH(config-if)# no spanning-tree portfast
Description	Configure/delete port portfast; the port will be forwarded directly after opening portfast. But the Port Fast Operational State will be disabled due to the receipt of BPDUs, so that it can normally participate in the STP algorithm and forwarding; it is disabled by default; optional configuration. Interface configuration mode.

12.2.6. Configure MST Parameters

- Enter MST Configuration Mode

Command	SWITCH(config)# spanning-tree mst configuration
Description	Enter MST configuration mode. Global configuration mode.

- Configure MST VLAN Instance

Command	SWITCH(config-mst)# instance <1-63> vlan VLANID SWITCH(config-mst)# no instance <1-63> vlan VLANID
Description	Configure/delete the association between MST instance and VLAN; optional configuration. MST configuration mode.

- Configure MST Region Name

Command	SWITCH(config-mst)# region NAME SWITCH(config-mst)# no region NAME
Description	Configure/delete MST area name; optional configuration. MST configuration mode.

- Configure MST Version

Command	SWITCH(config-mst)# revision <0-65535>
Description	Configure/delete the MST version number, the default is 0; optional configuration. MST configuration mode.

- Configure MSTI Port

Command	SWITCH(config-if)# spanning-tree instance <1-63> SWITCH(config-if)# no spanning-tree instance <1-63>
Description	Configure/delete port-instance association; optional configuration. By default, when configuring the instance and VLAN relationship, the system will automatically generate port and instance relationship data based on the VLAN and port relationship, and no manual configuration is required. After the instance configuration is ready, if the relationship between ports and VLANs is manually modified, such as adding/exiting all VLANs of an instance to ports, you need to manually maintain the relationship between ports and instances through this command. When there are major configuration changes, it is recommended to automatically generate port and instance data by reconfiguring the instance-VLAN relationship or restarting the device. MST configuration mode.

12.2.7. Configuration Protection Function

- Configure Root Guard

Command	SWITCH(config-if)# spanning-tree guard root SWITCH(config-if)# no spanning-tree guard root
Description	Configure/delete port root guard; when the root guard function is enabled on an interface, the port role on all instances is forced to be the designated port. Once the port receives configuration information with a higher priority, the root guard The function will put the interface into the blocked state; default closed; optional configuration. Interface configuration mode.

- Configure BPDU Guard

Command	SWITCH(config)# spanning-tree portfast bpdu-guard SWITCH(config)# no spanning-tree portfast bpdu-guard SWITCH(config-if)# spanning-tree portfast SWITCH(config-if)# no spanning-tree portfast or: SWITCH(config-if)# spanning-tree bpdu-guard enable SWITCH(config-if)# spanning-tree bpdu-guard disable
Description	Configure/delete BPDU Guard; after the port has BPDU Guard enabled, if a BPDU is received on the port, it will enter the Error-disabled (blocked) state; optional configuration. Interface configuration mode.

- Configure BPDU Filter

Command	SWITCH(config)# spanning-tree portfast bpdu-filter SWITCH(config)# no spanning-tree portfast bpdu-filter SWITCH(config-if)# spanning-tree portfast SWITCH(config-if)# no spanning-tree portfast or: SWITCH(config-if)# spanning-tree bpdu-filter enable
---------	---

	SWITCH(config-if)# spanning-tree bpd-filter disable
Description	Configure/delete BPDU Filter; after the port opens BPDU Filter, it neither sends BPDU nor receives BPDU message; optional configuration. Interface configuration mode.

- Configure TC Notification

Command	SWITCH(config-if)# spanning-tree restricted-tcn SWITCH(config-if)# no spanning-tree restricted-tcn SWITCH(config-if)# spanning-tree instance <1-63> restricted-tcn SWITCH(config-if)# no spanning-tree instance <1-63> restricted-tcn
Description	Configure/reset the topology change notification limit. After configuration, the port will not forward TC BPDUs, nor refresh the address table; optional configuration. Interface configuration mode.

- Configure Error Port Recover Time

Command	SWITCH(config)# spanning-tree errdisable-timeout enable SWITCH(config)# no spanning-tree errdisable-timeout enable SWITCH(config)# spanning-tree errdisable-timeout interval <10-1000000> SWITCH(config)# no spanning-tree errdisable-timeout interval
Description	Configure/reset error port timeout feature. By default, the error port timeout function is not enabled, that is, the error port will never timeout and automatically recover, and must be recovered manually. The timeout unit is seconds, the default is 300 seconds; Optional configuration. Global configuration mode.

12.2.8. Other Optional Configuration

- Configure Transmit-Holdcount

Command	SWITCH(config)# spanning-tree transmit-holdcount <1-10> SWITCH(config)# no spanning-tree transmit-holdcount
Description	Configure/reset the maximum number of BPDUs sent per second; default is 6. Optional configuration. Global configuration mode.

- Configure Link-Type

Command	SWITCH(config-if)# spanning-tree link-type <auto point-to-point shared> SWITCH(config-if)# no spanning-tree link-type
Description	Configure/reset link type, default is auto. Optional configuration. auto: Automatic setting mode based on the duplex capability of link negotiation, full duplex is point-to-point connection. point-to-point: Enable fast forwarding. shared: Fast Forwarding is disabled. Interface configuration mode.

- Configure Protocol Migration Processing

Command	SWITCH# clear spanning-tree detected protocols
Description	Force version checking on all ports. Execution mode.


- Configure Logging

Command	SWITCH(config)# spanning-tree logging SWITCH(config)# no spanning-tree logging
Description	Configure logging. Global configuration mode.

12.3. Examples

12.3.1. Example for Configuring RSTP

Simplified topology:



User P1 goes under S1, P2 goes under S2, P3{ 5> followed by S3;

Requirement description:

When the network is not faulty, the communication between users (ping)is ok

When the network has a single chain failure, the communication between users is still ok

Typical configuration:

S1/S2/S3:

- Enter global configuration mode, configure to use rstp mode, enable stp switch:

Use rstp mode


```
spanning-tree mode rstp
```

Enable stp switch

```
spanning-tree enable
```

12.3.2. Example for Configuring MSTP

Simplified topology:



Requirement description:

Users in the same VLAN communicate normally when the network is normal

Improve network reliability through redundant links; for example, for VLAN 10 20, a single link failure between Switch ABDs does not affect the communication of users under it.

Configuration plan:

The devices belong to the same region, the default 'Default' region is used here, no additional configuration is required

VLAN 20 is a shared vlan and is directly assigned to CST

Instance	VLAN
0	20
1	10
3	30
4	40

Typical configuration:

Switch A :

Configure VLAN and port

```
SWITCH(config)#vlan 10, 20, 30, 40
SWITCH(config)#interface gigabitEthernet0/9
SWITCH(config-if)#switchport mode trunk
SWITCH(config)#interface gigabitEthernet0/10
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 10, 20
SWITCH(config)#interface gigabitEthernet0/11
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20, 30
```

Configure MSTP instance

```
SWITCH(config)#spanning-tree mode mstp
SWITCH(config)#spanning-tree mst configuration
SWITCH(config-mst)#instance 1 vlan 10
SWITCH(config-mst)#instance 3 vlan 30
SWITCH(config-mst)#instance 4 vlan 40
```

Enable MSTP

```
SWITCH(config)#spanning-tree enable
```

Switch B:

Configure VLAN and port

```
SWITCH(config)#vlan 10, 20, 30, 40
```

```
SWITCH(config)#interface gigabitEthernet0/9
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20,30
SWITCH(config)#interface gigabitEthernet0/10
SWITCH(config-if)#switchport mode trunk
SWITCH(config)#interface gigabitEthernet0/11
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 10,20
```

Configure MSTP instance

```
SWITCH(config)#spanning-tree mode mstp
SWITCH(config)#spanning-tree mst configuration
SWITCH(config-mst)#instance 1 vlan 10
SWITCH(config-mst)#instance 3 vlan 30
SWITCH(config-mst)#instance 4 vlan 40
```

Enable MSTP

```
SWITCH(config)#spanning-tree enable
```

Switch C:

Configure VLAN and port

```
SWITCH(config)#vlan 10,20,30,40
SWITCH(config)#interface gigabitEthernet0/9
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20,40
SWITCH(config)#interface gigabitEthernet0/10
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20,30
SWITCH(config)#interface gigabitEthernet0/11
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20,30
```

Configure MSTP instance

```
SWITCH(config)#spanning-tree mode mstp
SWITCH(config)#spanning-tree mst configuration
SWITCH(config-mst)#instance 1 vlan 10
SWITCH(config-mst)#instance 3 vlan 30
SWITCH(config-mst)#instance 4 vlan 40
```

Enable MSTP

```
SWITCH(config)#spanning-tree enable
```

Switch D:

Configure VLAN and port

```
SWITCH(config)#vlan 10,20,30,40
SWITCH(config)#interface gigabitEthernet0/9
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 10,20
SWITCH(config)#interface gigabitEthernet0/10
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 20,40
SWITCH(config)#interface gigabitEthernet0/11
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 10,20
```

Configure MSTP instance

```
SWITCH(config)#spanning-tree mode mstp
SWITCH(config)#spanning-tree mst configuration
SWITCH(config-mst)#instance 1 vlan 10
SWITCH(config-mst)#instance 3 vlan 30
SWITCH(config-mst)#instance 4 vlan 40
```

Enable MSTP

```
SWITCH(config)#spanning-tree enable
```

12.4. Display Information

- View STP status

```
SWITCH# show spanning-tree
```

- View MSTP instance status

```
SWITCH# show spanning-tree mst instance <1-63>
```

13. Configuring MAC Address

13.1. Overview of MAC Address

The MAC address table contains address information that the switch uses to forward traffic between ports. The switch sends packets between any combination of ports, based on the destination address of the received packet. Using the MAC address table, the switch forwards the packet only to the port associated with the destination address. If the destination address is on the port that sent the packet, the packet is filtered and not forwarded.

The MAC address table includes these types of addresses:

Dynamic address: a source MAC address that the switch learns and then ages when it is not in use.

Static address: a manually entered unicast address that does not age and that is not lost when the switch resets.

Filter address: Also a static MAC address, but drop the packet with the specified source or destination unicast filter address.

All addresses are associated with a VLAN. An address can exist in more than one VLAN and have different destinations in each. Each VLAN maintains its own logical address table. A known address in one VLAN is unknown in another until it is learned or statically associated with a port in the other VLAN.

Dynamic addresses are source MAC addresses that the switch learns and then ages when they are not in use. You can change the aging time setting for all VLANs or for a specified VLAN. Setting too short an aging time can cause addresses to be prematurely removed from the table. Then when the switch receives a packet for an unknown destination, it floods the packet to all ports in the same VLAN as the receiving port. This unnecessary flooding can impact performance. Setting too long an aging time can cause the address table to be filled with unused addresses, which prevents new addresses from being learned.

13.2. Configuring

- Changing MAC Address Aging Time

Command	SWITCH(config)# mac-address-table aging-time <0-600> SWITCH(config)# no mac-address-table aging-time
Description	Set the length of time that a dynamic entry remains in the MAC address table. The range is 1 to 600 seconds. The default is 300 seconds. You can also enter 0, which disables aging.

- Adding Static MAC Address Entries

Command	SWITCH(config)# mac-address-table static MAC_ADDR vlan VLANID interface IFNAME SWITCH(config)# no mac-address-table static MAC_ADDR vlan VLANID interface IFNAME
Description	Add a static address to the MAC address table. MAC_ADDR: specify the destination MAC unicast address to add to the address table. Packets with this destination address received in the specified VLAN are forwarded to the specified interface. VLANID: specify the VLAN for which the packet with the specified MAC address is received, Valid VLAN IDs are 1 to 4094. IFNAME: specify the interface to which the received packet is forwarded, Valid interfaces include physical ports or port channels.

- Adding Filter MAC Address Entries

Command	SWITCH(config)# mac-address-table filter MAC_ADDR vlan VLANID SWITCH(config)# no mac-address-table filter MAC_ADDR vlan VLANID
Description	Add a filter address to the MAC address table. VLANID: specify the VLAN for which the packet with the specified MAC address is received, Valid VLAN IDs are 1 to 4094. IFNAME: specify the interface to which the received packet is dropped, Valid interfaces include physical ports or port channels.

- Clearing Dynamic MAC Address Entries

Command	SWITCH# clear mac-address-table dynamic SWITCH# clear mac-address-table dynamic vlan VLANID SWITCH# clear mac-address-table dynamic interface IFNAME
Description	Clear Dynamic Mac Address Entries. Support all, based on vlan or based on interface options.

- Enable/disable Port MAC Address Learning

Mainly used in the following scenarios:

When the network is relatively stable and the MAC addresses of the packets are relatively fixed, the device does not need to continue to learn the MAC addresses of all other packets. At this time, by applying a flow policy, the MAC address learning function is disabled for all traffic classifications under the policy, which can not only save the cost of MAC address entries, but also improve the operation efficiency of the device.

Some illegal users sometimes attack the network by changing the MAC address frequently. At this time, by applying the flow policy, and disabling the MAC address learning function for all traffic classifications under the policy, the device MAC address table caused by such attacks can be avoided. Item overflow problem to protect device performance from being affected.

Command	SWITCH(config-if)# mac-address-table learning disable action (forward drop) SWITCH(config-if)# no mac-address-table learning disable
Description	This command supports physical ports and AP ports, but does not support AP member ports. Disabling the port MAC address learning function. forward: If there is a matching entry in the MAC address table, the packet is forwarded according to the MAC table; if there is no matching entry, the packet is broadcast. discard: If there is a matching entry in the MAC address table, the packet is forwarded according to the MAC table; if there is no matching entry, the packet is discarded. The default port MAC address learning is enabled.

- Port MAC Address Learning Limit

In order to control the number of access users or prevent the MAC address table from being attacked, you can limit the number of MAC addresses that the switch module is allowed to learn, so as to control the number of access users to improve network security.

Command	SWITCH(config-if)# mac-address-table limit maximum MAXIMUM action (forward drop) SWITCH(config-if)# no mac-address-table limit
Description	This command supports physical ports and AP ports, but does not support AP member ports. Configuring the function of limiting the number of learned MAC addresses on a port. MAXIMUM: range <1-32767> forward: After the number of MAC address entries reaches the limit, the packets whose source MAC address is the new MAC address continue to be forwarded, but the MAC address entry is not recorded. discard: After the number of MAC address entries reaches the limit, the packets whose source MAC address is the new MAC address will be discarded.

- Enable/disable VLAN MAC Address Learning

To improve the security of the device, network administrators can specify certain VLANs to only allow packets from certain MAC addresses to pass through. After the MAC address learning function is disabled, the device will no longer learn a new MAC address from this VLAN, so it will not be able to communicate through this VLAN, which enhances the stability and security of the network.

When the MAC address learning function is enabled, it receives Ethernet frames from peripheral devices, parses out the source MAC address, and adds a new entry to the MAC address entry. Later, when the switching module receives the Ethernet frame destined for the destination MAC address, it can directly query the MAC address entry to obtain the correct sending interface, avoiding broadcast.

Command	SWITCH(config)# mac-address-table learning disable vlan VLAN-LIST action (forward drop) SWITCH(config)# no mac-address-table learning disable vlan VLAN-LIST
Description	Disabling the VLAN MAC address learning function. VLAN-LIST: Support single vlan or range mode, for example: 10 or 10-20. forward: If there is a matching entry in the MAC address table, the packet is forwarded according to the MAC table; if there is no matching entry, the packet is broadcast. discard: If there is a matching entry in the MAC address table, the packet is forwarded according to the MAC table; if there is no matching entry, the packet is discarded. The default port MAC address learning is enabled.

- Limit the Number of Learned Addresses on VLAN

In order to control the number of access users or prevent the MAC address table from being attacked, you can limit the number of MAC addresses that the switch module allows to learn in the VLAN, so as to control the number of access users to improve network security.

Command	SWITCH(config-if)# mac-address-table limit vlan VLAN-LIST maximum MAXIMUM action (forward drop) SWITCH(config-if)# no mac-address-table limit vlan VLAN-LIST
Description	Configuring the function of limiting the number of learned VLAN MAC addresses. VLAN-LIST: Support single vlan or range mode, for example: 10 or 10-20. MAXIMUM: range <1-32767>. forward: After the number of MAC address entries reaches the limit, the packets whose source MAC address is the new MAC address continue to be forwarded, but the MAC address entry is not recorded. discard: After the number of MAC address entries reaches the limit, the packets whose source MAC address is the new MAC address will be discarded.

- Turn On/off the Flipping Function

MAC address flapping means that the MAC address learned by one interface on the device is also learned on another interface in the same VLAN, and the MAC address entry learned later overwrites the original entry.

MAC address flapping may be caused by the following reasons:

The network cable of the switch module in the network is incorrectly connected or configured incorrectly to form a ring network, resulting in MAC address drift.

Some illegal users in the network conduct MAC address attacks.

Configuring the MAC address flapping detection function can detect whether all the MAC addresses on the device are flapping. If drift occurs, the drift event will be recorded, and maintenance personnel can locate the fault according to the alarm information.

Command	SWITCH(config)# mac-address-table flapping detect SWITCH(config)# no mac-address-table flapping detect
Description	Configure and enable the MAC address flapping function, which is disabled by default.

- Flapping Detected to Trigger Shutdown

After an interface is configured with a MAC address flapping action, if the system detects that the MAC learned by the interface is flapping, it will shut down the interface.

Whether the port shutdown action is executed depends on whether the Mac-address-table-flapping option of the errdisable module is selected. It is enabled by default.

Command	SWITCH(config)# mac-address-table flapping detect action shutdown SWITCH(config)# no mac-address-table flapping detect action
Description	Configure and enable the MAC address flapping function, which is disabled by default.

- Configure The Number Of Migrations Triggered By Flipping

MAC address migration may be caused by normal unplugging or plugging, or it may be caused by other abnormal reasons such as loops. If the number of MAC address migration exceeds the configured value, it is considered that a flapping event has occurred.

Command	SWITCH(config)# mac-address-table flapping detect times VALUE SWITCH(config)# no mac-address-table flapping detect times
Description	Configure the number of migrations triggered by flipping. VALUE: <1 50>, default value is 5

- Clear the Flapping Record Information

Command	SWITCH# clear mac-address-table flapping
Description	Clear the flapping record information.

13.3. Examples

Example 1: This example shows how to change MAC Address aging time to 60 seconds.

Step1: Enter configuration mode:

```
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
```

Step2: Change MAC Address aging time to 60 seconds.

```
SWITCH(config)#mac-address-table aging-time 60
```

Example 2: This example shows how to add a static MAC Address entry.

Step1: Enter configuration mode:

```
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
```

Step2: Add a static MAC Address entry.

```
SWITCH(config)#mac-address-table static 000E.C6C1.C8AB vlan 1 interface
gigabitEthernet0/1
```

Example 3: This example shows how to add a filter MAC Address entry.

Step1: Enter configuration mode:

```
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
```

Step2: Add a filter MAC Address entry

```
SWITCH(config)#mac-address-table filter 000E.C6C1.C8AB vlan 1
```

Example 4: This example shows how to clear dynamic MAC Address entries.

Step1: Clear MAC Address entries by interface.

```
SWITCH#clear mac-address-table dynamic interface gigabitEthernet0/1
```

13.4. Display Information

- Display MAC Address Table Entries

```
SWITCH#show mac-address-table
VLAN      MAC Address      Type      Ports
-----+-----+-----+-----+
20        0000.0000.0009   filter    drop
20        0000.0000.000a   filter    drop
```

- **Display MAC Address Table Statistics**

```
SWITCH#show mac-address-table count
Static Address Count: 0
Filter Address Count: 2
Dynamic Address Count: 0
```

- **Display MAC Address Learning Configuration Information**

```
SWITCH#show mac-address-table learning
```

Interface	Status	Action

GiE0/4	Disabled	Forward
Vlan 3-6	Disabled	Drop
Vlan 9-10	Disabled	Drop

- **Display MAC Address Limit Configuration Information**

```
SWITCH#show mac-address-table limit
```

Interface	Limit	Action

GiE0/5	1000	Drop
Vlan 20-25	100	forward

- **Display MAC Address Flapping Information**

```
SWITCH#show mac-address-table flapping
```

```
Mac-address-table Flapping Configurations:
```

```
-----
Mac-address-table flapping detect   : Disabled
Mac-address-table flapping times    : 5
Mac-address-table flapping action   : none
-----
```

```
Mac-address-table Flapping entries : 0
```

14. Configuring LLDP

14.1. Overview of LLDP

LLDP (Link Layer Discovery Protocol) provides a standard link layer discovery method, enabling devices of different manufacturers to discover each other in the network and exchange their system and configuration information. LLDP encapsulates the information of the local device (including main capabilities, management address, device identification, interface identification, etc.) in LLDPDU (Link Layer Discovery Protocol Data Unit) It is released to the neighbors directly connected to itself. After receiving the information, the neighbors save it in the form of standard MIB up for the network management system to query and judge the communication status of the link.

LLDPDU

LLDPDU is a data unit encapsulated in the data part of an LLDP message. Before forming an LLDPDU, the device first encapsulates the local information into a TLV format, and then combines several TLVs into one LLDPDU and encapsulates it in the data part of the LLDP packet for transmission.

Figure 1 LLDPDU encapsulation format



As shown in Figure 1, the blue Chassis ID TLV, Port ID TLV, and Time To Live TLV must be carried by each LLDPDU, and the remaining TLVs are optional. Each LLDPDU can carry up to 32 TLVs.

TLV

TLV is the unit that makes up LLDPDU, and each TLV represents a piece of information. The TLVs that LLDP can encapsulate include basic TLVs, 802.1 organization-defined TLVs, 802.3 organization-defined TLVs, and LLDP-MED (Link Layer Discovery Protocol Media Endpoint Discovery, Link Layer Discovery Protocol Media Endpoint Discovery) TLVs.

Basic TLV

Basic TLVs are a set of TLVs that are the basis for network device management. 802.1 organization-defined TLVs, 802.3 organization-defined TLVs, and LLDP-MED TLVs are TLVs defined by standards organizations or other organizations to enhance the management of network devices. Need to choose whether to send in LLDPDU.

Among the basic TLVs, there are several TLVs that are mandatory for implementing the LLDP function, that is, they must be published in the LLDPDU, as shown in Table 1.

Table 1 Basic TLV

TLV name	instruction	Must be published
Chassis ID	Bridge MAC address of the sending device	Yes
Port ID	Identifies the port of the sender of the LLDPDU. If LLDP-MED TLV is carried in LLDPDU, its content is the MAC address of the port; otherwise, its content is the name of the port	Yes
Time To Live	The survival time of this device information on the neighbor device	Yes
End of LLDPDU	The end identifier of the LLDPDU, which is the last TLV of the LLDPDU	no
Port Description	Description of the port	no
System Name	the name of the device	no
System Description	description of the system	no
System Capabilities	The main functions of the system and the function items that have been turned on	no
Management Address	Management address, as well as the interface number and OID (Object Identifier) corresponding to the address	no

802.1 Organization-Defined TLV

The content of TLV defined by IEEE 802.1 organization is shown in Table2.

Currently, the devices do not support sending Protocol Identity TLV and VID Usage Digest TLV, but can receive these two types of TLVs.

Layer 3 Ethernet interfaces only support Link Aggregation TLVs.

Table2 IEEE 802.1Organization defined TLV

TLV name	instruction
Port VLAN ID (PVID)	Port VLAN ID
Port and protocol VLAN ID (PPVID)	Port Protocol VLAN ID
VLAN Name	The name of the VLAN to which the port belongs
Protocol Identity	The type of protocol supported by the port
DCBX	Data Center Bridging Exchange Protocol
EVB module	(Not currently supported) Edge Virtual Bridging module, including EVB TLV and CDCP (S-Channel Discovery and Configuration Protocol, S-Channel Discovery and Configuration Protocol) TLV. For the detailed introduction of these two TLVs, please refer to "EVB Configuration Guide"
Link Aggregation	Whether the port supports link aggregation and whether link aggregation is enabled
Management VID	management VLAN
VID Usage Digest	Data containing a summary of VLAN ID usage
ETS Configuration	Enhanced Transmission Selection configuration
ETS Recommendations	Enhanced transfer selection recommendation
PFC	Priority-based Flow Control
APP	Application Protocol
QCN	(Not currently supported) Quantized Congestion Notification

802.3 Organization-Defined TLV

The content of TLV defined by Table3.

The Power Stateful Control TLV was defined in the IEEE P802.3at D1.0 version, and later versions no longer support this TLV. The device will only send this type of TLV after receiving the Power Stateful Control TLV.

Table3 IEEE 802.3Organization defined TLV

TLV name	instruction
MAC/PHY Configuration/Status	The rate and duplex status supported by the port, whether it supports port rate auto-negotiation, whether the auto-negotiation function is enabled, and the current rate and duplex status
Link Aggregation	Whether the port supports link aggregation and whether link aggregation is enabled
Power Via MDI	The power supply capability of the port, including the type of PoE (Power over Ethernet) (including PSE (Power Sourcing Equipment) and PD (Powered Device)), the remote power supply mode of the PoE port, Whether PSE power supply is supported, whether PSE power supply is enabled, whether the power supply mode is controllable, power supply type, power source, power priority, PD requested power value, and PSE allocated power value
Maximum Frame Size	Maximum frame length supported by the port

TLV name	instruction
Power Stateful Control	Power status control of ports, including the type of power used by the PSE/PD, the priority of supplying/receiving power, and the power supplied/received
Energy-Efficient Ethernet	Energy Efficient Ethernet

management address

The management address is an address for the network management system to identify and manage network devices. The management address can clearly identify a device, which facilitates the drawing of network topology and facilitates network management. The management address is encapsulated in the Management Address TLV of the LLDP packet and advertised.

LLDP Mode

Under the specified type of LLDP proxy, LLDP has the following four working modes:

- TxRx: Both send and receive LLDP packets.
- Tx: Only sends and does not receive LLDP packets.
- Rx: only receives and does not send LLDP packets.
- Disable: Neither sends nor receives LLDP packets.

When the LLDP working mode of the port changes, the port will initialize the protocol state machine. To prevent the port from continuously performing initialization operations due to frequent changes in the working mode of the port, you can configure the port initialization delay time.

Protocol Specification

The protocol specifications related to LLDP are:

- IEEE 802.1AB-2005: Station and Media Access Control Connectivity Discovery.
- IEEE 802.1AB 2009: Station and Media Access Control Connectivity Discovery.
- ANSI/TIA-1057: Link Layer Discovery Protocol for Media Endpoint Devices.
- IEEE Std 802.1Qaz-2011: Media Access Control (MAC) Bridges and Virtual Bridged Local Area Networks-Amendment 18: Enhanced Transmission Selection for Bandwidth Sharing Between Traffic Classes.

14.2. Configuring

14.2.1. Configuring Switch and Operating Mode

- Enabling/disabling the LLDP Function Globally

Command	SWITCH(config)# lldp run SWITCH(config)# no lldp run
Description	Global configuration mode. Enable/disable LLDP function. required.

- Entering LLDP Interface Proxy Configuration Mode

Command	SWITCH(config-if)# lldp -agent SWITCH(lldp-agent)# exit
Description	Interface configuration mode. Enter the LLDP interface proxy configuration mode. Optional.

- Configuring the Working Mode of an LLDP Interface

Command	SWITCH(lldp-agent)# lldp enable { rxonly txonly txrx } SWITCH(lldp-agent)# lldp disable
Description	LLDP interface proxy configuration mode. Configure the working mode of the LLDP interface. Optional.

14.2.2. Configuring Optional Basic Parameter

- Configuring System Name

Command	SWITCH(config)# lldp system-name NAME SWITCH(config)# no lldp system-name
Description	Global configuration mode. Configure/reset the system name. Optional.

- Configuring System Descriptor

Command	SWITCH(config)# lldp system-description LINE SWITCH(config)# no lldp system-description
Description	Global configuration mode. Configure /reset system descriptors. Optional.

- Configuring the Device Locally-assigned

Command	SWITCH(config)# lldp chassis locally-assigned NAME SWITCH(config)# no lldp chassis locally-assigned
Description	Global configuration mode. Configure/reset the device locally-assigned . Optional.

- Configuring Interface Locally-assigned

Command	SWITCH(config-if)# lldp locally-assigned NAME SWITCH(config-if)# no lldp locally-assigned
Description	Interface configuration mode. Configure/reset the interface locally-assigned . Optional.

- Configuring Interface Proxy Cable Identification

Command	SWITCH(config-if)# lldp agt-circuit-id VALUE SWITCH(config-if)# no lldp agt-circuit-id
Description	Interface configuration mode. Configuration/reset interfaceagt-circuit-id.can be used as a value for port-id-tlv. Optional.

- Configuring Interface Port Descriptor

Command	SWITCH(config-if)# lldp port-description LINE SWITCH(config-if)# no lldp port-description
Description	Interface configuration mode. Configure/reset interface port descriptors. Optional.

- Configuring the Device ID Type of LLDP Interface

Command	SWITCH(lldp-agent)# lldp chassis-id-tlv { if-alias if-name ip-address locally-assigned mac-address } SWITCH(lldp-agent)# no lldp chassis-id-tlv
Description	LLDP interface proxy configuration mode. Configure the device identification type of the LLDP interface. Optional.

- Configuring the Management Address Type of LLDP Interface

Command	SWITCH(lldp-agent)# lldp management-address-tlv { ip-address mac-address } SWITCH(lldp-agent)# no lldp management-address-tlv
Description	LLDP interface proxy configuration mode. Configure the management address type of the LLDP interface. Optional.

- Configuring the Port ID Type of LLDP Interface

Command	SWITCH(lldp-agent)# lldp port-id-tlv { agt-circuit-id if-alias if-name ip-address locally-assigned mac-address } SWITCH(lldp-agent)# no lldp port-id-tlv
Description	LLDP interface proxy configuration mode. Configure the port ID type of the LLDP interface. Optional.

14.2.3. Configuring Optional State Machine Parameter

- Configuring the MsgTxHold Parameter of an LLDP Interface

Command	SWITCH(lldp-agent)# lldp msg-tx-hold <1-100> SWITCH(lldp-agent)# no lldp msg-tx-hold
Description	LLDP interface proxy configuration mode. This variable is used as a multiplier for msgTxInterval to determine the value of txTTL carried in LLDP frames transmitted by the LLDP proxy. The default msgTxHold is 4. Administrators can change this value to any value in the range 1 to 100. TTL = msgTxInterval * msgTxHold + 1 . Optional.

- Configuring the TxFastInit Parameter of the LLDP Interface

Command	SWITCH(lldp-agent)# lldp tx-fast-init <1-8> SWITCH(lldp-agent)# no lldp tx-fast-init
Description	LLDP interface proxy configuration mode. This variable is used as the initial value of the txFast variable. This value determines the number of LLDPDUs transmitted during the fast transmission period. The default value of txFastInit is 4. Administrators can change this value to any value between 1 and 8. Optional.

- Configuring the TxCredit Parameter of the LLDP Interface

Command	SWITCH(lldp-agent)# lldp tx-max-credit <1-8> SWITCH(lldp-agent)# no lldp tx-max-credit
Description	LLDP interface proxy configuration mode. Configure the maximum value of txCredit. The default value is 5. Administrators can change this value to any value in the range 1 to 10. Optional.

- Configuring the msgFastTx Parameter of the LLDP Interface

Command	SWITCH(lldp-agent)# lldp timer msg-fast-tx <1-3600> SWITCH(lldp-agent)# no lldp timer msg-fast-tx
Description	LLDP interface proxy configuration mode. This variable defines the time interval of the timer interval between two transfers in a fast transfer period (i.e. txFast is not zero). The default value for msgFastTx is 1; administrators can change this value to any value between 1 and 3600. Optional.

- Configuring the MsgTxInterval Parameter of the LLDP Interface

Command	SWITCH(lldp-agent)# lldp timer msg-tx-interval <5-3600> SWITCH(lldp-agent)# no lldp timer msg-tx-interval
Description	LLDP interface proxy configuration mode. This variable defines the timer interval between normal transfers (i.e. txFast is zero). The default value for msgTxInterval is 30 s; admin can change this value to any value between 5 and 300. Optional.

- Configuring the ReinitDelay Parameter of an LLDP Interface

Command	SWITCH(lldp-agent)# lldp timer reinit-delay <1-10> SWITCH(lldp-agent)# no lldp timer reinit-delay
Description	LLDP interface proxy configuration mode. This parameter represents the amount of delay between when adminStatus becomes "disabled" and when reinitialization is attempted. The default value of reinitDelay is 2 s. Optional.

14.2.4. Configuring Send Tlv List

- Configuring Tlv Selection for LLDP Interfaces

Command	SWITCH(lldp-agent)# [no] lldp tlv-select basic-mgmt { management-address port-description system-capabilities system-description system-name } SWITCH(lldp-agent)# [no] lldp tlv-select ieee-8021-org-specific { link-agg mgmt-vid port-ptcl-vlanid port-vlanid ptcl-identity vid-digest vlan-name } SWITCH(lldp-agent)# [no] lldp tlv-select ieee-8023-org-specific { mac-phy max-mtu-size }
---------	---

Description	LLDP interface proxy configuration mode. tlvs can be selected with multiple commands. Optional. Note: When there are many VLAN configurations on the device, the VLAN-related tlv may cause the packet length to exceed the MTU, resulting in packet sending errors. It is necessary to configure not to send this type of tlv.
-------------	--

14.3. Examples

14.3.1. LLDP Basic Function Configuration Example


Requirements

NMS (Network Management System, network management system) is connected to Switch A, and Switch A is connected to the Terminal device and Switch B respectively.

By configuring the LLDP function on Switch A and Switch B, the NMS can judge the communication status of the link between Switch A and the terminal device, and between Switch A and Switch B.

Network diagram

Figure2 LLDP basic function configuration network diagram



Typical configuration example

Switch A/B:

```
Lldp run
```

14.4. Display Information

- Display the Status of the LLDP Interface

```
#show lldp interface gigabitEthernet0/2
```

```

Agent Mode : Nearest bridge
Enable (tx/rx): Y/Y
Message fast transmit time:1
Message transmission interval: 30
Reinitialisation delay: 2
MED Enabled:Y
Device Type: NOT_DEFINED
LLDP Agent traffic statistics:
Total frames transmitted: 4608
Total entries aged: 0
Total frames received: 150
Total frames received in error: 0
Total frames discarded: 0
Total discarded TLVs: 0
Total unrecognised TLVs: 0
  
```

- Show LLDP Interface Neighbors

```
#show lldp interface gigabitEthernet0/2 neighbor
```

```

Nearest bridge Neighbors
Interface Name : gigabitEthernet0/2
System Name :
System Description :
Port Description :
TTL: 3601
System Capabilities : Routing
Mandatory TLVs :
  
```

CHASSIS ID TYPE :
Chassis MAC Address: 000e.c6c1.3841
PORT ID TYPE :
Port MAC Address: 000e.c6c1.3841
8021 ORIGIN SPECIFIC TLV
Port Vlan id :0
PP Vlan id :0
Remote Protocols Advertised :
Remote VID Usage Digest : 0
Remote Management Vlan : 0
Link Aggregation Status : Disabled
Link Aggregation Port ID : 0
8023 ORIGIN SPECIFIC TLV
AutoNego Support : Supported Enabled
AutoNego Capability : 1
Operational MAU Type : 0
Max Frame Size : 0
MED Capabilities : Capabilities
MED Capabilities Dev Type : End Point Class-1
MED Application Type : Reserved
MED Vlan id : 0
MED Tag/Untag: Untagged
MED L2 Priority : 0
MED DSCP Val : 0

15. Configuring LOOP-DETECT

15.1. Overview of LOOP-DETECT

LOOP-DETECT is an Ethernet loop detection protocol, which is used to quickly detect loop faults on downlink interfaces. If a fault is found, LOOP-DETECT will notify the user to manually close or automatically close the relevant port according to the fault handling method configured by the user, so as to avoid affecting the normal data exchange.

Enable control: Enable control is divided into global enable control and port enable control. When the global enable control is enabled and the loop detection is enabled on the port, the port supports the loop detection function.

Loop action: When a loop fault is detected on the port, the user will be notified to manually handle the loop fault by default, and the automatic closing of the port can also be configured. When the port is automatically shut down, the port can recover from the fault by waiting for timeout, shutdown/no shutdown port, recovery command, or restarting the device.

Specify vlan: By default, the port vlan attribute is ignored; if you need to detect whether a loop fault occurs in a specific vlan domain, you can configure the specified vlan on the port, and only detect Whether there is a loop data path in this vlan domain.

The device supports loop fault alarm and loop fault recovery message traps to the snmp server, which is disabled by default.

15.2. Configuring

15.2.1. Enable LOOP-DETECT Globally

Command	SWITCH(config)# loop-detect enable SWITCH(config)# no loop-detect enable
Description	Enable the LOOP-DETECT function globally. Disabled by default.

15.2.2. Enable LOOP-DETECT On Interface

Command	SWITCH(config-if)# loop-detect enable SWITCH(config-if)# no loop-detect enable
Description	Enable the LOOP-DETECT Function Based on Ports. Disabled by default. Supports physical ports and AP ports, does not support AP members.

Note:

◆ For a port in the block state, the protocol considers that there is no possibility of a loop. Even if the port is enabled for loop detection, the actual function cannot run normally. In an environment where stp and erps are enabled, a similar situation may exist. It is recommended to make the function mutually exclusive in the configuration.

15.2.3. Configure Port Loop Action

Command	SWITCH(config-if)# loop-detect action (alarm error-down) SWITCH(config-if)# no loop-detect action
Description	Configure port loop action. Alarm: print alarm information. Error-down: print alarm information and shut down the port at the same time. The default action is alarm.

15.2.4. Specify Vlan Domain To Detect

Command	SWITCH(config-if)# loop-detect vlan VID SWITCH(config-if)# no loop-detect vlan VID SWITCH(config-if)# no loop-detect vlan
Description	Detect whether a data path loop occurs in the specified vlan domain. VID supports single vlan mode and range mode, such as 10-12, separated by "," in the middle. A port can specify up to 8 vlans. By default, if no vlan is specified, the port vlan attribute will be ignored. If the port is in the block state, the data path is considered to be blocked.

15.2.5. Set Packet Sending Interval

Command	SWITCH(config)# loop-detect interval SECONDS SWITCH(config)# no loop-detect interval
---------	---

Description	Configure the interval for sending loop detection packets. SECONDS: range 5-300, default 5, unit second.
-------------	---

15.2.6. Set Error-down Recovery Time

Command	SWITCH(config)# errdisable timeout (interval SECONDS enable disable) SWITCH(config)# no errdisable timeout interval
Description	Configure errdisable recovery time. SECONDS: range 10-1000000, unit second. Enable: enable errdisable recovery. Disable: disable errdisable recovery. The default time is 300 seconds. The time is shared by all errdisable applications, configuring this parameter will affect other applications.

15.2.7. Error-down Recovery

Recovery interface from errdisable status. If errdisable timeout is disabled, this command will not work, please use shutdown and no shutdown commands to recovery interface.

Command	SWITCH# errdisable recovery interface IFNAME
Description	Recovery Interface to normal.

15.2.8. Enable Trap

Command	SWITCH(config)# loop-detect trap enable SWITCH(config)# no loop-detect trap enable
Description	Enable trap loop fault occurrence and loop fault recovery messages to the snmp server. Disabled by default.

Definition of loop alarm trap node:

Node	Data
Mib files	DK-LDET-MIB.my
oid	1, 3, 6, 1, 4, 1, 57430, 1, 6, 2,1
lindex	port index

Definition of loop alarm recovery trap node:

Node	Data
Mib files	DK-LDET-MIB.my
oid	1, 3, 6, 1, 4, 1, 57430, 1, 6, 2,2
lindex	port index

15.3. Examples

Case 1: Configure port gi0/1 to enable the loop detection function, and configure the action to err-down.

```
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH(config)#loop-detect enable
SWITCH(config)#interface gigabitEthernet 0/1
SWITCH(config-if)# loop-detect enable
SWITCH(config-if)# loop-detect action error-down
```

When port gi0/1 detects a loop, it prompts the following information and shuts down the port.

```
LOOPDETECT-4: %Loop error detected on interface GigabitEthernet 0/1.set
interface err-down.
```

Case 2: Configure port gi0/1 to perform loop detection in the vlan10 domain.

```
SWITCH#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
SWITCH(config)#vlan 10
SWITCH(config)#loop-detect enable
SWITCH(config)#interface gigabitEthernet 0/1
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)# loop-detect enable
SWITCH(config-if)# loop-detect vlan 10
```

The port gi0/1 sends loop detection messages with tag and vid is 10. If a loop is detected in the vlan10 domain, the log information is output. if peer interface not allow vlan10, no loop detected.

```
LOOPDETECT-4: %Loop error detected on interface GigabitEthernet 0/1.
```

Case 3: Configure port gi0/1 to enable loop detection, enable trap, and configure the snmp server 192.168.64.1.

```
SWITCH#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
SWITCH(config)#snmp-server group public v2c read all write all
SWITCH(config)#snmp-server community public
SWITCH(config)#snmp-server host 192.168.64.1 traps v2c community public
SWITCH(config)#loop-detect enable
SWITCH(config)# loop-detect trap enable
SWITCH(config)#interface gigabitEthernet 0/1
SWITCH(config-if)# loop-detect enable
```

When port gi0/1 detects a loop, the snmp server receives the loop alarm trap information.

15.4. Display Information

15.4.1. Display LOOP-DETECT Information

```
SWITCH#show loop-detect
Global configuration:
  Loop-detect State           : Enabled
  Loop-detect Interval        : 5
  Loop-detect trap            : Enabled

Interface gigabitEthernet 0/1:
  Loop-detect State           : Enabled
  Loop-detect Action          : Alarm
  Loop-detect Action Last     : Normal
  Loop-detect Action Last Time : --
  Loop-detect Action Count    : 0
  Loop-detect Vlans           : 10, 20, 30-32
```

Analysis of the information:

Global Information	
Loop-detect State	Global enable status, Enabled or Disabled
Loop-detect Interval	Interval for sending loop detection packets, in seconds
Loop-detect trap	Whether to enable the alarm message trap to the server, Enabled or Disabled
Interface Information	
Loop-detect State	Interface enable status, Enabled or Disabled
Loop-detect Action	Action after loop detection, support alarm and error-down
Loop-detect Action Last	The last time a failure occurred: Normal: normal Alarm: output alarm Error-down: The port is down
Loop-detect Action Last Time	Time of last failure: No failures have occurred:-- Happened, for example: 2022-01-10 22:45:23
Loop-detect Action Count	Count of failures
Loop-detect Vlans	Loop packet specified vlan list

16. Configuring GVRP

16.1. Overview of GVRP

16.1.1. Introduction to GVRP

GVRP (GARP VLAN Registration Protocol) is a protocol for dynamically propagate VLAN attributes, and is an application of GARP (Generic Attribute Registration Protocol). It registers and propagates VLAN attributes through the GARP protocol, and implements dynamic creation and deletion of VLANs on the 802.1Q Trunk port.

16.1.2. Introduction to GARP

GARP provides a mechanism to assist members in the same switching network to distribute, propagate and register information such as VLANs and multicast addresses. The application entities following the GARP protocol are called GARP applications. Currently the main GARP applications are GVRP and GMRP. GVRP is a GARP application. It can dynamically configure and diffuse VLAN attributes, and realize dynamic automatic registration, log out of VLANs on 802.1Q Trunk ports.

GMRP (GARP Multicast Registration Protocol) is another GARP application. It mainly provides a restricted multicast diffusion function similar to the IGMP detection technology.

The GARP protocol is defined in 802.1D.

16.1.3. Port Registration Mode

There are three port registration modes of GVRP: Normal, Fixed and Forbidden:

Normal mode: Allow the port to dynamically register and log out of VLAN, and propagate dynamic VLAN and static VLAN information.

Fixed mode: Port is prohibited from dynamically registering and deregistering VLANs, and only transmits static VLAN information, not dynamic VLAN information. That is to say, the Trunk port set to Fixed mode, even if all VLANs are allowed to pass, the VLANs actually passed only those manually configured.

Forbidden mode: Port is prohibited from dynamically registering and deregistering VLAN, and does not propagate any VLAN information except VLAN1.

16.1.4. Messages and Timers

GARP **message**
The information exchange between GARP members is accomplished by means of message transmission. There are three main types of messages that work: Join messages, Leave messages, and LeaveAll messages.

When a GARP application entity wants other devices to register its own attribute information, it will send a Join message to the outside; when it receives a Join message from other entities or the device has statically configured some attributes and needs other GARP application entities to register, The Join message will also be sent out.

When a GARP application entity wants other devices to log out its own attribute information, it will send a Leave message to the outside; when it receives a Leave message from other entities to log off some attributes or statically log off some attributes, it will also send a Leave message to the outside information.

After each GARP application entity is started, it will start the LeaveAll timer at the same time. When the timer expires, the GARP application entity will send a LeaveAll message to the outside. The LeaveAll message is used to cancel all attributes, so that other GARP application entities can re-register with this entity.

The Join message, Leave message and LeaveAll message cooperate to ensure the re-registration or cancellation of information.

Through message exchange, all attribute information to be registered can be propagated to all devices configured with GARP in the same LAN.

GARP

Timer

The time interval for sending GARP messages is implemented through timers. GARP defines four timers for controlling the sending period of GARP messages.

Hold timer: When the GARP application entity receives the registration information sent by other devices, it will not immediately send the registration information as a Join message, but start the Hold timer. When the timer expires, the GARP application entity will All registration information received during this period is sent out in the same Join message, thereby saving bandwidth resources.

Join timer: The GARP application entity can send each Join message twice to ensure the reliable transmission of the message. When the Join message sent for the first time is not answered, the GARP application entity will send the Join message for the second time . The time interval between sending two Join messages is controlled by the Join timer.

Leave timer: When a GARP application entity wishes to cancel certain attribute information, it will send a Leave message to the outside world, and the GARP application entity that receives the message starts the Leave timer, and if it does not receive the Join message before the timer expires, it will log out The attribute information.

LeaveAll timer: After each GARP application entity starts, it will start the LeaveAll timer at the same time. When the timer expires, the GARP application entity will send a LeaveAll message to the outside, so that other GARP application entities can re-register all attribute information on this entity . Then start the LeaveAll timer again to start a new cycle.

16.1.5. Packet Format

GVRP protocol packets are encapsulated in Ethernet frames, and the packet format is shown in the figure below.




Table GVRP Ethernet packet field meaning:

Packet field	Bytes	Field meaning
Protocol ID	2	Protocol ID, Fixed 0x0001
Message	N	Message content, support N messages
Attribute type	1	Attribute type, GVRP fixed bit 0x01
Attribute list	N	Attribute list, consisting of multiple attributes and end mask
Attribute	N	attribute content
Attribute length	1	attribute content length
Attribute event	1	Events: 0x0:LeaveAll Event 0x1:JoinEmpty Event 0x2:JoinIn Event 0x3:LeaveEmpty Event 0x4:LeaveIn Event 0x5:Empty Event
Attribute value	N	Attribute value
End mask	1	End mask, fixed 0x00

16.2. Configuring

16.2.1. GVRP Enable Control

- Global Enable GVRP

Command	SWITCH(config)# gvrp enable SWITCH(config)# no gvrp enable
Description	Globally enable the GVRP function By default, the global GVRP function is disabled

- Port Enable GVRP

Command	SWITCH(config-if)# gvrp enable SWITCH(config-if)# no gvrp enable
Description	Enable the GVRP function on the interface By default, GVRP is disabled on an interface The GVRP function on the interface takes effect only when GVRP is enabled both on the interface and globally.

16.2.2. Set registration Mode

Command	SWITCH(config-if)# gvrp registration (fixed forbidden normal) SWITCH(config-if)# no gvrp registration
Description	Normal mode: Allow the interface to dynamically register and deregister VLANs, and propagate dynamic and static VLAN information. Fixed mode: This interface is prohibited from dynamically registering and deregistering VLANs, and only propagates static VLAN information, not dynamic VLAN information. That is to say, the Trunk interface set to the fixed mode, even if all VLANs are allowed to pass, the VLANs that actually pass can only be those manually configured. Forbidden mode: This interface is prohibited from dynamically registering and deregistering VLANs, and does not propagate any VLAN information to the outside world.

16.2.3. Set Timers

Command	SWITCH(config)# gvrp timer (join leave leaveall) CENTISEC SWITCH(config)# no gvrp timer
---------	--

Description	Set the value of the GARP timer Join: range <20 32765>, default 20, unit centisecond, required to be less than or equal to 1/3 Leave timer value Leave: range <20 32765>, default 60, unit centiseconds, required to be greater than or equal to 3 times the value of the join timer, less than the value of the leaveall timer Leaveall: range <20 32765>, default 1000, unit centisecond, required to be greater than Leave timer value
-------------	--

Note

◆ In the case of multiple devices on the entire network, the value of the LeaveAll timer of each device may be different, but each device will send the LeaveAll message based on the smallest LeaveAll timer on the entire network. Because the LeaveAll message is sent every time the LeaveAll timer expires, other devices will clear the LeaveAll timer after receiving it, so even if there are many different LeaveAll timers on the entire network, only the smallest LeaveAll timer takes effect.

16.2.4. Clear Statistics


Command	SWITCH#clear gvrp statistics [interface IFNAME)
Description	Clear port event statistics Without interface parameter, clear all ports With interface parameter, clear a specific port

16.3. Examples

16.3.1. Typical Cases

Case requirements:

SW1, SW2, SW3, and SW4 are connected through trunk ports. There are static VLANs 10-20 on SW1 and SW4, and SW2 and SW3 are required to learn these VLANs automatically without manual configuration. Enable GVRP globally and on the interfaces of each SW to realize dynamic registration and update of VLAN information between devices.



Steps:

SW1 configuration:

```
SWITCH(config)#Vlan 10-20
SWITCH(config)#gvrp enable
SWITCH(config)#interface gigabitEthernet 0/9
SWITCH(config-if)switchport mode trunk
SWITCH(config-if)gvrp enable
```

SW2 configuration:

```
SWITCH(config)#gvrp enable
SWITCH(config)#interface gigabitEthernet 0/9-10
SWITCH(config-if)switchport mode trunk
SWITCH(config-if)gvrp enable
```

SW3 configuration:

```
SWITCH(config)#gvrp enable
SWITCH(config)#interface gigabitEthernet 0/9-10
SWITCH(config-if)switchport mode trunk
SWITCH(config-if)gvrp enable
```

SW4 configuration:

```
SWITCH(config)#Vlan 10-20
SWITCH(config)#gvrp enable
SWITCH(config)#interface gigabitEthernet 0/9
SWITCH(config-if)switchport mode trunk
SWITCH(config-if)gvrp enable
```

Verify configuration results:
Execute show gvrp vlan command on SW2 and SW3, and it shows that gi0/9 and gi0/10 have dynamically learned vlan 10-20.
Execute show vlan all command on SW2 and SW3, and it shows that gi0/9 and gi0/10 belong to vlan 10-20.

16.4. Display Information

16.4.1. Display GVRP Status Information

```
SWITCH#show gvrp status
GVRP Global Information:
  Global State       : Enabled
  Join Timer         : 20 centisec
  Leave Timer        : 60 centisec
  LeaveAll Timer     : 1000 centisec

GVRP Port Based Information:
Interface           State      Registration Mode
-----
gigabitEthernet0/3 Enabled   normal
pol                 Enabled   normal
```

Displayed message definition:

GVRP Global Information:	Global Configuration Status Information
Global State	Global state, Enabled or Disabled
Join Timer	Join timer value
Leave Timer	Leave timer value
LeaveAll Timer	Leaveall timer value
GVRP Port Based Information:	Port configuration status information, the default status port is ignored and not displayed
Interface	Interface name
State	Port status, Enabled or Disabled
Registration Mode	Port registration mode, Normal, Fixed, Forbidden

16.4.2. Display GVRP VLAN Information

```
SWITCH#show gvrp vlan
Interface gigabitEthernet0/3:
  Static Vlan List   : 1
  Dynamic Vlan List  : 15-21
  Allow Vlan List    : all

Interface pol:
  Static Vlan List   : 1
  Dynamic Vlan List  : 1000-2000
  Allow Vlan List    : all

SWITCH#show gvrp vlan interface gigabitEthernet 0/3
Interface gigabitEthernet0/3:
  Static Vlan List   : 1
  Dynamic Vlan List  : 15-21
  Allow Vlan List    : all
```

Displayed message definition:

Static Vlan List	Static vlan list supported by the port
Dynamic Vlan List	Dynamic vlan list supported by the port
Allow Vlan List	port allow vlan list

16.4.3. Display GVRP Statistics

```
SWITCH#show gvrp statistics
Interface           Received      Transmitted    Drop
-----
gigabitEthernet0/3 1462120      7202490        0
pol                 7181418      1790511        0
```

Displayed message definition:

Interface	Interface name
Received	Receive GVRP attribute number
Transmitted	Send GVRP attribute number
Drop	Number of discarded GVRP attributes

```
SWITCH#show gvrp statistics interface gigabitEthernet 0/3
Interface gigabitEthernet0/3:
  Received Valid Attributes      : 1017
```

```

Transmitted Attributes           : 1
Drop Invalid Attributes         : 0
Received JoinEmpty Attributes   : 14
Received JoinIn Attributes      : 2
Received Empty Attributes       : 1001
Received LeaveEmpty Attributes  : 0
Received LeaveIn Attributes     : 0
Received LeaveAll Attributes    : 0
Transmitted JoinEmpty Attributes : 1
Transmitted JoinIn Attributes   : 0
Transmitted Empty Attributes    : 0
Transmitted LeaveEmpty Attributes : 0
Transmitted LeaveIn Attributes  : 0
Transmitted LeaveAll Attributes : 0

```

Displayed message definition:

Received Valid Attributes	The total number of valid Attributes received
Transmitted Attributes	The total number of Attributes transmitted
Drop Invalid Attributes	The total number of Attributes dropped
Received JoinEmpty Attributes	The number of JoinEmpty Attributes received
Received JoinIn Attributes	The number of JoinIn Attributes received
Received Empty Attributes	The number of Empty Attributes received
Received LeaveEmpty Attributes	The number of LeaveEmpty Attributes received
Received LeaveIn Attributes	The number of LeaveIn Attributes received
Received LeaveAll Attributes	The number of LeaveAll Attributes receiveds
Transmitted JoinEmpty Attributes	The number of JoinEmpty Attributes sent
Transmitted JoinIn Attributes	The number of JoinIn Attributes sent
Transmitted Empty Attributes	The number of Empty Attributes sent
Transmitted LeaveEmpty Attributes	The number of LeaveEmpty Attributes sent
Transmitted LeaveIn Attributes	The number of LeaveIn Attributes sent
Transmitted LeaveAll Attributes	The number of LeaveAll Attributes sent

17. Configuring Voice VLAN

17.1. Voice VLAN Overview

17.1.1. Introduction to Voice VLAN

Voice VLAN is a VLAN divided for users' voice data streams. By creating a Voice VLAN and adding the ports connected to voice devices to the Voice VLAN, users can centrally transmit voice data in the Voice VLAN, making it easier to configure QoS (Quality of Service) for voice streams, improve the transmission priority of voice traffic, and ensure call quality.

17.1.2. Speech Stream Recognition

To classify voice data streams into voice VLAN, the switching device must first be able to identify voice data. There are several ways to identify voice data:

- Identify voice data by using the OUI field

The source MAC address of the voice packet contains the OUI information of the voice device manufacturer. After the voice VLAN OUI is configured, the voice VLAN OUI is compared with the source MAC address of the received packet to identify the voice data packet and classify it into the voice VLAN for transmission.

- VLAN Tag carried in the packet

If a large number of IP phones are connected to the switch, configuring the OUI of the IP phones will be very cumbersome. You can configure the switch based on VLAN to increase the priority of voice packets. At this time, the device will determine whether the data packet is a voice packet based on the VLAN ID of the packet entering the interface. When the VLAN ID matches the voice VLAN configured by the system, it is considered to be a voice data stream.

When a large number of IP phones are connected, the configuration can be simplified.

- Automatically identify voice devices through the LLDP protocol

When there are a large number of IP phones in the network, it will be very complicated to configure the OUI of the voice device. If the IP phone supports LLDP (Link Layer Discovery Protocol), when the IP phone goes online, it will actively send LLDP messages. This device can capture the LLDP protocol messages sent by the IP phone, identify the device capability field in the protocol message, and identify the device with the capability of "Telephone" as a voice device. Then the source MAC in the protocol message is extracted and processed as the voice device MAC, thereby realizing automatic identification of the voice device.

If the LLDP voice VLAN policy is configured, this device can also capture the LLDP message sent by the IP phone, fill the voice VLAN information in the relevant fields and send it to the IP phone, and the IP phone will obtain the voice VLAN ID of this device. If the IP phone supports sending tagged messages, it will add the VLAN Tag when sending voice messages. When this device receives the tagged message sent by the IP phone, it will compare the VLAN Tag and the voice VLAN ID. If they are the same, it will identify this message as a voice data message.

The automatic identification of voice devices through the LLDP protocol is not currently supported.


17.1.3. Working Mode

17.1.3.1. OUI-based Working Mode

The voice data is identified by the OUI field. As long as the packet OUI matches the MAC address specified by the Voice VLAN, the CoS and DSCP fields of the packet are changed. The OUI-based Voice VLAN has two working modes: automatic and manual. The main difference lies in the different ways of adding ports to the Voice VLAN.

- Automatic mode

The most common connection method is to connect the PC-IP phone in series to the switch port. In this case, the port needs to transmit voice data and ordinary business data at the same time. When transmitting voice data, the port automatically joins the Voice VLAN.



Tagged packet
OUI: 0011.2200.0000
MASK:FFFF.FF00.0000

The working process of Voice VLAN automatic mode:


Initial status: Port gi0/1 is a trunk/hybrid port and is removed from the Voice VLAN.

Port join VLAN: Identify the source MAC address of the received message and compare it with the voice OUI address. If the OUI matches successfully, it is identified as a voice message. The device automatically adds the input port of the voice message to the Voice VLAN and transmits the voice message in the Voice VLAN.

Aging out of VLAN: Use the aging mechanism to maintain the ports in the Voice VLAN. After the MAC address of the voice message ages, if the port does not receive any voice message after a certain aging time, the port will be automatically deleted from the Voice VLAN.


■ Manual Mode

When an IP phone is connected to a port alone, because the port only needs to transmit voice packets, the manual mode can be used at this time, and the administrator can manually configure the port to join or delete it from the Voice VLAN. This networking method can make the port dedicated to transmitting voice data, avoiding the impact of business data on voice data transmission.



Untagged packet
 OUI: 0011.2200.0000
 MASK:FFFF.FF00.0000

17.1.3.2. VLAN-based Working Mode



The implementation principle of VLAN-based Voice VLAN is as follows: after receiving the message from PC and VoIP telephone, the switch will determine whether the VLAN ID of the message is the same as the Voice VLAN ID configured on the interface. If they are the same, the data flow is considered to be a voice data flow and the priority is increased. The untagged message sent by PC will be added with the VLAN Tag of PVID. Therefore, VLAN-based Voice VLAN requires that the VoIP telnetphone can manually specify the VLAN ID or support obtaining the Voice VLAN information configured on the switch to change the VLAN ID of the message it sends.

17.1.4. Security Mode

After a port is added to a voice VLAN, the device no longer checks the source MAC address of each message. In theory, all messages can be transmitted in the voice VLAN. Therefore, the device may be attacked by malicious messages, affecting normal voice communication in the voice VLAN. In order to better separate the transmission of user voice streams and data streams, Voice VLAN provides a security mode function. When the security mode is enabled, Voice VLAN only allows the transmission of voice streams; the device checks the source MAC addresses of the packets one by one. When the source MAC address of the packet matches the Voice VLAN OUI address, the packet is allowed to be transmitted in the Voice VLAN, otherwise it is discarded.

17.2. Configuring

17.2.1. Configuring a Port to Enable Voice VLAN

Command	SWITCH(config-if)# voice-vlan VID [include-all] SWITCH(config-if)# no voice-vlan
Description	Enable the Voice VLAN Function on a Port VID: The value range is 2~4094 . VLAN 1 cannot be set as Voice VLAN Include-all: is only supported in MAC-based manual mode. After configuration, the VLAN ID of the message matching the OUI will be forcibly changed to the VLAN ID corresponding to the Voice VLAN The Voice VLAN function is disabled on the port by default Before configuring Voice VLAN, you must first create the corresponding VLAN

17.2.2. Configuring the Voice VLAN Working Mode of a Port

Command	SWITCH(config-if)# voice-vlan remark-mode {vlan mac-address {auto manual}} SWITCH(config-if)# no voice-vlan remark-mode
Description	Set the port voice VLAN working mode vlan: Identify voice traffic based on VLAN information in the VLAN Tag in the message mac-address auto : Automatic mode based on OUI identification mac-address manual: manual mode based on OUI identification Port default VLAN mode

17.2.3. Configuring Voice VLAN OUI

Command	SWITCH(config)# voice vlan mac-address OUI mask OUI-MASK [description TEXT] SWITCH(config)# no voice vlan mac-address OUI
---------	--

Description	Configuring an OUI Address OUI: Format xxxx.xxxx.xxxx OUI-MASK: format xxxx.xxxx.xxxx The OUI address cannot be a multicast address. The configured mask must be continuous and cannot be all 0 TEXT: Descriptor configuration, length cannot exceed 64
-------------	---

17.2.4. Configuring the Voice VLAN CoS Value

Command	SWITCH(config)# voice vlan cos <0-7> SWITCH(config)# no voice vlan cos
Description	Voice VLAN voice flow CoS value, the value range is 0~7, the default value is 5 After configuring the CoS value, the priority takes effect according to the CoS value, and the DSCP value takes effect according to the corresponding value mapped by the CoS value.

17.2.5. Configuring the Voice VLAN DSCP Value

Command	SWITCH(config)# voice vlan dscp <0-63> SWITCH(config)# no voice vlan dscp
Description	DSCP value of voice VLAN voice traffic, ranging from 0 to 63, with a default value of 46 After configuring the DSCP value, the priority takes effect according to the DSCP value, and the CoS value takes effect according to the corresponding value mapped by the DSCP value By default, the DSCP value takes effect

17.2.6. Set the Voice VLAN Aging Time

In automatic mode, after the MAC address corresponding to the voice packet ages, if the device still does not receive any voice packet from the input port after a period of aging time, the port will be deleted from the Voice VLAN.

Command	SWITCH(config)# voice vlan aging <5-10000> SWITCH(config)# no voice vlan aging
Description	The Voice VLAN aging time is calculated from the last packet matching the MAC address configured in the OUI entering the port . The value range is 5 to 10000 , unit: minutes , and the default value is 1440 The aging time is only effective in automatic mode and has no meaning in other modes

17.2.7. Configuring the Voice VLAN Security Mode


Command	SWITCH(config-if)# voice-vlan security enable SWITCH(config-if)# no voice-vlan security enable
Description	Enable port-based voice VLAN security mode This mode is disabled by default. When enabled, only packets with source MAC addresses that match the Voice VLAN OUI address are allowed to be transmitted within the Voice VLAN. Otherwise, they are discarded The security mode can only be configured in the OUI-based working mode

17.3. Examples

17.3.1. VLAN-based Voice Flow Recognition Mode

Requirements:

SWITCH connects data services and voice services in the downstream. SWITCH uses VLAN 10 to transmit voice packets and VLAN 20 to transmit data packets. VoIP telephone A and PC A are connected to SWITCH in series, and VoIP telephone B is connected to SWITCH alone. VoIP telephone sends tagged voice packets. Users are sensitive to voice call quality and need to increase the transmission priority of voice data streams to ensure user call quality.



```

SWITCH(config)#interface gigabitEthernet 0/1
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk native vlan 20
SWITCH(config-if)#voicevlan 10
SWITCH(config-if)#mls qos trust dscp
SWITCH(config)#interface gigabitEthernet 0/2
SWITCH(config-if)#switchport access vlan 10
SWITCH(config-if)#voicevlan 10
SWITCH(config-if)#mls qos trust dscp
SWITCH(config)#interface gigabitEthernet 0/12
SWITCH(config-if)#switchport mode trunk

```

Check the configuration results:

```

SWITCH#show voice vlan
Voice VLAN aging time: 1440 minutes
Voice VLAN dscp : 46 (effect)
PORT VLAN MODE SECURITY

```

```


-----
gigabitEthernet0/1 10 VLAN false
gigabitEthernet0/2 10 VLAN false

```

17.3.2. Voice Stream Automatic Recognition Mode

Requirements:

SWITCH connects data services and voice services downstream. SWITCH uses VLAN 10 to transmit voice packets and VLAN 20 to transmit data packets. VoIP telephone A and PC A are connected to SWITCH in series, and VoIP telephone B is connected to SWITCH alone. VoIP telephone sends tagged voice packets. Users are sensitive to voice call quality and need to increase the transmission priority of voice data streams to ensure user call quality.



Configure SWITCH:

```

SWITCH(config)# mls qos enable
SWITCH(config)# vlan 10
SWITCH(config)# vlan 20
SWITCH(config)# voice vlan mac-address 0011.2200.0000 mask ffff.ff00.0000
SWITCH(config)# voice vlan mac-address 0011.3300.0000 mask ffff.ff00.0000
SWITCH(config)#interface gigabitEthernet 0/1
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk native vlan 20
SWITCH(config-if)#switchport trunk allowed vlan 1-9,11-4094
SWITCH(config-if)#voice vlan remark-mode mac-address auto
SWITCH(config-if)#voicevlan 10
SWITCH(config-if)#mls qos trust dscp
SWITCH(config-if)#interface gigabitEthernet0/2
SWITCH(config-if)#switchport mode trunk
SWITCH(config-if)#switchport trunk allowed vlan 1-9,11-4094
SWITCH(config-if)#voice vlan remark-mode mac-address auto
SWITCH(config-if)#voicevlan 10
SWITCH(config-if)#mls qos trust dscp
SWITCH(config-if)#interface gigabitEthernet 0/1 2
SWITCH(config-if)#switchport mode trunk

```

View the configuration results:

```

SWITCH#show voice vlan
Voice VLAN aging time: 1440 minutes
Voice VLAN dscp : 46 (effect)
PORT VLAN MODE SECURITY

```


```
gigabitEthernet0/1 10 MAC AUTO false
gigabitEthernet0/2 10 MAC AUTO false
SWITCH#show voice vlan oui
OUI Mask Description
```

```
-----
0011.2200.0000 ffff.ff00.0000
0011.3300.0000 ffff.ff00.0000
```

17.3.3. Manual Voice Recognition Mode

Requirements:

SWITCH connects data services and voice services downstream. SWITCH uses VLAN 10 to transmit voice packets and VLAN 20 to transmit data packets. VoIP telephone A and PC A are connected to SWITCH in series, and VoIP telephone B is connected to SWITCH alone. VoIP telephone sends untagged voice packets. Users are sensitive to voice call quality and need to increase the transmission priority of voice data streams to ensure user call quality.



Configure SWITCH:

```
SWITCH(config)# mls qos enable
SWITCH(config)# vlan 10
SWITCH(config)# vlan 20
SWITCH(config)# voice vlan mac-address 0011.2200.0000 mask ffff.ff00.0000
SWITCH(config)# voice vlan mac-address 0011.3300.0000 mask ffff.ff00.0000
SWITCH(config)# interface gigabitEthernet 0/1
SWITCH(config-if)# switchport mode trunk
SWITCH(config-if)# switchport trunk native vlan 20
SWITCH(config-if)# voice vlan remark-mode mac-address manual
SWITCH(config-if)# voice vlan 10 include-all
SWITCH(config-if)# mls qos trust dscp
SWITCH(config-if)# interface gigabitEthernet 0/2
SWITCH(config-if)# switchport access vlan 10
SWITCH(config-if)# voice vlan remark-mode mac-address manual
SWITCH(config-if)# voice vlan 10
SWITCH(config-if)# mls qos trust dscp
SWITCH(config-if)# interface gigabitEthernet 0/12
SWITCH(config-if)# switchport mode trunk
```

View the configuration results:

```
SWITCH#show voice vlan
Voice VLAN aging time: 1440 minutes
Voice VLAN dscp : 46 (effect)
PORT VLAN MODE SECURITY
```

```
-----
gigabitEthernet0/1 10 MAC MANUAL false
gigabitEthernet0/2 10 MAC MANUAL false
SWITCH#show voice vlan oui
OUI Mask Description
```

```
-----
0011.2200.0000 ffff.ff00.0000
0011.3300.0000 ffff.ff00.0000
```

17.4. Display Information

17.4.1. Display Voice VLAN Information

```
SWITCH#show voice vlan
Voice VLAN aging time: 1440 minutes
Voice VLAN dscp : 46 (effect)
```

PORT VLAN MODE SECURITY

```
gigabitEthernet0/1 10 MAC MANUAL false
gigabitEthernet0/2 10 MAC MANUAL false
```

Meaning of the displayed information:

Voice VLAN aging time	The aging time of the VLAN in the voice VLAN automatic mode of the port
Voice VLAN dscp	DSCP value configured for voice VLAN
Voice VLAN cos	CoS value configured for the voice VLAN
PORT	Port Name
VLAN	Voice VLAN of port settings
MODE	Voice VLAN mode of the port settings VLAN: VLAN mode MAC AUTO: Automatic mode MAC MANUAL : Manual mode
SECURITY	Safe Mode false: Not enabled true: Enable

17.4.2. Display Voice VLAN OUI Information

```
SWITCH#show voice vlan oui
OUI Mask Description
```

```
0011.2200.0000 ffff.ff00.0000
0011.3300.0000 ffff.ff00.0000
```

Meaning of the displayed information:

OUI	OUI address of voice packets
Mask	Voice message mask
Description	Descriptors

18. Configuring VLAN Classifier

18.1. VLAN Classifier Function Overview

VLAN classifier is a general term for the function of statically configuring port VLAN functions , which can classify and map VLAN based on the MAC /IP/PROTOCOL of the port ingress packet .

Port-based VLAN is the simplest VLAN division method. Users can divide the ports on the device into different VLANs. After that, the packets received from a certain port can only be transmitted in the corresponding VLAN, thereby achieving the isolation of broadcast domains and the division of virtual workgroups.

The port-based VLAN configuration is fixed after configuration is completed, and cannot be flexibly changed in the case where terminals often migrate between different switch ports and devices.

For such scenarios, the VLAN classifier function can identify and divide based on the terminal's MAC /IP or the PROTOCOL of different services, making the configuration more flexible.

MAC VLAN : Match the source MAC of the inbound packet and forward it to the specified VLAN .

IP VLAN : matches the source IP of the inbound packet and forwards it to the specified VLAN .

Protocl VLAN: Match the Protocol type of the inbound packet and forward it to the specified VLAN .

18.2. Configuring

- Create/Delete MAC-based VLAN Classifier Rules

Com man d	SWITCH(config)# vlan classifier rule ID Mac MAC_ADDR vlan VLAN ID SWITCH(config)# no vlan classifier rule ID
Des crip tion	ID: rule ID, value range is 1-256 MAC_ADDR : Configure the source MAC address of the MAC VLAN , in the format of HHHH.HHHH.HHHH VLANID : Range 1-4094

- Create/Delete IP-based VLAN Classifier Rules

Com man d	SWITCH(config)# vlan classifier rule ID ipv4 IPADDR/MASKLEN vlan VLAN ID SWITCH(config)# no vlan classifier rule ID
Des crip tion	ID: rule ID, value range is 1-256 IPADDR/MASKLEN : Configure the source IP and mask of the IP VLAN . The format is ABCD/M VLAN ID: Range 1-4094

- Create/Delete PROTOCOL-based VLAN Classifier Rules

Com man d	SWITCH(config)# vlan classifier rule ID proto {ip ipv6 arp ipx ETYPE} encap {ethv2 snapllc nosnapllc} vlan VLAN ID SWITCH(config)# no vlan classifier rule ID
Des crip tion	ID: rule ID, value range is 1-256 ETYPE: custom protocol number ip: IP protocol , protocol number 0x0800 ipv6 : IP v 6 protocol , protocol number 0x86dd arp: Address Resolution Protocol, protocol number 0x0806 ipx: IPX protocol , protocol number 0x8137 ethv2: Ethernet V2 snapllc: IEEE 802.3 SAP Ethernet frame, fixed DSNAP is 0xaa, SSAP is 0xaa, Ctrl is 0x3 nosnapllc: IEEE 802.3 SAP Ethernet frame, SSNAP/SSNAP/Ctrl non-fixed value VLAN ID: Range 1-4094

- Configure VLAN Classifier Groups

Com man d	SWITCH(config)# vlan classifier group GID {add del} rule ID
Des crip tion	GID : Group ID , range is 1-16 ID : Rule ID, the rule ID specified when configuring the rule .

- Applying VLAN Classifier Groups

Com man d	SWITCH(config)# interface IFNAME SWITCH(config-if)# vlan classifier activate GID
-----------------	---


Description	Enter the Ethernet port mode and apply the VLAN classifier group to the port. GID : Group ID , that is, the classifier group configured through the VLAN classifier group configuration command.
-------------	---

Notice

- ◆ VLAN classifier groups are not supported on AP ports and AP member ports.
- ◆ VLAN classifier groups are not supported on access ports.
- ◆ When the group applied to the interface has IP-based rules, all IP packets entering the interface only query the IP-based rules and ignore the MAC-based rules .
- ◆ If the rules applied to the port include both MAC and PROTOCOL rules , when a packet matches both MAC and PROTOCOL rules , the V ID specified by MAC takes effect.

18.3. Examples

18.3.1. MAC/IP VLAN Configuration Example



A company has Department A and Department B, and the networks between the two departments are isolated through VLAN .

Due to the need for mobile office within the company, some personnel will go to the conference room to hold meetings together, and the static switch configuration cannot meet the needs of frequent location changes.

In this scenario, the MAC /IP VLAN method can be used to allow the switch to flexibly match different VLANs according to the source MAC /IP of the message to achieve the migration of the terminal under different switches while keeping the corresponding business VLAN unchanged .

Configuration Example

Meeting room switch configuration
Create VLANs based on departments

```
SWITCH#configure terminal
SWITCH (config)#vlan 10
SWITCH (config)#vlan 20
SWITCH(config)#int gigabitEthernet 0/1 - 2
SWITCH(config-if)#switchport mode hybrid
SWITCH(config-if)#switchport hybrid untagged vlan 10,20
```

Configuring IP VLAN

```
SWITCH(config)#vlan classifier rule 1 ipv4 192.168.100.0/24 vlan 10
SWITCH(config)#vlan classifier rule 2 ipv4 192.168.200.0/24 vlan 20
SWITCH(config)#vlan classifier group 1 add rule 1
SWITCH(config)#vlan classifier group 1 add rule 2
```


Apply IP VLAN group to the port

```
SWITCH(config)#interface gigabitEthernet 0/1 - 2
SWITCH(config-if)#vlan classifier activate 1
```

- Information

```
SWITCH#show vlan classifier group
vlan classifier group 1 add rule 1
vlan classifier group 1 add rule 2
SWITCH#show vlan classifier interface group
vlan classifier group 1 interface gigabitEthernet0/1
vlan classifier group 1 interface gigabitEthernet0/2
SWITCH#show vlan classifier rule
vlan classifier rule 1 ipv4 192.168.100.0/24 vlan 10
vlan classifier rule 2 ipv4 192.168.200.0/24 vlan 20
```

18.3.2. PROTOCOL VLAN Configuration Example



There are two types of servers in a company, Novell Network server and Windows server . Novell Network server uses IPX protocol , while Windows server uses IP protocol . Department personnel access different servers based on their business needs. In order to improve server processing efficiency and reduce invalid messages, different types of servers need to be isolated through VLAN division. to distinguish them by configuring static VLANs on the switch . In this scenario, you can configure PROTOCOL VLAN to automatically divide VLANs based on services to reduce configuration difficulty.

Configuration Example

- Device Configuration Steps

Create VLANs based on services

```
SWITCH#configure terminal
SWITCH (config)#vlan 10
SWITCH (config)#vlan 20
SWITCH(config)#int gigabitEthernet 0/2
SWITCH(config-if)#switchport access vlan 10
SWITCH(config-if)#exit
SWITCH(config)#int gigabitEthernet 0/3
SWITCH(config-if)#switchport access vlan 20
SWITCH(config-if)#exit
SWITCH(config)#int gigabitEthernet 0/1
SWITCH(config-if)#switchport mode hybrid
SWITCH(config-if)#switchport hybrid untagged vlan 10,20
```

Configuring PROFINET VLAN

```
SWITCH(config)#vlan classifier rule 1 proto ipx encap ethv2 vlan 10
SWITCH(config)#vlan classifier rule 2 proto ip encap ethv2 vlan 20
SWITCH(config)#vlan classifier group 1 add rule 1
SWITCH(config)#vlan classifier group 1 add rule 2
```

Apply the PROTOCOL VLAN group to the port

```
SWITCH(config)#interface gigabitEthernet 0/1
SWITCH(config-if)#vlan classifier activate 1
```

- Information

```
SWITCH#show vlan classifier group
vlan classifier group 1 add rule 1
vlan classifier group 1 add rule 2
SWITCH#show vlan classifier interface group
vlan classifier group 1 interface gigabitEthernet0/1
SWITCH#show vlan classifier rule
vlan classifier rule 1 proto ipx encap ethv2 vlan 10
vlan classifier rule 2 proto ip encap ethv2 vlan 20
```

18.4. Display Information

- Show VLAN Classifier

```
SWITCH#show vlan classifier rule
vlan classifier rule 1 ipv4 1.1.1.1/24 vlan 2
vlan classifier rule 2 ipv4 2.2.2.1/24 vlan 2
SWITCH#show vlan classifier group
vlan classifier group 1 add rule 1
vlan classifier group 1 add rule 2
```

```
SWITCH#show vlan classifier interface group
vlan classifier group 1 interface gigabitEthernet0/24
```

19. Configuring L3

19.1. Overview of L3

L3 functions include: Layer 3 port management, ARP management and Routing management.

- Layer 3 Port Management:

Layer 3 ports are generally divided into routing ports (physical ports switched to Layer 3 ports) or SVI ports (Switch Virtual Interface, corresponding to a VLAN).

The SVI port is a logical interface, which is constructed on top of all the member ports included in the corresponding VLAN, Unlike the routing port, the packets that are forwarded through the SVI at Layer 3 will first pass through Layer 2 (such as VLAN filtering, address learning, etc.) and then go through three layers, and then go through three layers and then two layers when outputting (such as VLAN output rules).

At the network layer, routing devices use IP addresses to complete packet forwarding. (Protocol specification: RFC 1918: Address Allocation for Private Internets, RFC 1166: Internet Numbers).

Layer 3 port management includes IP address maintenance for Layer 3 ports.

An IP address is composed of 32-bit binary. For the convenience of writing and description, it is generally expressed in dotted decimal. When expressed in dotted decimal, it is divided into four groups, each with 8 digits, ranging from 0 to 255. The groups are separated by ".", for example, "192.168.1.1" is the IP address expressed in decimal.

The IP address, as the name suggests, is naturally the interconnection address of the IP layer protocol. A 32-bit IP address consists of two parts:

- 1) the network address part, which indicates which network it is;
- 2) the host address part, which indicates which host in the network.

The network address part and the host address part of the IP address are divided by the network mask. The network mask is also a 32-bit value, consisting of several bits "1" in the front and several bits "0" in the back. The IP address is related to the network.

The mask and the obtained is the corresponding part of the network address. Likewise, the netmask can also be directly represented by the mask length.

For example, "192.168.1.1 255.255.255.0" and "192.168.1.1/24" represent the same IP address.

The device supports the configuration of the second IP address, that is, a Layer 3 port can be configured with at most one IP address.

When a Layer 3 port is configured with an IP address, a network segment is determined.

Different Layer 3 ports of the same device must belong to different network segments, and IP addresses configured with different Layer 3 ports must belong to different network segments.

The Layer 3 port represented by the SVI, and the corresponding VLAN is used as the unique identifier of the Layer 3 port.

After the different Layer 3 ports of the device are divided into different network segments, the forwarding between these different network segments (such as VLAN1 and VLAN2) is called "Layer 3 forwarding" (across network segments, or across different VLANs).

- ARP Management:

In a local area network, each IP network device has two addresses:

- 1) The local address, since it is included in the frame header of the data link layer, should be more precisely the data link layer address, but in fact the local address is processed by the MAC sublayer in the data link layer, Therefore, it is customarily called a MAC address, and a MAC address represents an IP network device on a local area network.

- 2) The network address represents the IP network device on the Internet, and it also indicates the network to which the device belongs.

To communicate between two IP devices on the LAN, they must know each other's 48-bit MAC address. The process of learning the MAC address from the IP address is called address resolution.

There are two types of address resolution methods:

- 1) Address Resolution Protocol (ARP).
- 2) Proxy Address Resolution Protocol (Proxy ARP).

About ARP and Proxy ARP, they are described in RFC 826 and RFC 1027 documents respectively.

ARP (Address Resolution Protocol) is used to bind a MAC address and an IP address. Taking the IP address as an input, ARP can know its associated MAC address. Once the MAC address is known, the IP address to MAC address correspondence is stored in the device's ARP cache. With the MAC address, the IP device can encapsulate the link layer frame, and then send the data frame to the LAN. The encapsulation of IP and ARP on Ethernet is Ethernet II type.

ARP entries are divided into two categories: dynamic entries generated by the ARP protocol and static entries derived from static configuration. Dynamic ARP entries are formed by triggering the opening of IP packets. The opening process is an ARP request/response process. If the ARP entries formed after opening are unreachable, they will automatically age out. Static ARP entries do not need to be opened and will not age out.

- Routing Management:

Routing management is responsible for managing routing tables, integrate routes issued by various routing protocols to select the optimal route.

According to different sources, the routing table is usually divided into the following three categories:

- Directly connected route: The route discovered by the link layer protocol is also called the interface route. A direct route is automatically generated when an IP address is configured on a Layer 3 port, and the route prefix is the network directly connected to the Layer 3 port.
- Static route: manually configured by the network administrator.
- Dynamic routes: routes discovered by dynamic routing protocols (such as RIP, OSPF).

A routing table entry consists of two parts:

- Prefix: It is represented by an IP address and network mask (or mask length), which refers to the destination network or host determined by the routing table entry (when the mask length is 32, it means the host).
- Direct connection or next hop: Direct connection means that the destination network or host belongs to the directly connected network, and the direct connection route belongs to this situation. When configuring a static route, specifying a Layer 3 port instead of an IP address will also generate such a routing table item; the next hop is represented by an IP host address, indicating that to reach the destination network or host, it needs to be forwarded to the IP network device indicated by the IP address.

When forwarding IP packets according to the routing table entry, if the routing table entry specifies the next hop, when the link layer encapsulates the ARP query, the IP of the next hop is used, that is, the destination MAC address of the link layer encapsulation is the next hop. The destination MAC address of the hop. If the routing table entry is directly connected, the destination IP address of the packet is directly used for ARP query, that is, the destination MAC address encapsulated at the link layer is the final destination MAC address of the packet. Either way, if the ARP query fails, the route will be opened (a dynamic ARP entry will be generated). If the connection cannot be made, the IP packet cannot be forwarded and will be discarded. There may be an inclusion relationship between routing table entries (depending on the length of the mask), so the route lookup process satisfies the LPM (Longest Prefix Match). That is, when IP packets are forwarded for route lookup, if multiple routing entries are hit at the same time, the routing entry with the longest prefix mask length is selected.

19.2. Configuring

● Configuring SVI Port IP/IPv6 Address

Command	<p>Configure SVI Port IP: SWITCH(config)#int vlan10 SWITCH(config-if)#ip address IPADDR/MASKLEN [secondary] SWITCH(config-if)#ipv6 address IP(X::X::X/M) Or SWITCH(config-if)#ip address IPADDR MASK [secondary]</p> <p>Delete SVI Port IP: SWITCH(config)#int vlan10 SWITCH(config-if)#no ip address IPADDR/MASKLEN [secondary] SWITCH(config-if)#no ipv6 address IP(X::X::X/M) Or SWITCH(config-if)#no ip address IPADDR MASK [secondary]</p> <p>Show the IP/IPv6 address of the Layer 3 port: SWITCH#show ip interface brief SWITCH#show ipv6 interface brief</p>
Description	<p>Configure in the interface mode of the SVI. When a VLAN is created, the SVI is automatically created, and when the VLAN is deleted, the SVI is automatically deleted. int vlanXX is to enter the interface mode of the SVI. Therefore, when the SVI does not exist (the corresponding VLAN does not exist), entering the interface mode of the SVI will fail. At the same time, when the SVI is deleted, the IP address configured on it will be automatically cleared. Layer 3 ports support IP/IPv6 address configuration update, which has the same effect as deleting and reconfiguring. The IP addresses configured on different Layer 3 ports must belong to different network segments. SVI supports the configuration of the second ip. When configuring the second ip, you need to configure the primary ip first. When deleting the primary ip, if the second ip already exists, you need to delete all the second ip before deleting the primary ip, otherwise it cannot be deleted. Note: After this command is configured, the system will clear the management IP configuration (refer to: Configuring Management IP), and use the Layer 3 port IP address as the device management IP instead.</p>

● Configuring Routing Port IP/IPv6 Address

Command	<p>Configure Routing Port IP: SWITCH(config)#interface gigabitEthernet0/1 SWITCH(config-if)#no switchport SWITCH(config-if)#ip address IP(A.B.C.D/M) [secondary] SWITCH(config-if)#ipv6 address IP(X::X::X/M)</p>
---------	--

	<p>Or SWITCH(config-if)#ip address IP(A.B.C.D) MASK(A.B.C.D) [secondary]</p> <p>Delete Routing Port IP: SWITCH(config)# interface gigabitEthernet0/1 SWITCH(config-if)#no ip address IP(A.B.C.D/M) SWITCH(config-if)#no ipv6 address IP(X::X::X/M) Or SWITCH(config-if)#no ip address IP(A.B.C.D) MASK(A.B.C.D) SWITCH(config-if)#switchport</p>
--	---

Description	<p>Configure in interface mode. Before configuring the routing port IP, since the default attribute of the interface is the Layer 2 port attribute, you need to use the no switchport command to switch the port from the Layer 2 port attribute to the Layer 3 routing port attribute, and then use the ip address command to configure the routing port attribute. IP configuration, otherwise, switch the routing port to the Layer 2 port attribute, use the switchport command. Layer 3 ports support IP address configuration update, which has the same effect as deleting and reconfiguring. The IP addresses configured on different Layer 3 ports must belong to different network segments. The Layer 3 interface supports the configuration of the second ip. When configuring the second ip, you need to configure the primary ip first. When deleting the primary ip, if the second ip already exists, you need to delete all the second ip before deleting the primary ip, otherwise it cannot be deleted.</p>
-------------	---

- Configuring Static ARP Entries

Command	<p>SWITCH(config)#arp IPADDR MACADD SWITCH(config)#no arp IPADDR</p>
---------	--

Description	<p>Configure in global configuration mode. The IP address configured with static ARP must belong to the directly connected network segment, otherwise the configuration fails. Static ARP has a higher priority than dynamic ARP. When the two conflict, static ARP takes effect. When the IP address of the Layer 3 port is deleted or the Layer 3 port is deleted, if the IP address of the static ARP belongs to the directly connected network segment of the Layer 3 port, the static ARP will be invalid (you can see that the entry does not exist through show arp, but show run, you can see that the configuration is still there); Similarly, when a Layer 3 port is configured with an IP address, the ARP entry of the directly connected network segment whose IP address belongs to the Layer 3 port will change from an invalid state to a valid state. (You can see the existence of ARP entries through show arp).</p>
-------------	--

- Clearing ARP Cache

Command	SWITCH# clear arp-cache
---------	--------------------------------

Description	<p>Clear the ARP cache in privileged mode. This Command only clears dynamic ARP entries, and static ARP entries will not be cleared.</p>
-------------	--

- Configuring Static IPv6 Neighbor Entries

Command	<p>SWITCH(config)# ipv6 neighbor IPv6(X::X::X:X) IFNAME MAC(XXXX.XXXX.XXXX) SWITCH(config)#no ipv6 neighbor IPv6(X::X::X:X) IFNAME</p>
---------	--

Description	<p>Configure in global configuration mode. The IPv6 address configured with the static ipv6 neighbor must belong to the directly connected network segment, otherwise the configuration fails. The static ipv6 neighbor has a higher priority than the dynamic ipv6 neighbor. When the two conflict, the static ipv6 neighbor takes effect. When the IPv6 address of the Layer 3 port is deleted or the Layer 3 port is deleted, if the IPv6 address of the static ipv6 neighbor belongs to the directly connected network segment of the Layer 3 port, the static ipv6 neighbor will be invalid (you can see that the table does not exist through show ipv6 neighbors Item, but show run can see that the configuration is still there); Similarly, when a Layer 3 port is configured with an IPv6 address, the ipv6 neighbor entry whose IPv6 address belongs to the directly connected network segment of the Layer 3 port will change from an invalid state to valid state. (You can see that the neighbors table entry exists by show ipv6 neighbors).</p>
-------------	--

- Configuring Static Routes

Command	<p>SWITCH(config)#ip route {IPADDR/MASKLEN} IPADDR MASK} {NH_IPADDR IFNAME} SWITCH(config)#no ip route {IPADDR/MASKLEN IPADDR MASK} {NH_IPADDR IFNAME} SWITCH(config)#ipv6 route [IPv6(X::X::X/M) [NH_IPv6(X::X::X) IFNAME] SWITCH(config)#no ip v6 route [IPv6(X::X::X/M) [IPv6(X::X::X) IFNAME]</p>
---------	---

Description	<p>Configure in global configuration mode.</p> <p>Recursive routing is not supported (the configured next-hop IP must belong to the directly connected network segment);</p> <p>The route prefix cannot belong to the directly connected network segment (that is, the directly connected route is automatically generated and cannot be statically configured).</p> <p>When a Layer 3 port is configured with an IP address, if the prefix of a static routing entry belongs to the directly connected network segment of the Layer 3 port, the static route will be automatically deleted and a LOG prompt will be displayed;</p> <p>When the IP address of a Layer 3 port is deleted or the Layer 3 port is deleted, if the next hop IP of a static routing entry belongs to the directly connected network segment of the Layer 3 port, the static route is automatically deleted and a LOG prompt is displayed.</p>
-------------	--


- **Configuring ECMP**

If there are redundant links in the network environment, that is, there are multiple next hops for the route to the same destination address. On devices that support ECMP technology, multiple next hops can work at the same time, so that redundant links can be fully utilized, and when a link failure occurs on a redundant link, traffic can be switched to other redundant links. Network reliability and stability.

ECMP (Equal-Cost Multipath Routing), this technology enables the device to use multiple next-hop links of the corresponding route concurrently, and balance the traffic among the multiple next-hop links according to the set balance factor distribution; and supports fast switchover of faulty links.

19.3. Examples

Case 1: Weak Layer 3 Gateway



As a weak Layer 3 gateway, the Switch reduces the ARP burden for the real gateway.

- **Configure PC:**

Configure the IP addresses of PC1, PC2 and PC3 as shown in the figure, and specify the gateway at the same time. For example, the gateway of PC1 and P2 is 192.168.1.1.

- **Configure SWITCH:**


- **Configure the Layer 3 port and IP address:** (Assume that the interface connecting PC1-PC4 is gigabitEthernet0/1-4, and the uplink interface is gigabitEthernet0/17)

```
SWITCH(config)#vlan 2-3,100
SWITCH(config)#interface gigabitEthernet0/1-2
SWITCH(config-if)#switch access vlan 2
SWITCH(config)#interface gigabitEthernet0/3-4
SWITCH(config-if)#switch access vlan 3
SWITCH(config)#interface gigabitEthernet0/17
SWITCH(config-if)#switch access vlan 100
SWITCH(config)#int vlan2
SWITCH(config-if)#ip address 192.168.1.1/24
SWITCH(config)#int vlan3
SWITCH(config-if)#ip address 192.168.2.1/24
SWITCH(config)#int vlan100
SWITCH(config-if)#ip address 192.168.100.2/24
```

- **Configure a static route (default route):**

```
SWITCH(config-if) ip route 0.0.0.0/0 192.168.100.1
```

Case 2: Intranet Layer 3 Interconnection



In the network environment shown above, PC1, PC2 and PC3 are interconnected through S1, S2 and S3 respectively.

- Configure PC

Configure the IP addresses of PC1, PC2 and PC3 as shown in the figure, and specify the gateway at the same time. For example, the gateway of PC1 is 192.168.1.1.

- Configure S1

- Configure the Layer 3 port and IP address:

```
SWITCH(config)#vlan 2-4
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#switch access vlan 2
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#switch access vlan 3
SWITCH(config)#interface gigabitEthernet0/3
SWITCH(config-if)#switch access vlan 4
SWITCH(config)#int vlan2
SWITCH(config-if)#ip address 192.168.1.1/24
SWITCH(config)#int vlan3
SWITCH(config-if)#ip address 192.168.12.1/24
SWITCH(config)#int vlan4
SWITCH(config-if)#ip address 192.168.13.1/24
```

- Configure a static route:

```
SWITCH(config)#ip route 192.168.2.0/24 192.168.12.2
SWITCH(config)#ip route 192.168.3.0/24 192.168.11.3
```

- S2 and S3 are configured similarly to S1.

19.4. Display Information

- Show L3 Interface

```
SWITCH#show ip interface brief
Interface      IP-Address      Admin-Status    Link-Status
GiE0/3         10.10.20.1      up               down
vlan10         192.168.65.166 up               up
SWITCH#show ipv6 interface brief
Interface      IPv6-Address    Admin-Status
vlan10         2001:db8:0:f104::1 [up/up]
vlan1000      unassigned      [up/up]
```

- Show ARP Entries

```
SWITCH#show arp
Address          HWAddress        Interface      Type
192.168.1.238    00:00:00:00:04:86  vlan2         Static
192.168.2.46     00:00:00:00:05:45  vlan3         Static
192.168.3.110    00:00:00:00:08:59  vlan4         Static
192.168.0.12     00:00:00:00:00:09  vlan1         Static
192.168.0.1      00:0e:c6:d8:c7:f7  vlan1         Dynamic
10.100.2.2       00:01:a0:00:10:11  GiE0/2        Dynamic
```

- Show IPv6 Neighbor Entries

```
SWITCH #show ipv6 neighbors
IPv6 Address      MAC Address      Interface      Type
ff02::16          3333.0000.0016  vlan10         dynamic
ff02::1:ff00:1    3333.ff00.0001  vlan10         dynamic
```

ff02::1:ff40:251a

3333.ff40.251a vlan10

dynamic

● Show Routing Table Entries

```
SWITCH#show ip route
Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP
       O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter
area
       * - candidate default
IP Route Table for VRF "default"
Gateway of last resort is 192.168.1.3 to network 0.0.0.0
S*    0.0.0.0/0 [1/0] via 192.168.1.3, vlan2
S     192.168.0.0/16 [1/0] via 192.168.0.10, vlan1
C     192.168.0.0/24 is directly connected, vlan1
C     192.168.1.0/24 is directly connected, vlan2
C     192.168.2.0/24 is directly connected, vlan3
C     192.168.3.0/24 is directly connected, vlan4
C     10.100.2.0/30 is directly connected, gigabitEthernet0/2
SWITCH #show ipv6 route
IPv6 Routing Table
Codes: K - kernel route, C - connected, S - static, R - RIP, O - OSPF,
       IA - OSPF inter area, E1 - OSPF external type 1,
       E2 - OSPF external type 2, N1 - OSPF NSSA external type 1,
       N2 - OSPF NSSA external type 2, I - IS-IS, B - BGP
Timers: Uptime

IP Route Table for VRF "default"
C     2001:db8:0:f104::/64 via ::, vlan10, 00:00:56
```

20. Configuring IPv6 Addresses

20.1. Overview of Ipv6 Address

IPv6 (Internet Protocol Version 6) is the second-generation standard protocol of the network layer protocol, also known as IPng (IP Next Generation). It is a set of specifications designed by the Internet Engineering Task Force (IETF) and is an upgraded version of IPv4 (Internet Protocol Version 4).

20.2. IPv6 Address

The total length of an IPv6 address is 128 bits, usually divided into 8 groups, each group is in the form of 4 hexadecimal numbers, and each group of hexadecimal numbers is separated by a colon. For example: FC00:0000:130F:0000:0000:09C0:876A:130B, which is the preferred format of an IPv6 address.

For the convenience of writing, IPv6 also provides a compressed format. Taking the above IPv6 address as an example, the specific compression rules are as follows:

- The leading "0" in each group can be omitted, so the above address can be written as: FC00:0:130F:0:0:9C0:876A:130B.
- Two or more consecutive groups of 0s contained in the address can be replaced by double colons "::", so the above address can be further abbreviated as: FC00:0:130F::9C0:876A:130B.

IPv6 addresses are divided into three types: unicast addresses, anycast addresses, and multicast addresses. Compared with IPv4, the broadcast address type is cancelled and replaced by a richer multicast address, and the anycast address type is added.

20.2.1. IPv6 Unicast Address

An IPv6 unicast address identifies an interface. Since each interface belongs to a node, the unicast address on any interface of each node can identify the node. Messages sent to a unicast address are received by the interface identified by the address.

IPv6 defines multiple unicast addresses. The commonly used unicast addresses are: unspecified address, loopback address, global unicast address, link-local address, and unique local address (ULA).

● Unspecified Address

The unspecified address in IPv6 is 0:0:0:0:0:0:0:0/128 or ::/128. This address can indicate that an interface or node does not have an IP address and can be used as the source IP address of some messages (for example, it will appear in the duplicate address detection of NS messages). Messages with the source IP address of :: will not be forwarded by routing devices.

● Loopback Address

The loopback address in IPv6 is 0:0:0:0:0:0:1:1/128 or ::1/128. The loopback has the same function as 127.0.0.1 in IPv4 and is mainly used for the device to send packets to itself. This address is usually used as the address of a virtual interface (such as a loopback interface). The loopback address cannot be used as the source IP address or destination IP address in the actual data packet sent.

● Global Unicast Address

A global unicast address is an IPv6 address with a global unicast prefix, which acts like a public address in IPv4. This type of address allows aggregation of routing prefixes, thereby limiting the number of global routing table entries.

● Link-local Address

The link-local address is a limited-scope address type in IPv6 and can only be used between nodes connected to the same local link. It uses the specific link-local prefix FE80::/10 (the highest 10 bits are 111111010), and adds the interface identifier as the lower 64 bits of the address.

● Unique Local Address

Unique local addresses are another type of address with limited scope, which can only be used within a site. Due to the deprecation of site-local addresses (RFC3879), unique local addresses are used to replace site-local addresses.


The role of a unique local address is similar to that of a private network address in IPv4. Any organization that has not applied for a global unicast address assigned by a provider can use a unique local address. A unique local address can only be routed and forwarded within a local network and will not be routed and forwarded in the global network.

20.2.2. IPv6 Multicast Address

IPv6 multicast is the same as IPv4 multicast, which is used to identify a group of interfaces, which generally belong to different nodes. A node may belong to 0 or more multicast groups. Messages sent to a multicast address are received by all interfaces identified by the multicast address. For example, the multicast address FF02::1 represents all nodes in the link-local scope, and the multicast address FF02::2 represents all routers in the link-local scope.

An IPv6 multicast address consists of four parts: prefix, flag field, scope field, and multicast group ID:

- Prefix: The prefix of the IPv6 multicast address is FF00::/8.
- Flag field: 4 bits in length. Currently, only the last bit is used (the first three bits must be set to 0). When the value of this bit is 0, it indicates that the current multicast address is a permanent address assigned by IANA. When the value of this bit is 1, it indicates that the current multicast address is a temporary multicast address (non-permanently assigned address).
- Scope field: 4 bits in length, used to limit the range within which the multicast data stream is sent in the network. Figure 9-5 shows the correspondence between the value and meaning of this field.
- Multicast group ID: 112 bits in length, used to identify the multicast group. Currently, RFC2373 does not define all 112 bits as group IDs, but recommends using only the lowest 32 bits of the 112 bits as multicast group IDs, and setting the remaining 80 bits to 0. In this way, each multicast group ID is mapped to a unique Ethernet multicast MAC address (RFC2464).



IPv6 multicast address format

20.2.3. IPv6 Anycast Address

An anycast address identifies a set of network interfaces (usually belonging to different nodes). A packet destined for an anycast address is sent to the network interface that is closest to it in terms of routing.

Anycast addresses are designed to provide redundancy and load sharing when providing the same service to multiple hosts or nodes. Currently, anycast addresses are used by sharing unicast addresses. A unicast address is assigned to multiple nodes or hosts. If there are multiple routes to the address in the network, when the sender sends a datagram with the anycast address as the destination IP, the sender cannot control which device can receive it, which depends on the calculation result of the routing protocol in the entire network. This method can be applied to some stateless applications, such as DNS.

IPv6 does not specify a separate address space for anycast, and anycast addresses and unicast addresses use the same address space. Currently, anycast in IPv6 is mainly used in mobile IPv6.


20.3. IPv6 Message Format

An IPv6 message consists of three parts: an IPv6 basic header, an IPv6 extension header, and an upper-layer protocol data unit.

An upper layer protocol data unit generally consists of an upper layer protocol header and its payload, and the payload may be an ICMPv6 message, a TCP message or a UDP message.

- IPv6 Basic Header

The IPv6 basic header has 8 fields and a fixed size of 40 bytes. Every IPv6 datagram must contain a header. The basic header provides basic information for packet forwarding and will be parsed by all devices on the forwarding path.



IPv6 basic header format

The main fields in the IPv6 header format are explained as follows:

Version: Version number, 4 bits in length. For IPv6, the value is 6.

Traffic Class: Traffic class, 8 bits in length. Equivalent to the TOS field in IPv4, it indicates the class or priority of the IPv6 datagram and is mainly used for QoS.

Flow Label : Flow label, length is 20 bits. A new field in IPv6, used to distinguish real-time traffic. Different flow labels + source addresses can uniquely identify a data flow. Intermediate network devices can distinguish data flows more efficiently based on this information.

Payload Length: Payload length, 16 bits. Payload refers to the other parts of the datagram that follow the IPv6 header (i.e., the extension header and the upper-layer protocol data unit). This field can only represent a payload with a maximum length of 65535 bytes. If the payload length exceeds this value, this

field will be set to 0, and the payload length will be represented by the Extra Large Payload Option in the Hop-by-Hop Options extension header.

Next Header: Next header, length 8 bits. This field defines the type of the first extension header (if any) following the IPv6 header, or the protocol type in the upper-layer protocol data unit.

Hop Limit: Hop limit, length is 8 bits. This field is similar to the Time to Live field in IPv4. It defines the maximum number of hops that an IP datagram can go through. The value is reduced by 1 for each device it passes through. When the value of this field is 0, the datagram will be discarded.

Source Address: Source address, length is 128 bits. Indicates the address of the sender.


Destination Address: Destination address, 128 bits in length, indicating the address of the recipient.

Compared with IPv4, IPv6 removes the IHL, identifiers, Flags, Fragment Offset, Header Checksum, Options, and Padding fields, and only adds the flow label field. Therefore, the processing of the IPv6 message header is greatly simplified compared with IPv4, which improves the processing efficiency. In addition, in order to better support the processing of various options, IPv6 proposes the concept of extended headers. When adding new options, it is not necessary to modify the existing structure. In theory, it can be expanded infinitely, which reflects excellent flexibility.

- **IPv6 Extension Header**

In IPv4, the IPv4 header contains optional fields called Options, which include security, timestamp, and record route. These options can extend the length of the IPv4 header from 20 bytes to 60 bytes. During forwarding, processing IPv4 packets carrying these options will occupy a lot of device resources, so they are rarely used in practice.

IPv6 strips these Options from the IPv6 basic header and puts them into the extension header, which is placed between the IPv6 header and the upper-layer protocol data unit. An IPv6 message can contain 0, 1, or more extension headers. The sender will only add one or more extension headers when the device or destination node needs to do some special processing. Unlike IPv4, the IPv6 extension header can be of any length and is not limited to 40 bytes, which makes it easier to add new options in the future. This feature, coupled with the way options are processed, allows IPv6 options to be truly utilized. However, in order to improve the performance of processing option headers and transport layer protocols, the extension header is always an integer multiple of 8 bytes in length.



IPv6 extension header format

The main fields in the IPv6 extension header are explained as follows:

Next Header: The next header is 8 bits long. It has the same function as the Next Header of the basic header. It indicates the next extension header (if it exists) or the type of the upper layer protocol.

Extension Header Len: Header extension length, 8 bits long. Indicates the length of the extension header (excluding the Next Header field).

Extension Header Data: Extension header data, with variable length. The content of the extension header is a combination of a series of option fields and padding fields.

Currently, RFC 2460 defines six IPv6 extension headers: Hop-by-Hop Options Header, Destination Options Header, Routing Header, Fragmentation Header, Authentication Header, and Encapsulating Security Payload Header.

20.4. Configuration Notes

- IPv6 addresses support one of three methods: static configuration, SLAAC configuration, and RA + DHCPv6 configuration. Multiple addresses cannot be shared.
- ND attributes, including the configuration of receiving the default route, must be configured before the address configuration command, otherwise they will not take effect.
- an interface is configured with an IPv6 static address, the device supports the basic RA route advertisement function.

20.5. Configuring

20.5.1. Interface Configuration Commands

- Configure IPv6 Addresses on Interfaces

Command	SWITCH(config-if)# ipv6 address { dhcp autoconfig X:X::X:X/M } SWITCH(config-if)# no ipv6 address
Description	Configure an IPv6 address for the interface.

- Configure the Interface to Receive RA Advertisements

Command	SWITCH(config-if)# ipv6 nd accept-router SWITCH(config-if)# no ipv6 nd accept-router
Description	Configure the interface receives the default route advertised by RA. Supported only in SLAAC and DHCPv6 modes . Optional. By default, the default route advertised by RA is not received.

- Interface Configuration to Send RA Routing Advertisements

Command	SWITCH(config-if)# no ipv6 nd suppress-ra SWITCH(config-if)# ipv6 nd suppress-ra
Description	The RA route advertisement service can be enabled only when a static IPv6 address is configured on the interface . Optional. RA route advertisement is suppressed/disabled by default.

20.6. Examples

20.6.1. Conventional SLAAC Address Allocation Scenario

- 1) Requirement : Switch S1 dynamically obtains an IPv6 address from R1 through the SLAAC protocol
- 2) Network Diagram



Typical network diagram of SLAAC address allocation

3) Typical Configuration Examples

S1 Configuration :

```
SWITCH(config)#int vlan 1
SWITCH(config-if)# ipv6 nd accept-router
SWITCH(config-if)#ipv6 address autoconfig
```

R1 Configuration :

```
interface VLAN 1
ipv6 address A::A/64
no ipv6 nd suppress-ra
```

20.7. Display Information

- Display Interface IPv6 Address Information

```
SWITCH#show ipv6 interface brief
Interface IPv6-Address      Admin-Status
GiE0/6 *a::76a9:12ff:fe12:312 [up/up]
```

* address is assigned by SLAAC or DHCPv6 client

- Display IPv6 Routing Information

```
SWITCH#show ipv6 route
IPv6 Routing Table
Codes: K - kernel route, C - connected, S - static, R - RIP, O - OSPF,
IA - OSPF inter area, E1 - OSPF external type 1,
E2 - OSPF external type 2, N1 - OSPF NSSA external type 1,
N2 - OSPF NSSA external type 2, I - IS-IS, B - BGP
Timers: Uptime

IP Route Table for VRF "default"
S ::/0 [0/1024] via fe80::c670:abff:fef4:d6df, gigabitEthernet0/6, 00:01:56
C a::/64 via ::, gigabitEthernet0/6, 00:01:56
```

21. Configuring the DHCP Client

21.1. Overview of DHCP Client

DHCP (Dynamic Host Configuration Protocol) is a network protocol for local area networks that uses the UDP protocol and is widely used to dynamically allocate reusable network resources, such as IP addresses.

DHCP is based on the Client/Server working mode. The DHCP client obtains the IP address and other configuration information from the DHCP server by sending a request message. When the DHCP client and the server are not on the same subnet, a DHCP relay agent (DHCP Relay) is required to forward DHCP request and response messages.

21.1.1. Protocol Standards

RFC2132 DHCP Options and BOOTP Vendor Extensions. S. Alexander, R. Droms. March 1997. (Format: TXT, HTML) (Obsoletes RFC1533) (Updated by RFC3442, RFC3942, RFC4361, RFC4833, RFC5494) (Status: DRAFT STANDARD) (DOI: 10.174 87/RFC2132)

21.2. Configuration Notes

- The device interface IPv4 address can be either static IP or DHCP dynamic IP. The two methods are mutually exclusive and cannot be shared.
- This document is limited to IPv4 DHCP client. For IPv6 and DHCPv6 client , please refer to the IPv6 configuration section.

21.3. Configuring

21.3.1. Interface Configuration Commands

- Enable /disable DHCP Client on the Interface

Command	SWITCH(config-if) #ip address dhcp SWITCH(config-if) # no ip address
Description	Enable or disable the DHCP client on the interface .

- Configure DHCP Parameters on the Interface

Command	SWITCH(config- if)# ip dhcp client request routers SWITCH(config- if)# no ip dhcp client request routers
Description	Interface parameter configuration . Configure whether to request and apply the default route of the DHCP server. Enabled by default, optional configuration.

21.4. Examples

21.4.1. Conventional DHCP Server Address Allocation Scenario

- 4) Requirements : The switch is connected to a DHCP server and obtains an IP address dynamically through the DHCP protocol.
- 5) Typical Configuration Examples

Switch configuration:

```
SWITCH(config) #interface vlan1  
SWITCH(config-if)#ip address dhcp
```

DHCP server configuration:

```
service dhcp  
!  
ip dhcp pool a  
network 2.2.2.0 255.255.255.0 2.2.2.10 2.2.2.100
```

- 6) Check the IP address obtained by the switch

```
SWITCH#show ip interface brief  
Interface IP-Address Admin-Status Link-Status  
vlan1 *2.2.2.12 up up  
  
* address is assigned by DHCP client
```

21.5. Display Information

- Display IP Address Allocation

```
SWITCH#show ip interface brief  
Interface IP-Address Admin-Status Link-Status  
vlan1 *2.2.2.12 up up
```

* address is assigned by DHCP client

- **Display the Default Route Assignment**

```
SWITCH#show ip route
```

```
Codes: K - kernel, C - connected, S - static, R - RIP, B - BGP
```

```
O - OSPF, IA - OSPF inter area
```

```
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
```

```
E1 - OSPF external type 1, E2 - OSPF external type 2
```

```
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
```

```
* - candidate default
```

```
IP Route Table for VRF "default"
```

```
Gateway of last resort is 2.2.2.10 to network 0.0.0.0
```

```
S* 0.0.0.0/0 [0/0] via 2.2.2.10, vlan1
```

```
C 2.2.2.0/24 is directly connected, vlan1
```

22. Configuring ACL

22.1. Overview of ACL

The ACL Implement packet filtering by configuring matching rules and processing operations for packets. The ACL can effectively prevent illegal users from accessing the network, and can also control traffic and save network resources.

Packet matching rules defined by ACL can also be referenced by other functions that need to differentiate traffic, such as the definition of traffic classification rules in QoS.

The ACL classifies packets through a series of matching conditions, which can be SMAC, DMAC, SIP, DIP, etc. According to the matching conditions, ACLs can be divided into the following types:

Standard IP-based ACL: Make rules based only on the source IP address of the packet.

Extended IP-based ACL: formulate rules based on the source IP address, destination IP address, ETYPE, and protocol of the data packet.

MAC-based ACL: formulate rules based on the source MAC address and destination MAC address of the data packet.

IPv6-based ACL: develop rules based on the source IPV6 address, destination IPV6 address, protocol, etc. of the data packet.

22.2. Configuring

22.2.1. Configure IP Standard ACL

- Configure IP-based Standard ACL Rules

Command	SWITCH(config)# ip-access-list {<1-99> <1300-1999>} { permit deny } { host SIPADDR SIPADDR SIPADDRMASK any } SWITCH(config)# no ip-access-list {<1-99> <1300-1999>}
Description	Create /delete standard IP-based ACL rules

- Create a Standard IP ACL

Command	SWITCH(config)# ip-access-list standard {<1-99> <1300-1999> NAME} SWITCH(config)# no ip-access-list standard {<1-99> <1300-1999> NAME}
Description	Create/delete standard IP ACL and switch to IP standard ACL mode

- Configure Standard IP ACL Rules

Command	SWITCH(config-std-acl)# [SN] { permit deny } { host SIPADDR SIPADDR SIPADDRMASK any } SWITCH(config-std-acl)# no { permit deny } { host SIPADDR SIPADDR SIPADDRMASK any } SWITCH(config-std-acl)# no SN
Description	Create/delete a standard IP ACL rule SN: Serial number of each rule (1-2147483647)

22.2.2. Configure IP Extended ACL

- Configure IP-based Extended ACL Rules

Command	SWITCH(config)# ip-access-list {<100-199> <2000-2699>} { permit deny } PROTOCOL { host SIPADDR SIPADDR SIPADDRMASK any } [eq SPORT] { host DIPADDR DIPADDRMASK any } [eq DPORT] SWITCH(config)# no ip-access-list {<100-199> <2000-2699>}
Description	Create /delete IP-based extended ACL rules PROTOCOL list: <0-255>: Specify the ID of the protocol any: any protocol message gre: GRE message icmp: ICMP message igmp: IGMP message ip: IPv4 message (0x4) ipcomp: IPComp message ospf: OSPF message pim: PIM message rsvp: RSVP message tcp: TCP message udp: UDP message vrrp: VRRP message

	<p>The eq option is only available for TCP and UDP protocols. For the following port number names, you can use the port number name or port number to specify a specific port: TCP port number list: <0-65535> Specify port number bgp (179) ftp (21) ftp-data (20) Login (513) pop2 (109) pop3 (110) smtp (25) telnet (23) www (80)</p> <p>UDP port number list: <0-65535> Specify port number bootpc (68) boots (67) domain (53) echo (7) rip (520) snmp (161) syslog (514) tftp (69)</p>
--	--

- Create Extended IP ACL

Command	SWITCH(config)# ip-access-list extended {<100-199> <2000-2699> NAME} SWITCH(config)# no ip-access-list extended {<100-199> <2000-2699> NAME}
Description	Create/delete extended IP ACL and switch to IP extended ACL mode

- Configure Extended IP ACL Rules

Command	SWITCH(config-ext-acl)# [SN] { permit deny } PROTOCOL { host SIPADDR SIPADDR SIPADDRMASK any } [eq SPORT] { host DIPADDR DIPADDR DIPADDRMASK any } [eq DPORT] SWITCH(config-ext-acl)# no { permit deny } PROTOCOL { host SIPADDR SIPADDR SIPADDRMASK any } [eq SPORT] { host DIPADDR DIPADDR DIPADDRMASK any } [eq DPORT] SWITCH(config-ext-acl)# no SN
Description	Create/delete an extended IP ACL rule SN: Serial number of each rule (1-2147483647) PROTOCOL list: <0-255>: Specify the ID of the protocol any: any protocol message gre: GRE message icmp: ICMP message igmp: IGMP message ip: IPv4 message (0x4) ipcomp: IPComp message ospf: OSPF message pim: PIM message rsvp: RSVP message tcp: TCP message udp: UDP message vrrp: VRRP message For the following port number names, you can use the port number name or port number to specify a specific port: eq (TCP and UDP only) TCP port number list: <0-65535> Specify port number bgp (179) ftp (21) ftp-data (20) Login (513) pop2(109) pop3(110) smtp (25) telnet (23) www (80) UDP port number list: <0-65535> Specify port number bootpc (68) boots (67)

	domain (53) echo (7) rip (520) snmp (161) syslog (514) tftp (69)
--	---

22.2.3. Configure MAC ACL

- Configure MAC-based ACL Rules

Command	SWITCH(config)# mac-access-list <200-699> { permit deny } { host SMAC SMAC SMACMASK any } { host DMAC DMAC DMACMASK any } [ethertype ETYPE] [cos VALUE] SWITCH(config)# no mac-access-list <200-699>
Description	Create/delete MAC-based ACL rules ethertype: Ethernet protocol type (0x05DD-0xFFFF) cos: priority value of the message (0-7)

- Create MAC ACL

Command	SWITCH(config)# mac-access-list {<200-699> NAME} SWITCH(config)# no mac-access-list {<200-699> NAME}
Description	Create/delete standard MAC ACL and switch to MAC ACL mode

- Configure MAC ACL Rules

Command	SWITCH(config-mac-acl)# [SN] { permit deny } { host SMAC SMAC SMACMASK any } { host DMAC DMAC DMACMASK any } [ethertype ETYPE] [cos VALUE] SWITCH(config-mac-acl)# no { permit deny } { host SMAC SMAC SMACMASK any } { host DMAC DMAC DMACMASK any } [ethertype ETYPE] [cos VALUE] SWITCH(config-mac-ext-acl)# no SN
Description	Create/delete a MAC ACL rule SN: Serial number of each rule (1-2147483647) ethertype: Ethernet protocol type (0x05DD-0xFFFF) cos: priority value of the message (0-7)

22.2.4. Configure IPv6 ACL

- Create IPv6 ACL

Command	SWITCH(config)# ipv6-access-list {NAME} SWITCH(config)# no ipv6-access-list {NAME}
Description	Create/delete IPV6 ACL and switch to IPV6 ACL mode

- Configure IPV6 ACL Rules

Command	SWITCH(config-ipv6-acl)# [SN] { permit deny } [PROTOCOL] {SOURCE-IPV6-PREFIX/PREFIX-LENGTH any host SOURCE-IPV6-ADDRESS} [eq SPORT] {DESTINATION- IPV6-PREFIX / PREFIX-LENGTH any host DESTINATION-IPV6-ADDRESS} [eq DPORT] SWITCH(config-ipv6-acl)# no { permit deny } [PROTOCOL] {SOURCE-IPV6-PREFIX/PREFIX-LENGTH any host SOURCE-IPV6-ADDRESS} [eq SPORT] {DESTINATION- IPV6-PREFIX / PREFIX-LENGTH any host DESTINATION-IPV6-ADDRESS} [eq DPORT] SWITCH(config-ipv6-acl)# no SN
Description	Create/delete an IPV6 ACL rule SN: Serial number of each rule (1-2147483647) PROTOCOL list: <0-255>: Specify the ID of the protocol any: any protocol message icmp: ICMP message tcp: TCP message udp: UDP message For the following port number names, you can use the port number name or port number to specify a specific port: eq (TCP and UDP only) TCP port number list: <0-65535> Specify port number bgp (179)

	ftp (21) ftp-data (20) login (513) pop2 (109) pop3 (110) smtp (25) telnet (23) www (80) UDP port number list: <0-65535> Specify port number biff (512) bootpc (68) boots (67) discard (9) dnsix (195) domain 53) echo (7) Isakmp (500) ntp (123) pim-auto-rp (496) rip (520) snmp (161) snmptrap (162) tftp (69)
--	---

Note

- ◆ Up to 128 rules can be configured under a single ACL-ID;
- ◆ Mask inversion, if it matches an IP address in the 192.168.1.0/24 range, 192.168.1.0 0.0.0.255 should be configured;
- ◆ The name of the ACL can be named, and the first character cannot be a number;
- ◆ MAC ACL does not take effect on IPV6 packets;
- ◆ The final default configuration of each ACL is deny any item;

22.2.5. Other Configuration Items

- Configure ACL Counters

If the user wants to start the packet matching counting function on the access list, please enable it in the access list.

Command	SWITCH(config-std-acl)# counter enable SWITCH(config-std-acl)# no counter enable
Description	Enable / disable ACL counter in all ACL modes

- Clear ACL Counter

Command	SWITCH# clear access-list counter NAME
Description	Clear the ACL count value

- Configure ACL Descriptor

Command	SWITCH(config-std-acl)# description TEXT SWITCH(config-std-acl)# no description
Description	Configure/delete ACL descriptors TEXT: descriptor (up to 64 characters) Configurable in all ACL modes

- Trigger ACL Sequence Number Reordering

SN is the sequence number of the rule entry, and the value range is [1,2147483647]. This sequence number determines the priority of this rule entry in the access list. The smaller the sequence number, the greater the priority. The packet with the higher priority will be matched first. If the sequence number is not specified when configuring the matching rule, the system will automatically Assign a sequence number, the starting value of the sequence number is 10, and the increment value is 10.

Command	SWITCH(config-std-acl)# resequence START STEP SWITCH(config-std-acl)# no resequence
Description	Reorder serial numbers START: starting position (default value: 10, range <1-2147483647>) STEP: step size (default value: 10, range <1-2147483647>)

Configurable in all ACL modes

Note

- ◆ The serial number is unique;
- ◆ When configuring an ACL entry, if the sequence number is not specified, it will be specified in steps after the current maximum sequence number (rules cannot be added if it exceeds the set range);

● Applying ACL to an Interface

Command	SWITCH(config-if)# access-group ACLNAME {in out} SWITCH(config-if)# no access-group ACLNAME {in out}
Description	Configure/delete ACL applied to the port

● Apply ACL to a VLAN

Command	SWITCH(config)# access-group ACLNAME { in out } vlan <1-4094> SWITCH(config-if)# no access-group ACLNAME { in out } vlan <1-4094>
Description	Configure/delete ACL applied to a VLAN

Note

- ◆ When the ACL has been applied to the port or configured as a QOS flow matching rule, if you need to add or delete a rule, you need to first unapply it from the interface or QOS flow matching rule;
- ◆ The aggregation port does not support ACL application in the out direction, and the member ports of the aggregation port do not support ACL application;
- ◆ ACL applications not supported by VLAN interfaces;

22.3. Examples

Case 1: Filter the incoming packets of port gigabitEthernet0/1, release the packets with SIP 192.168.1.0/24, and discard other packets.

● Configure ACL rules:

```
SWITCH(config)#ip-access-list 1 permit 192.168.1.0 0.0.0.255
```

or

```
SWITCH(config)#ip-access-list standard 1  
SWITCH(config-std-acl)#permit 192.168.1.0 0.0.0.255
```

● Apply ACL to port gigabitEthernet0/1

```
SWITCH(config)#interface gigabitEthernet0/1  
SWITCH(config-if)#access-group 1 in
```

Case 2: Filter the entry packets of port gigabitEthernet0/1 and reject the packets sent by the host IP 192.168.1.2 with the packet type TCP and the source port number 40. Other packets will pass.

● Configure ACL rules:

```
SWITCH(config)#ip-access-list 100 deny tcp host 192.168.1.2 eq 40 any  
SWITCH(config)#ip-access-list 100 permit any any any
```

or

```
SWITCH(config)#ip-access-list extended 100  
SWITCH(config-ext-acl)#deny tcp host 192.168.1.2 eq 40 any  
SWITCH(config-ext-acl)#permit any any any
```

● Apply ACL to port gigabitEthernet0/1

```
SWITCH(config)#interface gigabitEthernet0/1  
SWITCH(config-if)#access-group 100 in
```

Case 3: Filter the export packets of port gigabitEthernet0/1 and reject the Ethernet type 0x804 packets sent by the host with MAC 0000.0047.5124. Other packets will pass.

● Configure ACL rules:

```
SWITCH(config)# mac-access-list 200 deny host 0000.0047.5124 any ethertype  
0x804  
SWITCH(config)# mac-access-list 200 permit any any
```

or

```
SWITCH(config)#mac-access-list 200  
SWITCH(config-mac-acl)#deny host 0000.0047.5124 any ethertype 0x804  
SWITCH(config-mac-acl)#permit any any
```

● Apply ACL to port gigabitEthernet0/1

```
SWITCH(config)#interface gigabitEthernet0/1
```

```
SWITCH(config-if)#access-group 200 out
```

Case 4: Filter the ingress packets of port gigabitEthernet0/1 , release the packets with the IPv6 address of the destination host::D0F8:1900:9F51:0000 , and discard other packets.

- Configure ACL rules:

```
SWITCH(config)#ipv6-access-list ip6-acl
```

```
SWITCH(config-ipv6-acl)#permit any any host ::D0F8:1900:9F51:0000
```

- Apply ACL to port gigabitEthernet0/1

```
SWITCH(config)#interface gigabitEthernet0/1
```

```
SWITCH(config-if)#access-group ip6-acl in
```

Case 5: Filter the incoming packets of port gigabitEthernet0/1, release the packets with SIP 192.168. 2. 1, discard other packets , and turn on the counter to view packet statistics .

- Configure ACL rules:

```
SWITCH(config)#ip-access-list standard 1
```

```
SWITCH(config-std-acl)#permit host 192.168.2.1
```

```
SWITCH(config-std-acl)#counter enable
```

- Apply ACL to port gigabitEthernet0/1

```
SWITCH(config)#interface gigabitEthernet0/1
```

```
SWITCH(config-if)#access-group 1 in
```

- port gigabitEthernet0/1 , send 10 packets with SIP 192.168.2.1 and SIP 192.168.2.2, check the packet statistics

```
SWITCH#show access-list 1
ip-access-list standard 1
10 permit host 192.168.2.1(10 match)
deny any (10 match)
```

22.4. Display Information

- Display ACL Information

```
SWITCH#show access-list 1
ip-access-list standard 1
10 permit host 1.1.1.1
deny any
```

```
SWITCH#show access-list 200
mac-access-list 200
10 permit host 0001.0002.0003 any
deny any
```


```
SWITCH#show access-list ip6-acl
ipv6-access-list ip6-acl
10 permit tcp host a::1 eq bgp any
deny any
```

23. Configuring QoS

23.1. Overview of QoS

Typically, networks operate on a best-effort delivery basis, which means that all traffic has equal priority and an equal chance of being delivered in a timely manner. When congestion occurs, all traffic has an equal chance of being dropped. When you configure the QoS feature, you can select specific network traffic, prioritize it according to its relative importance, and use congestion-management and congestion-avoidance techniques to provide preferential treatment. Implementing QoS in your network makes network performance more predictable and bandwidth utilization more effective.

The QoS implementation is based on the Differentiated Services (Diff-Serv) architecture, an emerging standard from the Internet Engineering Task Force (IETF). This architecture specifies that each packet is classified upon entry into the network. The following Figure shows the model of the QoS.



Classification

Classification is the process of distinguishing one kind of traffic from another by examining the fields in the packet. Classification is enabled only if QoS is globally enabled on the switch. By default, QoS is globally disabled, so no classification occurs.

During classification, the switch performs a lookup and assigns a QoS label to the packet. The QoS label identifies all QoS actions to be performed on the packet and from which queue the packet is sent.

The QoS label is based on the DSCP or the CoS value in the packet and decides the queuing and scheduling actions to perform on the packet. The label is mapped according to the trust setting and the packet type.

Trust CoS:

- QoS with CoS label.
- For tagged packets, the CoS uses the CoS information in the tag.
- For packets without tags, the CoS adopts the default CoS value of the port.

Trust DSCP:

- For non-IP packets, the QoS is labeled with CoS; for packets with tags, CoS uses the CoS information in the tag; for packets without tags, the CoS uses the default CoS of the port.
- For IP packets, QoS has a DSCP label; select the DSCP value of the packet.

No trust:

- QoS with CoS label
- CoS adopts the default CoS value of the port.

Policing(Ingress)

The ingress policer meters the given flow and classifies as either in-profile or out-of-profile. Out-of-profile packets may be discarded or have their QoS attributes remarked.

Marking

After a packet is classified and has a DSCP-based or CoS-based QoS label assigned to it, the marking process can begin.

For packets with CoS labels:

- Use the configured CoS-to-DSCP mapping relationship to generate DSCP values for packets.
- Select the egress queue for the packet through the CoS-to-Queue mapping relationship.

For packets with DSCP labels

- Modify the DSCP value of the packet through the DSCP-to-DSCP mapping relationship.
- Generate a new CoS value for the packet through the DSCP-to-CoS mapping relationship.
- Select the egress queue for the packet through the DSCP-to-Queue mapping relationship.

Queuing and scheduling

Generally, there are 8 queues for QoS exit, which map the 0-7 priority relationship of CoS. The packet enters the corresponding egress queue according to the final marked CoS and CoS-to-Queue relationship. For the priority of packet processing in the egress queue, there are the following algorithms:

- WRR: The weight scheduling algorithm processes the packets in each queue in turn. The weight configuration can be used to change the number of queue packets processed in each cycle. The larger the weight, the higher the queue priority.
- SP: Strict scheduling algorithm, traverse queue 7 to queue 0 in each loop, when the initial processing of the packets in the high-priority queue ends, continue to process the low-priority queue.
- SP+WRR: The combination of WRR and SP, the global WRR mode, supports a specific queue configured as SP mode, and the queue configured as SP mode is a high-priority queue, which is processed first.

Policing(Egress)

The egress policer meters the given flow and classifies as either in-profile or out-of-profile. Out-of-profile packets may be discarded.

23.2. Configuring

- Enabling QoS Globally

Command	SWITCH(config)# mls qos enable SWITCH(config)# no mls qos
Description	Enabling QoS Globally. Default is disabled.

- Configuring Scheduling algorithm

Command	SWITCH(config)# mls qos algorithm {sp wrr}
Description	Configuring the queue scheduling algorithm, support two modes: wrr and sp.

- Configuring Queue Wrr-weight

Command	SWITCH(config)# mls qos weight <0-7> <0-32>
Description	Configure the queue weight. The queue weight is only valid for wrr mode. The default weight of all queues is 1. When in wrr mode, configure the queue weight to 0, the queue will schedule in sp mode.

- Configuring Trust Mode on the Interface

Command	SWITCH(config-if)# mls qos trust {cos dscp} SWITCH(config-if)# no mls qos trust
Description	Configure the port trust mode, the default is not trust mode. When in no trust mode, the CoS field and DHCP field of the packet will be modified according to the default CoS of the port. When in trust cos mode, the same as the no trust mode for untagged packets, and for tagged packets, use the own CoS of the packet. When configuring trust dscp mode, for ip packets, select the packet with DSCP, and for non-ip packets, the same as trust cos mode.

- Configuring Default CoS on the interface

Command	SWITCH(config-if)# mls qos cos <0-7> SWITCH(config-if)# no mls qos cos
Description	Configure the default CoS of the port. The default CoS takes effect for the ingress packets without tags. The default port cos is 0.

- Configuring CoS-to-DSCP Mapping

Command	SWITCH(config)# mls qos cos-dscp <0-63> <0-63> <0-63> <0-63> <0-63> <0-63> <0-63> SWITCH(config)# no mls qos cos-dscp
Description	Configure CoS-to-DSCP mapping. Default CoS-to-DSCP mapping: 0-0, 1-8, 2-16, 3-24, 4-32, 5-40, 6-48, 7-56.

- Configuring CoS-to-Queue Mapping

Command	SWITCH(config)# mls qos cos-queue <0-7> <0-7> SWITCH(config)# no mls qos cos-queue <0-7>
Description	Configure CoS-to-Queue mapping. Default CoS-to-Queue mapping: 0-0, 1-1, 2-2, 3-3, 4-4, 5-5, 6-6, 7-7.

Note

When the configured port is no trust, trust cos or trust dscp and the port is not ip: the cos-dscp configuration takes effect, modify the packet dscp according to the mapping relationship, and the cos-queue configuration takes effect, modify the packet export queue according to the mapping relationship.

- Configuring DSCP-to-CoS Mapping

Command	SWITCH(config)# mls qos dscp-cos <0-63> to <0-7> SWITCH(config)# no mls qos dscp-cos
Description	Configure DSCP-to-CoS mapping. Default DSCP-to-CoS mapping: <0-7>-0, <8-15>-1, <16-23>-2, <24-31>-3, <32-39>-4, <40-47>-5, <48-55>-6, <56-63>-7.

- Configuring DSCP-to-DSCP Mapping

Command	SWITCH(config)# mls qos dscp-mutation <0-63> to <0-63> SWITCH(config)# no mls qos dscp-mutation
Description	Configure DSCP-to-DSCP mapping.

- Configuring DSCP-to-Queue Mapping

Command	SWITCH(config)# mls qos dscp-queue <0-63> <0-7> SWITCH(config)# no mls qos dscp-queue <0-63>
Description	Configure DSCP-to-Queue mapping. Default DSCP-to-Queue mapping: <0-7>-0, <8-15>-1, <16-23>-2, <24-31>-3, <32-39>-4, <40-47>-5, <48-55>-6, <56-63>-7.

Note

When configuring the port as trust dscp and ip packets: the dscp-cos configuration takes effect, modify the packet dscp according to the mapping relationship, and the dscp-queue configuration takes effect, and modify the packet egress queue according to the mapping relationship. When a colleague configures dscp-dscp at the same time, first perform dscp-dscp conversion, and then perform dscp-cos mapping as a result.

- Creating Class-map

Command	SWITCH(config)# class-map CNAME SWITCH(config-cmap)# SWITCH(config)# no class-map CNAME
Description	Create class-map. After creating a class-map, automatically enter the class-map mode.

- Configuring Class-map Matching Rule

Command	SWITCH(config-cmap)# match access-group ACLNAME SWITCH(config-cmap)# no match access-group ACLNAME
Description	Configure to match ACL entries for class-map.

Command	SWITCH(config-cmap)# match ip-dscp <0-63> SWITCH(config-cmap)# no match ip-dscp
Description	Configure to match the DHCP field in the IP packet, up to 64 different DHCP values can be configured.

Command	SWITCH(config-cmap)# match cos <0-7> SWITCH(config-cmap)# no match cos
Description	Configure to match the CoS field in the packet, up to 8 different CoS values can be configured.

Command	SWITCH(config-cmap)# match ethertype ETYPE SWITCH(config-cmap)# no match ethertype
Description	Configure to match the ethernet protocol type field of the packets.

Command	SWITCH(config-cmap)# match {vlan <1-4094> vlan-range <1-4094> to <1-4094>} SWITCH(config-cmap)# no match {vlan vlan-range}
Description	Configure to match vlan field in the packet, support range configuration.

Command	SWITCH(config-cmap)# match layer4 {tcp udp} {source-port destination-port} VALUE SWITCH(config-cmap)# no match layer4 {tcp udp} {source-port destination-port} VALUE
Description	Configure to match Layer 4 port fields of TCP and UDP packets.

Command	SWITCH(config-cmap)# match vlan-range <1-4094> to <1-4094> ethertype ETYPE SWITCH(config-cmap)# no match vlan-range
---------	--

Description	Configure to match vlan and etype fields in the packets.
-------------	--

- Creating Policy-map

Command	SWITCH(config)# policy-map PNAME SWITCH(config-pmap)# SWITCH(config)# no policy-map PNAME
---------	---

Description	Configure policy-map
-------------	----------------------

- Attaching Policy-map to Class-map

Command	SWITCH(config-pmap)# class CNAME SWITCH(config-pmap-c)# SWITCH(config-pmap)# no class CNAME
---------	---

Description	Attach class-map to policy-map. A policy-map can attach up to 8 class-maps.
-------------	--

- Configuring Action

Command	SWITCH(config-pmap-c)# set cos <0-7> SWITCH(config-pmap-c)# no set cos
---------	---

Description	Configure policy action: modify the cos field of packets.
-------------	---

Command	SWITCH(config-pmap-c)# set ip-dscp <0-63> SWITCH(config-pmap-c)# no set ip-dscp
---------	--

Description	Configure policy action: modify the ip-dscp field of packets.
-------------	---

Command	SWITCH(config-pmap-c)# set vlan <1-4094> SWITCH(config-pmap-c)# no set vlan
---------	--

Description	Configure policy action: modify packet vlan.
-------------	--

Command	SWITCH(config-pmap-c)# nest vlan <1-4094> SWITCH(config-pmap-c)# no nest vlan
---------	--

Description	Configure policy action: add external tags to matching packets.
-------------	---

Command	SWITCH(config-pmap-c)# police cir <32-1000000> cbs <4-31250> exceed-action drop SWITCH(config-pmap-c)# no police
---------	---

Description	Configure policy action: rate-limit. Cir is the speed limit water line, in kbps. Cbs is burst capacity, unit Kbyte.
-------------	---

Note

The value of cir is determinable. For example, if the speed limit is 1M, then the value of cir is 1024, but the value of cbs is taken from the empirical value. When the cbs value is set large, the flow peak is higher, and the speed limit is stable, but the average speed may be higher than the speed limit value; when the cbs value is set small, the flow peak is lower, the speed limit fluctuates greatly, and the average speed may be lower than the speed limit value. It is recommended that the cbs configuration take 4 times the value of cir.

- Applying Policy-map on the Interface

Command	SWITCH(config-if)# service-policy input PNAME SWITCH(config-if)# no service-policy input PNAME
---------	---

Description	Apply the policy-map on the interface. Only one policy-map can be applied to an interface.
-------------	---

- Configuring Ingress Rate-limit on the interface

Command	SWITCH(config-if)# rate-limit input <64-1000000> <32-16384> SWITCH(config-if)# no rate-limit input
---------	---

Description	Configure port ingress rate limit. The first parameter is limit level, in kbps. The second parameter is burst level, in Kbyte.
-------------	--

- Configuring Egress Rate-limit on the interface

Command	SWITCH(config-if)# rate-limit output <64-1000000> <32-16384> SWITCH(config-if)# no rate-limit output
Description	Configure port egress rate limit. The first parameter is limit value, in kbps. The second parameter is burst value, in Kbyte.

Note

The limit value is determinable. For example, if the speed limit is 1M, then the limit value is 1024, but the burst value is taken from the experience value. When the burst value is large, the flow peak is higher, and the speed limit is stable, but the average rate may be higher than the speed limit value; when the burst value is small, the flow peak is lower, the speed limit fluctuates greatly, and the average rate may be lower than the speed limit value. . It is recommended that the burst configuration be 4 times the limit value.

23.3. Examples

Example 1: This example shows how to Configure ingress and egress rate-limit on the interface.

Step 1: Configuring Ingress rate-limit on interface gigabitEthernet0/1.

```
SWITCH(config-if)#rate-limit input 1024 4096
```

Step 2: Configuring Egress rate-limit on interface gigabitEthernet0/1.

```
SWITCH(config-if)#rate-limit output 1024 4096
```

Example 2: This example shows how to configure flow-based rate-limit.

Step 1: Enable QoS globally.

```
SWITCH(config)#mls qos enable
```

Step 2: Create ACL rule.

```
SWITCH(config)#ip-access-list 1 permit 192.168.64.1
```

Step 3: Create class-map, policy-map, attach ACL to the class-map, attach class-map to the policy-map, and configure the policy-map action.

```
SWITCH(config)#class-map c1
SWITCH(config-cmap)#match access-group 1
SWITCH(config-cmap)#exit
SWITCH(config)#policy-map p1
SWITCH(config-pmap)#class c1
SWITCH(config-pmap-c)#police cir 1024 cbs 4096 exceed-action drop
```

Step 4: Apply policy-map to the interface.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#service-policy input p1
```

Example 3: This example shows how to configure port-based QoS service, to Implement preferential forwarding of specific port packets.

Step 1: Enable QoS globally.

```
SWITCH(config)#mls qos enable
```

Step 2: Configure interface gigabitEthernet0/1 and gigabitEthernet0/2 trust cos. Set gigabitEthernet0/1 default CoS to 0. Set gigabitEthernet0/2 default CoS to 2.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#mls qos trust cos
SWITCH(config-if)#mls qos cos 0
SWITCH(config-if)#exit
SWITCH(config)#interface gigabitEthernet0/2
SWITCH(config-if)#mls qos trust cos
SWITCH(config-if)#mls qos cos 2
```

Step 3: Configure CoS-to-Queue mapping.

```
SWITCH(config)#mls qos cos-queue 0 0
SWITCH(config)#mls qos cos-queue 2 2
```

Step 4: Configure scheduling algorithm wrr.

```
SWITCH(config)#mls qos algorithm wrr
```

Step 5: Configuring queue 2 weight 0.

```
SWITCH(config)#mls qos weight 2 0
```

23.4. Display Information

- Display Scheduling Algorithm and Weight Information

```
SWITCH#show mls qos algorithm
Mls qos algorithm is WRR.
```

```
Queue-id    0    1    2    3    4    5    6    7
Weight      1    1    1    1    1    1    1    1
```

- Display CoS-to-DSCP and CoS-to-Queue Mapping Information

```
SWITCH#show mls qos cos-maps
```

Cos	Dscp	Queue
0	0	0
1	8	1
2	16	2
3	24	3
4	32	4
5	40	5
6	48	6
7	56	7

- Display DSCP-to-CoS, DSCP-to-DSCP and DSCP-to-Queue Mapping Information

```
SWITCH#show mls qos dscp-maps
```

Dscp	Cos	Mutation	Queue
0	0	0	0
1	0	1	0
2	0	2	0
3	0	3	0
4	0	4	0
5	0	5	0
6	0	6	0
7	0	7	0
8	1	8	1
9	1	9	1
10	1	10	1
11	1	11	1
12	1	12	1
13	1	13	1
14	1	14	1
15	1	15	1

- Display QoS Configuration on the Interfaces

```
SWITCH#show mls qos interfaces
```

Interface	Trust mode	Cos
GiE0/1	Not	0
GiE0/2	Not	0
GiE0/3	Not	0
GiE0/4	Not	0
GiE0/5	Not	0
GiE0/6	Not	0
GiE0/7	Not	0
GiE0/8	Not	0

- Display Class-map Configuration

```
SWITCH#show class-map
```

```
CLASS-MAP-NAME: c1  
Match Cos: 3
```

- Display Policy-map Configuration

```
SWITCH#show policy-map
```

```
POLICY-MAP-NAME: p1  
State: detached
```

```
CLASS-MAP-NAME: c1  
Match Cos: 3  
Police: Mode: SrTCM  
cir (1024 Kbps)
```

```
cbs (4096 KBytes)
exceed-action (drop)
```

- Display Rate-limit Configuration on the Interfaces

```
SWITCH#show rate-limit
```

Interface	In limit	In burst	Out limit	Out burst
GiE0/1	--	--	--	--
GiE0/2	--	--	--	--
GiE0/3	1024	4096	--	--
GiE0/4	--	--	--	--
GiE0/5	--	--	--	--
GiE0/6	--	--	--	--
GiE0/7	--	--	--	--
GiE0/8	--	--	--	--
GiE0/9	--	--	--	--
GiE0/10	--	-	1024	4096

24. Configuring DHCP Snooping

24.1. Overview of DHCP Snooping

DHCP snooping (Dynamic Host Configuration Protocol) is a security feature that acts like a firewall between untrusted hosts and trusted DHCP servers. When DHCP snooping is enabled on a VLAN, the system examines DHCP messages sent from untrusted hosts associated with the VLAN and extracts their IP addresses and lease information. This information is used to build and maintain the DHCP snooping database.

DHCP snooping is enabled on a per-VLAN basis. By default, the feature is inactive on all VLANs. You can enable the feature on a single VLAN or a range of VLANs.

Trusted Sources

The DHCP snooping feature determines whether traffic sources are trusted or untrusted. DHCP snooping acts as a guardian of network security by keeping track of valid IP addresses assigned to downstream network devices by a trusted DHCP server. The default trust state of all interfaces is untrusted.

DHCP Snooping Limit Rate

Configure the number of DHCP packets per second that an interface can receive, to reduce or eliminate the impact of DHCP packet attack from this interface.

MAC Address Verification

With DHCP snooping MAC address verification enabled, DHCP snooping verifies that the source MAC address and the client hardware address match in DHCP packets that are received on untrusted ports. The source MAC address is a Layer 2 field associated with the packet, and the client hardware address is a Layer 3 field in the DHCP packet.

Option-82 Insertion

DHCP Option82 option is also called DHCP relay agent information option, one of many dhcp options. The Option82 option is a DHCP option proposed to enhance the security of the DHCP server and improve the IP address allocation strategy. The addition and stripping of options are implemented by the relay component.

DHCP Database

The DHCP snooping feature dynamically builds and maintains the database using information extracted from intercepted DHCP messages. The database contains an entry for each untrusted host with a leased IP address if the host is associated with a VLAN that has DHCP snooping enabled. The database does not contain entries for hosts connected through trusted interfaces. When the ip verify source function is enabled on the interface, database entries act as valid users on the interface.

24.2. Configuring

- Enable DHCP Snooping Globally

Command	SWITCH(config)# ip dhcp snooping SWITCH(config)# no ip dhcp snooping
Description	Enables DHCP snooping globally.

- Enable DHCP Snooping on Vlans

Command	SWITCH(config)# ip dhcp snooping vlan VID SWITCH(config)# no ip dhcp snooping vlan VIID
Description	Enables DHCP snooping on a VLAN or VLAN range, For example: Ip dhcp snooping vlan 3-10. By default, DHCP Snooping is enabled on all VLANs.

- Configuring Trust Resources

Command	SWITCH (config-if)# ip dhcp snooping trust SWITCH (config-if)# no ip dhcp snooping trust
Description	Configures the interface as trusted. By default, All interfaces are untrusted.

- Enabling Mac Address Verification

Command	SWITCH (config)# ip dhcp snooping verify mac-address SWITCH (config)# no ip dhcp snooping verify mac-address
Description	Enables DHCP snooping MAC address verification. By default is disabled.

- Configuring Rate Limit on Interface

Command	SWITCH (config-if)# ip dhcp snooping rate-limit PPS SWITCH (config-if)# no ip dhcp snooping rate-limit
Description	Configures DHCP packet rate limiting. PPS range from 0 to 128. If PPS is set to 0, this interface will drop all Incoming DHCP packets.

Note

◆ Due to hardware limitations, for DHCP rate limit, when the limit value is not 0, the software rate limit is used, and when the limit value is 0, the hardware rate limit is used. Software rate limit will consume CPU resources.

● Enabling Option-82 Data Insertion

Command	SWITCH (config)# ip dhcp snooping information option-82 (extend-format) SWITCH (config)# no ip dhcp snooping information option-82
Description	Enables DHCP option-82 data insertion. This option is disabled by default Extend format: remote-id, circuit-id compatible with Cisco format

● Configuring Option-82 Circuit-id

Command	SWITCH (config-if)# ip dhcp snooping information option-82 circuit-id WORD SWITCH (config-if)# no ip dhcp snooping information option-82 circuit-id
Description	Configure circuit-id customization content. The default information is vlan+port WORD: String information, valid length 3-63 characters.

For Option-82 Default Format:

Default Circuit-id Suboption

Suboption type (1 byte)	Length (1 byte)	Data (4 bytes)
1	4	vlan(2 bytes) module(1 bytes) port(1 bytes)

For User-configured Circuit-id Suboption

Suboption type (1 byte)	Length (1 byte)	Data (3-63 bytes)
1	N	N bytes

For Option-82 Extend-format:

Default Circuit-id Suboption

Suboption type (1 byte)	Length (1 byte)	Remote ID Type (1 byte)	Length (1 byte)	Data (4 bytes)
1	6	0	4	vlan(2 bytes) module(1 bytes) port(1 bytes)

For User-configured Circuit-id Suboption

Suboption type (1 byte)	Length (1 byte)	Remote ID Type (1 byte)	Length (1 byte)	Data (3-63 bytes)
1	N + 2	1	N	N bytes

● Configuring Option-82 Remote-id

Command	SWITCH (config-if)# ip dhcp snooping information option-82 remote-id WORD SWITCH (config-if)# no ip dhcp snooping information option-82 remote-id
Description	Configure remote-id custom content. The default information is the MAC address of the device WORD: String information, valid length 1-63 characters.

For Option-82 Default Format:

Default Remote-id Suboption

Suboption type (1 byte)	Length (1 byte)	Data (6 bytes)
2	6	MAC address

For User-configured Remote-id Suboption

Suboption type (1 byte)	Length (1 byte)	Data (1-63 bytes)
2	N	N bytes

For Option-82 Extend-format:

Default Remote-id Suboption

Suboption type (1 byte)	Length (1 byte)	Remote ID Type (1 byte)	Length (1 byte)	Data (6 bytes)
2	8	0	6	MAC address

For User-configured Remote-id Suboption

Suboption type (1 byte)	Length (1 byte)	Remote ID Type (1 byte)	Length (1 byte)	Data (1-63 bytes)
2	N+ 2	1	N	N bytes

- Configuring DHCP Snooping Database Write-delay Time

Command	SWITCH (config)# ip dhcp snooping database write-delay SECONDS SWITCH (config-if)# no ip dhcp snooping database write-delay
Description	Configuring DHCP Snooping data to be written to flash at regular intervals. SECONDS range from 600 to 86400 by unit second.

- Trigger DHCP Snooping Database Write-flash

Command	SWITCH (config)# ip dhcp snooping database write-flash
Description	Trigger DHCP Snooping database write-flash.

- Trigger DHCP Snooping Database renew from flash

Command	SWITCH(config)# ip dhcp snooping database renew
Description	Trigger DHCP Snooping database renew from flash.

- Clear DHCP Snooping Database

Command	SWITCH# clear ip dhcp snooping database (vlan VLANID interface IFNAME mac-address XXXX.XXXX.XXXX ip-address A.B.C.D flash)
Description	Clear DHCP Snooping database based on port, vlan, MAC address, or IP address. Support to clear database in flash.

24.3. Examples

Example 1: This is an example of DHCP Snooping typical application. The interface of gigabitEthernet0/8 is connected to DHCP server; USER-A obtains IP address by dynamic; There are other DHCP servers in the LAN, which will affect the IP address assignment of USER-A. Diagram as show in the Figure 1-1 below.




Figure 1-1 Typical application of DHCP Snooping Diagram

- Enable DHCP Snooping Globally.

```
SWITCH#configure terminal
SWITCH(config)#ip dhcp snooping
```

- Configuring gigabitEthernet0/8 as Trusted Resource.

```
SWITCH(config)#interface gigabitEthernet0/8
SWITCH(config-if)#ip dhcp snooping trust
```

24.4. Display Information

- Display DHCP Snooping Information

```
SWITCH#show ip dhcp snooping
Ip dhcp snooping           : Enabled
No ip dhcp snooping vlan   : 2-5
Verify mac-address         : Disabled
Information option-82      : No
database write-delay       : 0 seconds
```

Interface	Trusted	Rate limit (pps)
gigabitEthernet0/16	yes	unlimited

25. Configuring 802.1X Authentication

25.1. Overview of 802.1X Authentication

The IEEE802 LAN/WAN committee proposed the 802.1X protocol to solve the problem of wireless LAN network security. Later, the 802.1X protocol was widely used in Ethernet as a common access control mechanism for LAN ports, mainly to solve the problems of authentication and security in Ethernet.

The 802.1X protocol is a port based network access control protocol. "Port-based network access control" means that, at the port level of the LAN access device, the access to the network resources is controlled through authentication for the connected user equipment.

25.1.1. 802.1X Architecture

The 802.1X system is a typical Client/Server structure, as shown in Figure 1, including three entities: Client, Device and Authentication server.

Figure 1 802.1X Authentication System Architecture



- A client is an entity on a local area network that is authenticated by the device on the other end of the link. The client is generally a user terminal device, and the user can initiate 802.1X authentication by starting the client software. The client must support EAPOL (Extensible Authentication Protocol over LAN).
- The device side is another entity on the local area network that authenticates connected clients. The device side is usually a network device that supports the 802.1X protocol. It provides the client with a port to access the LAN. The port can be a physical port or a logical port.
- The authentication server is an entity that provides authentication services for the device. The authentication server is used for user authentication, authorization and accounting, usually a RADIUS (Remote Authentication Dial-In User Service) server.

25.1.2. 802.1X Authentication Method

The 802.1X authentication system uses EAP (Extensible Authentication Protocol) to realize the exchange of authentication information between the client, the device and the authentication server.

- Between the client and the device, the EAP protocol packets use the EAPOL encapsulation format and are directly carried in the LAN environment.
- There are two ways to exchange information between the device and the RADIUS server. One is that the EAP protocol packet is relayed by the device, and is carried in the RADIUS protocol using the EAPOR (EAP over RADIUS) encapsulation format; the other is that the EAP protocol packet is terminated by the device. Packets with the PAP (Password Authentication Protocol) or CHAP (Challenge Handshake Authentication Protocol) attribute interact with the RADIUS server for authentication.

25.1.3. 802.1X Basic Concepts

25.1.3.1. Controlled/Uncontrolled Port

The device side provides a port for the client to access the LAN. This port is divided into two logical ports: a controlled port and an uncontrolled port. Any frame arriving at this port is visible on both controlled and uncontrolled ports.


- The uncontrolled port is always in a two-way connection state and is mainly used to transmit EAPOL protocol frames to ensure that the client can always send or receive authentication packets.
- The controlled port is in a bidirectional connection state in the authorized state and is used to transmit service packets; in the unauthorized state, it is forbidden to receive any packets from the client.

25.1.3.2. Authorized/Unauthorized Status

The device uses the authentication server to authenticate the client that needs to access the LAN, and controls the authorization/unauthorized status of the controlled port according to the authentication result (Accept or Reject).

Figure 2 Shows the effect of different authorization states on the controlled port on packets passing through this port. The figure compares the port status of two 802.1X authentication systems. The controlled port of system 1 is in an unauthorized state (equivalent to opening the port switch), and the controlled port of system 2 is in an authorized state (equivalent to closing the port switch).

Figure 2 Effects of Authorization Status on Controlled Ports



The user can control the authorization status of the port through the access control mode configured under the port. The port supports the following three access control modes:

- Forced authorization mode (**authorized-force**): indicates that the port is always in an authorized state, allowing users to access network resources without authorization.
- Force unauthorized mode (**unauthorized-force**): Indicates that the port is always in an unauthorized state and does not allow users to authenticate. The device does not provide authentication services for clients accessing through this port.
- Auto-identification mode (**auto**): indicates that the initial state of the port is an unauthorized state, only EAPOL packets are allowed to send and receive, and users are not allowed to access network resources; If the authentication is passed, the port switches to the authorized state, allowing the user to access network resources. This is also the most common case.

25.1.3.3. Controlled Direction

In the unauthorized state, the controlled port can be set as one-way controlled and two-way controlled.

- When two-way control is implemented, the transmission and reception of frames are prohibited;
- When unidirectional control is implemented, receiving frames from the client is prohibited, but sending frames to the client is allowed.

25.1.4. Authentication process for 802.1X


The 802.1X system supports EAP relay mode and EAP termination mode to interact with the remote RADIUS server to complete authentication. The following descriptions of the two authentication methods take the client's initiative to initiate authentication as an example.

25.1.4.1. EAP Relay Mode

This method is specified by the IEEE 802.1X standard, and EAP (Extensible Authentication Protocol) is carried in other high-level protocols, such as EAP over RADIUS, so that the extensible authentication protocol packets can reach the authentication server through complex networks. Generally speaking, the EAP relay mode requires the RADIUS server to support EAP attributes: EAP-Message and Message-Authenticator, which are used to encapsulate EAP packets and protect RADIUS packets carrying EAP-Message respectively.

The following takes EAP-MD5 as an example to introduce the basic business process, as shown in Figure3

Figure3 IEEE 802.1X EAP relay business process of authentication system



The authentication process is as follows:

- 1) When the user needs to access the network, open the 802.1X client program, enter the username and password that have been applied and registered, and initiate a connection request (EAPOL-Start message). At this point, the client program will send a message requesting authentication to the device to start an authentication process.
- 2) After receiving the data frame requesting authentication, the device will send a request frame (EAP-Request/Identity message) to request the user's client program to send the entered username.
- 3) The client program responds to the request from the device and sends the username information to the device through a data frame (EAP-Response/Identity message). The device sends the data frame sent by the client through packet processing (RADIUS Access-Request message) to the authentication server for processing.
- 4) After receiving the username information forwarded by the device, the RADIUS server compares the information with the username table in the database, finds the password information corresponding to the username, and encrypts it with a randomly generated encrypted word, and also send this encrypted word to the device through the RADIUS Access-Challenge message, and the device forwards it to the client program.
- 5) After receiving the encrypted word (EAP-Request/MD5 Challenge message) from the device, the client program uses the encrypted word to encrypt the password part (this encryption algorithm is usually irreversible), generate an EAP-Response/MD5 Challenge packet, and send it to the authentication server through the device.
- 6) The RADIUS server compares the received encrypted password information (RADIUS Access-Request message) with the local encrypted password information. If they are the same, the user is considered to be a legitimate user, and the authentication is passed. messages (RADIUS Access-Accept packets and EAP-Success packets).
- 7) After receiving the authentication message, the device changes the port to the authorized state, allowing users to access the network through the port. During this period, the device will monitor the user's online status by periodically sending handshake messages to the client. By default, if the two handshake request packets are not answered by the client, the device will log the user offline, preventing the user from going offline due to abnormal reasons and the device cannot sense it.
- 8) The client can also send an EAPOL-Logoff message to the device to actively request to log off. The device changes the port status from authorized to unauthorized, and sends an EAP-Failure packet to the client.

25.2. Configuring

- Enabling/disabling 802.1X Authentication Globally

Command	SWITCH(config)# dot1x enable SWITCH(config)# no dot1x enable
Description	Enable and disable the 802.1X function globally.

- Enabling/disabling 802.1X authentication on the Interface

Command	SWITCH(config-if)# dot1x port-control auto SWITCH(config-if)# no dot1x port-control auto
Description	The port enables or disables the 802.1X function.

- Configuring RADIUS Server

Command	SWITCH(config)# radius-server host A.B.C.D auth-port <0-65535> acct-port <0-65535> key WORD SWITCH(config)# no radius-server host A.B.C.D
Description	Configure authentication server information. The default authentication port is 1812 and the accounting port is 1813. Please ensure that the RADIUS server and the device management address communicate with each other.

- Configuring EAPOL Protocol Version Number

Command	SWITCH(config-if)# dot1x protocol-version <1-2> SWITCH(config-if)# no dot1x protocol-version
Description	Configure the version number of the EAPOL protocol on the specified port. Optional configuration, default is 2.

- Configuring Authentication Silent Time

Command	SWITCH(config-if)# dot1x quiet-period <1-65535> SWITCH(config-if)# no dot1x quiet-period
Description	Configure the hold time of the HELD state. Optional configuration, the unit is seconds, the default is 60.

- Configuring the Re-authentication Function

Command	SWITCH(config-if)# dot1x reauthentication SWITCH(config-if)# no dot1x reauthentication
Description	The re-authentication function is enabled on the configuration port. Optional configuration, disabled by default.

- Configuring the Maximum Number of Re-authentications

Command	SWITCH(config-if)# dot1x reauthMax <1-10> SWITCH(config-if)# no dot1x reauthMax
Description	Configure the maximum number of times for port re-authentication. If the number of re-authentication requests exceeds the limit and there is no response, the port becomes unauthorized. Optional configuration, default 2 times.

- Configuring to Enable key Transfer Capability

Command	SWITCH(config-if)# dot1x keyxenabled { disable enable }
Description	Configure the port key transfer function. Optional, disabled by default.

- Configuring Timer Timeout

Command	SWITCH(config-if)# dot1x timeout {re-authperiod <1-4294967295> server-timeout <1-65535> supp-timeout <1-65535> tx-period <1-65535>} SWITCH(config-if)# no dot1x timeout {re-authperiod server-timeout supp-timeout tx-period}
Description	Configure the port timer time. Optional configuration, the default re-authentication period is 3600 seconds, the server timeout is 30 seconds, the client authentication timeout is 30 seconds, and the client request timeout is 30 seconds.

- Enabling/disabling MAC Authentication Globally

Command	SWITCH(config)# mac-auth enable SWITCH(config)# no mac-auth enable
Description	Enable or disable the MAC authentication function globally.

- Enabling/disabling MAC Authentication on the Interface

Command	SWITCH(config-if)# mac-auth {enable disable}
Description	The port enables or disables the MAC authentication function.

- Enabling/disabling MAC Authentication Dynamic VLAN Delivery on the Interface

Command	SWITCH(config-if)# mac-auth dynamic-vlan-creation {enable disable}
Description	The port enables or disables dynamic VLAN delivery of MAC authentication. The current version is not supported.

- Configuring MAC Authentication Failure Handling

Command	SWITCH(config-if)# mac-auth auth-fail-action {drop-traffic restrict-vlan <2-4094>}
Description	Configure the behavior of MAC authentication failure. Optional configuration, default is drop-traffic: drop traffic. The current version is not supported.

- Configuring RADIUS Server Death Time

Command	SWITCH(config)# radius-server deadtime <0-1440> SWITCH(config)# no radius-server deadtime
Description	Configure the RADIUS server death time. During the authentication process, the dead server will be automatically skipped, and the non-dead server will be selected for authentication. Optional configuration, the default is 0 minutes.

- Configuring RADIUS Server Default Key

Command	SWITCH(config)# radius-server key STRING SWITCH(config)# no radius-server key
Description	Configure the RADIUS server default key. Optional configuration.

- Configuring RADIUS Server Retransmission Times

Command	SWITCH(config)# radius-server retransmit <1-100> SWITCH(config)# no radius-server retransmit
Description	Configure the RADIUS server retransmission times. Optional configuration, the default is 3 times.

- Configuring RADIUS Server Timeout

Command	SWITCH(config)# radius-server timeout <1- 60> SWITCH(config)# no radius-server timeout
---------	---

Description	Configure the RADIUS server timeout period. Optional configuration, the default is 5 seconds.
-------------	--

25.3. Examples


25.3.1. 802.1X Port Authentication Scenario

7) Requirement

- Requires authentication of access users on port GigabitEthernet0/3 to control their access to the Internet.
- RADIUS server group IP address 1.1.1.2.
- Set the shared key to be used when the system exchanges packets with the RADIUS server as name.

8) Network Diagram

Figure 4 802.1X Typical network diagram for 802.1x authentication



9) Typical configuration example

Device side:

```
SWITCH(config)#dot1x enable
SWITCH(config)#interface gigabitEthernet0/3
SWITCH(config-if)#dot1x port-control auto
SWITCH(config-if)#exit
SWITCH(config)#radius-server host 1.1.1.2 key name
```

Server:

Configure NAS authentication device 1.1.1.1 and communication key name.

Add user account test password test.

The corresponding authentication method needs to be supported, such as EAP-MSCHAPv2

Client:

Enable 802.1X authentication client and log in with account test.

The corresponding authentication method needs to be supported, such as the EAP-MSCHAPv2 method.

25.3.2. MAC Authentication Scenario

1) Requirement

- Requires authentication of access users on port GigabitEthernet0/3 to control their access to the Internet.
- RADIUS server group IP address 1.1.1.2.
- Set the shared key when the system and the RADIUS server exchange messages as name.

2) Network Diagram

Figure 5 Typical network diagram for MAC authentication

26. Configuring Port Security

26.1. Overview of Port Security

You can use port security to block input to a Fast Ethernet, or Gigabit Ethernet port when the MAC address of the station attempting to access the port is different from any of the MAC addresses that are specified for that port. Alternatively, you can use port security to filter traffic that is destined to or received from a specific host that is based on the host MAC address.

The maximum number of MAC addresses that you can allocate for each port depends on your network configuration. After you allocate the maximum number of MAC addresses on a port, you can either specify the secure MAC address for the port manually or have the port dynamically configure the MAC address of the connected devices.

When a secure port receives a packet, the source MAC address of the packet is compared to the list of secure source addresses that were manually configured or autoconfigured (learned) on the port. If a MAC address of a device that is attached to the port differs from the list of secure addresses, A violation occurs.

Users can set a port to the following two modes to handle a security violation:

Restrict: Drops all packets from insecure hosts, but remains enabled, until the MAC of the host aged out dynamic. You can manually shutdown and no-shutdown the interface to recover from violation.

Shutdown: The shutdown mode option allows you to specify whether the port is to be permanently disabled or disabled for only a specified time. The default is for the port to shut down permanently. You can manually shutdown and no-shutdown the interface to recover from violation.

If you want to convert dynamic security users to static security users, you can enable the sticky function on the port. If the sticky function is enabled, the dynamic users learned on the port will exist as static users. If the configuration is saved, it will still exist after the device restarts.

Note

- ✧ Only support L2 port for port security, such as physical port and L2 AP port.
- ✧ Only supports configuring port security function in access mode.
- ✧ Do not support AP member port configuration port security function.
- ✧ The destination port of the SPAN does not support the port security function.
- ✧ Does not support the port security function on ports that have been configured with static MAC addresses.

26.2. Configuring

● Enable Port Security

Command	SWITCH(config-if)# switchport port-security SWITCH(config-if)# no switchport port-security
Description	Enable Port Security on the interface.

● Setting the Max Number of Security Mac-address

Command	SWITCH(config-if)# switchport port-security maximum VALUE SWITCH(config-if)# no switchport port-security maximum
Description	The default maximum number of secure addresses is 1 VALUE range from 1 to 1024.

● Entering a Security Mac-address

Command	SWITCH(config-if)# switchport port-security mac-address MAC_ADDR SWITCH(config-if)# no switchport port-security mac-address MAC_ADDR
Description	Enters a secure MAC address for the interface. If you configure fewer secure MAC addresses than the maximum, the remaining MAC addresses will be dynamically learned.

● Enable sticky

Command	SWITCH(config-if)# switchport port-security mac-address sticky SWITCH(config-if)# no switchport port-security mac-address sticky
Description	Enable sticky learning on the interface.

● Configuring Port Security Aging

Command	SWITCH(config-if)# switchport port-security aging time MINUTES SWITCH(config-if)# no switchport port-security aging time
Description	Sets the aging time for the secure port. Valid range for aging_time is from 0 to 1440 minutes. If the time is equal to 0, aging is disabled for this port.

● Enable Port Security Aging Static Mac-address

Command	SWITCH(config-if)# switchport port-security aging static SWITCH(config-if)# no switchport port-security aging static
Description	enables aging for statically configured secure addresses on this port.

- Setting the Violation Mode

Command	SWITCH(config-if)# switchport port-security violation { strict shutdown } SWITCH(config-if)# no switchport port-security violation
Description	Sets the violation mode, the action to be taken when a security violation is detected, as one of these: Restrict: A port security violation restricts data and causes the SecurityViolation counter to increment and send an SNMP trap notification. Shutdown: The interface is error-disabled when a security violation occurs. You can manually reenable the by entering the shutdown and no shut down commands. When a secure port is in the error-disabled state, it will recover after errdisable recovery time.

26.3. Examples

Example 1: This is an example of Port Security typical application. Port Security is enabled on the interface gigabitEthernet0/1, the MAX secure Mac-address of the interface gigabitEthernet0/1 is 3, and we enter 3 secure Mac-address on the interface.

When the interface gigabitEthernet0/1 receives a packet, If the SRC MAC-address of the packet differs from the list of secure Mac-addresses, the packet will be dropped.

```
SWITCH(config-if)#switchport port-security
SWITCH(config-if)#switchport port-security maximum 3
SWITCH(config-if)#switchport port-security mac-address 0001.0001.0001
SWITCH(config-if)#switchport port-security mac-address 0001.0001.0002
SWITCH(config-if)#switchport port-security mac-address 0001.0001.0003
```

26.4. Display Information

- Display Interfaces Port Security Brief

```
SWITCH#show port-security brief
interface mac-address mac-address violation violation
          maximum     count      count      action
-----
GiE0/1   10           3           0      shutdown
GiE0/2   1             0           0      restrict
GiE0/3   1             0           0      restrict
GiE0/4   1             0           0      restrict
GiE0/5   1             0           0      restrict
GiE0/6   1             0           0      restrict
GiE0/7   1             0           0      restrict
GiE0/8   1             0           0      restrict
```

- Display an Interface Port Security Information

```
SWITCH#show port-security interface gigabitEthernet0/1
Port Security           : Enabled
Maimum MAC Addresses   : 10
Violation Mode         : Shutdown
Aging Time(mins)       : 10
Aging static           : Enabled
Total MAC Addresses    : 3
Configured MAC Addresses : 2
Security Violation Count : 0
Last Violate Address   : --
```

- Display Secure Mac-address

```
SWITCH#show port-security Mac-address
interface vlan mac-address type left-time(min)
-----
GiE0/1 1 0001.0002.0004 static 10
GiE0/1 1 0001.0002.0003 static 10
GiE0/1 1 000e.c6c1.3a03 dynamic 10
```

- Display an Interface Secure Mac-address

```
SWITCH#show port-security mac-address interface gigabitEthernet0/1
interface vlan mac-address type left-time(min)
-----
GiE0/1 1 0001.0002.0004 static 10
GiE0/1 1 0001.0002.0003 static 10
GiE0/1 1 000e.c6c1.3a03 dynamic 10
```


27. Configuring Ip Source Guard

27.1. Overview of Ip Source Guard

IP Source Guard is a per-interface traffic filter that permits IP traffic only when the IP address and MAC address of each packet matches one of two sources of IP and MAC address bindings: Entries in the Dynamic Host Configuration Protocol (DHCP) snooping binding table; Static IP source entries that you configure.

Filtering on trusted IP and MAC address bindings helps prevent spoofing attacks, in which an attacker uses the IP address of a valid host to gain unauthorized network access.

Note

- ✧ Only support L2 port for port security, such as physical port and L2 AP port.
- ✧ Do not support AP member port configuration port security function.

27.2. Configuring

- Enabling Ip Source Guard

Command	SWITCH(config-if)# ip verify source SWITCH(config-if)# no ip verify source
Description	Enables IP Source Guard on the interface.

- Configuring Static Ip Source Binding Entry

Command	SWITCH(config)# ip source binding XXXX.XXXX.XXXX vlan VALUE A.B.C.D interface IFNAME SWITCH(config)# no ip source binding XXXX.XXXX.XXXX vlan VALUE A.B.C.D interface IFNAME
Description	Creates a static IP source binding entry for the current interface. Example: SWITCH(config)# ip source binding 0001.0001.0001 vlan 1 1.1.1.10 interface gigabitEthernet0/1 A single port can be configured with a maximum of 128 entries.

27.3. Examples

Example 1: This is an example of Ip Source Guard typical application. Ip Source Guard is enabled on the interface gigabitEthernet0/1, and we enter 3 static binding entries on the interface.

When the interface gigabitEthernet0/1 receives a packet, If the IP address and the MAC address of the packet differs from the list of static entries, the packet will be dropped.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#ip verify source
SWITCH(config)#ip source binding 0001.0001.0001 vlan 1 1.1.1.10 interface gigabitEthernet0/1
SWITCH(config)#ip source binding 0001.0001.0002 vlan 1 1.1.1.11 interface gigabitEthernet0/1
SWITCH(config)#ip source binding 0001.0001.0003 vlan 1 1.1.1.12 interface gigabitEthernet0/1
```

27.4. Display Information

- Display Ip Verify Source Binding Rules

```
SWITCH#show ip verify source
interface Filter-type Filter IP-address Mac-address vlan
-----
GiE0/1 Ip Permit 1.1.1.1 0001.0001.0001 1
GiE0/1 Ip Deny All All All
GiE0/2 Ip Deny All All All
```

- Display Ip Verify Source Binding Entries on the Interface

```
SWITCH#show ip verify source interface gigabitEthernet0/1
interface Filter-type Filter IP-address Mac-address vlan
-----
GiE0/1 Ip Permit 1.1.1.1 0001.0001.0001 1
GiE0/1 Ip Deny All All All
```

- Display Ip Source Binding Entries

```
SWITCH#show ip source binding
interface vlan IP-address Mac-address Lease Type
-----
GiE0/1 1 1.1.1.1 0001.0001.0001 infinite static
GiE0/2 1 1.1.2.1 0001.0002.0001 infinite static
```

- Display Ip Source Binding Entries on the Interface

```
SWITCH#show ip source binding interface gigabitEthernet0/1
```

interface	vlan	IP-address	Mac-address	Lease	Type
-----------	------	------------	-------------	-------	------

GiE0/1	1	1.1.1.1	0001.0001.0001	infinite	static
--------	---	---------	----------------	----------	--------

28. Configuring ARP-security

28.1. Overview of Function

28.1.1. ARP-check Function

The ARP-check function filters all ARP packets under the port and discards all illegal ARP packets, which can effectively prevent ARP attack in the network and improve network stability.

The ARP-check function can generate corresponding ARP filtering information based on the legitimate user information (IP+MAC) generated by security application modules such as IP Source Guard, thereby filtering illegal ARP packets in the network.

28.1.2. ARP-spoofing Function

Configuring this function on the interface of the device that is not connected to the gateway can prevent forged gateway attacks. After this function is configured on the interface, when the interface receives an ARP packet, it will detect whether the source IP address of the ARP packet is the same as the IP address of the configured protected gateway. If they are the same, the packet is considered illegal and discarded; otherwise, the packet is considered legal and continues to be processed.

28.1.3. Dynamic ARP Inspection Function

The dynamic ARP inspection (DAI) function is mainly used to defend against man-in-the-middle attacks. It prevents the ARP table entries of legitimate users on the device from being incorrectly updated by forged ARP packets sent by attackers.

The DAI function performs a match check on ARP packets based on the binding table (DHCP dynamic and static binding table).

When the device receives an ARP packet, it compares the source IP address, source MAC address, interface, VLAN information and binding table information corresponding to the ARP packet (the user can configure the comparison content as needed, for example, only the source IP address and VLAN information in the ARP packet can be compared with the binding table information):

- If the information matches, it means that the user sending the ARP packet is a legitimate user, and the ARP packet of this user is allowed to pass.
- Otherwise, it is considered an attack and the ARP packet is discarded.

28.2. Configuring

28.2.1. ARP-check Configuration Commands

- Enable the ARP-check Function

Command	SWITCH(config-if)# arp-check SWITCH(config-if)# no arp-check
Description	Enable / disable the ARP-check function on the interface

28.2.2. ARP-spoofing Configuration Commands

- Configure the Gateway IP Address on the Interface

Command	SWITCH(config-if)# anti-arp-spoofing IPADDR SWITCH(config-if)# no anti-arp-spoofing
Description	Configure the gateway IP address on the interface A maximum of 8 protected network management IP addresses can be configured on each interface

28.2.3. Dynamic ARP Inspection Configuration Commands

There is no additional configuration command for the dynamic ARP inspection function.

When DHCP snooping is configured on the device and ARP-check is enabled on the interface connecting the device to the user side, dynamic ARP inspection takes effect.

28.3. Examples

28.3.1. ARP-check Example

Case 1: Enable ARP-check on interface gi0/1 to allow ARP packets of users that meet the IP Source Guard static binding requirements to pass, while discarding other packets.

```
SWITCH(config)#interface gigabitEthernet0/1
SWITCH(config-if)#ip verify source
SWITCH(config-if)#arp-check
SWITCH(config)#ip source binding 0001.0001.0001 vlan 1 1.1.1.10 interface gigabitEthernet0/1
SWITCH(config)#ip source binding 0001.0001.0002 vlan 1 1.1.1.11 interface gigabitEthernet0/1
SWITCH(config)#ip source binding 0001.0001.0003 vlan 1 1.1.1.12 interface gigabitEthernet0/1
```

28.3.2. ARP-spoofing Example

Case 1: Interface gi0/1 is connected to a gateway device with a gateway IP address of 192.168.64.1. The anti-gateway ARP spoofing function is enabled on other ports of the device.

```
SWITCH(config)#interface gigabitEthernet0/2-12
```

```
SWITCH(config-if)#anti-arp-spoofing 192.168.64.1
```

28.3.3. Dynamic ARP Inspection Example

Case 1: In the case of DHCP Snooping, the dynamic ARP inspection function is enabled on the port connected to the user to prevent illegal users from accessing the network.

Configure and enable the DHCP Snooping function, where port gi0/8 is connected to the DHCP server.

```
SWITCH#configure terminal
SWITCH(config)#ip dhcp snooping
SWITCH(config)#interface gigabitEthernet0/8
SWITCH(config-if)#ip dhcp snooping trust
```

Configure gi0/1-7 to enable dynamic ARP detection

```
SWITCH#configure terminal
SWITCH(config)#interface gigabitEthernet0/ 1-7
SWITCH(config-if)#arp-check
```

28.4. Display Information

- Display ARP-check Entries

```
SWITCH#show ip verify source
interface Filter-type Filter IP-address Mac-address  vlan
-----
GiE0/1  Arp      Permit 1.1.1.10  0001.0001.0001  1
GiE0/1  Arp      Permit 1.1.1.11  0001.0001.0002  1
GiE0/1  Arp      Permit 1.1.1.12  0001.0001.0003  1
GiE0/1  Arp      Deny   All           All             All
```

- Display ARP-spoofing Entries

```
SWITCH#show anti-arp-spoofing
PORT          IP          STATUS
-----
gigabitEthernet0/2  192.168.64.1  active
gigabitEthernet0/3  192.168.64.1  active
gigabitEthernet0/4  192.168.64.1  active
gigabitEthernet0/5  192.168.64.1  active
gigabitEthernet0/6  192.168.64.1  active
gigabitEthernet0/7  192.168.64.1  active
gigabitEthernet0/8  192.168.64.1  active
```

- Display DAI Legal User Information

```
SWITCH#show ip source binding
interface vlan IP-address  Mac-address  Lease  Type
-----
GiE0/1  1  1.1.1.100  0001.0001.0100  --  snooping
GiE0/1  1  1.1.1.101  0001.0001.0101  --  snooping

SWITCH#show ip verify source
interface Filter-type Filter IP-address Mac-address  vlan
-----
GiE0/1  Arp      Permit 1.1.1.100  0001.0001.0100  1
GiE0/1  Arp      Permit 1.1.1.101  0001.0001.0101  1
GiE0/1  Arp      Deny   All           All             All
```

29. Configuring Dos Protection

29.1. Overview of Dos Protection

The purpose of a DoS (Denial of Service) attack is to prevent a computer or network from providing normal services. There are many types of DoS attacks, and they are implemented in various ways. What they have in common is that the victim host or network cannot receive and process external requests in a timely manner. Here are some typical DoS attack types.

SYN Flood attack

SYN Flood attack is the most common DDOS attack on the current network and the most classic DoS attack. By sending a large number of attack packets with forged source addresses to the port where the network service is located, the connection queue of the target server is filled, thereby preventing other legitimate users from accessing.

ICMP Flood attack

ICMP Flood is a DDOS attack that sends a large number of ping packets to the destination host in a short period of time, consuming host resources. After the host resources are exhausted, other services cannot be provided.

ARP Flood attack

ARP Flood is a DDOS attack that sends a large number of ARP request packets to the destination host in a short period of time, consuming host resources. After the host resources are exhausted, it cannot respond to other ARP requests.

NULL SCAN attack

The NULL SCAN attack mainly involves the attacker sending TCP packets without setting any flags to the target host IP. Some operating systems actively feedback RST packets, allowing the attacker to obtain the port of the unclosed session. The essence of preventing NULL SCAN attacks is to discard TCP packets without any TCP flag bits, which can effectively prevent attackers from obtaining the shutdown status of each port through NULL SCAN and launching subsequent attacks.

TCP message with SYN and FIN set at the same time

Under normal circumstances, the SYN flag (connection request flag) and FIN flag (connection teardown flag) cannot appear in a TCP message at the same time, and the RFC does not specify how the IP protocol stack handles such malformed messages. An attacker can use this feature to determine the type of operating system by sending messages with SYN and FIN set at the same time.

TCP message with FIN set but no ACK set

Under normal circumstances, except for the first message (SYN message), all messages have the ACK flag set, including TCP connection teardown messages (messages with the FIN flag set). However, some attackers may send TCP messages to the target host with the FIN flag set but the ACK flag not set, which may cause the target host to crash.

TCP packet with SYN set and source port number 0-1023

Port numbers 0-1023 are well-known port numbers assigned by IANA, and on most systems can only be used by system (or root) processes or programs executed by privileged users. These ports (0-1023) cannot be used as the source port number of the first TCP message sent by the client (with the SYN flag set). When the anti-illegal TCP packet attack function is enabled, the device will check the non-TCP packets based on their characteristics and discard them if they are illegal.

29.2. Configuring

29.2.1. Configure SYN Flood Anti-attack

- Global Configuration

Command	SWITCH(config)# dos syn-flood rate-limit <0-10000> SWITCH(config)#no dos syn-flood rate-limit
Description	Configure global SYN Flood anti-attack <0-10000>, speed limit range, deny all attack packets at 0, unit kbps

- Interface Configuration

Command	SWITCH(config-if)# dos syn-flood rate-limit <0-10000> SWITCH(config-if)#no dos syn-flood rate-limit
Description	Configure interfaces to resist SYN Flood attacks <0-10000>, speed limit range, deny all attack packets at 0, unit kbps

- Counter Enable

Command	SWITCH(config)# dos syn-flood counter enable SWITCH(config)# no dos syn-flood counter enable
Description	Configure and enable SYN Flood anti-attack counters Off by default When the counter is enabled, hit attack packets will be counted. Run the show dos syn - flood counter command to view statistical information.

29.2.2. Configure ARP Flood Anti-attack

- Global Configuration

Command	SWITCH(config)# dos arp-flood rate-limit <0-10000>
---------	---

	SWITCH(config)# no dos arp-flood rate-limit
Description	Configure global ARP Flood anti-attack <0-10000>, speed limit range, deny all attack packets at 0, unit kbps

- Interface Configuration

Command	SWITCH(config-if)# dos arp-flood rate-limit <0-10000> SWITCH(config-if)# no dos arp-flood rate-limit
Description	Configure interfaces to resist ARP Flood attacks <0-10000>, speed limit range, deny all attack packets at 0, unit kbps

- Counter Enable

Command	SWITCH(config)# dos arp-flood counter enable SWITCH(config)# no dos arp-flood counter enable
Description	Configure ARP Flood anti-attack counter enablement Off by default When the counter is enabled, hit attack packets will be counted. Run the show dos arp - flood counter command to view the statistical information.

29.2.3. Configure ICMP Flood Anti-attack

- Global Configuration

Command	SWITCH(config)# dos icmp-flood rate-limit <0-10000> SWITCH(config)# no dos icmp-flood rate-limit
Description	Configure global ICMP Flood anti-attack <0-10000>, speed limit range, deny all attack packets at 0, unit kbps

- Interface Configuration

Command	SWITCH(config-if)# dos icmp-flood rate-limit <0-10000> SWITCH(config-if)# no dos icmp-flood rate-limit
Description	Configure interfaces to resist ICMP flood attacks <0-10000>, speed limit range, deny all attack packets at 0, unit kbps

- Counter Enable

Command	SWITCH(config)# dos icmp-flood counter enable SWITCH(config)# no dos icmp-flood counter enable
Description	Configure ICMP Flood anti-attack counter enablement Off by default When the counter is enabled, hit attack packets will be counted. Use the show dos icmp-flood counter command to view statistical information.

29.2.4. Configure NULL SCAN Anti-attack

- Configure NULL SCAN Anti-attack

Command	SWITCH(config)# dos null-scan deny SWITCH(config)# no dos null-scan deny
Description	Configure global resistance to NULL SCAN attacks After enabling, discard TCP packets without any flags set.

29.2.5. Configure SYN FIN Anti-attack

- Configure SYN FIN Anti-attack

Command	SWITCH(config)#dos syn-fin deny SWITCH(config)# no dos syn-fin deny
Description	Configure global SYN FIN anti-attack After enabling, discard TCP packets with both SYN and FIN set at the same time.

29.2.6. Configure SYN SPORTL1024 Anti-attack

- Configure SYN SPORTL1024 Anti-attack

Command	SWITCH(config)#dos syn-sportl1024 deny SWITCH(config)# no dos syn-sportl1024 deny
Description	Configure global SYN SPORTL1024 anti-attack After enabling, discard source port (0-1023) TCP synchronization packets.

29.2.7. Configure FIN NO-ACK Anti-attack

- Configure FIN NO-ACK Anti-attack

Command	SWITCH(config)# dos fin-noack deny SWITCH(config)# no dos fin-noack deny
Description	Configure global FIN NO-ACK Anti-attack After enabling, discard TCP packets with FIN set but no ACK set.

29.3. Examples

29.3.1. SYN Flood Anti-attack Example

Port gi0/1 is connected to the FTP server, and ports gi0/2 and gi0/3 are connected to the terminal device respectively. The terminal connected to port gi0/2 launches a syn flood attack, causing the terminal connected to port gi0/3 to be unable to access the FTP server normally.

```
SWITCH(config)#interface gigabitEthernet0/2  
SWITCH(config-if)#dos syn-flood rate-limit 10
```

Enable syn flood attack prevention on port gi0/2, limit the speed to 10kbps, and restore normal access to the FTP server from the terminal on port gi0/3.

29.3.2. ICMP Flood Anti-attack Example

Port gi0/1 is connected to the FTP server, and ports gi0/2 and gi0/3 are connected to the terminal device respectively. The terminal connected to port gi0/2 initiates a large number of ICMP request messages, causing the FTP server to be unable to respond to other ICMP messages. The terminal connected to port gi0/3 cannot access the FTP server normally.

```
SWITCH(config)#interface gigabitEthernet0/2  
SWITCH(config-if)# dos icmp-flood rate-limit 10
```

29.3.3. ARP Flood Anti-attack Example

Port gi0/1 is connected to the FTP server, and ports gi0/2 and gi0/3 are connected to the terminal device respectively. The terminal connected to port gi0/2 forges a large number of IP and MAC addresses to launch ARP Flood attacks, causing the FTP server to be unable to process ARP messages for normal requests .

```
SWITCH(config)#interface gigabitEthernet0/2  
SWITCH(config-if)# dos arp-flood rate-limit 10
```

29.4. Display Information

- Show Dos Configuration

```
SWITCH#show dos  
Interface:Global  
Dos syn-flood state: Enable rate-limit :10  
Dos icmp-flood      state: Enable   rate-limit :10  
Dos arp-flood       state: Enable   rate-limit :10  
Dos null-scan deny  state: Disable  
Dos syn-fin deny    state: Disable  
Dos syn-sport1024 deny state: Disable  
Dos fin-noack deny  state: Disable  
Interface:GiE0/2  
Dos syn-flood      state: Enable   rate-limit :10  
Dos icmp-flood     state: Enable   rate-limit :10  
Dos arp -flood state: Enable rate-limit :10
```

- Show Dos ARP Flood Counter

```
SWITCH#show dos arp-flood counter  
  
arp -flood counter status: Enable  
  
Interface Rate-limit( kbps) Drops(Byte) Permit(Byte)  
-----  
Global 10 374660 25492  
GiE0/2 10 245820 11680
```

- Show Dos SYN Flood Counter

```
SWITCH#show dos syn-flood counter  
  
syn-flood counter status: Enable  
  
Interface Rate-limit(kbps) Drops(Byte) Permit(Byte)  
-----  
Global 10 348840 27404  
GiE0/2 10 348976 11832
```

- Show Dos ICMP Flood Counter

```
SWITCH#show dos icmp-flood counter
```

icmp-flood counter status: Enable


Interface	Rate-limit(kbps)	Drops(Byte)	Permit(Byte)
-----------	------------------	-------------	--------------

Global	10	1193302	58576
GiE0/2	10	274516	16050

30. Configuring DHCP Relay

30.1. DHCP Relay Overview

DHCP Relay is also called DHCP relay. When the DHCP client and server are not in the same network segment, the DHCP Relay function is required to relay the DHCP messages between the client and the server. The working process of DHCP Relay is shown in the figure below.



The DHCP relay function works only on Layer 3 interfaces, and the DHCP relay agent must be directly connected to the network segment where the DHCP client resides.

MAC Address Inspection

DHCP messages sent by the port, the source MAC address in the Layer 2 header of the message and the Client Hardware Address field in the data segment are detected. If they are different, the message is illegal.

Option-82

DHCP Option 82, also known as the DHCP Relay Agent Information Option, is an option in the DHCP message. Option 82 is a DHCP option proposed to enhance the security of the DHCP server and improve the IP address allocation strategy. The relay component implements the addition and removal of the option.

DHCP Relay Database

DHCP Relay monitors DHCP messages and collects statistics on user information allocated by legitimate servers.

DHCP Relay Suppression

DHCP relay interface suppression is configured on a specified interface, DHCP request messages received on the interface will be blocked; DHCP request messages received on other interfaces will be forwarded normally.

30.2. Configuring

- Enable/disable DHCP Relay Globally

Command	SWITCH(config)# ip dhcp relay SWITCH(config)# no ip dhcp relay
Description	Enable or disable the DHCP Relay function globally Default off

- Configuring the DHCP Server Address

Command	SWITCH(config)# ip helper-address A.B.C.D SWITCH(config)# no ip helper-address {A.B.C.D }
Description	Configuring the DHCP Server Address Maximum of 20 DHCP server addresses can be configured

- Configuring DHCP Relay Interface Suppression

Command	SWITCH(config-if)# ip dhcp relay suppression SWITCH(config-if)# no ip dhcp relay suppression
Description	Configure DHCP Relay interface suppression on the specified interface to block DHCP requests received on the interface. Default off

- Configuring MAC ADDRESS Verification

Command	SWITCH(config)# ip dhcp relay verify mac-address SWITCH(config)# no ip dhcp relay verify mac-address
Description	Set to support MAC address detection Default off

- Configuring Insertion Option-82

Command	SWITCH(config)# ip dhcp relay information option-82
---------	--

	SWITCH(config)# no ip dhcp relay information option-82
Description	Add option-82 information to the DHCP request message and remove option-82 information from the reply message Default off

- Configuring a Policy for Processing Packets Containing Option-82

Command	SWITCH(config-if)# ip dhcp relay info rmation strategy {drop keep replace} SWITCH(config-if)# no ip dhcp relay information strategy
Description	Configure the DHCP relay agent to handle request messages containing Option-82 drop : If the message contains Option-82, the message is discarded keep : If the message contains Option-82, keep Option-82 in the message unchanged and forward it replace : If the message contains Option-82, fill it with Option-82 according to the configured filling format , replace the original Option-82 in the message with this option, and forward it By default, the DHCP relay agent uses the replace policy to handle request messages with Option-82

- Configure the Circuit id of Option-82 on the Interface

Command	SWITCH(config-if)# ip dhcp relay information option-82 circuit-id WORD SWITCH(config-if)# no ip dhcp relay information option-82 circuit-id
Description	Configure circuit-id customization content Default with vlan+port information WORD: string information, valid length 3-63 characters

Non-customized circuit-id field

Suboption type (1 byte)	Length (1 byte)	Data (6 bytes)
1	6	0x0004(2bytes) + vlan(2 bytes) mo du le(1 bytes) port(1 bytes)

Note: The port of L3 and SVI ports is 0, and the vlan of L3 ports is 0

Customized circuit-id field

Suboption type (1 byte)	Length (1 byte)	Data (3-63 bytes)
1	N	N bytes

- Configure the Remote-id of Option- 82 on the Interface

Command	SWITCH(config-if)# ip dhcp relay information option-82 remote-id WORD SWITCH(config-if)# no ip dhcp relay information option-82 remote-id
Description	Configure remote-id custom content Default device MAC address information WORD: string information, valid length 1-63 characters

Non-customized remote-id field

Suboption type (1 byte)	Length (1 byte)	Data (8 bytes)
2	8	0x0006(2 bytes) + MAC address(6 bytes)

Custom remote-id field

Suboption type (1 byte)	Length (1 byte)	Data (1-63 bytes)
2	N	N bytes

- Clear DHCP Relay Database Data

Command	SWITCH# clear ip dhcp relay database {interface IFNAME mac-address XXXX.XXXX.XXXX ip-address A.B.C.D }
Description	Clearing database based on port, MAC address, and IP address


- Clear DHCP Relay Statistics

Command	SWITCH# clear ip dhcp relay statistics
Description	Clear DHCP Relay statistics

30.3. Examples

30.3.1. Typical Configuration Examples

Case: For SWITCH-A, interface vlan 20 is connected to the DHCP server, and PC-A, PC-B, and PC-C obtain IP addresses dynamically.



DHCP Server configuration:

- The server IP address is 10.1.1.1/24
- Server address pool: 10.10.1.3 to 10.10.1.254
- Add the server to the routing of the 10.10.1.0/24 network segments

SWITCH-A configuration:

- Enter global mode and specify the server IP address :

```
SWITCH#configure terminal
SWITCH(config)#ip helper-address 10.1.1.1
```

- Configure the IP address of the downlink interface vlan 10 and add the gigabitEthernet0/ 2 port to vlan 10:

```
SWITCH(config)# vlan 10
SWITCH(config)# interface vlan 10
SWITCH(config-if)# ip address 10.10.1.1/24
SWITCH(config) #int gigabitEthernet0/ 2
SWITCH(config-if ) #switchport access vlan 10
```

- Configure the IP address of the uplink interface vlan20 and configure gigabitEthernet0/ 1 as a trunk port :

```
SWITCH(config)# vlan 20
SWITCH(config)# interface vlan 20
SWITCH(config-if)# ip address 10.1.1.2/24
SWITCH(config) #int gigabitEthernet0/ 1
SWITCH(config-if ) #switchport mode trunk
```


- Enter global mode and enable the DHCP Relay function globally:

```
SWITCH(config)# ip dhcp relay
```

- PC-A, PC-B, and PC-C can obtain IP addresses in the 10.10.1.0/24 network segment normally.

30.3.2. Option-82 Configuration Example

Example : A company's office area is divided into three departments, Department-1 and Department-2. The company manages IP addresses through a DHCP server and allocates different ranges of addresses to different departments. The DHCP server distinguishes different departments through the circuit-id field of option-82.



This example only shows the SWITCH-A configuration:

- Enter global mode, configure the DHCP server globally, enable the DHCP Relay function , and enable option-82 :

```
SWITCH#configure terminal
SWITCH(config)#ip helper-address 10.1.1.1
SWITCH(config)#ip dhcp relay
SWITCH(config)#ip dhcp relay information option-82
```

- Configure the IP address of the uplink interface vlan20 and configure gigabitEthernet0/1 as a trunk port :


```
SWITCH(config)# vlan 20
SWITCH(config)# interface vlan 20
SWITCH(config-if)#ip address 10.1.1.2/24
SWITCH(config)#interface gigabitEthernet0/ 1
SWITCH(config-if)# switchport mode trunk
```

- Configure port option-82 to customize circuit-id

```
SWITCH(config)# vlan 10
SWITCH(config)# interface vlan 10
SWITCH(config-if)#ip address 10.10.1.1/24
SWITCH(config-if)#ip dhcp relay information option-82 circuit-id department-1
SWITCH(config)#interface gigabitEthernet0/ 2
SWITCH(config-if)# switchport access vlan 10
```

30.3.3. Multi-hop Relay Configuration Example

Case : Users need to go through multiple DHCP relays to apply for an IP address.



DHCP Server configuration:

- The server IP address is 10.30.1.1/24
- Server address pool: 10.10.1.3 to 10.10.1.254
- Add the server to the routing of the 10.20.1.0/24 and 10.10.10.0/24 network segments

SWITCH-A Configuration:

- Enter global mode, configure the DHCP server globally, and enable the DHCP Relay function:

```
SWITCH#configure terminal
SWITCH(config)#ip helper-address 10.20.1.1
SWITCH(config)#ip dhcp relay
```

- Configure the IP address of the uplink interface vlan20 and configure gigabitEthernet0/1 as a trunk port :

```
SWITCH(config)# vlan 20
SWITCH(config)# interface vlan 20
SWITCH(config-if)#ip address 10.20.1.2/24
SWITCH(config)#interface gigabitEthernet0/ 1
SWITCH(config-if)# switchport mode trunk
```

- Configure the IP address of the downlink interface vlan 10 and add the gigabitEthernet0/2 port to vlan 10:

```
SWITCH(config)# vlan 10
SWITCH(config)# interface vlan 10
SWITCH(config-if)#ip address 10.10.1.1/24
```

```
SWITCH(config)#interface gigabitEthernet0/ 2
SWITCH(config-if)# switchport access vlan 10
```

- Configure static routing:

```
SWITCH(config)#ip route 10.30.1.0/24 10.20.1.1
```

SWITCH-B Configuration:

- Enter global mode, configure the DHCP server globally, and enable the DHCP Relay function:

```
SWITCH#configure terminal
SWITCH(config)#ip helper-address 10.30.1.1
SWITCH(config)#ip dhcp relay
```

- Configure the IP address of the uplink interface vlan30 and configure gigabitEthernet0/1 as a trunk port :

```
SWITCH(config)# vlan 30
SWITCH(config)# interface vlan 30
SWITCH(config-if)#ip address 10.30.1.2/24
SWITCH(config)#interface gigabitEthernet0/ 1
SWITCH(config-if)# switchport mode trunk
```

- Configure the IP address of the downlink interface vlan 20 and configure the gigabitEthernet0/2 port as a trunk port:

```
SWITCH(config)# vlan 20
SWITCH(config)# interface vlan 20
SWITCH(config-if)#ip address 10.20.1.1/24
SWITCH(config)#interface gigabitEthernet0/ 2
SWITCH(config-if)# switchport mode trunk
```

- Configure the default route:

```
SWITCH(config)#ip route 0.0.0.0/0 10.20.1.2
```

30.4. Display Information

- Display DHCP Relay Configuration Information

```
SWITCH#show ip dhcp relay

IP DHCP relay          : Enabled
Verify mac-address    : Enabled
Information option-82 : Yes

Interface Suppression Strategy
-----
GiE0/2   Yes      Replace
vlan10   Yes      Keep
```

- Display DHCP Relay Information

```
SWITCH#show ip dhcp relay information

Interface: GiE0/2
Strategy: Replace
Circuit ID: aaa
Remote ID: abc
Interface: vlan10
Strategy: Keep
Circuit ID:
Remote ID:
```

- Display DHCP Relay Database Information

```
SWITCH#show ip dhcp relay database
Interface MacAddress IpAddress Lease(sec) Type
-----
vlan10 00:d0:f8:00:00:12 10.10.1.15 236 dynamic
vlan10 f8:e4:3b:53:9e:43 10.10.1.16 299 dynamic
```

- Display DHCP Relay Statistics

```
SWITCH#show ip dhcp relay statistics
DHCP packets dropped : 0
DHCP packets received: 87
DHCPDISCOVER : 59
DHCPREQUEST : 12
```

```
DHCPINFORM: 0
DHCPRELEASE : 0
DHCPCDECLINE: 0
DHCPPOFFER : 4
DHCPACK : 12
DHCPNAK : 0
DHCP packets relayed: 87
DHCPDISCOVER : 59
DHCPREQUEST : 12
DHCPINFORM: 0
DHCPRELEASE : 0
DHCPCDECLINE: 0
DHCPPOFFER : 4
DHCPACK : 12
DHCPNAK : 0
```

31. Configuring SNMP Network Management

31.1. Overview of SNMP Network Management

SNMP is the abbreviation of Simple Network Management Protocol, which became a network management standard RFC1157 in August 1988. Up to now, due to the support of this protocol by many manufacturers, SNMP has become the de facto network management standard and is suitable for use in the interconnected environment of multi-manufacturer systems.

Using the SNMP protocol, network administrators can perform information query, network configuration, fault location, and capacity planning for nodes on the network. Network monitoring and management are the basic functions of SNMP.

Currently the following versions of SNMP exist:

SNMPv1: The first official version of the Simple Network Management Protocol, defined in RFC1157.

SNMPv2C: Community-Based SNMPv2 Management Architecture, defined in RFC1901.

SNMPv3: By authenticating and encrypting data, it provides the following security features:

- Make sure that data is not tampered with during transmission.
- Make sure the data is sent from a legitimate data source.
- Encrypt messages to ensure data confidentiality.

31.2. Configuring

● Configuring Communication Community Words

Command	SWITCH(config)# snmp-server community COMMUNITY { ro } SWITCH(config)# no snmp-server community COMMUNITY
Description	Configure/delete SNMP communication community word. ro : read-only identifier, configure the community word as a community word with only read permission; the default configuration is a community word with both read and write permissions. Supports configuring multiple community characters at the same time.

● Configuring SNMPv3 Views

Command	SWITCH(config)# snmp-server view NAME {include exclude} OID SWITCH(config)# no snmp-server view name
Description	Configure/delete SNMPv3 views; Supports configuring multiple views at the same time, and supports configuring multiple rules for a single view; The system has all and none views by default and cannot be modified

● Configuring SNMP Groups

Command	SWITCH(config)# snmp-server group NAME {v3 } { noAuthNoPriv authNoPriv authPriv } read RVIEW write WVIEW SWITCH(config)# snmp-server group NAME {v1 v2c} read RVIEW write WVIEW SWITCH(config)# no snmp-server group name
Description	configure/delete SNMP groups; Support to configure multiple groups at the same time; create group information in order to be compatible with the old configuration when configuring the community , usually without additional attention

● Configuring SNMPv3 Users

Command	SWITCH(config)# snmp-server user NAME group GROUPNAME auth {md5 sha} {AUTHPASS} priv { aes des} PRIVPASS SWITCH(config)# no snmp-server user name
Description	configure/delete SNMP users; Support to configure multiple users at the same time;

● Configuring SNMP Host Notification Server

Command	SWITCH(config)# snmp-server host IPADDR {informs traps} {v3 } { noAuthNoPriv authNoPriv authPriv } user NAME SWITCH(config)# snmp-server host IPADDR {informs traps} {v1 v2c} community NAME SWITCH(config)# no snmp-server hostname _
Description	configure/delete SNMP server; Support to configure multiple servers at the same time;

31.3. Examples

Requirements: The IP address of the SNMP network management server is 2.2.2.2, and the read-write communication group word is unified as public.

- Enter the global configuration mode configuration:

```
SWITCH#  
SWITCH#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
SWITCH( config)#snmp-server community public  
SWITCH( config)#snmp-server 2.2.2.2 community public  
SWITCH( config)#
```

Case requirements: The IP address of the SNMP network management server is 2.2.2.2, SNMPv3 is used, the user test password is 12345678, the encryption key is 87654321; the authentication algorithm MD5, the encryption algorithm DES

```
SWITCH#  
SWITCH#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
SWITCH( config)# snmp -server group test v3 authPriv read all write all  
SWITCH( config)# snmp -server user test group test auth MD5 12345678 priv DES  
87654321  
SWITCH( config)# snmp -server host 2.2.2.2 informs v3 authPriv user test
```

32. Configuring RMON

32.1. Overview of RMON

SNMP is the most widely used network management protocol in the Internet. The collection and statistics of network communication information are realized through the agent software embedded in the device. The management software obtains the information by sending query signals to the MIB of the agent through polling, and realizes the management of the network through the obtained information. The management software sends queries to the proxy MIB by means of a query to obtain this information and manages the network through the information obtained. Although the MIB counter records the sum of the statistics, it does not allow historical analysis of the day-to-day communication situation. In order to provide a comprehensive view of the flow and traffic changes over the day, web hosting software requires continuous poll to analyze the status of the network through the information available.

Polling with SNMP has two distinct disadvantages:

- Occupies a lot of network resources. In a large-scale network, a large number of network communication packets will be generated by polling, which will cause network congestion and even cause network congestion. Therefore, SNMP is not suitable for managing large-scale networks. , not suitable for recycling large amounts of data, such as routing table information.
- The task of collecting data in SNMP polling is done by the network administrator through the network management software. If the network administrator monitors more than 3 network segments, it may occur that the network is overloaded due to the heavy burden. A situation in which a manager is unable to complete a task.

In order to improve the availability of management information, reduce the burden of management stations, and meet the needs of network administrators to monitor the performance of multiple network segments, IETF developed RMON to solve the limitations of SNMP in the expanding distributed interconnection. The monitoring function of the data traffic of the network segment and even the entire network. The following are the features of RMON:

- SNMP is the basis for the realization of RMON, and RMON is the enhancement of SNMP functions. RMON is implemented based on the SNMP architecture and is compatible with the existing SNMP framework. It is still composed of the network management workstation NMS and the agent running on each network device. Since RMON does not use another set of mechanisms, which are shared between NMS and SNMP, network managers do not need additional learning and are therefore simpler to achieve.
- RMON enables SNMP to monitor remote network devices more effectively and proactively, and provides an efficient means for monitoring the operation of the network.

The RMON protocol stipulates that the managed device can automatically send Trap information when the alarm threshold is reached, so the management device does not need to obtain the value of the MIB variable through polling multiple times for comparison. The purpose of efficiently managing large interconnected networks.

RMON allows multiple monitors, and monitors can collect data in the following two ways:

- Through a dedicated RMON Probe (detector), the NMS directly obtains management information from the RMON Probe and controls network resources. In this way, all the information of the RMON MIB can be obtained.
- Embed RMON Agent directly into network devices, making them network devices with RMON Probe function. The NMS uses SNMP to exchange data information with it and collect network management information. This method is limited by device resources and generally cannot obtain all the data of the RMON MIB. Basically, only four groups (alarms, events, history, and statistics) are collected.

Our equipment adopts the second method and implements the RMON Agent function on the equipment. Through this function, the management device can obtain information such as overall traffic, error statistics, and performance statistics on the network segment connected to the managed network device interface, thereby realizing network monitoring.

32.2. Rationale

Before configuring RMON, you need to understand the basic concepts of the four groups of statistics, history, alarms, and events defined by the RMON specification.

RMON features

RMON mainly implements statistics and alarm functions, and is used for remote monitoring and management of managed devices by management devices in the network.

The RMON statistics function can be implemented through the RMON statistics group or the RMON history group, which are divided into Ethernet statistics functions and historical statistics functions.

- Historical statistics function (corresponding to the historical group in the RMON MIB): The system periodically samples and collects network status statistics and stores them for subsequent processing.

The system will periodically collect statistics on various traffic information, including bandwidth utilization, number of error packets and total number of packets.

- Ethernet statistics function (corresponding to the statistics group in the RMON MIB): The system collects basic statistics about each network being monitored. The system will continuously count the traffic of a certain network segment and the distribution of various types of packets, or the number of error frames of various types, the number of collisions, etc. The system will keep track of all traffic information on a regular basis, including bandwidth utilization, erroneous packages and total packages.

The RMON alarm function includes the event definition function and the alarm threshold setting function. The RMON alarm function is realized by the combination of these two sub-functions.

- Event definition function (corresponding to the event group in the RMON MIB): The event group controls the events and prompts from the device, and provides all events generated by the RMON Agent. When an event occurs, it can record logs or send Trap to the network management station.
- Set the alarm threshold function (corresponding to the alarm group in the RMON MIB): The system monitors the specified alarm variable (the OID corresponding to any alarm object). After the user pre-defines a set of thresholds and sampling time for the specified alarm, the system will obtain the value of the specified alarm variable according to the defined time period. When the value of the alarm variable is greater than or equal to the upper threshold, an upper alarm event will be triggered; When the value of the variable is less than or equal to the lower limit threshold, a lower limit alarm event is triggered. RMON Agent will record the above monitored status as a log or send Trap to the network management station.

Multiple RMON groups are defined in the RMON specification (RFC2819), and the device implements four groups of statistics, history, alarm, and events supported in the public MIB. These groups are introduced separately below.

- Statistics group

The statistics group specifies that the system will continuously collect statistics on various traffic information of the Ethernet interface, and store the statistical results in the Ethernet statistics table (etherStatsTable) for the management device to view at any time. Statistics include the number of network collisions, the number of CRC check error packets, the number of data packets that are too small (or too large), the number of broadcast and multicast packets, the number of bytes received, and the number of received packets.

After the statistics entry is successfully created on the specified interface, the statistics group collects statistics on the number of packets on the current interface, and the statistics result is a continuous accumulated value.

- History group

The history group periodically collects network status statistics and stores them for subsequent processing.

The history group contains two tables:

- historyControlTable: It is mainly used to set control information such as sampling interval time.
- etherHistoryTable: It is mainly used to store the historical data collected by the historical group on a regular basis for network status statistics, and to provide network administrators with historical data on network segment traffic, error packets, broadcast packets, utilization, and collision times and other statistical information.

- Event group

The event defined by the event group is used in the alarm group configuration item and the extended alarm group configuration item. When the monitoring object reaches the alarm condition, the event will be triggered. RMON event management is to add events to the specified row of the event table and define how the events are handled:

- log: only send logs
- trap: only send trap messages to NMS
- log-trap: send both logs and trap messages to NMS
- none: do nothing

- Alarm group

Alarm groups allow monitoring of a predefined set of thresholds for alarm variables (which can be arbitrary objects in the local MIB). After the user defines the alarm table item (alarmTable), the system will obtain the value of the monitored alarm variable according to the defined time period. When the value of the alarm variable is greater than or equal to the upper limit threshold, an upper limit alarm event will be triggered; If the value is less than or equal to the lower limit threshold, a lower limit alarm event is triggered, and the alarm management will perform corresponding processing according to the definition of the event.

32.3. Configuring

- Configuring Statistics Group

Command	SWITCH(config)# rmon statistics <1-65535> interface IFNAME {owner OWNERNAME } SWITCH(config-if)# no rmon statistics <1-65535>
Description	configure/delete statistics group. <1-65535>: Group index. IFNAME : interface name. OWNERNAME : owner information.

- Configuring History Group

Command	SWITCH(config)# rmon history <1-65535> interface IFNAME buckets <1-65535> interval <1-3600> {owner OWNERNAME } SWITCH(config-if)# no rmon history <1-65535>
Description	configure/delete history group. <1-65535>: Group index. IFNAME : interface name. <1-65535>: History bucket size. <1-3600>: Recording period; the unit is seconds. OWNERNAME : owner information.

- Configuring Event Groups

Command	SWITCH(config)# rmon event <1-65535> {description DESCRIPTION } {log trap COMMUNITY log-trap COMMUNITY none} {owner OWNERNAME } SWITCH(config-if)# no rmon event <1-65535>
Description	configure/delete event groups. <1-65535>: Group index. DESCRIPTION: Event description. COMMUNITY: Trap communication group word. OWNERNAME: owner information.

- Configuring an Alarm Group

Command	SWITCH(config)# rmon alarm <1-65535> object STRING <1-65535> {absolute delta} rising-threshold <1-2147483645> <1-65535> falling-threshold <1-2147483645> <1- 65535> {owner OWNERNAME } SWITCH(config-if)# no rmon alarm <1-65535>
Description	Configure/delete alarm groups. <1-65535>: Group index. STRING: OID of alarm monitoring; for example, 1.3.6.1.2.1.2.2.1.10.1 indicates the number of bytes received by monitoring interface 1. <1-65535>: Monitoring period; the unit is seconds. <1-2147483645>: Rising Threshold. <1-65535>: Rising event index; corresponds to the index in the event group. <1-2147483645>: Falling Threshold. <1-65535>: Fall event index; corresponds to the index in the event group. OWNERNAME: owner information.

- Configuring the Upper Limit of Log Entries

Command	SWITCH(config)# rmon max-log <1-65535> SWITCH(config-if)# no rmon max-log
Description	Configure/reset the upper limit of log entries. <1-65535>: Number of entries. The log here refers to the log generated by the event group, not the system log. The default upper limit is 100; when the number of logs generated exceeds the limit of entries, the old logs will be deleted according to the generation time to maintain the upper limit.

32.4. Examples

Requirements

The IP address of the SNMP network management server is 2.2.2.2, and the community word for read and write communication is public.

The network management server needs to query the traffic of port 1 of the device through rmon

The network management server needs to monitor the input traffic of port 1 of the device through rmon.

The cycle is 10 seconds. Once the number of input bytes changes by more than 1MB (1000000B), an alarm is triggered and a log is recorded.

Configuration steps

Initialize the network management configuration

```
SWITCH#
SWITCH#configure terminal
```

```
Enter configuration commands, one per line. End with CNTL/Z.  
SWITCH(config)#snmp-server community public  
SWITCH(config)#snmp-server 2.2.2.2 community public  
SWITCH(config)#
```

Configure the rmon statistics group (the following rmon configurations can be configured on the NMS through the MIB)

```
SWITCH(config)# rmon statistics 1 interface gigabitEthernet0/1 owner abc
```

Configure rmon events and alarm groups (the following rmon configurations can be configured on the NMS through MIB)

```
SWITCH(config)# rmon event 1 log-trap public owner abc  
SWITCH(config)# rmon alarm 1 object 1.3.6.1.2.1.2.2.1.10.1 10 delta rising-  
threshold 1000000 1 falling-threshold 1000000 1
```

32.5. Display Information

- Show Event Group LSog

```
SWITCH#show rmon log  
event 1 log 226 time 2304 desc  
event 1 log 227 time 2314 desc  
event 1 log 228 time 2324 desc  
event 1 log 229 time 2334 desc  
event 1 log 230 time 2344 desc  
event 1 log 231 time 2354 desc  
event 1 log 232 time 2364 desc  
event 1 log 233 time 2374 desc  
.....
```

33. Configure sFlow

33.1. Overview

sFlow is a network monitoring technology jointly developed by InMon , HP and Foundry Networks in 2001. It has been standardized and can provide complete second to fourth layer information and can adapt to traffic analysis in extremely large network traffic environments. Allows users to analyze the performance , trends and existing problems of network transmission streams in detail and in real time.


sFlow has the following advantages:

- Enables precise monitoring of network traffic on gigabit or higher-speed networks.
- sFlow Collector can monitor thousands or hundreds of sFlow Agents, has good scalability.
- sFlow agent is embedded in the network device and the cost is low.

33.2. Principle

33.2.1. sFlow system composition

As shown in the figure, the sFlow system includes an sFlow Agent embedded in the device and a remote sFlow Collector. Among them, sFlow Agent obtains interface statistics and data information through sFlow sampling, and encapsulates the information into sFlow messages. When the sFlow message buffer is full or the sFlow message cache time times out (the cache time is 1 second), sFlow Agent The sFlow message will be sent to the specified sFlow Collector. sFlow Collector analyzes sFlow messages and displays the analysis results.



33.2.2. sFlow sampling

sFlow Agent provides two sampling methods for users to analyze network traffic conditions from different perspectives, namely Flow sampling and Counter sampling.

Flow sampling

Flow sampling means that the sFlow Agent device performs sampling and analysis on packets on a specified interface according to a specific sampling direction and sampling comparison to obtain information related to the packet data content. This sampling method mainly focuses on the details of traffic, so that the traffic behavior on the network can be monitored and analyzed.

Field	Description
Raw packet	Intercept all or part of the header of the original message (the specific length of the interception is determined by the configuration), encapsulate this part of the original message into an sFlow message and send it to the Collector.
Ethernet Frame Data	For Ethernet messages, parse the Ethernet header information of the message, encapsulate the parsed data into sFlow messages and send them to the Collector.
Extended Switch Data	For forwarded Ethernet packets, record the VLAN conversion and VLAN priority conversion of the packets, encapsulate the forwarding information into sFlow packets and send them to the Collector. When the VLAN ID is 0, it indicates an invalid VLAN.

Counter sampling

Counter sampling allows the sFlow Agent device to periodically obtain traffic statistics information on the interface. Counter sampling supports the acquisition of sampling information as shown in the following table. Compared with Flow sampling, Counter sampling only focuses on the quantity of traffic on the interface, but not on the detailed information of the traffic.

Field	Description
Generic Interface Counters	General interface statistics, including basic interface information and general interface traffic statistics.
Ethernet Interface Counters	For the Ethernet interface, it is used to collect Ethernet-related traffic statistics.
Processor Information	Used to count device CPU usage and memory

Field	Description
	usage.

33.2.3. sFlow message

sFlow messages are encapsulated by UDP, and the default destination port number is the well-known port 6343. There are four header formats for sFlow messages, namely Flow sample, Expanded Flow sample, Counter sample, and Expanded Counter sample. The Expanded Flow sample and Expanded Counter sample are new additions to sFlow version 5 and are extensions of the Flow sample and Counter sample, but are not forward compatible. All Extended sampling content must be encapsulated using the Expanded sampling packet header.

33.3. Configuration commands

- Configure agent address

Order	SWITCH(config)# sflow agent { ip IPV4ADDR ipv6 IPV6ADDR } SWITCH(config)# no sflow agent { ip ipv6 }
describe	Configure/delete a gent address; IPV4ADDR: agent/ device IPv4 address IPV6ADDR: a gent/device IPv6 address Supports configuring ipv 4 and ipv 6 addresses at the same time, for collectors of ipv 4 and ipv 6 respectively There is no configuration by default. If not configured, the protocol may not send packets.

- Configure collector

Order	SWITCH(config)# sflow collector <1-2> { ip IPV4ADDR ipv6 IPV6ADDR } [datagram-size <200-9000> port <1024-65535> description STRING] SWITCH(config)# no sflow collector <1-2>
describe	Configure/delete collector; <1-2>: collector index IPV4ADDR: collector/ server IPv4 address IPV6ADDR: collector/ server IPv6 address <200-9000>: Maximum length of data packet, optional, default 1 400 <1024-65535>: Server port number, optional, default 6 343 STRING: c collector description information, optional, default is none

- Configure interface flow sampling

Order	SWITCH(config -if) # sflow flow -sampling collector <1-2> SWITCH(config -if)# no flow-sampling collector
describe	Configure/delete interface flow sampling; <1-2>: c collector index ss

- Configure interface counter sampling

Order	SWITCH(config -if)# sflow counter-sampling collector <1-2> SWITCH(config -if)# no counter-sampling collector
describe	Configure/delete interface counter sampling; <1-2>: collector index ss

- Configure interface flow sampling parameters

Order	SWITCH(config-if)# sflow flow-sampling direction { inbound outbound } SWITCH(config-if)# sflow flow-sampling rate <1024-65536> SWITCH(config-if)# sflow flow-sampling max-header <18-256> SWITCH(config-if)# no flow-sampling direction SWITCH(config -if)# no flow-sampling rate SWITCH(config -if)# no flow-sampling max-header
describe	Configure/ reset interface flow sampling parameters; { inbound outbound } : flow sampling direction, optional, the default is to sample inbound + outbound at the same time <1024-65536>: flow sampling rate, optional, default is 2 048, one sample for every 2 048 flows <18-256> : Flow sampling message length, unit byte, optional, default 6 4

- Configure interface counter sampling parameters

Order	SWITCH(config -if)# sflow counter-sampling interval <3-65535> SWITCH(config -if)# no sflow counter-sampling interval
describe	Configure/reset interface counter sampling parameters; <3-65535>: counter sampling period, unit seconds, optional, default 1 0

33.4. Examples

Requirements

sFlow network management server is 2.2.2.2 and the device IP address is 2.2.2.95.

The network management server needs to monitor the status of device port 3 through sFlow . It is required to perform flow sampling and counter sampling at the same time. The parameters can be defaulted.

Configurations

Initialize network management configuration

```
SWITCH#  
SWITCH#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
SWITCH(config)# sflow -agent- ip 2.2.2.95  
SWITCH(config)# sflow collector 1 ip 2.2.2.2  
SWITCH(config)#  
Configure sampling for port 3
```

```
SWITCH( config)#int gi 0/3  
SWITCH( config-if)#sflow flow-sampling collector 1  
SWITCH( config-if)#sflow counter-sampling collector 1
```

33.5. Display Information

● Show sFlow

```
SWITCH#show sflow  
Collector 1:  
Address: 2.2.2.2 Agent: 2.2.2.95  
Port: 6343 Datagram-Size: 1400 Description:  
  Fd : 11 Seq: 45 Tx Timer: (nil)  
  Buf : 0xab0d8 Alloc : 1400 Used: 0  
-----  
| Flow | Counter |  
Interface | ID Rate Direction Max-header Sequence | ID Interval Sequence |  
-----  
GiE0/3 1 2048 both 64 2 1 10 7462  
SWITCH#
```

34. Configuring DHCP Server

34.1. Overview of DHCP Server

DHCP (Dynamic Host Configuration Protocol) is a local area network network protocol that works using the UDP protocol and is widely used to dynamically allocate reusable network resources such as IP addresses. DHCP is based on the Client/Server working mode. The DHCP client obtains the IP address from the DHCP server by sending a request message, and other configuration information. When the DHCP client and server are not on the same subnet, there must be a DHCP relay agent (DHCP Relay) to forward DHCP request and reply messages.

Protocol Standard:

RFC2132 DHCP Options and BOOTP Vendor Extensions. S. Alexander, R. Droms. March 1997. (Format: TXT, HTML) (Obsoletes RFC1533) (Updated by RFC3442, RFC3942, RFC4361, RFC4833, RFC5494) (Status: DRAFT STANDARD) (DOI: 10.17487/RFC2132)

34.2. Configuring

34.2.1. Global Configuration Commands

- Enabling/disabling DHCP Server Globally

Command	SWITCH(config)# ip dhcp-server enable SWITCH(config)# no ip dhcp-server enable
Description	Enable and disable the DHCP server globally.

- Configuring Global Parameters

Command	SWITCH(config)# ip dhcp-server parameter NAME VALUE SWITCH(config)# ip dhcp-server parameter (authoritative (on off) server-name NAME server-identifier IDENTIFY default-lease-time <1-2147483648> max-lease-time <1-2147483648> ping-timeout-ms <1-65535> ping-timeout <1-65535>) SWITCH(config)# no ip dhcp-server parameter NAME SWITCH(config)# no ip dhcp-server parameter (authoritative server-name server-identifier default-lease-time max-lease-time ping-timeout-ms ping-timeout)
Description	Global parameter configuration. When parameter values conflict, global parameters take precedence over parameters for subnets and address pools with more precise ranges. Default lease time: 43200s/12h. Optional.

- Configuring Global Options

Command	SWITCH(config)# ip dhcp-server option NAME VALUE SWITCH(config)# ip dhcp-server option (routers A.B.C.D domain-name NAME domain-name-servers A.B.C.D capwap-ac-v4 A.B.C.D) SWITCH(config)# no ip dhcp-server option NAME SWITCH(config)# no ip dhcp-server option (routers domain-name domain-name-servers capwap-ac-v4)
Description	Global option configuration. When option values conflict, global options take precedence over options for subnets and address pools with more precise ranges. Optional.

- Configuring Custom Domain Fields

Command	SWITCH(config)# ip dhcp-server custom-space NAME [code width <1-4>] [length width <1-4>] [hash size <1-65535>] SWITCH(config)# no ip dhcp-server custom-space NAME
Description	Configure custom domain information fields. Optional.

- Configuring Custom Options

Command	SWITCH(config)# ip dhcp-server custom-option NAME code <1-255> (boolean integer ip-address text string encapsulate) SWITCH(config)# no ip dhcp-server custom-option NAME
Description	Configure custom options fields. The configured custom option code value cannot conflict with the configured common options. Optional.

- Configuring Force Send Options

Command	SWITCH(config)# ip dhcp-server force-option <1-255> SWITCH(config)# no ip dhcp-server force-option <1-255>
Description	Configure mandatory options fields. Optional.

- Configuring Static Address

Command	SWITCH(config)# ip dhcp-server static-lease NAME XX:XX:XX:XX:XX A.B.C.D SWITCH(config)# no ip dhcp-server static-lease NAME
Description	Configure static address binding. Optional.

- Configuring Whitelist

Command	SWITCH(config)# ip dhcp-server whitelist NAME XX:XX:XX:XX:XX SWITCH(config)# no ip dhcp-server whitelist NAME
Description	Configure the whitelist. Optional.

- Configuring Blacklist

Command	SWITCH(config)# ip dhcp-server blacklist NAME XX:XX:XX:XX:XX SWITCH(config)# no ip dhcp-server blacklist NAME
Description	Configure the blacklist. Optional.

- Configuring Custom Classification

Command	SWITCH(config)# ip dhcp-server class NAME match EXP SWITCH(config)# no ip dhcp-server class NAME
Description	Configure custom classification. For professional usage, please configure it under the guidance of technicians. Example: ip dhcp-server class win_pc match " substring (option vendor-class-identifier,0,4)=MSFT " Optional.

34.2.2. Subnet Configuration Command

- Configuring Subnet Information

Command	SWITCH(config)# ip dhcp-server subnet A.B.C.D/M SWITCH(config)# no ip dhcp-server subnet A.B.C.D/M
Description	Configure subnet information and enter subnet configuration mode. At least one correct subnet configuration is required for the server to start normally.

- Configuring Subnet Address Range

Command	SWITCH(config-dhcp-subnet)# range A.B.C.D A.B.C.D SWITCH(config-dhcp-subnet)# no range A.B.C.D
Description	Configure the address range of the subnet. The server needs at least one assignable address range to start normally, which can be configured in the address pool below. Can be configured multiple times, with different ranges.

- Configuring Subnet Parameters

Command	SWITCH(config-dhcp-subnet)# parameter NAME VALUE SWITCH(config-dhcp-subnet)# parameter (authoritative (on off) server-name NAME server-identifier IDENTIFY default-lease-time <1-2147483648> max-lease-time <1-2147483648> ping-timeout-ms <1-65535> ping-timeout <1-65535>) SWITCH(config-dhcp-subnet)# no parameter NAME SWITCH(config-dhcp-subnet)# no parameter (authoritative server-name server-identifier default-lease-time max-lease-time ping-timeout-ms ping-timeout)
Description	Configuration parameter information. Optional.

- Configuring Subnet Options

Command	SWITCH(config-dhcp-subnet)# option NAME VALUE SWITCH(config-dhcp-subnet)# option (routers A.B.C.D domain-name NAME domain-name-servers A.B.C.D capwap-ac-v4 A.B.C.D) SWITCH(config-dhcp-subnet)# no option NAME SWITCH(config-dhcp-subnet)# no option (routers domain-name domain-name-servers capwap-ac-v4)
Description	Configuration option information. It is usually necessary to configure the gateway routing address and DNS server address of the subnet. Optional.

34.2.3. Address Pool Configuration Command

- Configuring Address Pool Information

Command	SWITCH(config-dhcp-subnet)# pool NAME SWITCH(config-dhcp-subnet)# no pool NAME
Description	Configure the address pool in subnet mode. Subnets can be further divided through the address pool and used on demand. Optional.

- Configuring the Address Range of the Address Pool

Command	SWITCH(config-dhcp-pool)# range A.B.C.D A.B.C.D SWITCH(config-dhcp-pool)# no range A.B.C.D
Description	Configure the address range of the address pool. The server needs at least one assignable address range to start normally, which can be configured in the above subnet. Can be configured multiple times, with different ranges.

- Configuring Address Pool Parameters

Command	SWITCH(config-dhcp-pool)# parameter NAME VALUE SWITCH(config-dhcp-pool)# parameter (authoritative (on off) server-name NAME server-identifier IDENTIFY default-lease-time <1-2147483648> max-lease-time <1-2147483648> ping-timeout-ms <1-65535> ping-timeout <1-65535>) SWITCH(config-dhcp-pool)# no parameter NAME SWITCH(config-dhcp-pool)# no parameter (authoritative server-name server-identifier default-lease-time max-lease-time ping-timeout-ms ping-timeout)
Description	Configuration parameter information. Optional.

- Configure Address Pool Options

Command	SWITCH(config-dhcp-pool)# option NAME VALUE SWITCH(config-dhcp-pool)# option (routers A.B.C.D domain-name NAME domain-name-servers A.B.C.D capwap-ac-v4 A.B.C.D) SWITCH(config-dhcp-pool)# no option NAME SWITCH(config-dhcp-pool)# no option (routers domain-name domain-name-servers capwap-ac-v4)
Description	Configuration option information. It is usually necessary to configure the gateway routing address and DNS server address of the address pool. Optional.

- Configuring Condition Filter Command

Command	SWITCH(config-dhcp-pool)# (allow deny ignore) CLASSNAME SWITCH(config-dhcp-pool)# (allow deny ignore) (known-clients unknown-clients bootp duplicates declines) SWITCH(config-dhcp-pool)# no (allow deny ignore) (CLASSNAME known-clients unknown-clients bootp duplicates declines)
Description	Configure the address pool filter conditions. Custom CLASSNAME refer to the Configuring Custom Classifications section in the global configuration. Optional.

34.3. Examples


34.3.1. General DHCP Server Address Assignment Scenario

10) Requirement

See the description of the network diagram.

11) Network Diagram

Figure1- 1 DHCP server typical network diagram



S1: Layer 3 switch

VLAN 100: 192.168.100.1/24 Directly connected to S2

VLAN 200: 192.168.200.1/24 directly connected to S3

S2, S3: Layer 2 switches

PC1, PC2, and PC3 are automatically assigned IP

Expect:

PC1 and PC2 can obtain the IPs of their respective network segments, and can ping each other.

PC3 can be assigned to the address of 192.168.200.2

Description: The MAC address of PC3 during the test is 00:0E:C6:C1:38:41

12) Typical Configuration Example

S1:

```

SWITCH(config)# ip dhcp-server subnet 192.168.100.0/24
SWITCH(config-dhcp-subnet)#range 192.168.100.2 192.168.100.254
SWITCH(config-dhcp-subnet)#option routers 192.168.100.1
SWITCH(config-dhcp-subnet)#exit
SWITCH(config)# ip dhcp-server subnet 192.168.200.0/24
SWITCH(config-dhcp-subnet)#range 192.168.200.2 192.168.200.254
SWITCH(config-dhcp-subnet)#option routers 192.168.200.1
SWITCH(config-dhcp-subnet)#exit
SWITCH(config)# ip dhcp-server static-lease pc3 00:0E:C6:C1:38:41 192.168.200.2
SWITCH(config)#ip dhcp-server option domain-name-servers 114.114.114.114
SWITCH(config)#ip dhcp-server enable
  
```

S2/S3: Empty configuration transparent transmission.


34.3.2. Supports DHCP Server Address Allocation Scenarios Delivered by Private Attributes

1) Requirement

See the description of the network diagram.

2) Network Diagram

Figure 1-2 DHCP server typical network diagram



S1: Layer 3 switch

VLAN 100: 192.168.100.1/24 Directly connected to PC1

PC1 automatically assigns IP

Expect:

PC1 can get the correct IP and private option information

3) Typical Configuration Example

S1:

```
SWITCH(config)# ip dhcp-server custom-space dkw1 code width 1 length width 1
SWITCH(config)# ip dhcp-server custom-option dkw1.name code 1 string
SWITCH(config)# ip dhcp-server custom-option dkw1.ip code 2 ip-address
SWITCH(config)# ip dhcp-server custom-option vendor_dkw1 code 43 encapsulate dkw1
SWITCH(config)# ip dhcp-server option dkw1.ip 1.1.1.1
SWITCH(config)# ip dhcp-server option dkw1.name "dockeer"
SWITCH(config)# ip dhcp-server subnet 192.168.100.0/24
SWITCH(config-dhcp-subnet)#range 192.168.100.2 192.168.100.254
SWITCH(config-dhcp-subnet)#option routers 192.168.100.1
SWITCH(config-dhcp-subnet)#exit
SWITCH(config)#ip dhcp-server option domain-name-servers 114.114.114.114
SWITCH(config)#ip dhcp-server enable
```


34.3.3. A DHCP Server Address Assignment Scenario that Supports Guest Separation

1) Requirement

- See the description of the network diagram.
- Normal user allocation addresses 192.168.100.2-192.168.100.100 and 192.168.200.2-192.168.200.100.
- Guest assigned address 192.168.100.200-192.168.100.254.

2) Network Diagram

Figure 1-3 DHCP server typical network diagram



S1: Layer 3 switch

VLAN 100: 192.168.100.1/24 Directly connected to S2

VLAN 200: 192.168.200.1/24 directly connected to S3

S2, S3: Layer 2 switches

PC1, PC2, and PC3 are automatically assigned IP

Expect:

PC1 and PC2 can obtain the normal user IP respectively

PC3 can be assigned to the guest segment address

3) Typical Configuration Example

S1:

```
SWITCH(config)# ip dhcp-server subnet 192.168.100.0/24
SWITCH(config-dhcp-subnet)#range 192.168.100.2 192.168.100.100
SWITCH(config-dhcp-subnet)#option routers 192.168.100.1
SWITCH(config-dhcp-subnet)#exit
SWITCH(config)# ip dhcp-server subnet 192.168.200.0/24
SWITCH(config-dhcp-subnet)#pool employee
SWITCH(config-dhcp-pool)#range 192.168.200.2 192.168.200.100
SWITCH(config-dhcp-pool)#deny unknown-clients
SWITCH(config-dhcp-pool)#pool guest
SWITCH(config-dhcp-pool)#range 192.168.200.200 192.168.200.254
SWITCH(config-dhcp-pool)#allow unknown-clients
SWITCH(config-dhcp-pool)#exit
SWITCH(config-dhcp-subnet)#option routers 192.168.200.1
SWITCH(config-dhcp-subnet)#exit
SWITCH(config)#ip dhcp-server option domain-name-servers 114.114.114.114
SWITCH(config)#ip dhcp-server enable
```

S2/S3: Empty configuration transparent transmission.

34.4. Display Information

- Display DHCP Server Status Information

```
SWITCH#show ip dhcp-server status
DHCP Server: Enable (conf.Enable)
```

- **Display Address Assignment Information**

```
SWITCH#show ip dhcp-server leases
Name MAC IP Begin End Manufacturer
```

```
-----
liulang-work 00:0e:c6:c1:38:4a 3.3.3.254 1970-01-01 00:00:36 1970-01-01 00:10:36 ASIX
ELECTRONICS CORP.
```

35. Configuring AAA

35.1. Overview of AAA

AAA is the abbreviation of Authentication Authorization and Accounting, which provides for authentication, authorization and accounting function into the configuration of the consistency framework.

AAA provides the following services in a modular fashion:

- Authentication: Verify whether the user can obtain access rights. Optionally use RADIUS protocol, TACACS+ protocol or Local (local) and so on. Identity authentication is a method of identifying a user's identity before allowing access to the network and network services.
- Authorization: Which services are available to authorized users. AAA authorization is achieved by defining a series of attribute pairs, these attribute pairs describe the operations that the user is authorized to perform. These attribute pairs can be stored on a network device or remotely on a secure server.
- Accounting: record the user's use of network resources. When AAA accounting is enabled, the network device starts to send user usage of network resources. Each accounting record is composed of attribute pairs and stored on a secure server. These records can be read and analyzed by special software, so as to realize accounting, statistics and tracking of users' use of network resources.

Using AAA has the following advantages:

- Flexibility and controllability.
- Scalability.
- Standardized Certification.
- Multiple backup systems.

AAA has the following relevant standards:

RFC2865 Remote Authentication Dial In User Service (RADIUS). C. Rigney, S. Willens, A. Rubens, W. Simpson. June 2000. (Format: TXT, HTML).

RFC2866 RADIUS Accounting. C. Rigney. June 2000. (Format: TXT, HTML).

RFC8907 The Terminal Access Controller Access-Control System Plus (TACACS+) Protocol. T. Dahm, A. Ota, DC Medway Gash, D. Carrel, L. Grant. September 2020.

35.2. Configuring

- Enabling/disabling AAA Function Globally

Command	SWITCH(config)# aaa new-model SWITCH(config)# no aaa new-model
Description	Globally enable or disable the AAA function.

- Configuring AAA Server Group

Command	SWITCH(config)# aaa group server (radius) (default NAME) SWITCH(config) # aaa group server (tacacs +) (default NAME) SWITCH(config)# no aaa group server (radius tacacs +) (default NAME)
Description	Server group configuration. Optional. By default there is no server group configuration and no server method is used.

- Configuring AAA Server

Command	SWITCH(config-gs-rad) # server A.B.C.D (auth-port <1-65535>) (acct-port <1-65535>) (key STRING) SWITCH(config-gs-tac)# server A.B.C.D (port <1-65535>) (key STRING) SWITCH(config-gs-rad)# no server A.B.C.D SWITCH(config-gs-tac)# no server A.B.C.D
Description	server group mode . Configure RADIUS, TACACS + server information, including basic IP address, port information, shared key Optional. Note: Due to implementation restrictions, the current radius accounting port number is always the authentication port number + 1, and the configuration is invalid.

- Configuring Server Group Timeout

Command	SWITCH(config-gs-rad)# timeout <1-120> SWITCH(config-gs-tac)# timeout <1-120> SWITCH(config-gs-rad)# no timeout SWITCH(config-gs-tac)# no timeout
Description	server group mode . Configure the timeout period for servers in the group. Optional. Note: The actual effective range of the radius service timeout is 5-60 seconds; it is not recommended to be used in web authentication and authorization


- Configuring AAA Method Information

Command	SWITCH(config)# aaa (authentication authorization) (login ssh web) default {group (radius tacacs+ NAME) local} SWITCH(config)# no aaa (authentication authorization) (login ssh web) default
Description	Global configuration mode. Configure AAA method information . Login: serial port authentication or telnet authentication, authorization Ssh: ssh authentication and authorization Web: web authentication, authorization Optional configuration. Local authentication and authorization are used by default. Note: It is not recommended to enable radius authorization separately, unless the same group is specified for authentication and authorization. Tacplus and local authorization will not verify the password again.

35.3. Examples

35.3.1. Use Tacacs+ Method for SSH Login Authentication and Authorization

- 1) Requirement : PC users log in to the switch and implement remote authentication and authorization through tacacs+ Server.
- 2) Network Diagram



Typical network diagram of SSH through tacacs+ server authentication and authorization

3) Typical Configuration

Server:

Server selects tacacs+ server, running on Ubuntu system

Server Configuration

```
#/etc/tacacs+/tac_plus.conf
key = testing123
user = admin {
    global = cleartext "admin"
    service = exec {
        priv-lvl=15
    }
}
```

Switch :


```
SWITCH(config)# aaa new-model
SWITCH(config)# aaa group server tacacs+ default
SWITCH(config-gs- tac)# server 192.168.64.102 key testing123
SWITCH(config-gs- tac)# exit
```

```
SWITCH(config)# aaa authentication ssh default group tacacs+
SWITCH(config)# aaa authorization ssh default group tacacs+
```

For device IP configuration and ssh configuration, refer to the corresponding sections of the configuration document, which are omitted here.

35.3.2. Use the radius method for Telnet login authentication and authorization

- 1) Requirement : PC users log in to the switch and implement remote authentication and authorization through the Radius Server.
- 2) Network Diagram



Typical network diagram of Telnet through radius server and local authentication and authorization

3) Typical Configuration Examples

Server:

Server selects freeradius 3.0 as the server, running on the Ubuntu system

Server configuration:

```
.....
#/etc/freeradius/3.0/clients.conf
client 192.168.64.64 {
    ipaddr = 192.168.64.64
    secret = testing123
}

#/etc/freeradius/3.0/users
admin Cleartext-Password := "admin"
    Service-Type = 7,
    Management-Privilege-Level = 15
```

Switch :

```
SWITCH(config)# aaa new-model
SWITCH(config)# aaa group server radius default
SWITCH(config-gs- rad )# server 192.168.64.102 key testing123
SWITCH(config-gs- rad )# exit
SWITCH(config)# aaa authentication login default group radius local
SWITCH(config)# aaa authorization login default group radius local
```

Device IP configuration and telnet configuration, refer to the corresponding chapters in the configuration document, which are omitted here.

36. Configuring DNS

36.1. Overview of DNS

In a TCP/IP network environment, DNS (Domain Name System) is an important and commonly used system. The main function of DNS is to convert easy-to-remember domain names with difficult-to-remember IP addresses. The process of obtaining the IP address corresponding to a host name through a host name is called domain name resolution (or host name resolution). When resolving a domain name, you can first use the static domain name resolution method. If the static domain name resolution fails, then use the dynamic domain name resolution method. You can put commonly used domain names into the static domain name resolution table, which can improve the efficiency of domain name resolution. The TCP and UDP port numbers of DNS are both 53, and UDP is usually used.

36.2. Configuring

36.2.1. Static DNS

- Configure the IP address corresponding to the domain name

Command	SWITCH(config)# ip dns host HOST-NAME {IPADDR IPV6ADDR} {IPADDR IPV6ADDR } SWITCH(config)# no ip dns host HOST-NAME IPADDR
Description	Configure the IP address corresponding to the domain name Each domain name corresponds to at most one IPv4 address and one IPv6 address HOST-NAME: domain name, up to 64 characters

Illustrate

- ◆ The switch can be configured with up to 100 static DNS entries.

36.2.2. Dynamic DNS

- Configure the IP address of the domain name server

Command	SWITCH(config)# ip dns name-server {IPADDR IPV6ADDR} {IPADDR IPV6ADDR } {IPADDR IPV6ADDR } SWITCH(config)# no ip dns name-server {IPADDR IPV6ADDR } {IPADDR IPV6ADDR } {IPADDR IPV6ADDR }
Description	Configure the IP address of the domain name server The switch supports configuring up to 3 DNS server IP addresses (shared by IPv4 and IPv6)

- Configure Domain Name Suffix

Command	SWITCH(config)# ip dns domain-list DOMAIN-NAME SWITCH(config)# no ip dns domain-list DOMAIN-NAME
Description	Configure domain name suffix

Illustrate

- ◆ The switch can be configured with up to 6 domain name suffixes.
- ◆ When a user enters a host name that does not contain a fully qualified domain name (FQDN), the system will append these domain name suffixes to the host name in turn and attempt to perform DNS resolution .

36.3. Examples

36.3.1. Static Domain Name Resolution

4) Requirements

SWITCH can access the Server with IP address 2.2.2.106 through the domain name www.test.com.

5) Configuration

SWITCH:

- Enter global configuration mode and configure the default route and IP address

```
SWITCH> enable
SWITCH# configure terminal
SWITCH(config)#ip route 0.0.0.0/0 2.2.2.106
SWITCH(config)# interface vlan 1
SWITCH(config-if)#ip address 2.2.2.95/24
SWITCH(config-if)# exit
```

- Configure the correspondence between domain name and IP

```
SWITCH(config)# ip dns host www.test.com 2.2.2.106
```

6) Verify

- View the configuration of static domain name table items

```
SWITCH# show ip dns hosts
Host                                     Address
www.test.com                             2.2.2.106
```

- **Execute the ping command**

```
SWITCH# ping www.test.com
PING www.test.com (2.2.2.106) 56(84) bytes of data.
64 bytes from www.test.com (2.2.2.106): icmp_seq=1 ttl=128 time=0.969 ms
64 bytes from www.test.com (2.2.2.106): icmp_seq=2 ttl=128 time=0.607 ms
64 bytes from www.test.com (2.2.2.106): icmp_seq=3 ttl=128 time=0.777 ms
64 bytes from www.test.com (2.2.2.106): icmp_seq=4 ttl=128 time=0.490 ms

--- www.test.com ping statistics ---
4 packets transmitted, 4 received, 0% packet loss, time 3034ms
rtt min/avg/max/mdev = 0.490/0.710/0.969/0.180 ms
SWITCH#
```

36.3.2. Dynamic DNS

1) Requirements

As a DNS client, SWITCH can resolve domain names through the DNS server on the network.

2) Configuration

SWITCH:

- **Enter global configuration mode and configure the default route and IP address**

```
SWITCH> enable
SWITCH# configure terminal
SWITCH(config)# interface vlan 1
SWITCH(config)#ip route 0.0.0.0/0 2.2.2.106
SWITCH(config-if)#ip address 2.2.2.95/24
SWITCH(config-if)# exit
```

- **Configuring DNS server addresses**

```
SWITCH(config)#ip dns name-server 2.2.2.106
```

- **Configure Domain name suffix**

```
SWITCH(config)#ip dns domain-list com
```

3) Verify

- **View the configured DNS servers**

```
SWITCH# show ip dns hosts
Domain name list:
com

Name Servers:
2.2.2.106 static
```

- **Execute the ping command**

```
SWITCH# ping baidu
PING baidu.com (39.156.66.10) 56(84) bytes of data.
64 bytes from 39.156.66.10 (39.156.66.10): icmp_seq=1 ttl=50 time=46.6 ms
64 bytes from 39.156.66.10 (39.156.66.10): icmp_seq=2 ttl=50 time=46.4 ms
64 bytes from 39.156.66.10 (39.156.66.10): icmp_seq=3 ttl=50 time=46.4 ms
64 bytes from 39.156.66.10 (39.156.66.10): icmp_seq=4 ttl=50 time=46.7 ms

--- baidu.com ping statistics ---
4 packets transmitted, 4 received, 0% packet loss, time 3004ms
rtt min/avg/max/mdev = 46.434/46.536/46.695/0.106 ms
SWITCH# ping baidu.com
PING baidu.com (110.242.68.66) 56(84) bytes of data.
64 bytes from 110.242.68.66 (110.242.68.66): icmp_seq=1 ttl=54 time=49.0 ms
64 bytes from 110.242.68.66 (110.242.68.66): icmp_seq=2 ttl=54 time=49.0 ms
64 bytes from 110.242.68.66 (110.242.68.66): icmp_seq=3 ttl=54 time=49.0 ms
64 bytes from 110.242.68.66 (110.242.68.66): icmp_seq=4 ttl=54 time=49.0 ms

--- baidu.com ping statistics ---
4 packets transmitted, 4 received, 0% packet loss, time 3005ms
rtt min/avg/max/mdev = 48.965/48.994/49.041/0.028 ms
SWITCH#
```

36.4. Display Information

- **Display DNS Configuration Information**

```
SWITCH# show ip dns hosts
Domain name list:
```

com
net

Name Servers:

192.168.1.1 static

192.168.5.100 static

Host

Address

hostB

192.168.1.1

37. Configuring SSH

37.1. Overview of SSH

SSH (Secure Shell) is a network security protocol that requires encryption and authentication for remote access and file transfer. SSH is based on a server/client structure, and the device supports both SSH server and client functions. As a server, the device allows connections from multiple SSH clients; as a client, the device allows users to establish SSH connections with devices that support SSH server functions.

The SSH function is similar to the Telnet service, but the encryption and authentication features of SSH can provide users with a stronger security mechanism. When users log in to the device in an insecure network environment, SSH can effectively protect the device from attacks such as IP address fraud and plain text password interception.

SSH interaction process

stage	Illustrate
Connection Establishment	The SSH server listens for the client's connection request on port 22. After the client initiates a connection request to the server, a TCP connection is established between the two parties.
Version Negotiation	The two parties determine the final SSH version number to be used through version negotiation.
Algorithm negotiation	SSH supports multiple algorithms. The two parties negotiate the key exchange algorithm used to generate session keys, the encryption algorithm used to encrypt data information, the public key algorithm used for digital signature and authentication, and the HMAC algorithm used to protect data integrity based on the algorithms supported by the local and remote ends.
Key Exchange	The two parties exchange DH (Diffie-Hellman Exchange) to dynamically generate a session key for protecting data transmission and a session ID for identifying the SSH connection, and complete the client's identity authentication of the server.
User Authentication	The SSH client sends an authentication request to the server, and the server authenticates the client.
Session Request	After authentication, the SSH client sends a session request to the server, requesting the server to provide a certain type of service (Stelnet, SFTP, or SCP), that is, requesting to establish a corresponding session with the server.
Conversational Interaction	After the session is established, the SSH server and client exchange data information on the session.

37.2. Configuring

37.2.1. SSH Server Configuration

- Enable/disable SSH Server Function

Command	SWITCH(config)# ssh-server enable SWITCH(config)# no ssh-server enable
Description	By default, the SSH server function is disabled If the client vty has no operation for 10 minutes, the server will disconnect the vty connection By running the "exec-timeout minutes" command, you can configure the vty timeout

- Configure The SSH Server Listening Port Number

Command	SWITCH(config)# ssh-server port L4-PORT SWITCH(config)# no ssh-server port
Description	Valid range: 22, 10000 – 65535 By default, the listening port number of the SSH server is 22

1.1.1. SFTP Server Configuration

- Enable/disable SFTP Server Function

Command	SWITCH(config)# sftp-server enable SWITCH(config)# no sftp-server enable
Description	By default, the SFTP server function is disabled

- Configure The SFTP Server Listening Port Number

Command	SWITCH(config)# sftp-server port L4-PORT SWITCH(config)# no sftp-server port
Description	Valid range: 10000 – 65535; By default, the listening port number of the SFTP server is 10022

- Configure The File Upload And Download Path of The SFTP Server

Command	SWITCH(config)# sftp-server topdir {log key upgrade} SWITCH(config)# no sftp-server topdir
Description	Set the root path for uploading and downloading files on the SFTP server log: only supports log download, not file upload key: supports uploading and downloading client public key files, which are used to associate client public keys with users Upgrade: supports uploading firmware files. After uploading, execute upgrade firmware upgrade xxx.bin to decompress the file. After successful decompression, restart the device to update the device firmware. The firmware file will be deleted if the decompression succeeds or fails. After the device restarts, the files in the upgrade directory will be cleared By default, the root path specified by the SFTP server is log

- ◆ The sftp server does not support remote login using aaa.

1.1.2. Common Configuration For SSH And SFTP Servers

- Generate/Delete SSH Public Keys

Command	SWITCH(config)# crypto key generate {dsa ecc rsa} SWITCH(config)# crypto key zeroize {dsa ecc rsa}
Description	By default, the device generates only the ECC public key If SSH does not generate a key, this item must be configured

- Configure The Public Key File And User Name of The Associated Client

Command	SWITCH(config)# ip ssh peer NAME public-key key FILE SWITCH(config)# no ip ssh peer NAME public-key key FILE
Description	When the client uses public-key authentication, the switch as the server needs to associate the client's public key and login user name on the device Only OpenSSH public key format is accepted. The specific public key format is as follows:[type-name] [base64-encoded-ssh-public-key] [comment] Example: ssh-rsa AAAAB3NzaC1yc2EAAAADAQABAAQACdQ02P1Eamz/nT4I3 root

Illustrate

- ◆ When a user logs in to the device through SSH, the device processes the authentication request in the following order:
 - ◆ Public key authentication: Checks whether the client carries a valid public key and matches the public key stored locally on the device
 - ◆ AAA remote authentication: If public key authentication is not enabled or fails, the remote authentication configured by AAA (such as RADIUS password authentication) is triggered.
 - ◆ Local user authentication: If AAA remote authentication is not configured, local user database authentication is performed.

- Configure The DH Key Exchange Algorithm Supported By The SSH Server And SFTP Server.

Command	SWITCH(config)# ip ssh key-exchange {dh-group-exchange-sha1 dh-group14- sha1 dh-group1-sha1 ecdh-sha2-nistp256 ecdh-sha2-nistp384 ecdh-sha2- nistp521} SWITCH(config)# no ip ssh key-exchange {dh-group-exchange-sha1 dh- group14- sha1 dh-group1-sha1 ecdh-sha2-nistp256 ecdh-sha2-nistp384 ecdh-sha2- nistp521 }
Description	By default, the SSH server supports the following DH key exchange algorithms: dh- group-exchange-sha1, dh-group14-sha1, ecdh-sha2-nistp256, ecdh-sha2-nistp384, and ecdh-sha2-nistp521 dh-group1-sha1 is an older key exchange algorithm and is generally not recommended

- Configure The Encryption Mode Supported By The SSH Server And SFTP Server

Command	SWITCH(config)# ip ssh cipher-mode {3des-cbc aes128-cbc aes128-ctr aes128-gcm aes192-cbc aes192-ctr aes256-cbc aes256-ctr aes256-gcm} SWITCH(config)# no ip ssh cipher-mode {3des-cbc aes128-cbc aes128- ctr aes128-gcm aes192-cbc aes192-ctr aes256-cbc aes256-ctr aes256-gcm }
Description	By default, the SSH server supports the following encryption algorithms: aes128-ctr , aes128-gcm , aes192-ctr , aes256-ctr , and aes256-gcm The CBC encryption algorithm has been proven to be crackable within a limited time. Therefore, in some organizations or units with high security requirements, the encryption mode can be selected as CTR and GCM mode to improve the security level of the SSH server

- Configure The Message Authentication Algorithms Supported By The SSH Server And SFTP Server

Command	SWITCH(config)# ip ssh hmac-algorithm {md5 md5-96 sha1 sha1-96 sha2-256 sha2-512} SWITCH(config)# no ip ssh hmac-algorithm {md5 md5-96 sha1 sha1-96 sha2-256 sha2-512 }
Description	By default, the SSH server supports the following message authentication algorithms: sha2-256 and sha2-512 md5 , md5-96, sha1, and sha1-96 are insecure HMAC algorithms and are generally not recommended

- Disconnecting SSH Client

Command	SWITCH# clear line vty LINE
Description	Vty indicates the remote login user be viewed in the show users command Does not support kicking the user itself

- ◆ When the no ssh-server enable or no sftp-server enable command is executed, the device will shut down the corresponding SSH or SFTP server service. At the same time, all user sessions currently connected to the server will be forcibly terminated and the users will be disconnected.
- ◆ After executing other server configuration commands, the normal use of connected SSH users will not be affected, but newly connected SSH users will be affected by the updated configuration.

1.1.3. SCP And SFTP Clients For File Upload And Download

- Use SCP/SFTP Client to Upgrade Firmware/data/uboot

Command	SWITCH# upgrade {firmware data uboot} scp://USERNAME@A.B.C.D/FILE SWITCH# upgrade {firmware data uboot} sftp://USERNAME@A.B.C.D/FILE
Description	USERNAME : The ssh username created by the server A.B.C.D : remote scp/sftp server ip address FILE : upgrade file The configuration takes effect after the device is restarted

- Use SCP/SFTP Client to Import Configuration

Command	SWITCH# copy scp scp://USERNAME@A.B.C.D /FILE {startup-config running-config} SWITCH# copy sftp sftp://USERNAME@A.B.C.D /FILE {startup-config running-config}
Description	USERNAME: The ssh username created by the server A.B.C.D: remote scp/sftp server ip address FILE: configuration file

- Use SCP/SFTP Client to Export Configuration

Command	SWITCH# copy {startup-config running-config} scp scp://USERNAME@A.B.C.D/F ILE SWITCH# copy {startup-config running-config} sftp sftp://USERNAME@A.B.C.D/F ILE
Description	USERNAME : The ssh username created by the server A.B.C.D : remote scp/sftp server ip address FILE : A new file created on the remote server to save the exported file

- Use SCP/SFTP Client to Import Files

Command	SWITCH# scp {cipher {3des-cbc aes128-cbc aes192-cbc aes256-cbc aes128-ctr aes192-ctr aes256-ctr aes128-gcm aes256-gcm} } {hmac {md5-96 md5-128 sha1-96 sha1-160 sha2-256 sha2-512} } scp: //USERNAME@A.B.C.D/FILE {key upgrade} {PATH }
---------	--

	SWITCH# <code>sftp {cipher { 3des-cbc aes128-cbc aes192-cbc aes256-cbc aes128-ctr aes192-ctr aes256-ctr aes128-gcm aes256-gcm } } {hmac {md5-96 md5-128 sha1-96 sha1-160 sha2-256 sha2-512 } } sftp://USERNAME@A.B.C.D/FILE {key upgrade} {PATH }</code>
Description	USERNAME: The ssh username created by the server A.B.C.D: remote scp/sftp server ip address FILE: The file to be imported on the remote server PATH: The file storage path of the device

- Use SCP/SFTP Client to Export Files

Command	SWITCH# <code>scp {cipher {3des-cbc aes128-cbc aes192-cbc aes256-cbc aes128-ctr aes192-ctr aes256-ctr aes128-gcm aes256-gcm} } {hmac {md5-96 md5-128 sha1-96 sha1-160 sha2-256 sha2-512 } } {log key upgrade} FILE scp://USERNAME@A.B.C.D/PATH/FILE</code> SWITCH# <code>sftp {cipher {3des-cbc aes128-cbc aes192-cbc aes256-cbc aes128-ctr aes192-ctr aes256-ctr aes128-gcm aes256-gcm} } {hmac {md5-96 md5-128 sha1-96 sha1-160 sha2-256 sha2-512 } } {log key upgrade} FILE sftp://USERNAME@A.B.C.D/PATH/FILE</code>
Description	USERNAME : The ssh username created by the server A.B.C.D: remote scp/sftp server ip address FILE: File on the device PATH/FILE: The newly created file on the remote server where the exported file is saved

1.2. Examples

1.2.1. Configuring SSH Local User Authentication

7) Requirements

After the SSH server function is enabled on the device, users can log in to the device through SSH using the local account on the device;

After the SFTP server function is enabled on the device, users can use the local account on the device to access device files through SFTP.

8) Network Diagram



9) Configuration

SWITCH:

- Enter global configuration mode and add local user test.

```
SWITCH(config)# username test password test
```

- Enable the SSH server and SFTP server (the default port number of the SFTP server is 10022).

```
SWITCH(config)# ssh-server enable
```

```
SWITCH(config)# sftp-server enable
```

10) Verify

- Use client software to log in through SSH .

```
root@Ubuntu:~# ssh test@2.2.2.95
```

```
Password:
```

```
SWITCH>
```

- Use client software to log in to SFTP .

```
root@Ubuntu:~# sftp -P 10022 test@2.2.2.95
```

```
Password:
```

```
Connected to 2.2.2.95.
```

```
sftp> ls
```

```
all btmp fsck mstp.log.1 snmpd.log syslog wtmp.1 yes yes.pub zonlist
```

1.2.2. Configuring SSH Public Key Authentication

1) Requirements

After the SSH server function is enabled on the device , users can log in through public-key authentication without using a password.

2) Network Diagram



3) Configuration

SWITCH:

- Enter global configuration mode and enable the SFTP server and SSH server.

```
SWITCH(config)# sftp-server topdir key
SWITCH(config)# sftp-server enable
SWITCH(config)# ssh-server enable
```

PC:

- The client generates a key pair and uploads the public key file to the SFTP shared directory of the device.

```
root@Ubuntu:~# ssh-keygen -t dsa
Generating public/private dsa key pair.
Enter file in which to save the key (/root/.ssh/id_dsa):
Enter passphrase (empty for no passphrase):
Enter same passphrase again:
Your identification has been saved in /root/.ssh/id_dsa.
Your public key has been saved in /root/.ssh/id_dsa.pub.
The key fingerprint is:
SHA256:UpwCGUibXy24D/NVD5h0AsNhWfW9yPdmuhmADv55aS4 root@Ubuntu
The key's randomart image is:
+----[DSA 1024]-----+
| ..oB*...          |
| .++= o = .        |
| o . = 0 + .       |
| . o B + + .       |
| = o S + +         |
| * = o .           |
| + . .. +         |
| .E. + *           |
| o=. +.            |
+----[SHA256]-----+
root@Ubuntu:~#
root@Ubuntu:~# sftp -P 10022 admin@2.2.2.95
Password:
Connected to 2.2.2.95.
sftp> put /root/.ssh/id_dsa.pub
Uploading /root/.ssh/id_dsa.pub to /id_dsa.pub
/root/.ssh/id_dsa.pub
100% 600 29.4KB/s 00:00
```

SWITCH :

- Associate the public key with user test .

```
SWITCH(config)# ip ssh peer test public-key key id_dsa.pub
```

4) Verify

- Use the client software to log in to SSH without a password .

```
root@Ubuntu:~# ssh test@2.2.2.95
Connected to 2.2.2.95.
SWITCH>
```

- Use client software to log in to SFTP without a password .

```
root@Ubuntu:~# sftp -P 10022 test@2.2.2.95
Connected to 2.2.2.95.
sftp>
```

1.2.3. Configuring the SFTP Server

1) Requirements

After the SFTP server function is enabled on the device, users can use the sftp command to upload or download files to the device.

2) Network Diagram



3) Configuration

SWITCH: (The default root directory of the SFTP server is the log directory, which only supports file downloads)

- Enter global configuration mode, enable the SFTP server (the default port number is 10022), and add local user test.

```
SWITCH(config)# sftp-server enable
SWITCH(config)# username test password test
```

4) Verify

Download log file:

PC:

- Use client software to log in to the device through SFTP and download the syslog file to the device.

```
root@Ubuntu:~# sftp -P 10022 test@2.2.2.95
Password:
Connected to 2.2.2.95.
sftp> get syslog
sftp> exit
root@Ubuntu:~# ls -lh syslog
-rw-r----- 1 test test 15K March 6 11:20 syslog
```

Upload the public key file:

SWITCH:

- Enter the global configuration mode and change the SFTP server root directory to the key directory.

```
SWITCH(config)# sftp-server topdir key
```

PC:

- Use the client software to log in to SFTP and upload the public key file to the device.

```
root@Ubuntu:~# sftp -P 10022 test@2.2.2.95
Password:
Connected to 2.2.2.95.
sftp> put /root/.ssh/id_dsa.pub
```

Switch:

- View uploaded files.

```
SWITCH# show dir key
List directory contents on key:
-----
-rw----- 1 root root 600 Jan 2 01:00 id_dsa.pub
-----
```

```
1 files, 0 directories
48624 total bytes, 28448 available bytes
```

```
SWITCH# more key id_dsa.pub
ssh-dss
```

```
AAAAB3NzaC1kc3MAAACBAMuQ6mHkndEe4UYOgb04j1pH6YeyPXyo8nkSAKkFz/9PNh1Dg jEXdufHc000TqSNQ
19Zm31Y/g0Vd1wpf inHTnUbxYgS/mUV4ZxwLs3gvRYjVxbnybxti5p6FGi9wvDk2HOTIoaEwz3v5gsWGCL/e
xJebop0aq1Es576XxDzyn3AAAAFQC8micjd1a01LDhStcs175+I9yRMwAAAIUAUaLt4Ls2xFLxr1fsWHOvVAK1
XqszyU2ofvym+1kcuzs1PvBLk19D9uYKjoJCXIsxsFjrSNgdumNCsA18wv/H7jqiw0p+z2jYeRrtuP1Cz3au
hn8fA/7+zTb1MNzTR3wVsE4Vu9ib2eP/qoB1eK3InQY1ywiitj7Wodg+FnoQQAAAIBS/8xCdKC91CPJL+UF
o9iHDZBCRTIcvVnoESTXo6ZWbZZ9FH5oTe+w3BXpJJ2rMM2TYZ34Gww3hM4NcnJWBsrxe3bD06geVkoqVHG0
x18vkivHQf4Hxx/4urlpctvve6s6pzWuwf+2umEXjvp+oDsmDOYA0Wywo762v9LKofFw==
```

To perform a firmware upgrade:

SWITCH:

- Enter global configuration mode and change the SFTP server root directory to the upgrade directory.

```
SWITCH(config)# sftp-server topdir upgrade
```

PC:

- Use the client software to log in to SFTP and upload the bin file to the device.

```
root@Ubuntu:~# sftp -P 10022 test@2.2.2.95
Password:
Connected to 2.2.2.95.
sftp> put ac5-hotfix-7.3.2.bin
```

SWITCH:

- Upgrade the firmware.

```
SWITCH#upgrade firmware upgrade ac5-hotfix-7.3.2.bin
Un-packet install file success.
Check upgrade file success.
Firmware upgrade successful.
Reboot system to finish upgrade? (y/n): y
```

1.2.4. Configuring the SFTP Client

1) Requirements

On the device, users can use the sftp command to upload or download files to the SFTP server.

2) Network Diagram



3) Configuration

PC:

Add the available user test to the SFTP Server. (Configuration omitted)

4) Verify

Upload log file:

SWITCH:

- Run the sftp command to upload the log file to the SFTP server.

```
SWITCH# sftp log syslog sftp://test@2.2.2.106:22/home/test/syslog
(test@192.168.5.100) Password:
Copy Success
```

To perform a firmware upgrade:

SWITCH:

- Use the sftp command to upgrade the firmware.

```
SWITCH# upgrade firmware sftp://test@192.168.5.100:22/ac5-hotfix-7.3.2.bin
(test@192.168.5.100) Password:
Un-packet install file success.
Check upgrade file success.
Firmware upgrade successful.
Reboot system to finish upgrade? (y/n): y
```

- Use the sftp command to specify the algorithm to upgrade the firmware.

```
SWITCH# sftp cipher aes128-gcm hmac sha2-512
sftp://test@192.168.5.100:22/ac5-hotfix-7.3.2.bin upgrade
(test@192.168.5.100) Password:
Copy Success
SWITCH# upgrade firmware upgrade ac5-hotfix-7.3.2.bin
Un-packet install file success.
Check upgrade file success.
Firmware upgrade successful.
Reboot system to finish upgrade? (y/n): y
```

Upload and download files without password:

SWITCH:

- View the device host public key.

```
SWITCH#show crypto key mypubkey ecc
-----
Time of Key pair created : 1970-01-01 00:00:06
Key name : Host
Key type : ECC Encryption Key
-----
```

Key fingerprint:

```
256 SHA256:jE2wMZ06ERheN8KcY5is91mcokfQ3htD+afjWCIJRuI no comment (ECDSA)
```

Host public key for PEM format code:

```
-----BEGIN PUBLIC KEY-----
```

```
MFkwEwYHKoZIzj0CAQYIKoZIzj0DAQcDQgAEk+xRNsnGwPSd9FWg6ZvBOvXQXOQz  
g1e1G7a3nJe4fefsY7Y3hv1Et2MwCu98bFGGZwsp/Yuc8L0ThKTKUqjIka==
```

```
-----END PUBLIC KEY-----
```

After removing the newline, the public key code for pasting into OpenSSH authorized_keys file:

```
ecdsa-sha2-nistp256 AAAAE2VjZHNhLXNoYTItbmlzdHAyNTYAAAAIbmlzdHAyNTYAAABBBJP5UTbJ  
4FjOnfRVoOmbwTr10F9EM4NXtRu2t5yXuH3n7G02N4b5RLdjMARvfGxRhmcLKf2LnPC9E4Sky1KoyJA=
```

Delete the line breaks from the host public key of the device and copy it to /home/test/.ssh/authorized_keys on the SSH server .

SWITCH:

- Verify the configuration results and upload the log file without password

```
SWITCH# sftp log syslog sftp://test@2.2.2.106:22/home/test/syslog  
Copy Success
```

1.2.5. Configuring the SCP Client

1) Requirements

On the device, users can use the sftp command to upload or download files to the SCP server.

2) Network Diagram



3) Configuration

Add the available user test to the SCP Server. (Configuration omitted).

4) Verify

Upload log file:

SWITCH:

- Run the scp command to upload the log file to the SCP server.

```
SWITCH# scp log syslog scp://test@2.2.2.106:22/home/test/syslog  
(test@192.168.5.100) Password:  
Copy Success
```

To perform a firmware upgrade:

SWITCH:

- Use the scp command to upgrade the firmware.

```
SWITCH# upgrade firmware scp://test@192.168.5.100:22/ac5-hotfix-7.3.2.bin  
(test@192.168.5.100) Password:  
Un-packet install file success.  
Check upgrade file success.  
Firmware upgrade successful.  
Reboot system to finish upgrade? (y/n): y
```

- Use the scp command to specify the algorithm to upgrade the firmware.

```
SWITCH# scp cipher aes128-gcm hmac sha2-512 scp://test@192.168.5.100:22/ac5-  
hotfix-7.3.2.bin upgrade  
(test@192.168.5.100) Password:  
Copy Success  
SWITCH# upgrade firmware upgrade ac5-hotfix-7.3.2.bin  
Un-packet install file success.  
Check upgrade file success.  
Firmware upgrade successful.  
Reboot system to finish upgrade? (y/n): y
```

Upload and download files without password:

SWITCH:

- View the device host public key.

```
SWITCH#show crypto key mypubkey ecc
```

```
-----  
Time of Key pair created : 1970-01-01 00:00:06
```

```
Key name : Host
```

```
Key type : ECC Encryption Key  
-----
```

```
Key fingerprint:
```

```
256 SHA256:jE2wMZ06ERheN8KcY5is91mcokfQ3htD+afjWCIJRuI no comment (ECDSA)
```

```
Host public key for PEM format code:
```

```
-----BEGIN PUBLIC KEY-----
```

```
MFkwEwYHKOzIzjOCAQYIKoZIZjODAQcDQgAEk+xRNsnGWPsd9FWg6ZvBOvXQX0Qz
```

```
gle1G7a3nJe4fefsY7Y3hv1Et2MwCu98bFGGZwsp/Yuc8L0ThKTKUqjIkA==
```

```
-----END PUBLIC KEY-----
```

After removing the newline, the public key code for pasting into OpenSSH authorized_keys file:

```
ecdsa-sha2-nistp256 AAAAE2VjZHNhLXNoYTItbmlzdHAyNTYAAAAIbmlzdHAyNTYAAABBBJPsUTbJ  
4FjOnfRV0ombwTr10F9EM4NXtRu2t5yXuH3n7G02N4b5RLdjMARvfGxRhmcLKf2LnPC9E4Sky1KoyJA=
```

Delete the line breaks from the host public key of the device and copy it to /home/test/.ssh/authorized_keys on the SSH server .

SWITCH:

- Verify the configuration results and upload the log file without password

```
SWITCH# scp log syslog scp://test@2.2.2.106:22/home/test/syslog  
Copy Success
```

1.3. Display Information

1.3.1. View SSH Server And SFTP Server Configuration Information

```
SWITCH# show sshd status
```

```
SSH Enable - version 2.0
```

```
SSH Stelnet Server Port : 22
```

```
SSH Stelnet Server : enabled
```

```
SSH SFTP Server Port : 10022
```

```
SSH SFTP Server : enabled
```

```
SSH SFTP Server Topdir : log
```

```
Status of the Stelnet Server and SFTP Server sharing algorithm:
```

```
SSH Key Exchange En : dh_group_exchange_sha1,dh_group14_sha1,
```

```
ecdh_sha2_nistp256,ecdh_sha2_nistp384,
```

```
ecdh_sha2_nistp521
```

```
SSH Key Exchange Dis : dh_group1_sha1
```

```
SSH Cipher Mode En : aes128-ctr,aes128-gcm,aes192-ctr,
```

```
aes256-ctr,aes256-gcm
```

```
SSH Cipher Mode Dis : 3des-cbc,aes128-cbc,aes192-cbc,aes256- cbc,blowfish-  
cbc,des-cbc,arcfour
```

```
SSH HMAC Algorithm En : sha2-256,sha2-512
```

```
SSH HMAC Algorithm Dis : md5,md5-96,sha1,sha1-96
```

1.3.2. View the Public Key Information of the SSH Server

```
SWITCH# show crypto key mypubkey dsa
```

```
-----  
Time of Key pair created : 1970-01-01 01:09:31
```

```
Key name : Host
```

```
Key type : DSA Encryption Key  
-----
```

```
Key fingerprint:
```

```
1024 SHA256:qcAqmIUpn7FNMQ0A7x1V59YGxy1bHU8xwXrpA3zCFQw no comment (DSA)
```

```
Host public key for PEM format code:
```

```
-----BEGIN PUBLIC KEY-----
```

```
MIIBtjCCASsGByqGSM44BAEwggEeAoGBAIwS+1w2uId2Vydoj3yvqzSYJvG01k0y
lsQposnBqX/XxMOBki5kzTj8ZIU9cXLRzwf6d9Z1FFqi50LRWKCUPcbgGC4JyEnm
BL/bVgDYBrz+bPIdqcyxT1fuIdpe9YVtaJwVQ2qxZX302xxp1aLORgWI5RDgdgB4
fRdiV7aLaMDLAhUA46v3vR99sa545Pn/Sj/Hn7z/xJcCgYAdGmpTqNxn7vZpq49c
0J/3DAXkxy6a/XEE78pTfjvUYh2+aFhon7ZRCtrJXVKEaoBFodB/TNiQ+zPzJt6v
mtBsa5R0cBxJ4YM3yCVME1ZXE8Ees5JtDaadvBIUEdfvv1NMwSkMgwFqdbv+tuD8
PdGnv6/kfC0Ro16bNqquH8L7w0BhAACgYBUuSLIYMuIVBMyKFj5D1gVnxqqwAuNC
FvKwDfifnSy76qu16NoTm5cjhprhqmDTmCEpkPyh+iN5BRkRpzRGo20J2GNsJbsD
qBhRrUtohpUtuTqKKNtCytHFhg2UXjnZz2YmLWyecROOSBGpGUOZOhgNZRwNOKDOGN
QfFmfXhT6ZyAdQ==
-----END PUBLIC KEY-----
```

After removing the newline, the public key code for pasting into OpenSSH authorized_keys file:

```
ssh-dssAAAAB3NzaC1kc3MAAACBAIwS+1w2uId2Vydoj3yvqzSYJvG01k0y1sQposnBqX/XxMOBki5kzTj8ZIU9cXLRzwf6d9Z1FFqi50LRWKCUPcbgGC4JyEnmBL/bVgDYBrz+bPIdqcyxT1fuIdpe9YVtaJwVQ2qxZX302xxp1aLORgWI5RDgdgB4fRdiV7aLaMDLAAAFQDjq/e9H32xrnjk+f9KP8efvP/ElwAAAIADGmpTqNxn7vZpq49c0J/3DAXkxy6a/XEE78pTfjvUYh2+aFhon7ZRCtrJXVKEaoBFodB/TNiQ+zPzJt6vmtBsa5R0cBxJ4YM3yCVME1ZXE8Ees5JtDaadvBIUEdfvv1NMwSkMgwFqdbv+tuD8PdGnv6/kfC0Ro16bNqquH8L7wAAAIuSLIYMuIVBMyKFj5D1gVnxqqwAuNCFvKwDfifnSy76qu16NoTm5cjhprhqmDTmCEpkPyh+iN5BRkRpzRGo20J2GNsJbsDqBhRrUtohpUtuTqKKNtCytHFhg2UXjnZz2YmLWyecROOSBGpGUOZOhgNZRwNOKDOGNQfFmfXhT6ZyAdQ==
```

```
SWITCH# show crypto key mypubkey ecc
```

```
-----
Time of Key pair created : 1970-01-01 00:00:07
Key name : Host
Key type : ECC Encryption Key
-----
```

Key fingerprint:

256 SHA256:FPaSV13T1KzbMTxkCSi9Byo1HVFSWNnq7zj7DJ/665Y no comment (ECDSA)

Host public key for PEM format code:

```
-----BEGIN PUBLIC KEY-----
MFkwEwYHKoZIzj0CAQYIKoZIzj0DAQcDQgAEPK++Ze2FpAhM3eT5xdkA03b2ZPdL
vYPATvJ97x8rn1GHZKCQVwhfp3ypFGkKb0DyPss6akViyeQwTbNMWTzt1Q==
-----END PUBLIC KEY-----
```

After removing the newline, the public key code for pasting into OpenSSH authorized_keys file:

```
ecdsa-sha2-nistp256 AAAAE2VjZHNhLXNoYTItbmlzdHAyNTYAAAAIbmlzdHAyNTYAAABBBdyvvmXt
haQITN3k+cXZADt29mT3S72DwE7yfe8fK59Rh2SgkFcB36d8qRRpCm9A8j7L0mpFYsnkME2zTFk2bdU=
```

```
SWITCH# show crypto key mypubkey rsa
```

```
-----
Time of Key pair created : 1970-01-01 00:00:07
Key name : Host
Key type : RSA Encryption Key
-----
```

Key fingerprint:

4096 SHA256:ffzwCGvE5+5WJG51ecxjp9RsF5aYWiZ/srU18s4Q9oA no comment (RSA)

Host public key for PEM format code:

```
-----BEGIN RSA PUBLIC KEY-----
MIICCgKCAgEA3gXmWM4BjozUC/NrLAYKaH5BzaUqXoXKxE1HG/g/LjpaJ9QNxbp9
ja51ZjjWIGbQu5FpYp+11D/VIj91wD69m6M0ApWFOD4K/vXTY6P+qjVJdk1FnAzT
3idamH8j51HI+T12bKvKvTuoSKu2PYTeDLkBvsAU5bN/dmFg4Z3MXU/UrMJwC1z8
3y0ci5WxGfge4UboomOXEOMgcRoDtxi3ob06k2HHC1VjUJXPORAY5xXor0nEB1fS
yTDOGcjCBBsza1X9QHNS0pBG+av+fPYqfJW1CukYyZjW+KLBwt/KEB01n80+wEr
xKV6sCPpbKqLj8VeQQBhLzxJucpWwq9M7ziVnb49BtRV50USyBZwPr7/+MQXPRKo
```

```
3K1Y798PQugOZQXTacs9j10eHV/wbUTLHNQGbC2z4ccvDozbVFADoUPdeLpe+Vhv
y5lHZhouYowBfPpWE14iwg6vnYkLC1KpVx5BZG+RdnPBxwQ+LddyoyKB6PDzYvMS
VgYQAZzR0scpvdRvHKBVnLoZ4n+LOet3LrNCKnxzqDMHyQcDQwJURqsqAHW81AUO
01XmSiB0pjeZdifU51xqfuXQJcPwXfsB84DgdICmJJpxz5JbLEFh4vDyVgbI21xi
mzJLp8bujeB830BETjgDBY9FPnJMweGoySpKOSH6aY7ycmP+8uFWYnUCAwEAAQ==
-----END RSA PUBLIC KEY-----
```

After removing the newline, the public key code for pasting into OpenSSH authorized_keys file:

```
ssh-rsaAAAAB3NzaC1yc2EAAAADAQABAAQDeBeZYzgG0jNQL82ssBgpofkHNpSpehcrESUcb+D8u
0lon1A3Fun2NrmVmONYgZtC7kwl1n6WUP9UiP3XAPr2bozQC1YXQPgr+9dnjo/6qNUkOTUwCDNPeJ1qY
fyPnUc.j5OXZsq8q906Iq7Y9hN4MuQG+wBtlS390wWDhncxdT9SswAKXPzflRyL1bEZ+B7hRuiiY5cT
QyBxGgO3GLEhvTqTYccKVWNQk9c5EDLnFeivScQHV9LJMPQYK0IEGzNrVf1Ac1LSkEb5q/589ip81aU
JSRjJmNb4osHC3+QQHSWfw77ASvEpXqWI+lsqouPxV5BAGEvPEm5y1bCr0zv0JWdvj0G1FXnRRLIFnA+
vv/4xBc9EqjcrVjv3w9C6A51BdNpyz2PU54dX/BtRMsc1AZsLbPhxy80jNtUUA0hQ914u175WG/LmUdm
Gi5ijAF8+1YSXiLCDq+diQsLUq1XHkFkb5F2c8HHBD4t13KjIoHo8PNi8xJWBhABnNE6xym92tUcoFWc
uhnif4vR63cus0IqfHOoMwfJBwNDA1RGqyoAdbyUBQ7SvEzKIE6mN512J9TnXGp+5dAlw/Bd+wHzgOB0
gKYkmmHPk1ssQWHi8PJWBSjbXGkbMkunxu6NwHzfQEROAMFjOU+ckzB4ajJkkrRlfppjvJyY/7y4VZidQ==
```

1.3.3. View the File Information in the SFTP Shared Directory

```
SWITCH# show dir log
```

```
List directory contents on log:
```

```
-----
-rw-r----- 1 root adm 304K Jan 1 01:09 all
-rw----- 1 root root 59K Jan 1 00:02 btmp
drw-r--r-- 2 root root 296 Oct 25 2023 fsck
-rw-r----- 1 root root 21K Jan 1 00:06 mstp.log.1
-rw-r--r-- 1 root root 448 Jan 1 00:00 snmpd.log
-rw-r----- 1 root adm 1.5K Jan 1 01:09 syslog
-rw-r--r-- 1 root root 175M Jan 1 00:00 wtmp.1
-rw----- 1 root root 1.8K Jan 4 1970 yes
-rw-r----- 1 root root 393 Jan 4 1970 yes.pub
-rw-r----- 1 root root 4.7K Jan 1 1970 zonlist
-----
```

```
9 files, 1 directories
```

```
48624 total bytes, 30456 available bytes
```

```
SWITCH#show dir key
```

```
List directory contents on key:
```

```
-----
-rw----- 1 root root 387 Jan 1 1970 id_rsa.pub
-----
```

```
1 files, 0 directories
```

```
48624 total bytes, 30096 available bytes
```

```
SWITCH#more key id_rsa.pub
```

```
ssh-rsa
```

```
AAAAB3NzaC1yc2EAAAADAQABAAQACnouac9AIYmH8fR7IShaJracQdju7j14y+/HoOd9II4kRN81mEvaEU0
1uPyWZBMWvNdKLAclc49JdaDOEfoYSvkqg8DEV03poMztrd3Shlxg3m9B2kqvKlcVdt324yBw3KS11sw4luSj
f8B3+ozR2Xu3zKvkiHaJs/gS8sW+UVpgfU2J2yo0HKCpG8X3hvmzZsBwSxAjRxHoAEevkr6s9OUR9a8KbFmXn
dGcY5BfJ/Cla05gn8LnYf86WxeoagMsfceHUnfFwUy91rKNzLNP5SOLzPQ46ZunS99px1/1cR0pe5i15yeT1
F6cKdw711ts56wONdfdqev2CJRckkN7L
```

38. Fault Diagnosis

38.1. Ping/tracerout

- ping

Command	SWITCH# ping {ip IPADDR ipv6 IPV6ADDR}
Description	Ping a remote host through IP.

- traceroute

Command	SWITCH# traceroute {ip IPADDR ipv6 IPV6ADDR }
Description	Trace the path that packets take through the network.

38.2. Port Optical Module

38.2.1. Configuring Port Optical Module

- Configuring Optical-transceiver Monitor Enable

Command	SWITCH(config-if)# optical-transceiver monitor enable SWITCH(config-if)# no optical-transceiver monitor enable
Description	Enable monitor the specified interface, detect the status of optical module periodically. Default is disabled.

- Configuring Optical-transceiver Monitor Interval

Command	SWITCH(config)# optical-transceiver monitor interval MINUTES SWITCH(config-if)# no optical-transceiver monitor interval
Description	Set the interval of the transceiver monitor. Default is 15 minutes. Range from 1 to 1440 minutes.

- Configuring Optical-transceiver Temperature Threshold

Command	SWITCH(config-if)# optical-transceiver threshold temperature HALARM HWARN LWARN LALARM SWITCH(config-if)# no optical-transceiver threshold temperature
Description	By default, the optical module has own temperature threshold setting, so it is not recommended to configure the temperature threshold. HALARM: high-alarm threshold value, range from -255 to 255 C HWARN: high-warning threshold value, range from -255 to 255 C LWARN: low-warning threshold value, range from -255 to 255 C LALARM: low-alarm threshold value, range from -255 to 255 C The HALARM value should not smaller than HWARN value. The LWARN value should not smaller than LALARM value.

- Configuring Optical-transceiver Voltage Threshold

Command	SWITCH(config-if)# optical-transceiver threshold voltage HALARM HWARN LWARN LALARM SWITCH(config-if)# no optical-transceiver threshold voltage
Description	By default, the optical module has own voltage threshold setting, so it is not recommended to configure the voltage threshold. HALARM: high-alarm threshold value, range from 0.00 to 5.00 V HWARN: high-warning threshold value, range from 0.00 to 5.00 V LWARN: low-warning threshold value, range from 0.00 to 5.00 V LALARM: low-alarm threshold value, range from 0.00 to 5.00 V The HALARM value should not smaller than HWARN value. The LWARN value should not smaller than LALARM value.

- Configuring Optical-transceiver Bias Threshold

Command	SWITCH(config-if)# optical-transceiver threshold bias HALARM HWARN LWARN LALARM SWITCH(config-if)# no optical-transceiver threshold bias
Description	By default, the optical module has own bias threshold setting, so it is not recommended to configure the bias threshold. HALARM: high-alarm threshold value, range from 0.00 to 500.00 mA HWARN: high-warning threshold value, range from 0.00 to 500.00 mA LWARN: low-warning threshold value, range from 0.00 to 500.00 mA

	LALARM: low-alarm threshold value, range from 0.00 to 500.00 mA The HALARM value should not smaller than HWARN value. The LWARN value should not smaller than LALARM value.
--	---

- Configuring Optical-transceiver Rx-power Threshold

Command	SWITCH(config-if)# optical-transceiver threshold rx-power HALARM HWARN LWARN LALARM SWITCH(config-if)# no optical-transceiver threshold rx-power
Description	By default, the optical module has own rx-power threshold setting, so it is not recommended to configure the rx-power threshold. HALARM: high-alarm threshold value, range from -40.00 to 10.00 dBm HWARN: high-warning threshold value, range from -40.00 to 10.00 dBm LWARN: low-warning threshold value, range from -40.00 to 10.00 dBm LALARM: low-alarm threshold value, range from -40.00 to 10.00 dBm The HALARM value should not smaller than HWARN value. The LWARN value should not smaller than LALARM value.

- Configuring Optical-transceiver Tx-power Threshold

Command	SWITCH(config-if)# optical-transceiver threshold tx-power HALARM HWARN LWARN LALARM SWITCH(config-if)# no optical-transceiver threshold tx-power
Description	By default, the optical module has own tx-power threshold setting, so it is not recommended to configure the tx-power threshold. HALARM: high-alarm threshold value, range from -40.00 to 10.00 dBm HWARN: high-warning threshold value, range from -40.00 to 10.00 dBm LWARN: low-warning threshold value, range from -40.00 to 10.00 dBm LALARM: low-alarm threshold value, range from -40.00 to 10.00 dBm The HALARM value should not smaller than HWARN value. The LWARN value should not smaller than LALARM value.

38.2.2. Alarm/Warning Trap

In addition to the alarm or warning message, the optical module monitor will also send a trap message to the smmp server.

Node	data
Mib files	TNPL_private_2.1.89(interface_ddm).mib
Alarm oid	1, 3, 6, 1, 4, 1, 37831, 101, 110, 1
Warning oid	1, 3, 6, 1, 4, 1, 37831, 101, 110, 2
Iindex oid	1, 3, 6, 1, 4, 1, 37831, 100, 30, 2, 1, 1
Information oid	1, 3, 6, 1, 4, 1, 37831, 100, 30, 2, 1, 2

38.2.3. Display Port Optical Module DDM Information

- Show interface optical-transceiver information

Display the information of the optical/copper module inserted in the optical port.

Command	SWITCH# show interface {IFNAME } optical-transceiver {info }
Description	If no interface-id is specified, the module information of all ports will be displayed. If info is not specified, the DDM information of the port module will be displayed, and if specified, the complete module information (basic information, alarm information, manufacturer information) will be displayed.

DDM information display elements are as follows:

Key Word	Description
Temp	The temperature of the module, in °C, accurate to 1°C.
Voltage	The voltage of the module, the unit is V, accurate to 0.01V.
Bias	The current of the module, in mA, accurate to 0.01mA.
RX power	The received optical power of the module, in dBm, accurate to 0.01dBm.
TX power	The transmit optical power of the module, in dBm, accurate to 0.01dBm.
OK	normal, no intervention required.
WARN	Alarm, indicating that the allowable range of the device is exceeded, and attention should be paid to.
ALARM	Abnormal, indicating that the device's allowable state is seriously exceeded and immediate intervention is required.
ABSENT	Absent.
NA	Port not supported/module not supported.

TIMEOUT	Time out.
ERR	Mistake.

Display all port module DDM information

```
SWITCH#show interface optical-transceiver
  Port      Temp      Voltage    Bias      RX power   TX power
   [C]      [V]       [mA]      [dBm]     [dBm]
```

Port	Temp [C]	Voltage [V]	Bias [mA]	RX power [dBm]	TX power [dBm]
GiE0/9	42 (OK)	3.20 (OK)	32.34 (OK)	-3.98 (OK)	1.64 (OK)
GiE0/10	ABSENT	ABSENT	ABSENT	ABSENT	ABSENT
GiE0/11	ABSENT	ABSENT	ABSENT	ABSENT	ABSENT
GiE0/12	ABSENT	ABSENT	ABSENT	ABSENT	ABSENT

- Display the overall information of the port optical module/copper module

Error message:

Key Word	Description
Transceiver absent!	Failed to get information, maybe the module is not in place.
Get transceiver info timeout!	Timeout to get information, need to get it again.
Port doesn't support get module info!	The port does not support getting module information.

Basic Information

Key Word	Description
Transceiver Type	module type.
Connector Type	Interface Type.
Wavelength(nm)	Wavelength.
Link Length	Supported link lengths.
Digital Diagnostic Monitoring	Whether to support DDM function.
Vendor Serial Number	Module serial number.

Warning Information

Key Word	Description
RX Channel loss of signal	Received signal loss.
RX Channel power high	High received optical power alarm.
RX Channel power low	Low received optical power alarm.
TX Channel fault	Send Error.
TX Channel bias high	Bias current high alarm.
TX Channel bias low	Bias current low alarm.
TX Channel power high	Sending high optical power alarm.
TX Channel power low	Sending low optical power alarm.
Temperature high	High temperature alarm.
Temperature low	Low temperature alarm.
Voltage high	High voltage alarm.
Voltage low	Low voltage alarm.
None	no alarm.
This module doesn't support getting alarm!	The module does not support getting alarm information.

Manufacturer information

Key Word	Description
Vendor Name	Manufacturer Names.
Vendor OUI	Manufacturer OUI.
Vendor Part Number	Manufacturer part number.
Vendor Revision	Manufacturer version number.
Manufacturing Date	Production Date.
Encoding	encoding type.

Displays overall information about a single port module

```
SWITCH#show interface gigabitEthernet0/9 optical-transceiver info
#####
```

```

gigabitEthernet0/9
-----
|Transceiver base information:|
-----
|Transceiver Type   : 1000BASE-ZX-SFP|
|Connector Type    : LC|
|Wavelength(nm)   : 1550|
|Link Length      :|
|   SMF fiber|
|   -- 80km|
|Digital Diagnostic Monitoring : YES|
|Vendor Serial Number      : WT1703230031|
-----
|Transceiver current alarm information:|
-----
|None|
-----
|Transceiver vendor information:|
-----
|Vendor Name       : OEM|
|Vendor OUI        : 000000|
|Vendor Part Number : SFP-GE-ZX-SM1550|
|Vendor Revision   : V2|
|Manufacturing Date : 2017-03-25|
|Encoding          : 8B10B|
-----
SWITCH#

```

Displays overall information for all port blocks

```

SWITCH#show interface optical-transceiver info
#####
gigabitEthernet0/9
-----
|Transceiver base information:|
-----
|Transceiver Type   : 1000BASE-ZX-SFP|
|Connector Type    : LC|
|Wavelength(nm)   : 1550|
|Link Length      :|
|   SMF fiber|
|   -- 80km|
|Digital Diagnostic Monitoring : YES|
|Vendor Serial Number      : WT1703230031|
-----
|Transceiver current alarm information:|
-----
|None|
-----
|Transceiver vendor information:|
-----
|Vendor Name       : OEM|
|Vendor OUI        : 000000|
|Vendor Part Number : SFP-GE-ZX-SM1550|
|Vendor Revision   : V2|
|Manufacturing Date : 2017-03-25|
|Encoding          : 8B10B|
-----
#####
gigabitEthernet0/10
-----
|Transceiver base information:|
-----
|Transceiver Type   : 1000BASE-GT-SFP|
|Connector Type    : Unknown or unspecified|
|Wavelength(nm)   : 16652|
|Link Length      :|
|   Cable Assembly copper|
|   -- 100m|
|Digital Diagnostic Monitoring : NO|

```

```

|Vendor Serial Number      : MTC100046 |
+-----+
|Transceiver current alarm information: |
+-----+
This module doesn't support getting alarm!
|This module doesn't support getting alarm! |
+-----+
|Transceiver vendor information: |
+-----+
|Vendor Name      : OEM |
|Vendor OUI      : 000000 |
|Vendor Part Number : SFP-T-CBTX |
|Vendor Revision  : F |
|Manufacturing Date : 2014-10-01 |
|Encoding        : 8B10B |
+-----+
#####
gigabitEthernet0/11
Get result error(Maybe Transceiver absent)!
#####
gigabitEthernet0/12
Get result error(Maybe Transceiver absent)!
SWITCH#

```

- Show interface optical-transceiver threshold information

Display the information of the optical/copper module inserted in the optical port.

Command	SWITCH# show interface {IFNAME } optical-transceiver threshold
Description	If no IFNAME is specified, the module information of all ports will be displayed. If the threshold is not configured, the own threshold information of the module will be displayed.

```

SWITCH#show interface optical-transceiver threshold

Interface tengigabitEthernet0/25:
Item      High-alarm  High-warn   Low-warn   Low-alarm
Temp(Celsius)  100          90          -40        -50
Voltage(V)    3.50         3.47        3.15       3.04
Bias(mA)     15.00        12.00       4.00       5.58
RX power(dBm) 10.25        5.30        -10.22     -12.40
TX power(dBm) 2.100        1.100       -9.100     -11.00

```

38.3. Dying Gasp

Dying Gasp is referenced in section 7.1.2.5.3 of ITU-T Recommendation G.991.2 (12/2003) as the Power Status bit.

The networking devices rely on a temporary back-up power supply on a capacitor, that allows for a graceful shutdown and the generation of the dying-gasp message. This temporary power supply is designed to last from 10 to 20 milliseconds to perform these tasks.

In addition to the dying-gasp message, the power-down device will also send a trap message to the smmp server.

Node	data
Mib files	DOT3-OAM-MIB.mib
oid	1, 3, 6, 1, 2, 1, 158, 1, 6, 1, 4
value	dyingGaspEvent(257)

- Enable dying-gasp

Command	SWITCH(config)# dying-gasp enable SWITCH(config)# no dying-gasp
Description	Enable dying gasp function

LOG messages

For example: "Device 00:d0:f8:c8:23:12 power down."

38.4. Cable Detect

A cable fault may cause the interface to be in the Down state or the interface rate to be abnormal even though the interface is in the Up state. Users can execute this command to detect whether the cable is faulty and locate the fault point to help solve the cable fault. Please pay attention to the following points when using the cable detection function:

- ◇ Only copper interfaces support this command.

✧ When this command is executed, the normal service of the interface may be affected in a short period of time.

✧ When the line length is less than 6 meters, there will be a deviation between the test results and the actual value. The shorter the line, the greater the deviation.

● Port Performs Cable Detection Function

Command	SWITCH(config-if)# cable-detect
Description	Perform a cable detection on the port. After 2 seconds, use the show command to view the detection results.

Perform a cable test on port g i0 /1:

```
SWITCH# configure terminal
SWITCH(config)#interface gigabitEthernet 0/1
SWITCH(config-if)#cable-detect

%Please wait for about 2 seconds and execute the show cable-detect command to view the execution results.
```

View cable test results:

```
SWITCH#show cable-detect interface gigabitEthernet 0/1
Pair A length(meters): 0
Pair B length(meters): 0
Pair C length(meters): 0
Pair D length(meters): 0
Pair A state: OK
Pair B state: OK
Pair C state: OK
Pair D state: OK
```

Field	Explain
Pair X length(meters)	Cable length. When there is a fault, it represents the length from the interface to the fault. Unit: meter
Pair X state	Network cable status: OK: Indicates that the line pair is terminated normally. Open: Indicates that the line pair is open. Short: Indicates a short circuit on the pair. Unknown: Other unknown causes of failure.

39. Configuring EFM

39.1. Overview of EFM

EFM (Ethernet in the First Mile) is mainly used for Ethernet physical layer specifications and Ethernet management and maintenance in the access part. It is link-level OAM (Operation and Management). For the link between two directly connected devices, it provides link connectivity detection, link fault monitoring, remote fault notification, and remote loopback functions.

■ OAM Common Protocol Messages

OAMPDU Type	Illustrate
Information OAMPDU	Used for EFM peer discovery, the OAM entity in the handshake phase periodically sends information OAMPDU at a certain time interval to detect the connectivity of the link. Used for fault notification. When the local end receives the information OAMPDU containing the emergency event Flags of the remote device, it sends an alarm to the network management to notify the remote device of the fault.
Event Notification OAMPDU	Used for link monitoring. When an interface detects an error frame limit exceeding event, an error frame period limit exceeding event, or an error frame second limit exceeding event, the interface sends an event notification OAMPDU to the peer device to notify the fault.
Remote loopback OAMPDU (Loopback Control OAMPDU)	Used for remote loopback, controls the OAM loopback status of the remote device, and enables or disables the remote loopback function according to the information of enabling and disabling the loopback function in the OAMPDU.

■ Establishing an EFM Connection

The local EFM and remote EFM negotiate by sending and responding to OAMPDU messages, establish an EFM connection after mutual confirmation, and continuously send Information messages to maintain the connection. Only after the EFM connection is established can the remote loopback function, link monitoring function, remote fault detection, etc. be realized. After the local device turns on the EFM function, if the mode is Active mode, it actively sends Information OAMPDU messages to the outside and waits for the remote response. At this time, the state is active_send_local.

After receiving the OAMPDU message, the remote EFM sends the Information OAMPDU message to the local EFM. When the local EFM receives the remote OAMPDU message, it enters the send_local_Remote state. Then it checks whether the state field and OAM configuration field in the local and remote messages match. If they do, it sets the corresponding flag bit and sends the OAMPDU message containing the local and remote information TLVs, and then enters the send_local_remote_ok state.

After the remote end receives the OAMPDU from the local end, it confirms a match, sets the corresponding flag bit, and sends the OAMPDU message to the local end; after the local end receives the OAMPDU message from the remote end and confirms that the remote end also meets the requirements, it establishes a connection and enters the send_any state.

After the local device turns on the EFM function, if the mode is passive, it is in the passive_wait state, waiting for the remote message. Once the remote message is received, it enters the send_local_remote state and sends the corresponding information OAMPDU message to the remote end.

■ Link Monitoring

After an EFM connection is established, you can use the EFM function to monitor the link status and send Event Notification OAMPDU messages to notify when general link events occur.

local EFM establishes a connection with the remote EFM, it monitors the link status and counts the error frames and error information of the interface. When a general link event is detected, it records the local general link event and sends an Event Notification OAMPDU message to the remote end. After the remote end receives the corresponding message, it counts the corresponding event information. General link events include the following types:

- Errored Frame Event: When the number of error frames per unit time exceeds the threshold, an Errored Frame Event Notification OAMPDU message is sent for notification.
- Errored Frame Period Event: When the number of error frames within a specified frame time exceeds the threshold, an Errored Frame Period Event Notification OAMPDU message is sent for notification.
- Errored Frame Seconds Event: When the statistical value of the errored frame seconds within the specified time exceeds the threshold, the Errored Frame Seconds Event Notification OAMPDU message is sent for notification.

■ Remote Loopback

After the EFM establishes a connection, the link can be set to loopback state. The remote device does not forward non-OAMPDU messages after receiving them, but returns them along the original path. When the link is in remote loopback state, the health of the link can be detected (link delay, jitter, bit error, etc.).

➤ Establishing Remote Loopback Function

After the local end establishes a connection with the remote EFM, the EFM loopback function can be enabled on the local end. Then the local EFM sends a Loopback Control OAMPDU message with the EFM loopback flag enabled to the remote EFM.

After receiving the OAMPDU message, the remote EFM sets its own port receiving action to loopback, initiates the action as discard, and notifies the local EFM of the information through the information

OAMPDU message.

After receiving the message, the local EFM confirms that the remote EFM has been set, then sets its own port receiving action to Discard and launching to Farward, and enters the remote loopback state.

➤ In Remote Loopback

When in the remote loopback state, all messages except OAMPDU of the remote EFM are no longer forwarded, but are transferred back to the local end along the original route. At this time, the health status of the link such as delay, jitter, and bit error can be tested.

➤ Exit Remote Loopback Function

To exit the remote loopback function, you can disable the EFM loopback function on the local end. Then the local EFM sends a loopback Control OAMPDU message with the EFM loopback disable flag bit to the remote EFM .

After receiving the OAMPDU message, the remote EFM sets its own port receiving action and sending action to Farward, and notifies the local EFM of the information through the Information OAMPDU message.

After receiving the message, the local EFM confirms that the remote EFM has been set, and then sets its own port receiving action and sending action to Farward, and then exits the remote loopback state.

■ Remote Fault Detection

After the EFM establishes a connection, if the local device encounters a fault such as interface shutdown or restart, it sends an Information OAMPDU message with a fault flag to the remote end. After receiving the message, the remote end performs corresponding statistics, records log information, and other processing. After the local EFM establishes a connection with the remote EFM, when an emergency link event occurs on the local device (such as interface shutdown, device restart), it can be marked in the flag bit of the Information OAMPDU and sent to the remote end. After receiving the information, the remote device can do corresponding processing such as recording log information. As long as the EFM connection is established, this function is automatically enabled.

➤ Emergency Link Event

Critical link events include:

Link fault: A fault occurs in the receiving direction of the link of the local device, such as plugging or unplugging the network cable.

Dying gasp: An unrecoverable fault occurs on the local device, such as device restart or interface shutdown.

Critical event: An emergency event that cannot be determined, such as abnormal temperature.

➤ Set Remote Fault Action

If the action of remote fault is set to set the link status of the port to Down, then when a remote fault is received, it will be linked with the port and set the link status of the port to Down. When the remote fault is restored, the link status of the port will be restored to Up.

39.2. Configuring

39.2.1. Configuring Basic EFM Functions

● Enable/disable EFM Function

Command	SWITCH(config-if) #efm enable SWITCH(config-if) # no efm enable
Description	Enable/disable EFM function, configured in port mode Enabling EFM on a port is a prerequisite for other EFM functions to take effect

● Configuring EFM Mode

Command	SWITCH(config-if) # efm mode {active passive}
Description	The default port EFM mode is active. If you want to change the EFM mode, you need to disable EFM first. When using EFM to detect a link, at least one of the two ends of the link should be configured as active.

● Configure the Heartbeat Message Sending Interval

Command	SWITCH(config) # efm global timer hello INTERVAL SWITCH(config) # no efm global timer hello SWITCH(config-if) # efm timer hello INTERVAL SWITCH(config-if) # no efm timer hello
Description	INTERVAL: valid range 100 – 5000, unit: ms Supports configuration in global mode and port mode. The default EFM heartbeat message sending interval is 1000 ms The sending time of EFM heartbeat messages must be less than the timeout period of the EFM connection and must be a multiple of 100. When the global mode and port mode are set at the same time, the command in the port mode takes precedence.

● Configure The Connection Timeout

Command	SWITCH(config) # efm global timer keepalive INTERVAL SWITCH(config) # no efm global time keepalive SWITCH(config-if) # efm timer keepalive INTERVAL
---------	--

	SWITCH(config-if)# no efm time keepalive
Description	INTERVAL: valid range 200 – 25000, unit: ms Supports configuration in global mode and port mode. The default EFM connection timeout is 6000 ms. The EFM connection timeout must be greater than the EFM heartbeat message sending time and must be a multiple of 100. When the global mode and port mode are set at the same time, the command in the port mode takes precedence.

Note: When setting the global hello time or keepalive time, the following conditions must be met: (global) hello time < (global) keepalive time. When setting the port hello time or keepalive time, if the other time of the port has not been set before, it is necessary to compare it with its global time. For example, when setting the port hello time, the following conditions must be met: (interface) hello time < ((interface) keepalive time ? (interface) keepalive time : (global) keepalive time).

39.2.2. Configuring General Link Events

Note: Since the message statistics are updated every five seconds, assuming that the device receives an error frame every second and the threshold of the error frame event is 1, the event will not be triggered once a second, but will be triggered at the 5th second when the message statistics increase uniformly; similarly, the error frame second event is also triggered once every five seconds. When the window is 60 seconds, the errors statistics of the error frame second are displayed for a maximum of 12 seconds.

- Configuring Error Frame Event Detection Parameters

Command	SWITCH(config)# efm global errored-frame {window WVALUE [threshold TVALUE]} SWITCH(config)# efm global errored-frame {threshold TVALUE [window WVALUE]} SWITCH(config)# no efm global errored-frame SWITCH(config-if)# efm errored-frame {window WVALUE [threshold TVALUE]} SWITCH(config-if)# efm errored-frame {threshold TVALUE [window WVALUE]} SWITCH(config-if)# no efm errored-frame
Description	Supports configuration in global mode and port mode; WVALUE: valid range 10 - 600, unit: 100ms TVALUE: valid range 0 - 65535, unit: frame The default window detection period for error frame events is 10, and the threshold detection threshold is 1

- Configure the Error Frame Period Event Detection Parameters

Command	SWITCH(config)# efm global errored-frame-period {window WVALUE [threshold TVALUE]} SWITCH(config)# efm global errored-frame-period {threshold TVALUE [window WVALUE]} SWITCH(config)# no efm global errored-frame-period SWITCH(config-if)# efm errored-frame-period {window WVALUE [threshold TVALUE]} SWITCH(config-if)# efm errored-frame-period {threshold TVALUE [window WVALUE]} SWITCH(config-if)# no efm errored-frame-period
Description	Supports configuration in global mode and port mode WVALUE : valid range 10000 – 4294967295, unit: frame TVALUE: valid range 0 – 4294967295, unit: frame The default window detection period for the error frame period event is 1000000 frames, and the threshold detection threshold is 1

- Configuring Errored Frame Seconds Event Detection Parameters

Command	SWITCH(config)# efm global errored-frame-seconds {window WVALUE [threshold TVALUE]} SWITCH(config)# efm global errored-frame-seconds {threshold TVALUE [window WVALUE]} SWITCH(config)# no efm global errored-frame-seconds SWITCH(config-if)# efm errored-frame-seconds {window WVALUE [threshold TVALUE]} SWITCH(config-if)# efm errored-frame-seconds {threshold TVALUE [window WVALUE]} SWITCH(config-if)# no efm errored-frame-seconds
Description	Supports configuration in global mode and port mode WVALUE: valid range 100 – 9000, unit: 100ms TVALUE: valid range 0 – 900, unit: s The default window detection period for error frame seconds events is 600, and the threshold detection threshold is 1

- Configure the Notification Switch For Error Frame, Error Frame Period, And Error Frame Seconds Events

Command	SWITCH(config)# efm global {errored-frame errored-frame-period errored-frame-seconds} notification {enable disable} SWITCH(config)# no efm global {errored-frame errored-frame-period errored-frame-seconds} notification SWITCH(config-if)# efm {errored-frame errored-frame-period errored-frame-seconds} notification {enable disable} SWITCH(config-if)# no efm {errored-frame errored-frame-period errored-frame-seconds} notification
Description	When an error event is triggered, it is used to control whether to send an error event message to the peer end Supports configuration in global mode and port mode By default, the error frame, error period, and error frame seconds event notifications are all enabled, that is, error event messages are sent by default

39.2.3. Configuring the Remote Loopback Function

- Enable/disable EFM Remote Loopback Function

Command	SWITCH(config-if)# efm loopback enable SWITCH(config-if)# no efm loopback enable
Description	A remote loopback request can only be initiated when the EFM protocol at both ends is in the handshake (SEND_ANY) state and the local EFM working mode is active mode. If the request fails, the relevant state will automatically roll back.

- Configure the EFM Remote Loopback Timeout Period

Command	SWITCH(config-if)# efm loopback timeout INTERVAL SWITCH(config-if)# no efm loopback timeout
Description	INTERVAL: valid range 0-65535, unit: minute It takes effect when it is used as the loopback initiator. The default remote loopback timeout is 20 minutes. When the timeout is reached, the local end will automatically send a message to cancel the remote loopback Try not to set the remote loopback timeout to 0. If it is set to 0, the link will always be in loopback state

- Reject (Or Ignore) the EFM Remote Loopback Sent by The Remote End

Command	SWITCH(config-if)# efm loopback reject-request SWITCH(config-if)# no efm loopback reject-request
Description	By default, the remote EFM loopback is processed

Note: When a port is used as the responding end of a loopback and the rx direction messages are mirrored to other ports, the loopback function of the port becomes invalid and the messages are no longer forwarded directly to the initiating end of the loopback.

39.2.4. Configuring the Remote Fault Detection Function

- Configure the action when EFM receives a remote fault (or configure port violation handling)

Command	SWITCH(config-if)# efm remote-failure action error-link-down SWITCH(config-if)# no efm remote-failure
Description	By default, the action when EFM receives a remote fault is to log the violation The violation processing action can only take effect when the corresponding function of the errdisable module is enabled The command to enable the corresponding function of the errdisable module is "SWITCH(config)#errdisable efm-remote-failure enable" This function is enabled by default

- Configuring Violation Recovery Time

Command	SWITCH(config)# errdisable timeout {interval SECONDS enable disable} SWITCH(config)# no errdisable timeout interval
Description	Configuring Violation Recovery Time SECONDS : range 10-1000000 , unit is seconds, default time is 300 seconds Configuring enabling/disabling violation recovery Default violation recovery to enabled state The violation time is shared by all violation processing. Configuring this parameter will affect the violation processing of other functions

- Violation Recovery

If the timeout recovery is set to disable in the errdisable module, the port violation recovery cannot be achieved through this command. It is recommended to use shutdown + no The shutdown command implements the recovery operation.

Command	SWITCH# errdisable recovery interface IFNAME
Description	Violation recovery interface

39.3. Examples

39.3.1. Link Detection

Requirement: Configure basic EFM functions on SWITCH A and SWITCH B to implement automatic detection of link connectivity failures.

Topology:



Configuration:

Configure SWITCH A. Set the EFM connection mode to active on interface Gi0/1 and enable the Ethernet EFM function .

```
SWITCH# configure terminal
SWITCH(config)# interface gigabitEthernet 0/1
SWITCH(config-if)# efm mode active
SWITCH(config-if)# efm enable
```

Configure SWITCH B. Set the EFM connection mode to passive on interface Gi0/1 and enable the Ethernet EFM function .

```
SWITCH# configure terminal
SWITCH(config)# interface gigabitEthernet 0/1
SWITCH(config-if)# efm mode passive
SWITCH(config-if)# efm enable
```

test:

After the configuration is complete, run the show efm local command on SWITCH A to view the EFM protocol status of interface Gi0/1. At this time, the value of EFM Operation Status of interface Gi0 /1 is Send_Any.

```
SWITCH#show efm local
gigabitEthernet0/1:
-----
Link Status      : Up
Enable Status    : Enable
Operation Status : Send_Any
Loopback Status  : None
State Field:
  Local Mux Action : Fwd          Local Par Action: Fwd
  Local Pdu       : ANY
Configuration Field:
  OAM Mode        : Active        Unidirection   : Support
  Link Events     : Support       Remote Loopback : Support
  Variable Retrieval: UnSupport   Max OAMPDU Size : 1518
Flags Field:
  Link Fault      : No            Critical Event  : No
  Dying Gasp     : No            Local Evaluating: Complete
  Remote Evaluating : Complete
Time of connect  : 1970-01-01 00:04:21
```

39.3.2. Remote Loopback

Requirement: Configure EFM remote loopback on SWITCH A.

Based on Case 1, configure EFM remote loopback on SWITCH A.

```
SWITCH# configure terminal
SWITCH (config)# interface gigabitEthernet 0/1
SWITCH(config-if)# efm loopback enable
```

After the configuration is complete, run the show efm local command on SWITCH A to view the loopback status of interface Gi0/1 . If the loopback is successful, the value of loopback Status is Remote (the initiator of the loopback).

```
SWITCH#show efm local
gigabitEthernet0/1:
```

```
-----
Link Status      : Up
Enable Status    : Enable
Operation Status : Send_Any
Loopback Status  : Remote
State Field:
  Local Mux Action : Fwd          Local Par Action: Discard
  Local Pdu        : ANY
Configuration Field:
  OAM Mode         : Active        Unidirection    : Support
  Link Events      : Support        Remote Loopback : Support
  Variable Retrieval: UnSupport     Max OAMPDU Size : 1518
Flags Field:
  Link Fault       : No            Critical Event   : No
  Dying Gasp       : No            Local Evaluating: Complete
  Remote Evaluating : Complete
Time of connect   : 1970-01-01 00:04:21
```

Run the show efm local command on SWITCH B to view the loopback status of interface Gi0/1 . If the loopback is successful, the value of loopback Status is Local (the responding end of the loopback).

```
SWITCH#show efm local
gigabitEthernet0/1:
```

```
-----
Link Status      : Up
Enable Status    : Enable
Operation Status : Send_Any
Loopback Status  : Local
State Field:
  Local Mux Action : Discard       Local Par Action: LoopBack
  Local Pdu        : ANY
Configuration Field:
  OAM Mode         : Passive        Unidirection    : Support
  Link Events      : Support        Remote Loopback : Support
  Variable Retrieval: UnSupport     Max OAMPDU Size : 1518
Flags Field:
  Link Fault       : No            Critical Event   : No
  Dying Gasp       : No            Local Evaluating: Complete
  Remote Evaluating : Complete
Time of connect   : 1970-01-01 00:18:25
```

39.3.3. Remote Fault Detection

Configure EFM link monitoring on SWITCH A.

```
SWITCH# configure terminal
SWITCH(config)# interface gigabitEthernet 0/1
SWITCH(config-if)# efm errored-frame window 50 threshold 5
SWITCH(config-if)# efm errored-frame-period window 100000 threshold 5
SWITCH(config-if)# efm errored-frame-seconds window 600 threshold 5
```

Configure remote fault detection on SWITCH A. When EFM detects a link fault, it sets the link status of the port to error-link-down.

```
SWITCH# configure terminal
SWITCH(config)# interface gigabitEthernet 0/1
SWITCH(config-if)# efm remote-failure action error-link-down
```

After the configuration is complete, run the show efm configuration interface gigabitEthernet 0/1 command on SWITCH A. The value of Action of remote-failure is error-link-down.

```
SWITCH#show efm configuration interface gigabitEthernet 0/1
gigabitEthernet0/1:
Action of remote-failure      : error-link-down
Configuration of link event: (ms = milliseconds)
-----
Errored-frame Event:
  Window(in 100ms)           : 10          Threshold(in frames)   : 1
  Notification                 : Yes
```

```

Errored-frame-period Event:
  Window(in frames)      : 1000000      Threshold(in frames)   : 1
  Notification           : Yes
Errored-frame-seconds Event:
  Window(in 100ms)       : 600          Threshold(in seconds)  : 1
  Notification           : Yes
Configuration of Timer: (ms = milliseconds, min = minutes)
-----
Hello timer(in ms)      : 1000          keepalive timer(in ms) : 6000
Loopback timeout(in min) : 20

```

39.4. Display Information

39.4.1. Check the EFM Global Configuration Information

```

SWITCH#show efm configuration global
EFM global configuration:
Configuration of link event: (ms = milliseconds)
-----
Errored-frame Event:
  Window(in 100ms)       : 10            Threshold(in frames)   : 1
  Notification           : Yes
Errored-frame-period Event:
  Window(in frames)      : 1000000      Threshold(in frames)   : 1
  Notification           : Yes
Errored-frame-seconds Event:
  Window(in 100ms)       : 600          Threshold(in seconds)  : 1
  Notification           : Yes
Configuration of Timer: (ms = milliseconds)
-----
Hello timer(in ms)      : 1000          keepalive timer(in ms) : 6000

```

39.4.2. Check the EFM Interface Configuration Information

```

SWITCH#show efm configuration interface gigabitEthernet 0/1
gigabitEthernet0/1:
Action of remote-failure      : log
Configuration of link event: (ms = milliseconds)
-----
Errored-frame Event:
  Window(in 100ms)       : 10            Threshold(in frames)   : 1
  Notification           : Yes
Errored-frame-period Event:
  Window(in frames)      : 1000000      Threshold(in frames)   : 1
  Notification           : Yes
Errored-frame-seconds Event:
  Window(in 100ms)       : 600          Threshold(in seconds)  : 1
  Notification           : Yes
Configuration of Timer: (ms = milliseconds, min = minutes)
-----
Hello timer(in ms)      : 1000          keepalive timer(in ms) : 6000
Loopback timeout(in min) : 20

```

39.4.3. View The Local EFM Connection Information

```

SWITCH#show efm local
gigabitEthernet0/2:
-----
Link Status      : Up
Enable Status    : Enable
Operation Status : Send_Any
Loopback Status  : None
State Field:
  Local Mux Action : Fwd          Local Par Action: Fwd
  Local Pdu        : ANY
Configuration Field:
  OAM Mode         : Active          Unidirection      : Support
  Link Events      : Support         Remote Loopback   : Support

```

Variable Retrieval: UnSupport Max OAMPDU Size : 128
 Flags Field:
 Link Fault : No Critical Event : No
 Dying Gasp : No Local Evaluating: Complete
 Remote Evaluating : Complete
 Time of connect : 2024-08-29 13:59:24

EFM connection information display elements are as follows :

Fields	Illustrate
Link Status	Port link status
Enable Status	EFM enable status of the port.
Operation Status	EFM Discovery Process Status.
Loopback Status	EFM remote loopback status.
Local Mux Action	The working mode of the local transmitter .
Local Par Action	The working mode of the local receiver .
Local Pdu	Used to manage the sending and receiving of oampdu as part of the discovery process.
Link Fault	The receiving direction of the link of the local device fails, such as plugging or unplugging the network cable.
Dying Gasp	An unrecoverable fault occurs on the local device, such as a device restart or an interface shutdown.
Critical Event	Uncertain emergency events occur, such as abnormal temperature.

Meaning of the Operation Status value:

Fields	Illustrate
Link_Fault	This includes link failure, EFM connection timeout or EFM re-enabling.
Active_Send_Local	The DTE configured in Active mode actively sends Information to the outside. OAMPDU message and wait for the remote response.
Passive_Wait	A DTE configured in Passive mode will wait for the remote end's Information OAMPDU, and then send the Information OAMPDU message.
Send_Local_Remote	After receiving the remote information OAMPDU, the local DTE will start sending information OAMPDU containing local and remote information TLVs.
Send_Local_Remote_OK	The local OAM considers that the settings on both the local and remote DTEs are acceptable .
Send_Any	An OAMPDU is received indicating that the remote device is also satisfied with the corresponding settings .

Meaning of Loopback Status value:

Fields	Illustrate
None	Not entering loopback.
Local	Acts as the responding end of the loopback.
Remote	Acts as the loopback initiator.
Initing	When initiating a loopback, the transition state is to wait for a response from the remote end.
Terminating	When canceling loopback, the device is in the transition state of waiting for a response from the remote end.

The meaning of Local Mux Action value:

Fields	Illustrate
Fwd	Indicates that the sending direction is FORWARDING, and any message is allowed to be sent.
Discard	Indicates that the sending direction is DISCARDING and only OAMPDU is allowed to be sent .

The meaning of Local Par Action value:

Fields	Illustrate
Fwd	Indicates that the receiving direction is FORWARDING, allowing any message to be received.
Discard	Indicates that the receiving direction is DISCARDING and only OAMPDU is allowed to be received .
LoopBack	Indicates that the receiving direction is in loopback state, and all non-OAMPDUs received are Will return along the original route.

The meaning of Local Pdu value:

Fields	Illustrate
LF_INFO	Information OAMPDUs are neither sent nor received.
INFO	Send and receive Information OAMPDU.
RX_INFO	Only Information OAMPDUs are received.
ANY	Send and receive any OAMPDU.

39.4.4. Check The Remote EFM Connection Information

```
SWITCH#show efm remote
```

```

gigabitEthernet0/2:
-----
Link Status      : Up
Mac Address      : 34b3.543e.2100
OUI              : 00-e0-fc
State Field:
  Remote Mux Action : Fwd           Remote Par Action: Fwd
Configuration Field:
  OAM Mode          : Active         Unidirection      : Support
  Link Events       : Support        Remote Loopback   : Support
  Variable Retrieval: UnSupport      Max OAMPDU Size   : 128
Flags Field:
  Link Fault        : No             Critical Event     : No
  Dying Gasp        : No             Local Evaluating  : Complete
  Remote Evaluating : Complete

```

39.4.5. View EFM Message Statistics

When a critical event is triggered, four Information OAMPDUs with the same fault flag set to 1 are generally sent. Here, the first message with the fault flag received is considered to be the Unique Event OAMPDU, and the remaining messages with the same fault flag are considered to be Duplicate Event OAMPDUs.

```

SWITCH#show efm packet
gigabitEthernet0/2:
OAMPDU statistic:          TX          RX
-----
Information OAMPDU        341          331
Unique Event OAMPDU       1             0
Duplicate Event OAMPDU    3             0
Loopback Control OAMPDU  4             0
Variable Request OAMPDU   0             0
Variable Response OAMPDU  0             0
Organization Specific OAMPDU 0             0
Unsupported OAMPDU        0             0
Lost OAMPDU               0             0

```

39.4.6. View EFM Event Statistics

```

SWITCH#show efm event critical
gigabitEthernet0/2:
-----
Link Fault      : No           time stamp : 0           total : 0
Dying Gasp      : Yes          time stamp : 1724940337  total : 2
Critical Event  : No           time stamp : 0           total : 0

SWITCH#show efm event link local
(ms = milliseconds, f = frames, s = seconds)
gigabitEthernet0/2:
-----
Errored-frame Event:
  Event Time Stamp : 41066           Window(in 100ms) : 10
  Threshold(in f)  : 1             Errors             : 50005
  Error Running Total : 1437659      Event Running Total : 32
Errored-frame-period Event:
  Event Time Stamp : 40666           Window(in f)      : 1000000
  Threshold(in f)  : 1             Errors             : 1037591
  Error Running Total : 1037591      Event Running Total : 1
Errored-frame-seconds Event:
  Event Time Stamp : 41104           Window(in 100ms) : 600
  Threshold(in s)  : 1             Errors             : 12
  Error Running Total : 32           Event Running Total : 3

SWITCH#show efm event link remote
(ms = milliseconds, f = frames, s = seconds)
gigabitEthernet0/2:
-----

```

Errored-frame Event:

Event Time Stamp	: 0	Window(in 100ms)	: 0
Threshold(in f)	: 0	Errors	: 0
Error Running Total	: 0	Event Running Total	: 0

Errored-frame-period Event:

Event Time Stamp	: 0	Window(in f)	: 0
Threshold(in f)	: 0	Errors	: 0
Error Running Total	: 0	Event Running Total	: 0

Errored-frame-seconds Event:

Event Time Stamp	: 0	Window(in 100ms)	: 0
Threshold(in s)	: 0	Errors	: 0
Error Running Total	: 0	Event Running Total	: 0

40. Configuring Relay Warning

40.1. Overview

Relay Warning function helps network administrators effectively manage unexpected network situations by providing a digital input DI and a digital output DO (Relay) for external alarm devices on the panel. Digital input DI can be used to detect and record the status of external equipment such as access control intrusion detector. Digital output DO can be used for device port link interruption, abnormal system temperature, abnormal PoE status, and abnormal power supply to issue an alarm.

The switch's digital input DI can be activated by external sensors sensing physical changes including certain physical changes in intrusion detection or monitoring area.

Type	Trigger Condition	Description
DI input	Low level	Low level input trigger alarm with the voltage limit "-30V-3V"
	High level	High level input trigger alarm with the voltage limit "12V-30V"

The switch can detect in real time through the digital input DI and trigger some internal event processing of the device:

Type	Trigger Condition	Description
DI input: Low level ← → high level	Port event	Port shutdown and then up
		Port shutdown
	Port PoE event	Port PoE is powered off and then powered on
		Port PoE is powered off
	DO output event	Relay is normally open
		Relay is normally closed
		Relay is in alternating normally open and normally closed cycles

The main function of the digital output DO is to allow switch automatic, manual or remote control of the software application to trigger external devices:

Type	Mode	Description
Relay output	Normally open	The default mode is normally closed and becomes normally open after the alarm is triggered
	Normally closed	The default mode is normally open and becomes normally closed after the alarm is triggered
	Pulse	By default, the output is in normally open state, and after the alarm is triggered, it becomes in the status of alternating normally open and normally closed cycles with a default period of 2s, and a 50% duty cycle

The switch can not only manually configure the output status, but associate the equipment internal events to trigger the relay output alarm:

Event	Action
Ambient temperature	When the ambient temperature exceeds the configured limit, the relay output alarm is triggered
Ambient humidity	When the ambient humidity exceeds the configured limit, the relay output alarm is triggered
System temperature	When the system temperature exceeds the configured limit, the relay output alarm is triggered
PoE power consumption	When the system PoE power consumption exceeds the configured percentage limit, the relay output alarm is triggered
PoE voltage	When the PoE chip voltage exceeds the configured limit, the relay output alarm is triggered
PoE temperature	When the PoE chip temperature exceeds the configured limit, the relay output alarm is triggered
PoE port power supply change	When the PoE port power supply is powered off or on, the relay alarm output is triggered
Port link status change	When the port link changes from up to down or from down to up, the relay alarm output is triggered



prompt
This function requires an external related sensor

The switch can detect in real time through DI input and trigger relay output alarm.

40.2 Configuration

40.2.1. Configuring DI Alarm

Configure the DI Alarm Trigger Mode

Command	SWITCH(config)# relay-warning di ID alarm-mode {low-level high-level off} SWITCH(config)# no relay-warning di ID alarm-mode
Description	ID: DI index parameter, range <1 16> Low-level: low level trigger High-level: high level trigger Off: the function is off Off mode by default

Configure the DI Description

Command	SWITCH(config)# relay-warning di ID description TEXT SWITCH(config)# no relay-warning di ID description
Description	ID: DI index parameter, range <1 16> TEXT : the parameter is a string with a maximum length of 64 characters.

Configure DI Associated Relay Output

Command	SWITCH(config)# relay-warning di ID trigger relay ID SWITCH(config)# no relay-warning di ID trigger relay ID
Description	First ID: DI index parameter, range <1 16> Second ID: relay index parameter, range <1 16>

Configure DI Associated Ports

Command	SWITCH(config)# relay-warning di ID trigger port interface IFNAME SWITCH(config)# no relay-warning di ID trigger port interface IFNAME
Description	ID: DI index parameter, range <1 16> IFNAME: port name

Configure the Port Alarm Triggering Mode

Command	SWITCH(config)# relay-warning di port-action interface IFNAME {reboot shutdown none} SWITCH(config)# no relay-warning di port-action interface IFNAME
Description	IFNAME: port name Reboot: force the port link to be down, and the n be up automatically Shutdown: shutdown port. When the DI alarm is restored, no shutdown port is reset. None: do nothing None mode by default

Configure DI Associated PoE Ports

Command	SWITCH(config)# relay-warning di ID trigger poe interface IFNAME SWITCH(config)# no relay-warning di ID trigger poe interface IFNAME
Description	ID: DI index parameter, range <1 16> IFNAME: port name

Configure the PoE Port Alarm Trigger Mode

Command	SWITCH(config)# relay-warning di poe-action interface IFNAME {reboot power-off none} SWITCH(config)# no relay-warning di poe-action interface IFNAME
Description	IFNAME: port name Reboot: Force the powered port to power down, and then automatically power it up again Power-off: Turn off the PoE power supply of the port. When the DI alarm is restored, turn on the PoE power supply of the port None: do nothing None mode by default

40.2.2. Configuring Relay Warning

- Configure the Relay Output Alarm Trigger Mode

Command	SWITCH(config)# relay-warning relay ID alarm-mode {normally-open normally- closed pulse off} SWITCH(config)# no relay-warning relay ID alarm-mode
---------	--

Description	<p>ID: relay output index parameter, range <1 16></p> <p>Normally-open: when the configuration takes effect, the relay output is normally closed, and it is normally open after the alarm is triggered.</p> <p>Normally-closed: when the configuration takes effect, the relay output is normally open , and it is normally closed after the alarm is triggered.</p> <p>Pulse: when the configuration takes effect, the relay output state is normally open, and the pulse level outputs after the alarm is triggered. In the default state, the cycle is 2 seconds and the duty cycle is 50%.</p> <p>Off: the function is off</p> <p>Off mode by default</p>
-------------	---

- Configure the Relay Description

Command	<p>SWITCH(config)# relay-warning relay ID description TEXT</p> <p>SWITCH(config)# no relay-warning relay ID description</p>
Description	<p>ID: relay output index parameter, range <1 16></p> <p>TEXT : the parameter is a string with a maximum length of 64 characters.</p>

- Configure the Relay Output to Correlate With the Ambient Temperature

Command	<p>SWITCH(config)# relay-warning relay ID alarm ambient-temperature</p> <p>SWITCH(config)# no relay-warning relay ID alarm ambient-temperature</p>
Description	<p>ID: relay output index parameter, range <1 16></p>

- Configure the Relay Output to be Associated With the Ambient Humidity

Command	<p>SWITCH(config)# relay-warning relay ID alarm ambient-humidity</p> <p>SWITCH(config)# no relay-warning relay ID alarm ambient-humidity</p>
Description	<p>ID: relay output index parameter, range <1 16></p>

- Configure the Relay Output to Correlate System Temperature

Command	<p>SWITCH(config)# relay-warning relay ID alarm system-temperature</p> <p>SWITCH(config)# no relay-warning relay ID alarm system-temperature</p>
Description	<p>ID: relay output index parameter, range <1 16></p>

- Configure the Relay Output Associated With PoE Power Consumption

Command	<p>SWITCH(config)# relay-warning relay ID alarm poe-power</p> <p>SWITCH(config)# no relay-warning relay ID alarm poe-power</p>
Description	<p>ID: relay output index parameter, range <1 16></p>

- Configure the Relay Output to Associate With the PoE Voltage

Command	<p>SWITCH(config)# relay-warning relay ID alarm poe-volt</p> <p>SWITCH(config)# no relay-warning relay ID alarm poe-volt</p>
Description	<p>ID: relay output index parameter, range <1 16></p>

- Configure Relay Output to Associated With the PoE Temperature

Command	SWITCH(config)# relay-warning relay ID alarm poe-temperature SWITCH(config)# no relay-warning relay ID alarm poe-temperature
Description	ID: relay output index parameter, range <1 16>

- Configure the Relay Output to Associate the PoE Port Power Supply

Command	SWITCH(config)# relay-warning relay ID alarm poe-change interface IFNAME SWITCH(config)# no relay-warning relay ID alarm poe-change interface IFNAME
Description	ID: relay output index parameter, range <1 16> IFNAME: port name

- Configure the Relay Output to Associate With the Port Status

Command	SWITCH(config)# relay-warning relay ID alarm port-change interface IFNAME SWITCH(config)# no relay-warning relay ID alarm port-change interface IFNAME
Description	ID: relay output index parameter, range <1 16> IFNAME: port name

- Configure Ambient Temperature Alarm Parameters

Command	SWITCH(config)# relay-warning alarm-config ambient-temperature MIN MAX SWITCH(config)# no relay-warning alarm-config ambient-temperature
Description	<p>MIN: the alarm minimum limit. When the ambient temperature is lower than the minimum, an alarm is triggered. The minimum limit is low to -60°C</p> <p>MAX: the alarm maximum limit. When the ambient temperature is higher than the maximum, an alarm is triggered. The maximum limit is up to 100°C</p> <p>The default minimum is -40°C, and the default maximum is 85°C</p> <p>The minimum difference between the MIN and MAX is 5°C</p> <p>When the ambient temperature is higher than the maximum limit, an alarm is triggered. When the temperature drops to 2°C below the maximum limit, a prompt is given to return to normal.</p> <p>When the ambient temperature is lower than the minimum limit, an alarm is triggered. When the temperature rises to 2°C higher than the minimum limit, a prompt is given to return to normal.</p>

- Configure Environmental Humidity Alarm Parameters

Command	SWITCH(config)# relay-warning alarm-config ambient-humidity VALUE SWITCH(config)# no relay-warning alarm-config ambient-humidity
Description	<p>VALUE: ambient humidity alarm value, range <0 100></p> <p>Default value: 95%</p> <p>When the ambient humidity is higher than the alarm value, an alarm is triggered. When the humidity drops to 2% below the alarm value, a prompt is given to return to normal.</p>

- Configure System Temperature Alarm Parameters

Command	SWITCH(config)# relay-warning alarm-config system-temperature MIN MAX SWITCH(config)# no relay-warning alarm-config system-temperature
---------	---

Description	<p>MIN: the alarm minimum limit. When the system temperature is lower than the minimum, an alarm will be triggered. The minimum value is low to -40°C</p> <p>MAX: the alarm maximum limit. When the system temperature is higher than the maximum, an alarm will be triggered. The maximum is up to 125°C</p> <p>The default minimum limit is -40°C and the default maximum limit is 125°C</p> <p>The minimum difference value between the MIN and MAX is 5°C</p> <p>When the system temperature is higher than the maximum, an alarm is triggered. When the temperature drops to 2°C below the maximum, a prompt is given to return to normal.</p> <p>When the system temperature is lower than the minimum, an alarm is triggered. When the temperature rises to 2°C higher than the minimum, a prompt is given to return to normal.</p>
-------------	--

- Configure PoE Temperature Alarm Parameters

Command	<pre>SWITCH(config)# relay-warning alarm-config poe-temperature MIN MAX</pre> <pre>SWITCH(config)# no relay-warning alarm-config poe-temperature</pre>
Description	<p>MIN: the alarm minimum limit, If the system temperature is lower than the minimum limit, an alarm will be triggered. The minimum is low to -20°C</p> <p>MAX: the alarm maximum limit. When the system temperature is higher than the maximum, an alarm is triggered. The maximum is up to 110°C</p> <p>The default minimum is -20°C and the default maximum is 110°C</p> <p>The minimum difference value between the MIN and MAX is 5°C</p> <p>When the PoE temperature is higher than maximum, an alarm is triggered. When the temperature drops to 2°C below the maximum , the prompt is given to return to normal</p> <p>When the PoE temperature is lower than maximum, an alarm is triggered. When the temperature rises to 2°C higher than the maximum , the prompt is given to return to normal</p>

- Configure PoE Power Consumption Alarm Parameters

Command	<pre>SWITCH(config)# relay-warning alarm-config poe-power VALUE</pre> <pre>SWITCH(config)# no relay-warning alarm-config poe-power</pre>
Description	<p>VALUE: PoE power consumption alarm value, range <0 100></p> <p>The default value is 80%, which means that when the PoE power consumption reaches to 80% of the total power, an alarm is triggered.</p> <p>When the PoE power consumption is higher than the alarm value, an alarm is triggered. When the power consumption drops to 2% below the alarm value, a prompt is given to restore to normal.</p>

- Configure PoE Voltage Alarm Parameters

Command	<pre>SWITCH(config)# relay-warning alarm-config poe-volt MIN MAX</pre> <pre>SWITCH(config)# no relay-warning alarm-config poe-volt</pre>
Description	<p>MIN: the alarm minimum limit. If PoE voltage is lower than the minimum , then will trigger an alarm. The minimum is low to 44V</p> <p>MAX: the alarm maximum limit. When the PoE voltage is higher than the maximum value, an alarm is triggered. The maximum is up to 57V</p> <p>The default minimum is 44V and the default maximum is 57V</p> <p>The minimum difference value between the MIN and MAX is 5V</p> <p>When the PoE voltage is higher than the maximum, an alarm is triggered. When the</p>

	<p>voltage drops to 1V below the maximum, a prompt is given to return to normal.</p> <p>When the PoE voltage is lower than the minimum, an alarm is triggered. When the voltage rises to 1V higher than the minimum, the prompt returns to normal</p>
--	---

- Configure Port Change Alarm Parameters

Command	<pre>SWITCH(config)# relay-warning alarm-config port-change interface IFNAME {down up} SWITCH(config)# no relay-warning alarm-config port-change interface IFNAME</pre>
Description	<p>IFNAME: port name</p> <p>Down : the port link status changes from up to down</p> <p>Up: the port link status changes from down to up</p> <p>Down by default</p>

- Configure PoE Change Alarm Parameters

Command	<pre>SWITCH(config)# relay-warning alarm-config poe-change interface IFNAME {power-on power-off} SWITCH(config)# no relay-warning alarm-config poe-change interface IFNAME</pre>
Description	<p>IFNAME: port name</p> <p>Power-on: power on the PoE port</p> <p>Power-off: power off the PoE port</p> <p>Power-off by default</p>

40.2.3. Other Configuration Commands

Configure Relay Pulse Output

Command	<pre>SWITCH(config)# relay-warning relay ID config pulse period VALUE closed-time VALUE SWITCH(config)# no relay-warning relay ID config pulse period</pre>
Description	<p>ID: relay output index parameter, range <1 16></p> <p>First VALUE: pulse period, range <2 60></p> <p>The second VALUE: the time of the closed state, range <0 60></p>

Configure Relay Output Force Mode

Command	<pre>SWITCH(config)# relay-warning relay ID force {normally-open normally-closed pulse off} SWITCH(config)# no relay-warning relay ID force</pre>
Description	<p>ID: relay output index parameter, range <1 16></p> <p>Normally-open: the configuration takes effect, and the relay output is normally open.</p> <p>Normally-closed: the configuration takes effect and the relay output is normally closed.</p> <p>Pulse: configuration takes effect and relay output is pulse level, period 2 seconds, duty cycle 50%</p> <p>Off: Function is off</p> <p>Off mode by default. After configuring the force mode, the relay is not controlled by the alarm trigger mode.</p>

Configure the Alarm Log Output of Relay Warning

Command	SWITCH(config)# relay-warning alarm-config alarm-log enable SWITCH(config)# no relay-warning alarm-config alarm-log enable
Description	Enable/disable alarm log Enable by default

Configure the Trap Output of Relay-warning

Command	SWITCH(config)# relay-warning alarm-config alarm-trap enable SWITCH(config)# no relay-warning alarm-config alarm-trap enable
Description	Enable/disable alarm trap Disable by default

40.3. Examples

40.3.1. DI Alarm Case

Example 1: DI input is connected to the relay for opening/closing the access control. By default, when the access control is closed, the DI input is low level. When the access control is opened, the DI input is high level. The switch detects the DI input alarm, prints the log locally, and sends the log to the log server.

Switch configuration:

```
SWITCH(config)#relay-warning di 1 alarm-mode high-level
```

When the door is opened, the log received by the local and log server is:

```
SWITCH %IPCM-6: External DI 1 is triggered
```

40.3.2. DI Associated Relay Output

Example 2: DI input is connected to the relay for opening/closing the access control. By default, when the access control is closed, the DI input is low level. When the access control is opened, the DI input is high level. The Relay output is connected to the external LED alarm light. When the access control is detected to be opened, the LED alarm light is required to flash. The switch detects the DI input alarm, prints the log locally, and sends the log to the log server.

Switch configuration:

```
SWITCH(config)#relay-warning di 1 alarm-mode high-level
```

```
SWITCH(config)#relay-warning di 1 trigger relay 1
```

```
SWITCH(config)#relay-warning relay 1 alarm-mode pulse
```

When the door is opened, the log received by the local and log server is:

```
SWITCH %IPCM-6: External DI 1 is triggered, triggers relay 1 alarm pulse output
```

40.3.3. Event Association Relay Output

Example 3: Relay output is connected to an external LED alarm light. When the switch PoE power consumption reaches to 85% of the total power, the LED alarm light is required to flash. The switch detects the DI input alarm, prints the log locally, and sends the log to the log server.

Switch configuration:

```
SWITCH(config)#relay-warning relay 1 alarm poe-power
```

```
SWITCH(config)#relay-warning alarm-config poe-power 85
```

```
SWITCH(config)#relay-warning relay 1 alarm-mode pulse
```

When the PoE power consumption is greater than 85% of the total power, the logs received by the local and log servers are:

40.4. Display Information

Display All Relay Warning Information

```
SWITCH# show relay-warning
```

Alarm-log : Enable

Alarm-trap : Disable

System Temperature : 39.0(C)

System Temperature no-alarm range: -40 - 125(C)

Ambient Temperature : 24.8(C)

Ambient Temperature no-alarm range : -40 - 85(C)

Ambient Humidity : 46.9%

Ambient Humidity alarm Threshold : 95%

PoE Temperature : 50.8(C)

PoE Temperature no-alarm range : -20 - 110(C)

PoE Voltages : 51.7V

PoE Voltages no-alarm range : 44 - 57V

PoE Power Percent : 6%

PoE Power Percent Threshold : 85%

DI ID : 1

DI Status : low

DI Trigger Mode : off

Relay ID : 1

Relay output Status : normally open

Alarm-mode : pulse output

Pulse period : 2 (sec)

Closed time : 1 (sec)

Alarm trigger

PoE Power Percentage triggered: false

Display Relay Warning System Information

```
SWITCH#show relay-warning system-info
```

Alarm-log : Enable

Alarm-trap : Disable

System Temperature : 39.0(C)

System Temperature no-alarm range : -40 - 125(C)

Ambient Temperature : 24.8(C)
Ambient Temperature no-alarm range : -40 - 85(C)
Ambient Humidity : 46.8%
Ambient Humidity alarm Threshold : 95%
PoE Temperature : 50.8(C)
PoE Temperature no-alarm range : -20 - 110(C)
PoE Voltages : 51.7V
PoE Voltages no-alarm range : 44 - 57V
PoE Power Percent : 6%
PoE Power Percent Threshold : 85%

Display Relay Warning DI Information

DI ID : 1
DI Status : low
DI Trigger Mode : off

Display Relay Warning Relay Information

SWITCH#show relay-warning relay-info

Relay ID : 1
Relay output Status : normally open
Alarm-mode : pulse output
Pulse period : 2 (sec)
Closed time : 1 (sec)
Alarm trigger
PoE Power Percentage triggered: false

Display Relay Warning Event Statistic

event	count	Last time

Digital Input: 1	2	Thu Jan 1 00:02:22 1970
Port gigabitEthernet0/1 Changes	0	--
Port gigabitEthernet0/2 Changes	0	--
Port gigabitEthernet0/3 Changes	0	--
Port gigabitEthernet0/4 Changes	0	--
Port gigabitEthernet0/5 Changes	0	--
Port gigabitEthernet0/6 Changes	0	--
Port gigabitEthernet0/7 Changes	0	--
Port gigabitEthernet0/8 Changes	0	--
Port gigabitEthernet0/9 Changes	0	--
Port gigabitEthernet0/10 Changes	0	--
Port gigabitEthernet0/11 Changes	0	--


Port gigabitEthernet0/12 Changes	0	--
PoE gigabitEthernet0/1 Changes	0	--
PoE gigabitEthernet0/2 Changes	0	--
PoE gigabitEthernet0/3 Changes	0	--
PoE gigabitEthernet0/4 Changes	0	--
PoE gigabitEthernet0/5 Changes	0	--
PoE gigabitEthernet0/6 Changes	0	--
PoE gigabitEthernet0/7 Changes	0	--
PoE gigabitEthernet0/8 Changes	0	--
System Temperature	0	--
Sensor disconnected	0	--
Ambient Temperature	0	--
Ambient Humidity	0	--
PoE Temperature	0	--
PoE Voltages	0	--
PoE Power Percent	1	Thu Jan 1 00:03:09 1970

41. Configuring Serial Device Server

41.1. Overview of Serial Device Server

The serial device server is used to connect serial devices to the Ethernet. The serial device server supports bidirectional conversion and transmission of network data and serial data.


Serial device server work in tcp-client mode, as shown in figure below.



Serial device server work in tcp-client mode

Serial device server in tcp-client mode provides client connections for TCP network servers. it actively initiate a connection and connect to the server to realize the interaction between serial device and tcp server. The Tcp/ip and serial data are transparently transmitted in both directions. The serial device server supports to establish multiple TCP Clients to connect to different Tcp Server.

Serial device server work in tcp-server mode, as show in figure below.



Serial device server work in tcp-server mode

In TCP Server mode, the module monitors the local port, accepts and establishes a connection for data communication when a connection request is sent. Used for communication with TCP clients within a local area network. It is suitable for scenarios where there is no server in the LAN and there are multiple computers or mobile phones requesting data from the module.

41.2. Configuring

I Entering Serial Port Config Mode

Command	SWITCH(config)#serial port NPORT
Description	NPORT: serial port server port number, which can be viewed through show serial port all summary.

I Clearing all Config on a Serial Port

Command	SWITCH(config)#no serial port NPORT
Description	NPORT: serial port server port number, which can be viewed through show serial port all summary.

I Configuring Operation Mode

Command	SWITCH(config-serial-port)#operation mode (tcp-client tcp-server)
Description	Tcp-client: tcp client operation mode. Tcp-server: tcp server operation mode. Support no operation mode command, return to disabled state.

I Configuring Tcp-client

Command	SWITCH(config-serial-port)# tcp-client CLIENTID remote-address A.B.C.D remote-port L4-PORT (local-port L4-PORT)
Description	CLIENTID: <1 4 >, support to create 4 clients. A.B.C.D: IPv4 addresses L4-PORT: Layer 4 port number Local-port is an optional configuration, the default system automatically assigns.

I Configuring Tcp-server

Command	SWITCH(config-serial-port)# tcp-server local-port L4-PORT
Description	L4-PORT: Layer 4 port number To configure tcp-server mode, the local-port parameter must be configured.

I Configuring Tcp-server Max Connection

Command	SWITCH(config-serial-port)# tcp-server connection max CMAX
Description	CMAX: The maximum number of connections in tcp-server mode, the default is 1.

I Configuring Tcp Alive-check Time

Command	SWITCH(config-serial-port)# tcp alive-check time SECONDS
Description	SECONDS: If there is no data interaction during this time period, start alive detection Range: <10-300>, in seconds This parameter is supported in both Tcp-client and tcp-server modes.

I Configuring Rtu Baud-rate

Command	SWITCH(config-serial-port)# serial baud-rate (300 1200 9600 19200 38400 57600
---------	---

	115200)
Description	Default baud rate is 115200.

I Configuring Rtu Data-bit

Command	SWITCH(config-serial-port)# serial data-bits (7 8)
Description	Default data is bit 8.

I Configuring Rtu Parity

Command	SWITCH(config-serial-port)# serial parity (none odd even mark space)
Description	Default check digit none.

I Configuring Rtu Stop-bits

Command	SWITCH(config-serial-port)# serial stop-bits (1 2)
Description	Default stop bit is 1.

I Configuring Packet Length Max

Command	SWITCH(config-serial-port)# serial packet length LENGTH
Description	The length of the serial data packet. If the length exceeds the LENGTH value, it will be packetized and forwarded to the network. LENGTH: range from 0 to 1460, default value is 1460.

I Configuring Packet Interval

Command	SWITCH(config-serial-port)# serial packet interval MILLISECONDS
Description	If the interval between bytes before and after the serial port data exceeds MILLISECONDS, the last byte of data is regarded as the new header byte. MILLISECONDS: range from 1 to 1000, default value is 10, in milliseconds.

I Configuring Fifo

Command	SWITCH(config-serial-port)# serial fifo length LENGTH
Description	Serial data bits are transmitted at low speed, and data is transferred from the network end to the serial port to increase the fifo to improve the forwarding capability LENGTH: range from 0 to 128, default value is 64.

41.3. Examples

43.3.1. Example for Tcp-client

The following examples shows how to configure the serial device server work in tcp-client mode, As show in Figure below.



Serial device server work in tcp-client mode

in this case, IP address of TCP Server is 192.168.64.1, local port number is 2000. We need to configure the serial port server to work in tcp-client mode, configure tcp-client 1 to connect to the target TCP Server, and the local port is dynamically generated by the system.


The serial parameters are all in default.

```
SWITCH(config)#serial port 1

SWITCH(config-serial-port)#operation mode tcp-client
SWITCH(config-serial-port)#tcp-client 1 remote-address 192.168.64.1 remote-port 2000
SWITCH(config-serial-port)#tcp-client 2 remote-address 192.168.64.2 remote-port 2001
```

41.3.2. Example for Tcp-server

The following examples shows how to configure the serial device server work in tcp-server mode, As show in Figure below.



Serial device server work in tcp-server mode

In this case, we need to configure the serial device server to work in tcp-server mode, configure the local port number 2000, configure the maximum number of connections to 3.

TCP Client A/B/C access to server.

The serial parameters are all in default.

```
SWITCH(config)#serial port 1

SWITCH(config-serial-port)#operation mode tcp-server
SWITCH(config-serial-port)#tcp-server local-port 2000
SWITCH(config-serial-port)#tcp-server connection max 3
```

TCP Client A/B/C transmits data stream to serial device, and will not forward it between clients. when serial device transmits, the data stream will broadcast a copy on each client.

41.4. Display Information

- Display serial port summary

```
SWITCH#show serial port 1 summary

Operation mode      : tcp-client
Tcp client 1       : 192.168.64.1:2000
Tcp client 2       : --
Tcp client 3       : --
Tcp client 4       : --
Tcp server local port : --
```

```
Tcp server connection max : 1
Tcp alive-check time      : 30
Serial baud-rate          : 115200
Serial data-bits          : 8
Serial parity             : none
Serial stop-bits          : 1
Serial packet length      : 1460
Serial packet interval    : 10
Serial fifo length        : 64
```

| Display serial port status

```
SWITCH#show serial port 1 status
```

Port entity	Status	Remote	Local
1	tcp client 1 link	192.168.64.1:1024	192.168.64.100:47188

| Display serial port statistic

```
SWITCH#show serial port 1 statistic
```

```
Net Octets Rx          : 5824
Net Packets Rx         : 728
Net Octets Tx          : 5120
Net Packets Tx         : 834
Serial Octets Rx       : 5120
Serial Packets Rx      : 834
Serial Octets Tx       : 5824
Serial Packets Tx      : 728
```

